



# SERVICE

---

---



928 S  
928 S<sub>4</sub>

# TEST PLAN ABS



944  
944 S  
944 *Turbo*

---

# INFORMATION

---

Printed in Germany  
Copyright by Dr.-Ing. h. c. F. Porsche  
Aktiengesellschaft

WKD 493 721

**TECHNIK**

CONTENTS	Page
Introduction .....	1
ABS System Diagram .....	2
Guidelines for repair operations on vehicles with ABS .....	3
Location of ABS components (928 Series) .....	4
Location of ABS components (944 Series) .....	6
ABS Test Unit Bosch K7-ETT 016.00 or VAG 1516. ....	7
Notes on test unit and directions on connecting test unit .....	8
Test Plan 1: Test procedures using Bosch K7-ETT 016.00 or VAG 1516 Test Unit .....	13
ABS Test Unit: Bosch ABS 2-LED .....	21
Particulars and description of ABS-2-LED Test Unit. ....	22
Connecting the test unit .....	27
Test Plan 2: Test procedures using ABS 2-LED Test Unit .....	29
ABS Wiring Diagram: 928 S, Model Year '84 .....	34
ABS Wiring Diagram: 928 S, '85 model onwards, and 928 S 4 .....	35
ABS Wiring Diagram: 944, 944 S, 944 Turbo, '87 models onwards. ....	36

## INTRODUCTION

This manual describes testing procedures and serves as a troubleshooting guide for the ABS systems installed in Porsche 928 and 944 series vehicles.

The troubleshooting program consists of two test plans.

**Test Plan No. 1** is required for testing procedures using the Bosch K7-ETT 016.00 or VAG 1516 ABS Testing Unit.

**Test Plan No. 2** is required for testing procedures using the Bosch ABS-2-LED Testing Unit.

Both testing units can be used for all Porsche vehicles fitted with ABS.

The testing program is valid for all 8-cylinder vehicles from '84 models onwards and all 4-cylinder vehicles from '87 models onwards.

### \*Note:

#### Test data for 928 S – USA, Model Year '86


U.S. specification 928 S vehicles of Model Year '86, with chassis numbers from VIN 929 GS 80061 to 922 GS 860936 are equipped with the Model Year '85 form of ABS system.

The test data and electrical circuit diagram for Model Year '85 apply to the above vehicles.

The test data and electrical circuit diagram for 928 S Model Year '86 apply to chassis numbers from VIN 927 GS 86 1001 onwards.

**ABS SYSTEM**

The (Bosch) three-channel ABS system is provided with one speed sensor per wheel. The braking system is divided front and rear (black/white division), i.e. one brake circuit operates on the front axle (push rod circuit) and the second on the rear axle (floating circuit).



- 1 - Tandem brake master cylinder
- 2 - Hydraulic unit
- 3 - Speed sensors (cross-pole), front
- 4 - ABS control unit
- 5 - ABS indicator lamp
- 6 - Stop lights
- 7 - Speed sensors (flat pole), rear

## IMPORTANT GUIDELINES FOR REPAIR OPERATIONS ON VEHICLES WITH ABS

When working on vehicles with ABS the following must be observed:

### Multiple-pin plug in electronic control unit

Never disconnect or connect the multi-pin plug from the electronic control unit with ignition switched on.

### Welding

Disconnect plug from electronic control unit before carrying out any welding operations with an electric welder.

### Painting

During painting operations, the electronic control unit may be exposed briefly up to 95 °C max. and for a longer period (approx. 2 hours) up to 85 °C max.

### Battery charging

Disconnect battery from vehicle electrical system before boost-charging battery.

### Battery installation

If battery has been removed, both leads must be properly secured to battery terminals on reinstallation.

### Assisted start

Do not use a boost battery charger to start engine.

### Function testing


A simple function test is all that is necessary after repairs to components of the braking system not directly related to the ABS system have been made. This means that, with the ABS system intact, the indicator lamp in the combination instrument must go out when the engine is started. Operations of this nature include changing or reconditioning of brake linings, brake hoses, brake discs, brake assemblies, tandem master cylinders, brake cables and parking brake components, together with brake lines not connected to the hydraulic unit.

If operations are carried out on the hydraulic unit (\*, \*\*), electronic control unit (\*, \*\*), speed sensors or cable set, or if any assemblies are replaced in the course of e.g. accident repairs, a function test must be carried out with the ABS test unit (\* in conjunction with a brake test on a brake dynamometer).


- \* ) (ABS testing with Bosch K7-ETT 016.00 or VAG 1516 ABS-Testing Unit).
- \*\* ) Do not attempt to repair or disassemble the hydraulic unit or electronic control unit.

## LOCATIONS OF ABS COMPONENTS — 928 Series —

The control unit is located against the wheel housing in the driver's side (left) footwell (above the central warning unit).




The ABS relay is located on the CEB —  
Model Year '84: relay No. XI  
Model Year '85: relay No. XVII.




The hydraulic unit is located under the front left fender in the opening leading from the wheel housing to the engine compartment.

Brake line connections are accessible from the engine compartment.



The pump motor, complete with pump motor relay and solenoid valve relay with electrical connections, is accessible from the wheel housing side after removal of the cover plate.


- 6 — Cable (battery +)
- 7 — Relay for solenoid valves
- 8 — Relay for pump motor
- 9 — Ground lead



**LOCATIONS OF COMPONENTS – 928 Seires –**


The solenoid valve and pump motor relays are located on the hydraulic unit.

- 1 – Solenoid valve relay
- 2 – Pump motor relay
- 3 – 12-pole wiring harness plug




**LOCATIONS OF ABS COMPONENTS**  
 — 944 Series —


The control unit is located against the wheel housing in the passenger's side (right) footwell.



The ABS relay is located on the central electric relay G 20.




The hydraulic unit is installed in the rear of the right front fender.



The solenoid valve and pump motor relay are located on the hydraulic unit.

- 1 — Solenoid valve relay
- 2 — Pump motor relay
- 3 — Brake pressure regulator





**ABS TEST UNIT, Bosch K7-ETT 016.00 (Order No. 0684 101 600)  
or VAG 1516**

Adapter lead, to connect to ABS Test Unit, Order No. 1 684 460 120


**Note:** The overvoltage protection relay supplied with the adapter lead cannot be used for operations on Porsche vehicles. A separate relay,  
No. 928.615.124.00 (relay with fuse, '84 models) or  
No. 928.615.124.01 (relay without fuse, '85 models onwards)  
must be used for Test Stage 5 as laid down in the Testing Program.

**Additional test equipment and tools required:**

**Brake dynamometer**

**Standard tools and instruments**

2 Control unit plug test leads, approx. 60 cm long with 2 insulated alligator clips and 2 flat pin plugs N 17.457.2.



The test lead must be used for testing the control unit plug.

**Plug terminal designations**

Control unit multiple-pin plug, looking towards plug terminals.




**NOTES ON TEST UNIT K7**

The test unit is used for function tests on the control unit, hydraulic unit, cable harness and peripheral sub-assemblies of the Anti-lock Braking System.


Actual values recorded by the test unit must be compared with the respective specified values.

If the actual value deviates from the specified value, the fault should be located in accordance with instructions in the troubleshooting program.



- 1 = Digital LED display unit, 3 1/2 positions
- 2 = Lamp 1 (green): battery voltage OK
- = Lamp 2 (red): low battery voltage
- 3 = Lamp 3 (green): motor and valve relay and overvoltage protection OK
- = Lamp 4 (red): motor and valve relay and overvoltage protection faulty
- 4 = LED pushbutton (yellow): to activate individual test stages
- 5 = Pushbutton channel selector (wheel selection)
  - 5.1 = Front axle
  - 5.2 = Front left wheel
  - 5.3 = Front right wheel
  - 5.4 = Rear axle
  - 5.5 = Rear left wheel
  - 5.6 = Rear right wheel
- 6 = Program switch

- 7 – Connecting lead
- 7.1 – Connection to wiring harness
- 7.2 – Connection to control unit
- 8 – Adapter lead




#### Adapter lead for Porsche

The adapter lead serves to connect and test the electronic relay with overvoltage protection at the socket in back of the test unit.

- 9 – Plug socket in ABS test unit
- 10 – Adapter lead
- 11 – Porsche electronic relay with overvoltage protection

The overvoltage protection relay supplied with the test unit must not be used for Porsche. It is necessary to use the Porsche-Relay with overvoltage protection (see page 7).




#### Caution:

It is essential to fit the adapter lead for testing the electronic relay for Porsche vehicles in accordance with the diagram.

### Connecting the test unit

1. With ignition switched off, disconnect multi-pin (35-pole) plug (2) from electronic control unit (1).  
(Control unit remains installed).
2. Connect multi-pin plug (2) of electronic control unit to test unit (3) plug.
3. Install test unit (3) plug in electronic control unit (1). Retaining spring must lock into position audibly.
4. Switch ignition on.  
All other power-consuming systems must be switched off.




### Caution:

Vehicle must not be driven with test unit connected.

Test unit should preferably be placed as shown during testing.

### Caution:

All test stages must be carried out, beginning with stage 1.



Test stages 23 and 24 must be carried out before stages 20, 21 and 22.

A brake dynamometer is necessary for test stages 20 to 23\*).

The following points must be observed:

1. Do not drive with test unit connected.
2. During testing, dynamometer rollers and vehicle tires must be dry.
3. When testing vehicles with automatic transmission, the selector lever must not be in PARK position for rear axle testing.
4. Do not use a brake pedal winch to adjust braking force.
5. Allow at least 20 seconds to elapse between test repeats and channel changes.

\*) Test stage 23 can also be carried out on car hoist by rotating individual wheels.

Display	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.									
Lamps 1 and 2	Lamp 1 (green) must be on (throughout entire test)	<p><b>No display:</b></p> <ol style="list-style-type: none"> <li>1. Check power supply at ABS relay (on CEB*). Passage between terminals 30 and 31. (Due to diode, passage in one direction only).</li> <li>2. Multi-pin plug in control unit incorrectly connected.</li> <li>3. Electronic relay defective, replace.</li> <li>4. Positive lead to electronic relay terminal 87 interrupted.</li> <li>5. Positive lead from battery + CEB to electronic relay terminal 30 or lead from electronic relay terminal 87 to control unit terminal 1 interrupted.</li> </ol> <p><b>Lamp 2 (red) on or lights up intermittently during testing:</b></p> <p>Break off testing and rectify fault.</p> <p><b>Cause of fault:</b></p> <ol style="list-style-type: none"> <li>1. Battery insufficiently charged; charge battery or run engine.</li> <li>2. Excessive voltage drop at ground terminals to control unit or relay for control unit, including plug connections.</li> </ol> <p>Ground lead to control unit terminal 10 subject to excessive transfer resistance, or interrupted.</p> <p>Ground lead from electronic relay subject to excessive transfer resistance, or interrupted.</p> <p>After rectifying fault, carry out complete test program.</p>									
Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up:</b></p> <ol style="list-style-type: none"> <li>1. Ground lead subject to excessive transfer resistance, or interrupted.</li> <li>2. Switch off ignition, disconnect control unit plug and check following leads for continuity: from ground to terminal 8, hydraulic unit; from terminal 8 to terminal 32 control unit plug, or with test lamp on positive and test prod at terminal 32, test lamp must light up.</li> <li>3. Valve relay defective.</li> </ol>									
Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up:</b></p> <ol style="list-style-type: none"> <li>1. Switch off ignition, disconnect control unit plug and check following leads for continuity: from terminal 27, control unit plug to terminal 28 and from terminal 27 to terminal 87, electronic relay frame. Connect control unit plug terminal 1 to positive and terminal 27 to negative. With test lamp at terminal 32; lamp must light up.</li> <li>2. Valve relay defective.</li> </ol> <p>* <b>Location of ABS relay (electronic relay):</b></p> <table border="0"> <tr> <td>928 S, model year '84</td> <td>= Relay XI</td> <td>on CEB</td> </tr> <tr> <td>928 S, '85 model onwards, 928 S 4</td> <td>= Relay XVII</td> <td>on CEB</td> </tr> <tr> <td>944, 944 S, 944 Turbo, '87 models onwards</td> <td>= Relay G20</td> <td>on CEB</td> </tr> </table>	928 S, model year '84	= Relay XI	on CEB	928 S, '85 model onwards, 928 S 4	= Relay XVII	on CEB	944, 944 S, 944 Turbo, '87 models onwards	= Relay G20	on CEB
928 S, model year '84	= Relay XI	on CEB									
928 S, '85 model onwards, 928 S 4	= Relay XVII	on CEB									
944, 944 S, 944 Turbo, '87 models onwards	= Relay G20	on CEB									

TEST PLAN 1 ABS

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Display	Specified response/value	Troubleshoot Refer to circuit
All	Power supply available in all program switch positions		Lamps 1 and 2	Lamp 1 (green) must be on (throughout entire test)	<p><b>No display:</b></p> <ol style="list-style-type: none"> <li>1. Check power supply (Passage block only).</li> <li>2. Multi-pin connector.</li> <li>3. Electronic control unit.</li> <li>4. Positive terminal.</li> <li>5. Positive terminal electronic control unit.</li> </ol> <p><b>Lamp 2 (red):</b></p> <p>Break off test.</p> <p>Cause of failure:</p> <ol style="list-style-type: none"> <li>1. Battery is discharged.</li> <li>2. Excessive current draw from unit, including ground lead or interrupted ground lead.</li> </ol> <p>Ground lead or interrupted ground lead interrupted. After rectification.</p>
1	Valve relay, OFF position		Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red):</b></p> <ol style="list-style-type: none"> <li>1. Ground lead.</li> <li>2. Switch of continuity terminal terminal.</li> <li>3. Valve relay.</li> </ol>
2	Valve relay function		Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red):</b></p> <ol style="list-style-type: none"> <li>1. Switch of continuity terminal terminal 32; lamp 32.</li> <li>2. Valve relay.</li> </ol> <p>* Location: 928 S, model 928 S, '80, 944, 944.</p>

Display	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.									
Lamps 1 and 2	Lamp 1 (green) must be on (throughout entire test)	<p><b>No display:</b></p> <ol style="list-style-type: none"> <li>1. Check power supply at ABS relay (on CEB*). Passage between terminals 30 and 31. (Due to diode, passage in one direction only).</li> <li>2. Multi-pin plug in control unit incorrectly connected.</li> <li>3. Electronic relay defective, replace.</li> <li>4. Positive lead to electronic relay terminal 87 interrupted.</li> <li>5. Positive lead from battery + CEB to electronic relay terminal 30 or lead from electronic relay terminal 87 to control unit terminal 1 interrupted.</li> </ol> <p><b>Lamp 2 (red) on or lights up intermittently during testing:</b></p> <p>Break off testing and rectify fault.</p> <p><b>Cause of fault:</b></p> <ol style="list-style-type: none"> <li>1. Battery insufficiently charged; charge battery or run engine.</li> <li>2. Excessive voltage drop at ground terminals to control unit or relay for control unit, including plug connections.</li> </ol> <p>Ground lead to control unit terminal 10 subject to excessive transfer resistance, or interrupted.</p> <p>Ground lead from electronic relay subject to excessive transfer resistance, or interrupted.</p> <p>After rectifying fault, carry out complete test program.</p>									
Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up:</b></p> <ol style="list-style-type: none"> <li>1. Ground lead subject to excessive transfer resistance, or interrupted.</li> <li>2. Switch off ignition, disconnect control unit plug and check following leads for continuity: from ground to terminal 8, hydraulic unit; from terminal 8 to terminal 32 control unit plug, or with test lamp on positive and test prod at terminal 32, test lamp must light up.</li> <li>3. Valve relay defective.</li> </ol>									
Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up:</b></p> <ol style="list-style-type: none"> <li>1. Switch off ignition, disconnect control unit plug and check following leads for continuity: from terminal 27, control unit plug to terminal 28 and from terminal 27 to terminal 87, electronic relay frame. Connect control unit plug terminal 1 to positive and terminal 27 to negative. With test lamp at terminal 32; lamp must light up.</li> <li>2. Valve relay defective.</li> </ol> <p>* <b>Location of ABS relay (electronic relay):</b></p> <table border="0"> <tr> <td>928 S, model year '84</td> <td>= Relay XI</td> <td>on CEB</td> </tr> <tr> <td>928 S, '85 model onwards, 928 S 4</td> <td>= Relay XVII</td> <td>on CEB</td> </tr> <tr> <td>944, 944 S, 944 Turbo, '87 models onwards</td> <td>= Relay G20</td> <td>on CEB</td> </tr> </table>	928 S, model year '84	= Relay XI	on CEB	928 S, '85 model onwards, 928 S 4	= Relay XVII	on CEB	944, 944 S, 944 Turbo, '87 models onwards	= Relay G20	on CEB
928 S, model year '84	= Relay XI	on CEB									
928 S, '85 model onwards, 928 S 4	= Relay XVII	on CEB									
944, 944 S, 944 Turbo, '87 models onwards	= Relay G20	on CEB									



	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.									
3	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up:</b></p> <ol style="list-style-type: none"> <li>1. Switch off ignition, disconnect control unit plug. Check following leads for continuity: connect control unit terminal 1 to positive and terminal 28 to negative. With test lamp at terminal 14, lamp must light up. Test lamp must go out if terminal 1 or 28 is disconnected.</li> <li>2. Motor relay defective.</li> <li>3. Check that ground terminals and positive connection from pump motor are properly secured.</li> <li>4. Check pump motor for continuity. If pump motor defective, replace hydraulic unit.</li> </ol>									
3	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up:</b></p> <p>See test stage 3.</p>									
3	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up:</b></p> <ol style="list-style-type: none"> <li>1. Repeat test stage.</li> <li>2. Electronic relay connected to adapter lead is defective.</li> </ol> <p><b>* Location of ABS relay (electronic relay):</b></p> <table data-bbox="436 1717 1346 1818"> <tr> <td>928 S, model year '84</td> <td>= Relay XI</td> <td>on CEB</td> </tr> <tr> <td>928 S, '85 model onwards, 928 S 4</td> <td>= Relay XVII</td> <td>on CEB</td> </tr> <tr> <td>944, 944 S, 944 Turbo, '87 models onwards</td> <td>= Relay G 20</td> <td>on CEB</td> </tr> </table>	928 S, model year '84	= Relay XI	on CEB	928 S, '85 model onwards, 928 S 4	= Relay XVII	on CEB	944, 944 S, 944 Turbo, '87 models onwards	= Relay G 20	on CEB
928 S, model year '84	= Relay XI	on CEB									
928 S, '85 model onwards, 928 S 4	= Relay XVII	on CEB									
944, 944 S, 944 Turbo, '87 models onwards	= Relay G 20	on CEB									

TEST PLAN 1 ABS

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Display	Specified response/value	Troubleshooting, if specified Refer to circuit diagrams
3	Motor relay OFF position		Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up</b></p> <ol style="list-style-type: none"> <li>1. Switch off ignition. Check following lead and terminal 28 to motor. Test lamp must go out.</li> <li>2. Motor relay defective.</li> <li>3. Check that ground terminal properly secured.</li> <li>4. Check pump motor unit.</li> </ol>
4	Motor relay function (pump motor running)	LED pushbutton pos. 4 lights up; depress button	Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up</b></p> <p>See test stage 3.</p>
5	Electronic relay with overvoltage protection for control unit	<ol style="list-style-type: none"> <li>1. Switch off ignition. Disconnect plug from control unit.</li> <li>2. Remove electronic relay* from CEB and with adapter lead install in test plug in back of test unit.</li> <li>3. Plug (new) electronic relay* into CEB.</li> <li>4. Switch on ignition, wait approx. 1 sec., then depress LED pushbutton pos. 4 (lights up).</li> <li>5. Display OK. Electronic relay on adapter lead OK. Reinstall tested relay in CEB.</li> <li>6. Switch off ignition. Reinstall control unit plug for further tests.</li> </ol>	Lamps 3 and 4	Lamp 3 (green) must light up	<p><b>Lamp 4 (red) lights up</b></p> <ol style="list-style-type: none"> <li>1. Repeat test stage.</li> <li>2. Electronic relay correct.</li> </ol> <p>* Location of ABS relay: 928 S, model year '84 928 S, '85 model year 944, 944 S, 944 T</p>

TEST PLAN 1 ABS

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Display	Specified response/value	Troubleshooting Refer to circuit
6	6.1 Valve FL internal resistance	Ignition on, depress button FL (pos. 5.2)	Digital display unit	0.7 ... 1.7 $\Omega$	1. Check int terminals 2. Repeat te 3. If specific
	6.2 Valve FR internal resistance	Depress button FR (pos. 5.3)	Digital display unit	0.7 ... 1.7 $\Omega$	1. Check int terminals 2. Repeat te 3. If specific
	6.3 Valve RA internal resistance	Depress button RA (pos. 5.4)	Digital display unit	0.7 ... 1.7 $\Omega$	1. Check int terminals 2. Repeat te 3. If specific
7	Ground connection, terminal 10	Ignition on LED pushbutton, pos. 4 lights up, depress button	Digital display unit	< 300 mV (60 ... 200 mV)*	1. Check gro 2. Check lea unit plug
8	Ground connection, terminal 34	LED pushbutton, pos. 4 lights up, depress button	Digital display unit	< 250 mV (30 ... 150 mV)*	1. Check gro 2. Check lea unit plug
9	Ground connection, terminal 20  FL = front left FR = front right RA = rear axle	Ignition on LED pushbutton, pos. 4 lights up, depress button	Digital display unit	< 250 mV (30 ... 150 mV)*	1. Check gro 2. Check lea unit plug  * Values in 928 S fro

Display	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.
Digital display unit	0.7 ... 1.7 $\Omega$	<ol style="list-style-type: none"> <li>1. Check internal resistance and continuity at removed control unit plug between terminals 2 and 32.</li> <li>2. Repeat test on hydraulic unit between terminals 4 and 1.</li> <li>3. If specified value not met, replace hydraulic unit.</li> </ol>
Digital display unit	0.7 ... 1.7 $\Omega$	<ol style="list-style-type: none"> <li>1. Check internal resistance and continuity at removed control unit plug between terminals 35 and 32.</li> <li>2. Repeat test on hydraulic unit between terminals 4 and 3.</li> <li>3. If specified value not met, replace hydraulic unit.</li> </ol>
Digital display unit	0.7 ... 1.7 $\Omega$	<ol style="list-style-type: none"> <li>1. Check internal resistance and continuity at removed control unit plug between terminals 18 and 32.</li> <li>2. Repeat test on hydraulic unit between terminals 4 and 5.</li> <li>3. If specified value not met, replace hydraulic unit.</li> </ol>
Digital display unit	< 300 mV (60 ... 200 mV)*	<ol style="list-style-type: none"> <li>1. Check ground terminal for excessive transfer resistance and interruption.</li> <li>2. Check lead for breakage, from ground – steering bracket to removed control unit plug terminal 10.</li> </ol>
Digital display unit	< 250 mV (30 ... 150 mV)*	<ol style="list-style-type: none"> <li>1. Check ground terminal for excessive transfer resistance and interruption.</li> <li>2. Check lead for breakage, from ground – steering bracket to removed control unit plug terminal 34.</li> </ol>
Digital display unit	< 250 mV (30 ... 150 mV)*	<ol style="list-style-type: none"> <li>1. Check ground terminal for excessive transfer resistance and interruption.</li> <li>2. Check lead for breakage, from ground – steering bracket to removed control unit plug terminal 20.</li> </ol>

\* Values in () apply to  
928 S from '86 model onwards, 928 S 4, and 944 from '87 model onwards.

	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.
display	0.8 . . . 1.8 k $\Omega$	1. Check internal resistance and continuity at removed control unit plug between terminals 4 and 6. 2. Check plug connection. 3. If specified value not met, replace speed sensor.
display	0.8 . . . 1.8 k $\Omega$	As under 10.1, but check terminals 21 and 23 (11)*.
display	0.8 . . . 1.8 k $\Omega$	As under 10.1, but check terminals 8 and 9.
display	0.8 . . . 1.8 k $\Omega$	As under 10.1, but check terminals 24 and 26.
display	> 20 k $\Omega$	Plug connection OK? Disconnect sensor plug. Bridge coupling plug (sleeve side). Repeat test: if display now OK, replace speed sensor. If display still below specified value, leads from control unit plug terminals 4 and 6 to coupling plug are defective. Inspect all leads for chafing.
display	> 20 k $\Omega$	As under 11.1, but applies to leads from control unit terminals 21 and 23 (11)*.
display	> 20 k $\Omega$	As under 11.1, but applies to leads from control unit terminals 8 and 9.
display	> 20 k $\Omega$	As under 11.1, but applies to leads from control unit terminals 24 and 26.

\* Values in ( ) apply to  
928 S from '86 model onwards, 928 S 4, and 944 from '87 model onwards.

# TEST PLAN 1 ABS

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Display	Specified response/value	Troubleshooting, if sp Refer to circuit diagr
10	10.1 Speed sensor FL, internal resistance	Depress button FL (pos. 5.2)	Digital display unit	0.8 . . . 1.8 kΩ	1. Check internal res terminals 4 and 6. 2. Check plug connec 3. If specified value n
	10.2 Speed sensor FR, internal resistance	Depress button FR (pos. 5.3)	Digital display unit	0.8 . . . 1.8 kΩ	As under 10.1, but ch
	10.3 Speed sensor RL, internal resistance	Depress button RL (pos. 5.5)	Digital display unit	0.8 . . . 1.8 kΩ	As under 10.1, but ch
	10.4 Speed sensor RR, internal resistance	Depress button RR (pos. 5.6)	Digital display unit	0.8 . . . 1.8 kΩ	As under 10.1, but ch
11	11.1 Speed sensor FL, insulation resistance	Depress button FL (pos. 5.2)	Digital display unit	> 20 kΩ	Plug connection OK? Disconnect sensor plu Repeat test: if display value, leads from com Inspect all leads for c
	11.2 Speed sensor FR, insulation resistance	Depress button FR (pos. 5.3)	Digital display unit	> 20 kΩ	As under 11.1, but ap
	11.3 Speed sensor RL, insulation resistance	Depress button RL (pos. 5.5)	Digital display unit	> 20 kΩ	As under 11.1, but ap
	11.4 Speed sensor RR, insulation resistance	Depress button RR (pos. 5.6)	Digital display unit	> 20 kΩ	As under 11.1, but ap
FL = front left FR = front right RL = rear left RR = rear right					* Values in ( ) apply t 928 S from '86 mo

TEST PLAN 1 ABS

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Display	Specified response/value	Troubleshooting Refer to circuit
12	DC voltage in leads from				
	12.1 Speed sensor FL	Depress button FL (pos. 5.2)	Digital display unit	0... 100 mV	Disconnect Repeat test. value, leads leads for ch
	12.2 Speed sensor FR	Depress button FR (pos. 5.3)	Digital display unit	0... 100 mV	As under 12 21.
	12.3 Speed sensor RL	Depress button RL (pos. 5.5)	Digital display unit	0... 100 mV	As under 12
	12.4 Speed sensor RR	Depress button RR (pos. 5.6)	Digital display unit	0... 100 mV	As under 12
13	Control unit supply voltage	LED pushbutton pos. 4 lights up, depress button	Digital display unit	4.75 – 5.25 V	Replace con
14	Diode in conduction direction: indicator lamp	<b>Note:</b> ABS indicator lamp lights up	Digital display unit	< 1.5 V	Indicator la 1. Indicator 2. Switch of at remove must regi right-han 3. Check lea  Display out 1. Switch of terminals (see abov 2. Check lea (928 S, '8 terminal 3. Check inc connectio  If diode c  * Values in 928 S fro

FL = front left  
FR = front right  
RL = rear left  
RR = rear right

Display	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.
Digital display unit	0 . . . 100 mV	Disconnect sensor plug and bridge coupling plug (sleeve side). Repeat test. If display now OK, replace speed sensor. If display still above specified value, leads from control unit plug terminals 6 and 4 are defective. Inspect all leads for chafing.
Digital display unit	0 . . . 100 mV	As under 12.1 but applies to leads from control unit plug terminals 23 (11)* and 21.
Digital display unit	0 . . . 100 mV	As under 12.1 but applies to leads from control unit plug terminals 8 and 9.
Digital display unit	0 . . . 100 mV	As under 12.1 but applies to leads from control unit plug terminals 24 and 26.
Digital display unit	4.75 – 5.25 V	Replace control unit.
Digital display unit	< 1.5 V	<p><b>Indicator lamp does not light up:</b></p> <ol style="list-style-type: none"> <li>1. Indicator lamp defective.</li> <li>2. Switch off ignition. With ohmmeter, check diode between terminals 29 and 32 at removed control unit plug, in conducting and reverse directions. Display must register high resistance, then low resistance. For this operation, pull off right-hand multi-pin plug from combination instrument.</li> <li>3. Check leads between terminals 29 and 32 for breakage.</li> </ol> <p><b>Display out of tolerance:</b></p> <ol style="list-style-type: none"> <li>1. Switch off ignition. Inspect leads from removed control unit plug between terminals 29 and 32 for breakage, also diode in conducting and reverse directions (see above).</li> <li>2. Check lead between control unit plug terminal 29 and combination instrument (928 S, '84 model, terminal 2; 928 S '85 model onwards, terminal 3; 944, terminal 14, plug L) for breakage.</li> <li>3. Check indicator lamp plug connection, also ground lead and valve relay plug connection for voltage drop.</li> </ol> <p>If diode defective, replace hydraulic unit.</p> <p>* Values in () apply to 928 S from '86 model onwards, 928 S 4, and 944 from '87 model onwards.</p>



	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.
display	2.5 . . . 8.5 V	<b>Display out of tolerance, indicator lamp does not light up:</b>  1. Check indicator lamp and leads. 2. Pull out valve relay; lamp lights up; diode defective; replace hydraulic unit.
indicator in vehicle	Indicator lamp must go out within 3 secs.	<b>Indicator lamp does not go out:</b>  1. Repeat test stage with engine running. 2. Replace control unit.
indicator	Indicator lamp must remain on while button depressed	<b>Indicator lamp goes out:</b>  1. Repeat test stage with engine running. 2. Replace control unit.
display	1.9 . . . 2.3 A	1. Repeat test stage with engine running. 2. Replace control unit.
display	1.9 . . . 2.4 A	1. Repeat test stage with engine running. 2. Replace control unit.
display	1.9 . . . 2.3 A	1. Repeat test stage with engine running. 2. Replace control unit.  FL = front left FR = front right RA = rear axle

TEST PLAN 1 ABS

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Display	Specified response/value	Troubleshooting. Refer to circuit d
15	Diode in reverse direction; indicator lamp	Note: ABS indicator lamp glows less brightly, valve relay trips	Digital display unit	2.5 . . . 8.5 V	Display out of tol  1. Check indicato 2. Pull out valve r
16	Control unit bite triggered	LED pushbutton pos. 4 lights up, depress button minimum 3 secs.  Note: Lamp may flash twice while button depressed: pump motor startup	ABS indicator lamp in vehicle	Indicator lamp must go out within 3 secs.	Indicator lamp do  1. Repeat test stag 2. Replace contro
17	Control unit bite triggered with fault simulation	LED pushbutton pos. 4 lights up, depress button minimum 3 secs.  Note: Lamp may flash twice while button depressed.	ABS indicator lamp in vehicle	Indicator lamp must remain on while button depressed	Indicator lamp go  1. Repeat test stag 2. Replace contro
18	Control unit valve flows – pressure holding	LED pushbutton pos. 4 lights up; depress button again after each selected valve. Touching is sufficient, with display at zero, press button again  Note: Pump motor starts twice.			
	18.1 Valve FL	Depress button FL (pos. 5.2); depress LED pushbutton pos. 4	Digital display unit	1.9 . . . 2.3 A	1. Repeat test stag 2. Replace contro
	18.2 Valve FR	Wait until display registers zero! Depress button FR (pos. 5.3), depress LED pushbutton pos. 4.	Digital display unit	1.9 . . . 2.4 A	1. Repeat test stag 2. Replace contro
	18.3 Valve RA	Wait until display registers zero! Depress button RA (pos. 5.4), depress LED pushbutton item 4.	Digital display unit	1.9 . . . 2.3 A	1. Repeat test stag 2. Replace contro  FL = front left FR = front right RA = rear axie

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Display	Specified response/value	Troubleshoot Refer to circ
19	Control unit valve flows – pressure reduction	LED pushbutton pos. 4 lights up; depress button again after each selected valve. Touching is sufficient, with display at zero, press button again.  <b>Note:</b> Pump motor starts twice.			
	19.1 Valve FL	Depress button FL (pos. 5.2); depress LED pushbutton pos. 4.	Digital display unit	4.8 . . . 6.0 A	1. Repeat test 2. Replace c
	19.2 Valve FR	Wait until display registers zero! Depress button FR (pos. 5.3), depress LED pushbutton pos. 4.	Digital display unit	4.8 . . . 6.0 A	1. Repeat test 2. Replace c
<b>Caution:</b> changed sequence	19.3 Valve RA	Wait until display registers zero! Depress button RA (pos. 5.4), depress LED pushbutton pos. 4.	Digital display unit	4.8 . . . 6.0 A	1. Repeat test 2. Replace c
24	Stop light switch  <b>Note:</b> Display of 0.00 – 0.25 V without pedal applied is of no significance	Apply brake pedal	Digital display unit	10 . . . 15 V	If no display Check stop and lead con  Display less Correct tran switch.
23	Speed sensor signal  <b>Note:</b> see also page 11  FL = front left FR = front right RA = rear axle RL = rear left RR = rear right	<ul style="list-style-type: none"> <li>• Drive vehicle with front axle, then rear axle in sequence, on dynamometer</li> <li>• Engage brake rollers for front and rear wheels separately.</li> <li>• Speed sensor selection occurs by depressing appropriate button FL, FR and RL, RR (pos. 5.2, 5.3 and 5.5, 5.6).</li> </ul>	Digital display unit	> 1.5 (2.5)*  Take lowest value if display fluctuates  <b>Note:</b> If display registers 1.5 (2.5)*, check air gap.  < 1.0	<ul style="list-style-type: none"> <li>• Display of Dynamom</li> <li>• Display 0</li> <li>• Speed sen</li> <li>• Check ass</li> <li>• control in</li> <li>• Air gap be</li> <li>• Check wh</li> <li>• Replace s</li> <li>• Check nu</li> <li>• 928 S bef</li> <li>• 928 S '86</li> <li>• <b>Caution:</b></li> <li>• <b>Values in</b></li> <li>• 928 S '86</li> </ul>

Display	Specified response/value	Troubleshooting, if specified value not met. Refer to circuit diagram when troubleshooting.
Digital display unit	4.8 ... 6.0 A	1. Repeat test stage with engine running. 2. Replace control unit.
Digital display unit	4.8 ... 6.0 A	1. Repeat test stage with engine running. 2. Replace control unit.
Digital display unit	4.8 ... 6.0 A	1. Repeat test stage with engine running. 2. Replace control unit.
Digital display unit	10 ... 15 V	<p><b>If no display:</b> Check stop light switch, adjustment, power supply to switch, plug connections and lead connection from control unit plug terminal 25 to stop light switch.</p> <p><b>Display less than 10 V:</b> Correct transfer resistance in plug and lamp connections or replace stop light switch.</p>
Digital display unit	<p>&gt; 1.5 (2.5)*</p> <p>Take lowest value if display fluctuates</p> <p><b>Note:</b> If display registers 1.5 (2.5)*, check air gap.</p> <p>&lt; 1.0</p>	<ul style="list-style-type: none"> <li>• <b>Display of 999 signifies:</b> Dynamometer speed excessive (over 15 kph)</li> <li>• <b>Display 0 or less than 1.5 (2.5)*</b></li> <li>• Speed sensor wrongly connected? Check assignments. Speed sensors must correspond to specific wheels and control instrument inputs.</li> <li>• Air gap between speed sensor and ring gear excessive. Check installation.</li> <li>• Check wheel bearing clearance on front wheels.</li> <li>• Replace speed sensors.</li> <li>• Check number of teeth of pulse gear: 928 S before '86 = 90 teeth 928 S '86 model onwards and 944 '87 model onwards = 45 teeth</li> </ul> <p><b>Caution:</b> Carry out test stages 20 – 22 when test stage 23 passed satisfactorily.</p> <p>* Values in () applicable to: 928 S '86 model onwards, 928 S 4, and 944 '87 model onwards.</p>

	Specified response/value	Troubleshooting, if specified value not met
<p>not obtained with the foot. 21/22 is 2000 N (200 kp)</p> <p>0 N (200 kp), rear axle</p> <p>pushbutton. meter display stabilizes. seconds. light up. If it does, repeat</p> <p>conds, i. e. wait approx. pushbutton (internal test</p>	<p><b>Front axle</b> &lt; 1500 N &lt; (150 kp)</p> <p>Lamp 1 (green) must remain on throughout</p> <p><b>Rear axle</b> &lt; 800 N &lt; (80 kp)</p>	<ul style="list-style-type: none"> <li>Repeat test stages with engine running, making sure that braking force is not changed during testing.</li> <li>If lamp 2 (red) lights up, charge battery and run engine.</li> <li>Existing braking system OK? Properly bled? Brake line connections not leaking? Brake linings must not be badly worn. Brake discs OK? Master and wheel brake cylinder OK? Wheel brake cylinders and linings. Must move freely, clean if necessary.</li> </ul>
<p>er. pushbutton, pos. 5.2.</p> <p>orce display registers</p> <p>left) must occur. ess FR button and</p>	<p>After a period of low pressure, braking force display rises again to: <b>at front axle:</b> &lt; 2000 N &lt; (200 kp)</p> <p>Lamp 1 (green) must remain on throughout</p> <p><b>at rear axle:</b> &lt; 1000 N &lt; (100 kp)</p>	<ul style="list-style-type: none"> <li>Brake lines wrongly connected to hydraulic unit?</li> <li>Re-check assignment of brake rollers to pushbutton FL, FR and RA.</li> <li>Check ground terminals at pump motor and vehicle body. Re-check positive terminal of pump motor.</li> <li>Replace hydraulic unit.</li> </ul>
<p>ndbrake; test stages 20,</p>		<p><b>Notes on test stage 21:</b></p> <p>A noticeable reduction in pressure must have occurred before the registered specified value is reached (wheel braking force reduced).</p>
<p>wheel about to be tested, n constant 2000 N. Do not</p> <p>meter display stabilizes</p> <p>constant at other running wheel.</p> <p>force are permissible, but do</p> <p>on both wheels.</p> <p>20, 21 and 22</p>	<p>After dropping pressure twice without recirculating pump, the pump will switch on briefly. Braking force display must then drop below &lt; 600 N &lt; (60 kp)</p>	<p>If pressure rises immediately after application of reset button on test unit, the hydraulic lines assignment or cable harness must be checked for correct connection. If necessary, replace hydraulic unit.</p>
<p>ivated, facilitating brake</p> <p>d maintain constant ch to adjust braking force meter display stabilizes</p>	<p>Brake pedal resists slightly.</p> <p>Lamp 1 (green) must remain on throughout.</p>	<p><b>Notes on test stage 22:</b></p> <p>Yellow button must be kept depressed until braking force rises again (approx. 5 secs.).</p> <p>End of test stage is signified by a steep rise in braking force.</p>


TEST PLAN 1 ABS

Switch ignition ON for all program switch positions

Program switch position	Item tested	Additional operations Ignition on	Specified response/value
20	Hydraulic unit, pressure reduction in brake lines	<p>Run engine if undervoltage occurs or braking force not obtained with the foot. Braking force on dynamometer for test stages 20/21/22 is 2000 N (200 kp) for front axle, 1000 N (100 kp) for rear axle.</p> <p><b>1. Observe correct sequence of operations</b></p> <ul style="list-style-type: none"> <li>• Select test stage (program switch position).</li> <li>• Select channel (wheel).</li> <li>• Set braking force with the foot, front axle 2000 N (200 kp), rear axle 1000 N (100 kp).</li> <li>• After short delay (approx. 0.5 s), depress LED pushbutton.</li> <li>• Keep LED pushbutton depressed until dynamometer display stabilizes. The internal test unit program runs for a few seconds.</li> <li>• During test procedure, lamp 2 (red) must not light up. If it does, repeat test with engine running.</li> <li>• Resume or repeat test only after approx. 20 seconds, i. e. wait approx. 20 seconds between two applications of LED pushbutton (internal test unit program must be concluded).</li> </ul>	<p><b>Front axle</b> &lt; 1500 N &lt; (150 kp)</p> <p>Lamp 1 (green) must remain on throughout</p> <p><b>Rear axle</b> &lt; 800 N &lt; (80 kp)</p>
21	Hydraulic unit, pressure build-up in brake lines	<p><b>2. Check brake lines for correct connection</b></p> <ul style="list-style-type: none"> <li>• Drive vehicle with front wheels on dynamometer.</li> <li>• Select test stage 20, then front left wheel with pushbutton, pos. 5.2.</li> <li>• Engage front left brake roller.</li> <li>• Apply brake pedal, keep down until braking force display registers 2000 N (200 kp) on dynamometer.</li> <li>• Depress LED pushbutton.</li> <li>• Reduction in pressure to selected wheel (front left) must occur.</li> <li>• Carry out same test on front right wheel. Depress FR button and engage only the front right brake roller.</li> </ul> <p><b>3. Front axle hydraulic unit test; apply handbrake; test stages 20, 21 and 22</b></p> <ul style="list-style-type: none"> <li>• Set test stage.</li> <li>• Select one wheel (front left or front right).</li> <li>• Engage both brake rollers.</li> <li>• Preapply 2000 N (200 kp) braking force to the wheel about to be tested, with brake pedal. Throughout the test, maintain constant 2000 N. <b>Do not use a brake pedal winch to adjust braking force!</b></li> <li>• Keep LED pushbutton depressed until dynamometer display stabilizes and value has been read off (approx. 6 secs.).</li> <li>• During test, check that braking force remains constant at other running wheel.</li> </ul> <p>If pedal travel varies: minor variations in braking force are permissible, but do affect the display!</p> <ul style="list-style-type: none"> <li>• Carry out test stages 20, 21 and 22 in succession on both wheels.</li> </ul> <p><b>4. Rear axle hydraulic unit test: test stages 20, 21 and 22</b></p> <ul style="list-style-type: none"> <li>• Drive vehicle with rear axle on dynamometer.</li> <li>• Set test stage.</li> <li>• Depress pushbutton for rear axle.</li> <li>• Engage both brake rollers.</li> <li>• Run engine (braking force reinforcement is activated, facilitating brake application).</li> <li>• Preapply 1000 N (100 kp) with brake pedal and maintain constant throughout test: <b>Do not use a brake pedal winch to adjust braking force!</b></li> <li>• Keep LED pushbutton depressed until dynamometer display stabilizes (test duration approx. 6 secs.).</li> </ul>	<p>After a period of low pressure, braking force display rises again to: <b>at front axle:</b> &lt; 2000 N &lt; (200 kp)</p> <p>Lamp 1 (green) must remain on throughout</p> <p><b>at rear axle:</b> &lt; 1000 N &lt; (100 kp)</p>
22	Hydraulic unit, pump output	<p>• Preapply 2000 N (200 kp) braking force to the wheel about to be tested, with brake pedal. Throughout the test, maintain constant 2000 N. <b>Do not use a brake pedal winch to adjust braking force!</b></p> <p>• Keep LED pushbutton depressed until dynamometer display stabilizes and value has been read off (approx. 6 secs.).</p> <p>• During test, check that braking force remains constant at other running wheel.</p> <p>If pedal travel varies: minor variations in braking force are permissible, but do affect the display!</p> <ul style="list-style-type: none"> <li>• Carry out test stages 20, 21 and 22 in succession on both wheels.</li> </ul> <p><b>4. Rear axle hydraulic unit test: test stages 20, 21 and 22</b></p> <ul style="list-style-type: none"> <li>• Drive vehicle with rear axle on dynamometer.</li> <li>• Set test stage.</li> <li>• Depress pushbutton for rear axle.</li> <li>• Engage both brake rollers.</li> <li>• Run engine (braking force reinforcement is activated, facilitating brake application).</li> <li>• Preapply 1000 N (100 kp) with brake pedal and maintain constant throughout test: <b>Do not use a brake pedal winch to adjust braking force!</b></li> <li>• Keep LED pushbutton depressed until dynamometer display stabilizes (test duration approx. 6 secs.).</li> </ul>	<p>After dropping pressure twice without recirculating pump, the pump will switch on briefly. Braking force display must then drop below &lt; 600 N &lt; (60 kp)</p> <p>Brake pedal resists slightly.</p> <p>Lamp 1 (green) must remain on throughout.</p>

**ABS TEST UNIT Bosch ABS-2-LED TEster, order No. KDAS 0003**

**Adapter lead, order No. KDAS 0003/2**  
(supplied as standard with tester)



**Standard tools and instruments**


- 2 Control unit plug test leads, approx. 60 cm long with 2 insulated alligator clips and 2 flat pin plugs N 17.457.2.



The test lead must be used for testing the control unit plug.

**Plug terminal designations**

Control unit multiple-pin plug, looking towards plug terminals.



## EXPLANATION OF THE ABS-2-LED Test Unit

This tester can be used to test the following peripheral system components in six program stages.

- Hydraulic unit
- Motor relay
- Valve relays
- Speed sensors
- Warning lamp
- Wiring harness
- Plug connections
- Ground leads
- Stop light switch signal
- Generator signal


If a fault is present, it will be indicated by the various LED displays on the tester. Speed sensor signals can be evaluated by the deflection registered by the pointer-type instrument. The ABS regulating unit is not included in this Test Plan. This is a self-diagnostic unit which does not require additional testing with this test equipment.

**ABS testing with this tester does not require a dynamometer.** The tests can be carried out on a vehicle hoist of the type which leaves the wheels free to rotate.

**If, in spite of this, a dynamometer is used, there is a danger that the vehicle may jump off the rollers. The responsibility for using a dynamometer rests with the personnel carrying out the tests.**




## ABS-2-LED Tester Layout



- 1 – 1 LED display for wheel speed in program switch position 6
- 2 – 1 LED display for battery voltage
- 3 – Program switch
- 4 – 7 LED displays for program switch position 1
- 5 – 2 LED displays for program switch position 2
- 6 – Adapter lead for connection to ABS wiring harness in vehicle
- 7 – Pushbutton for motor relay activation in program switch position 3
- 8 – 1 LED display for program switch position 3
- 9 – 2 LED displays for program switch position 4
- 10 – 3 LED displays for program switch position 5
- 11 – 2 Pushbuttons to release solenoid valve functions, pressure-holding and pressure-reduction in program switch position 5
- 12 – Rotary switch for selection of individual wheels; functions in program switch positions 5 and 6
- 13 – Pointer-type instrument for program switch position 6


**Description of symbols**

The tester draws its power supply from the vehicle battery. The supply voltage is monitored in all program switch positions throughout the entire test procedure. An LED (1) provides a continuous indication of a satisfactory power supply.




**Program switch position 1**

- 1 = LED display for ground connection 1
- 2 = LED display for ground connection 2
- 3 = LED display for diode activating warning lamp
- 4 = LED displays for internal resistance of solenoid valves in hydraulic unit and valve relay in OFF condition.
  - 4.1 = LED display for front left wheel
  - 4.2 = LED display for front right wheel
  - 4.3 = LED display for rear axle of vehicles with 3-channel hydraulic unit (figures in () apply).
  - 4.4 = No function applicable to Porsche vehicles (broken line signifies that LED must only light up for 4-channel hydraulic units).




**Program switch position 2**

- 1 – LED display for connection to generator terminal 61
- 2 – LED display for connection to stop light switch



**Program switch position 3**

- 1 – LED display for motor relay and recirculating pump in hydraulic unit.
- 2 – Pushbutton to activate motor relay. LED display lights up only after pushbutton has been depressed.




**Program switch position 4**

No function applicable to Porsche vehicles (928, 944) as no acceleration transmitter fitted.

**Program switch position 5**

Function testing of solenoid valves and valve relay in hydraulic unit.  
Testing of channel assignments of solenoid valves (interchange test).


- 1 – Pushbutton and LED display for pressure reduction function. LED must light up when button depressed.
- 2 – Pushbutton and LED display for pressure-holding function. LED must light up when button depressed.
- 3 – LED display for valve relay function. LED must remain lit continuously in program switch position 5.
- 4 – Symbol for solenoid valves.



**Switch for wheel selection**

In program switch position 5 and 6, the switch must be set to the wheel to be tested.

- 1 – Rotary switch for wheel selection
  - 2 – Front left wheel
  - 3 – Front right wheel
  - 4 – Rear left wheel, when testing speed sensor in program switch position 6 (left signal represents rear left)
  - 5 – Rear right wheel, when testing speed sensor in program switch position 6.
- Rear axle on vehicles with 3-channel hydraulic unit when testing solenoid valve and valve relay in program switch position 5 (right symbol).



**Program switch position 6**

Testing of speed sensor signal and change in dynamic air gap between speed sensor and ring gear. Test for incorrect assignment of speed sensors.

- 1 – Pointer-type instrument
- 2 – LED display for rotary movement of wheels.  
LED remains on continuously so long as sufficient wheel speed exists for testing. Do not take reading from indicating instrument before this condition is obtained.



**ABS-2-LED Tester connection**

1. With ignition switched OFF, disconnect multi-pin (35-pole) plug from control unit.
2. Connect ABS-2-LED tester to ABS wiring harness multi-pin (35-pole) plug by means of adapter lead plug.
3. Switch ignition ON. All other power-consuming systems must be switched off.

**CAUTION: Vehicle must not be driven with test unit connected.**

Tester connection  
928 Series






Tester connection  
944 Series






### Preparations for tests using the ABS-2-LED Tester








- Check ground connection of recirculating pump and overvoltage protection relay terminal 31 for secure attachment and corrosion.
- Check hydraulic connections and junctions on hydraulic unit for leaks (visual inspection).
- If, when driving, the ABS warning lamp lights up intermittently (e.g. when items of electrical equipment are switched on) and goes out of its own accord, check battery and power supply (generator, regulator and voltage drops).
- If the ABS warning light remains on and does not go out, check the following points:
  - Is multi-pin plug correctly installed (and locked) in control unit?
  - Are all plug contacts OK?
  - Are spring-loaded contacts locked in position?
  - Are V-belts cracked?  
(generator produces no voltage, charging and ABS warning lamp lights up).
- For testing operations, switch ignition ON in all program switch positions (tester operates on power supply from vehicle battery).
- Observe LED for power supply in all program switch positions.

Switch ignition ON for all program switch positions

Program switch position	Item tested (measured at terminals)	Additional operations	Specified response (display)	Possible causes of fault Refer to circuit diagram
All	Power supply (terminal 20/ground and terminal 1/positive)	Ignition ON	LED  remains on continuously	<p>LED does not remain on</p> <ul style="list-style-type: none"> <li>• Battery insufficiently charged</li> <li>• Fuse blown (928 S '84: fuse 26 on CEE)</li> <li>• No ground at terminal 20</li> <li>• No voltage at terminal 1                             <ul style="list-style-type: none"> <li>- Lead from terminal 1 interrupted</li> <li>- No voltage at terminal 20</li> <li>- No voltage at terminal 30 interrupted</li> <li>- Relay or diode in terminal 31, passage in one direction interrupted</li> </ul> </li> <li>• Excessive voltage drop                             <ul style="list-style-type: none"> <li>928 S, '84 model</li> <li>928 S, '85 model on terminal 1</li> <li>944, '87 model on terminal 1</li> </ul> </li> </ul>
1	Ground connections (terminals 34, 10), diode for warning lamp (terminals 29, 32) solenoid valves, internal resistances (terminals 2, 35, 18) valve relay OFF condition and ground connection	Ignition ON	First 6 LEDs glow with uniform brightness	<ul style="list-style-type: none"> <li>• LED  does not glow                             <ul style="list-style-type: none"> <li>Check ground connection</li> </ul> </li> <li>• LED  does not glow                             <ul style="list-style-type: none"> <li>- ABS warning lamp diode defective</li> <li>- Lead between control terminal and terminal 29 interrupted.</li> <li>- Excessive voltage drop across valve relay plug</li> <li>- Test with ohmmeter with valve relay switched OFF. Display must register in both directions. (Pull out yellow plug)</li> </ul> </li> </ul> <p>If specified results are not obtained</p> <ul style="list-style-type: none"> <li>- The diode is defective</li> <li>- Leads from control terminal interrupted</li> </ul>









Specified response (display)	Possible causes of fault. Refer to circuit diagram when troubleshooting.
LED  remains on continuously	<p>LED does not remain on continuously:</p> <ul style="list-style-type: none"> <li>• Battery insufficiently charged (low voltage) &lt; 9.9 V</li> <li>• Fuse blown (928 S '84 model: fuse in ABS relay; '85 model onwards: fuse 16 cm CEB; 944: fuse 26 on CEB).</li> <li>• No ground at terminal 20 of control unit plug (test with ohmmeter).</li> <li>• No voltage at terminal 1 of control unit plug.               <ul style="list-style-type: none"> <li>– Lead from terminal '87 of ABS relay* to terminal 1 of control unit plug interrupted.</li> <li>– No voltage at terminal 30 of ABS relay, as positive lead from battery + to ABS relay terminal 30 interrupted.</li> <li>– No voltage at terminal 15 to ABS relay.</li> <li>– Relay or diode in relay defective (test diode with ohmmeter between terminals 30 and 31, passage in one direction only).</li> </ul> </li> <li>• Excessive voltage drop in supply leads.               <ul style="list-style-type: none"> <li>928 S, '84 model = relay XI</li> <li>928 S, '85 model onwards = relay XVI</li> <li>944, '87 model onwards = relay G 20</li> </ul> </li> </ul>
6 LEDs glow with uniform brightness	<ul style="list-style-type: none"> <li>• LED  does not light up: Check ground connections between terminals 34, 10 and MP.</li> <li>• LED  does not light up:           <ul style="list-style-type: none"> <li>– ABS warning lamp defective.</li> <li>– Lead between control unit plug terminal 29 and combination instrument (928 S, '84 model: terminal 2; 928 S, '85 model onwards: terminal 3; 944 terminal 14, plug L) interrupted.</li> <li>– Excessive voltage drop at indicator lamp plug connection, valve relay ground connection or valve relay plug connection.</li> <li>– Test with ohmmeter between terminals 29 and 32 of control unit plug with ignition switched OFF. Display must register low resistance in conducting direction, high resistance in reverse direction. (Pull out yellow plug from central information board for this test).</li> </ul> </li> </ul> <p>If specified results not met, either:</p> <ul style="list-style-type: none"> <li>– The diode is defective, replace hydraulic unit, or:</li> <li>– Leads from control unit plug terminals 29 or 32 to hydraulic unit interrupted.</li> </ul>








Response	<p>Possible causes of fault. Refer to circuit diagram when troubleshooting.</p>
LEDs glow	<ul style="list-style-type: none"> <li>• LED  4.1 does not light up: <ul style="list-style-type: none"> <li>– Lead from control unit terminal 2 to solenoid valve terminal 1, hydraulic unit or plug connection interrupted.</li> <li>– Solenoid valve defective, test with ohmmeter between control unit plug terminal 2 and ground (specified value 0.7 . . . 1.7 <math>\Omega</math>).</li> </ul> </li> <li>• LED  4.2 does not light up: <ul style="list-style-type: none"> <li>– Lead from control unit terminal 35 to solenoid valve terminal 3, hydraulic unit or plug connection interrupted.</li> <li>– Solenoid valve defective, test with ohmmeter between control unit plug terminal 35 and ground (specified value 0.7 . . . 1.7 <math>\Omega</math>).</li> </ul> </li> <li>• LED  4.3 does not light up: <ul style="list-style-type: none"> <li>– Lead from control unit terminal 18 to solenoid valve terminal 5, hydraulic unit or plug connection interrupted.</li> <li>– Solenoid valve defective, test with ohmmeter between control unit plug terminal 18 and ground (specified value 1.7 . . . 1.7 <math>\Omega</math>).</li> </ul> </li> <li>• If all LEDs  and LEDs  do not light up: <ul style="list-style-type: none"> <li>– Check valve relay ground connection.</li> <li>– Valve relay defective.</li> </ul> </li> <li>• If one LED glows weakly, this signified excessive transfer resistance in the corresponding circuit.</li> </ul> <p><b>CAUTION:</b> 4.4 does not light up, due to 3-channel only system.</p>
	<ul style="list-style-type: none"> <li>• LED does not light up: <ul style="list-style-type: none"> <li>– Cable connection from control unit plug terminal 15 to generator terminal 61 (D+) interrupted.</li> </ul> </li> </ul>
LEDs out with flashing	<ul style="list-style-type: none"> <li>• LED does not go out: <ul style="list-style-type: none"> <li>– Open throttle once; sometimes LED goes out only in response to a single application of throttle.</li> <li>– Generator or regulator defective.</li> </ul> </li> </ul>
	<ul style="list-style-type: none"> <li>• LED does not go out: <ul style="list-style-type: none"> <li>– Stop light fuse blown (928 S, '84 model: fuse 7; 928 S, '85 model onwards: fuse 4; 944: fuse 19)</li> <li>– No voltage at stop light switch.</li> <li>– Cable connection from control unit plug terminal 25 to stop light switch interrupted.</li> <li>– Stop light switch defective.</li> </ul> </li> </ul>

## TEST PLAN 2 ABS

Switch ignition ON for all program switch positions


Program switch position	Item tested (measured at terminals)	Additional operations	Specified response (display)	Possible causes of fault. Refer to circuit diagram when
1	Ground connections (terminals 34, 10), diode for warning lamp (terminals 29, 32) solenoid valves, internal resistances (terminals 2, 35, 18) valve relay OFF condition and ground connection	Ignition ON	First 6 LEDs glow with uniform brightness	<ul style="list-style-type: none"> <li>• LED  4.1 does not light               <ul style="list-style-type: none"> <li>– Lead from control unit to connection interrupted.</li> <li>– Solenoid valve defective, ground (specified value 0.2)</li> </ul> </li> <li>• LED  4.2 does not light               <ul style="list-style-type: none"> <li>– Lead from control unit to connection interrupted.</li> <li>– Solenoid valve defective, ground (specified value 0.2)</li> </ul> </li> <li>• LED  4.3 does not light               <ul style="list-style-type: none"> <li>– Lead from control unit to connection interrupted.</li> <li>– Solenoid valve defective, ground (specified value 1.2)</li> </ul> </li> <li>• If all LEDs  and LED  <ul style="list-style-type: none"> <li>– Check valve relay ground</li> <li>– Valve relay defective.</li> </ul> </li> <li>• If one LED glows weakly, check circuit.</li> </ul> <p><b>CAUTION: 4.4 does not light</b></p>
2	Generator voltage from terminal 61 (terminal 15)	Ignition ON	LED  lights up	<ul style="list-style-type: none"> <li>• LED does not light up:               <ul style="list-style-type: none"> <li>– Cable connection from control unit interrupted.</li> </ul> </li> </ul>
		Start engine	LED goes out with engine running	<ul style="list-style-type: none"> <li>• LED does not go out:               <ul style="list-style-type: none"> <li>– Open throttle once; some throttle.</li> <li>– Generator or regulator defective</li> </ul> </li> </ul>
	Stop light switch (terminal 25)	Ignition ON	LED  lights up	<ul style="list-style-type: none"> <li>• LED does not go out:               <ul style="list-style-type: none"> <li>– Stop light fuse blown (92 fuse 4; 944: fuse 19)</li> <li>– No voltage at stop light switch</li> <li>– Cable connection from control unit interrupted.</li> <li>– Stop light switch defective</li> </ul> </li> </ul>
		Operate brake pedal	LED  goes out	


Program switch position	Item tested (measured at terminals)	Additional operations	Specified response (display)	Possible causes of fault Refer to circuit diagram
3	Motor relay, pump motor in hydraulic unit (terminal 28)	Ignition ON Depress pushbutton continuously	LED  lights up, pump motor runs. After release of pushbutton, LED lights up again as pump motor slows down	If pump motor does not run: - Hydraulic unit has no pressure - No voltage at hydraulic unit - No voltage at hydraulic unit - Control lead from hydraulic unit defective - Motor relay defective - Pump motor defective
4	Acceleration transmitter			Program switch position with four-wheel drive.
5	Valve relay function (terminal 27)	Ignition ON	LED  remains on continuously	LED does not light up: - Check lead connection - Check lead connection 87 for continuity. - Valve relay defective

Specified response (display)	Possible causes of fault. Refer to circuit <b>diagram</b> when troubleshooting.
<p>LED </p> <p>LED lights up, pump motor runs. After release of pushbutton, LED lights up again as pump motor slows down.</p>	<p>If pump motor does not start, and LED does not light up:</p> <ul style="list-style-type: none"> <li>- Hydraulic unit has no ground connection (program part 1).</li> <li>- No voltage at hydraulic unit terminal 12 (power supply motor relay load current).</li> <li>- No voltage at hydraulic unit terminal 10 (power supply control circuit motor relay).</li> <li>- Control lead from hydraulic unit terminal 11 to control unit plug terminal 28 interrupted.</li> <li>- Motor relay defective.</li> <li>- Pump motor defective.</li> </ul>
<p>LED </p> <p>LED remains on continuously.</p>	<p>Program switch position not required, as acceleration transmitter only fitted to vehicles with four-wheel drive.</p>
<p>LED </p> <p>LED does not light up:</p>	<ul style="list-style-type: none"> <li>- Check lead connection between control unit plug terminal 27 and 28 for continuity.</li> <li>- Check lead connection between control unit plug terminal 27 and ABS relay terminal 87 for continuity.</li> <li>- Valve relay defective.</li> </ul>

LED response Possible causes of fault.  
Refer to circuit diagram when troubleshooting.

LED on continuously  
when program switch  
position 5.



**CAUTION:**  
Switch position   
Not required in program switch  
position 5.

P= LED lights up  
when wheel  
is braked by  
P= LED  
lights out,  
braked.  
P+ LED  
lights up,  
brake pressure  
is detectable by  
P+ LED  
lights out,  
brake pressure  
is not detectable


**LED does not light up:**

- Low battery voltage: repeat test with engine running.



**Characteristic:** Current requirement not met, LED P ↓ for pressure-holding or P = for pressure-reduction goes out, as battery insufficiently charged.


- If a wheel other than that set on the test unit responds, the brake lines at the hydraulic unit have been incorrectly connected.
- Check ground terminals on hydraulic unit and vehicle body.
- Check hydraulic unit positive lead.
- Hydraulic unit defective.

LED in box



TEST PLAN 2 ABS

Program switch position	Item tested (measured at terminals)	Additional operations	Specified response (display)	Possible causes of fault. Refer to circuit diagram when
5	Solenoid valves in hydraulic unit for function and correct assignment.  <b>Note:</b> Carry out tests on each front wheel individually in succession. Rear axle testing can be carried out on either the left or right wheel.	Raise vehicle on hoist. Ignition ON. Wheel to be tested must be freely rotatable by hand. Set wheel selector switch to appropriate wheel (position 2, 3, 4 in diagram).  Carry out operations in specified sequence.	LED  remains on continuously in program switch position 5.	
	Function pressure-holding	1. Depress push-button (2) continuously	LED P= (2) lights up	<p>LED does not light up:</p> <ul style="list-style-type: none"> <li>• Low battery voltage: repeat</li> <li>• Characteristic: Current required P = for press</li> <li>• If a wheel other than that set hydraulic unit have been in</li> <li>• Check ground terminals on in</li> <li>• Check hydraulic unit positive</li> <li>• Hydraulic unit defective.</li> </ul>
		2. Depress brake pedal continuously	Tested wheel rotatable by hand	
		3. Release push-button (2)	LED P= (2) goes out, wheel locked.	
	Function pressure-reduction	4. Depress push-button (1) for pressure reduction	LED P↓ (1) for pressure-reduction lights up, wheel rotatable by hand	
		5. Release push-button (1) for pressure-reduction	LED P↓ (1) for pressure-reduction goes out, wheel locked	
		6. Release brake pedal		
		Pushbuttons and LED designated in box headed "Additional operations":		




Program switch position	Item tested (measured at terminals)	Additional operations	Specified response (display)	Possible causes of fault. Refer to circuit diagram
6	Speed sensors for function and correct assignment.	Raise vehicle on hoist. Ignition ON. Wheel to be rested must be freely rotatable by hand.	Minimum display	<p><b>LED does not light up</b> instrument registers no</p> <ul style="list-style-type: none"> <li>• Speed sensor lead in</li> <li>• Speed sensor lead in (test with ohmmeter specified in column 2 connection).</li> <li>• Speed sensor defective (with ohmmeter, measure 0.8 ... 1.8 Ω).</li> <li>• No effective pulse gear</li> </ul> <p><b>If displayed value below</b></p> <ul style="list-style-type: none"> <li>• Excessive air gap between pulse gear.</li> <li>• Pulse gear loose, damaged</li> <li>• Pulse gear with incorrect installed</li> </ul> <p>928 S, '84 and '85 models 928 S, '86 model onwards 944, 944 S, 944 Turbo '87 models onwards</p> <p><b>Fluctuating display:</b></p> <ul style="list-style-type: none"> <li>• Pulse gear or gear hub (excessive eccentricity)</li> </ul>
	<p><b>Note:</b> Carry out tests on each wheel individually in succession.</p> <p><b>Front left wheel:</b> Terminals 4 and 6</p> <p><b>Front right wheel:</b> 928 S '84 model Terminals 21 and 23 928 S '86 model onwards and 944 '87 model onwards Terminals 21 and 11</p>	<p>Set wheel selector switch (No. 1, diagram above) to wheel to be tested (position 2, 3, 4, 5).</p> <p>Rotate wheel by hand until LED (No. 2, diagram below) above instrument glows steadily (speed approx. 1 revolution per second).</p>	<p>928 S before '86 model</p> <p>&gt; 1.5</p> <p>scale divisions.</p>	
	<p><b>Rear left wheel:</b> Terminals 8 and 9</p> <p><b>Rear right wheel:</b> Terminals 24 and 26</p>	<p>Read off display on instrument.</p> <p><b>Caution:</b> Lock rear wheel not being tested.</p>	<p>928 S '86 model onwards and 944 '87 model onwards</p> <p>&gt; 2.0</p> <p>scale divisions.</p>	
			<p>Permissible fluctuation range:</p> <p>max. 15 %</p> <p>of maximum displayed value.</p>	

WIRING DIAGRAM ABS Model Year '84


Program switch position	Item tested (measured at terminals)	Additional operations	Specified response (display)	Possible causes of fault. Refer to circuit diagram
6	<p>Speed sensors for function and correct assignment.</p> <p><b>Note:</b> Carry out tests on each wheel individually in succession.</p> <p><b>Front left wheel:</b> Terminals 4 and 6</p> <p><b>Front right wheel:</b> 928 S '84 model Terminals 21 and 23</p> <p>928 S '86 model onwards and 944 '87 model onwards Terminals 21 and 11</p> <p><b>Rear left wheel:</b> Terminals 8 and 9</p> <p><b>Rear right wheel:</b> Terminals 24 and 26</p>	<p>Raise vehicle on hoist. Ignition ON. Wheel to be rested must be freely rotatable by hand. Set wheel selector switch (No. 1, diagram above) to wheel to be tested (position 2, 3, 4, 5).</p> <p>Rotate wheel by hand until LED (No. 2, diagram below) above instrument glows steadily (speed approx. 1 revolution per second).</p> <p>Read off display on instrument.</p> <p><b>Caution:</b> Lock rear wheel not being tested.</p>	<p>Minimum display</p> <p>928 S before '86 model</p> <p style="text-align: center;">&gt; 1.5</p> <p>scale divisions.</p> <hr/> <p>928 S '86 model onwards and 944 '87 model onwards</p> <p style="text-align: center;">&gt; 2.0</p> <p>scale divisions.</p> <hr/> <p>Permissible fluctuation range:</p> <p>max. 15 %</p> <p>of maximum displayed value.</p>	<p><b>LED does not light up</b> instrument registers no</p> <ul style="list-style-type: none"> <li>• Speed sensor lead inc</li> <li>• Speed sensor lead int (test with ohmmeter specified in column 2 connection).</li> <li>• Speed sensor defecti (with ohmmeter, me 0.8 . . . 1.8 Ω).</li> <li>• No effective pulse ge</li> </ul> <p><b>If displayed value below</b></p> <ul style="list-style-type: none"> <li>• Excessive air gap bet pulse gear.</li> <li>• Pulse gear loose, dam</li> <li>• Pulse gear with incor installed</li> </ul> <p>928 S, '84 and '85 m 928 S, '86 model ony 944, 944 S, 944 Turf '87 models onwards</p> <p><b>Fluctuating display:</b></p> <ul style="list-style-type: none"> <li>• Pulse gear or gear hu (excessive eccentricit</li> </ul>






- a - Pump motor
- b - Pump relay
- c<sub>1</sub> - Solenoid valve, front left
- c<sub>2</sub> - Solenoid valve, front right
- c<sub>3</sub> - Solenoid valve, rear
- d - Valve relay
- d<sub>1</sub> - Plug connection, black
- d<sub>2</sub> - Plug connection, yellow
- e - Diode
- g<sub>1</sub> - Speed sensor, front left
- g<sub>2</sub> - Speed sensor, front right
- g<sub>3</sub> - Speed sensor, rear left
- g<sub>4</sub> - Speed sensor, rear right


WIRING DIAGRAM ABS Model Year '84



- |                                |                            |                                |  |                                  |
|--------------------------------|----------------------------|--------------------------------|--|----------------------------------|
| A - ABS Control unit           | E - Screw connection (30)  | ⊗ - Ground on steering bracket | a - Pump motor                               | d - Valve relay                  |
| B - ABS hydraulic control unit | F - Combination instrument | △ - Ground on wheel housing    | b - Pump relay                               | d <sub>1</sub> - Plug connection |
| C - Power supply relay XI      | G - Speed sensor           |                                | c <sub>1</sub> - Solenoid valve, front left  | d <sub>2</sub> - Plug connection |
| D - Central information board  | Y - Plug Y on CEB          |                                | c <sub>2</sub> - Solenoid valve, front right | e - Diode                        |
|                                | S - Starter                |                                | c <sub>3</sub> - Solenoid valve, rear        |                                  |



- |                               |                              |                       |  |                          |
|-------------------------------|------------------------------|-----------------------|--|--------------------------|
| A - ABS Control unit          | F - Combination instrument   | 1 - Terminal 15       | a - Pump motor                               | d <sub>1</sub> - Plug co |
| B - Hydraulic control unit    | G - Speed sensor             | 2 - D +/61            | b - Pump relay                               | d <sub>2</sub> - Plug co |
| C - ABS relay XVII            | Y - Four-pin plug (near CEB) | 3 - Stop light switch | c <sub>1</sub> - Solenoid valve, front left  | e - Diode                |
| D - Central information board |                              | 4 - Terminal 15       | c <sub>2</sub> - Solenoid valve, front right | g <sub>1</sub> - Speed s |
| E - Cable connector           |                              | 5 - MP V              | c <sub>3</sub> - Solenoid valve, rear        | g <sub>2</sub> - Speed s |
|                               |                              | 6 - B +               | d - Valve relay                              | g <sub>3</sub> - Speed s |
|                               |                              |                       |  | g <sub>4</sub> - Speed s |





- a - Pump motor
- b - Pump relay
- c<sub>1</sub> - Solenoid valve, front left
- c<sub>2</sub> - Solenoid valve, front right
- c<sub>3</sub> - Solenoid valve, rear
- d - Valve relay

- d<sub>1</sub> - Plug connection, black
- d<sub>2</sub> - Plug connection, yellow
- e - Diode
- g<sub>1</sub> - Speed sensor, front left
- g<sub>2</sub> - Speed sensor, front right
- g<sub>3</sub> - Speed sensor, rear left
- g<sub>4</sub> - Speed sensor, rear right

- MP III - Ground point, front left wheel housing
- MP IV - Ground point, via steering column
- MP V - Ground point, above CEB
- MP VIII - Ground point, upper left engine compartment, near clutch bell-housing


\*) Values in (), '86 models onwards  
 \*\*) Combination lead, '87 model onwards





- A - ABS Control unit
- B - Hydraulic control unit
- C - ABS relay (G 20 on CEB)
- D - Central Electric Board
- E - To starter terminal 30
- F - ABS plug connector (RHD only)
- G - ABS wiring harness
- H - Combination lead 4 x
- I - Four-pin plug (near CEB)
- MP VI - Ground pin - control unit
- Ground lead - hydraulic unit

- a - Pump motor
- b - Pump relay
- c<sub>1</sub> - Solenoid valve, front left
- c<sub>2</sub> - Solenoid valve, front right
- c<sub>3</sub> - Solenoid valve, rear
- d - Valve relay
- e - Diode
- g<sub>1</sub> - Speed sensor, front left
- g<sub>2</sub> - Speed sensor, front right
- g<sub>3</sub> - Speed sensor, rear left
- g<sub>4</sub> - Speed sensor, rear right
- h - Stop light
- k - ABS lamp in combination instrument



461

WIRING DIAGRAM Model Year '87

