

Service every 20,000 km	Page
Diagnosis system: read out fault memory	1
Change engine oil	
Air cleaner: replace filter element	
Particle filter: replace filter element	
V-belt or Polyrib belt: check condition and tension	
Replace spark plugs (only on vehicles without catalytic converter)	
Visual check for leaks: oils and fluids	
Crankcase ventilation: check tightness of hose connections	
Fuel system: visual inspection for damage, routing and tight fit of line and hose connections	
Intake air system: check hoses, lines and connections for tight fit	
Parking brake: check free travel of parking brake lever	
Brake system: visual check of brake pads and brake discs for wear	
Brake hoses and pipes: visual check for damage, routing and corrosion	
Clutch: check free travel and pedal end position	
Throttle actuator: check for smooth operation and full-load position	
Check operation of resonance flap	
Steering gear: visual check of rubber bellows for damage. Tie rod joints: check play and condition of dust caps	
Power steering: check fluid level	14
Ball joints: visual inspection of dust caps for damage. Check bolt connections of front and rear suspension alignment for tight fit	
Transmission / final drives: check oil levels	15
Automatic transmission: check ATF fluid level	
Drive shafts: visual inspection of bellows for leaks and damage	
Exhaust system: visual inspection for leaks and damage, check fitting	
Tires: check condition and tire pressure	
Door hinges: lubricate with oil	
Check door and hinge locks and safety hook of front hood for tightness and operation	
Seat belts: check operation and condition	
Seals of doors, hoods and roof: remove rubber abrasions. Apply suitable lubricant.	
Check operation of vehicle lighting. All headlights: check adjustment. Signal horn: check operation	
Windshield washer system, headlight cleaning system: Check fluid level and nozzle adjustment, check antifreeze content in winter season	21
All other electrical systems, monitor lamps and warning lamps: check operation	21
Ignition circuits 1 and 2: check operation	
Test drive: Brake pedal and parking brake, clutch, automatic speed control, steering, heater, air conditioning and instruments: check operation	
Visual inspection for leaks: oils and fluids	22

	Page
Additional service every 40,000 km	
Automatic transmission: change ATF and ATF filter	23
Toothed belt for power steering: check condition	
Replace spark plugs (only for vehicles with catalytic converter)	
Replace both engine oil filters	
Additional service every 80,000 km	
Replace fuel filter	30
Manual transmission / final drives: change oil	
Automatic transmission: change oil in final drive	
Yearly service – starting after the first 2 years	
File Status Report for Long-life warranty	
Service every 3 years	
Change brake fluid (use only genuine Porsche brake fluid)	31
Service every 4, 8, 10 years and then every 2 years	
Check airbag system	see page 68 - 20
Recommended annual service	
Visual inspection for leaks: oils, fluids	
Diagnosis system: read out fault memory	
Parking brake: check free travel of parking brake lever	
Brake system: visual check of brake pads and brake discs for wear	
Check brake fluid level	
Steering gear: visual inspection of bellows for damage	
Tie rod joints: check play and condition of dust caps	
Ball joints: visual inspection of dust caps for damage	
Drive shafts: visual inspection of bellows for leaks and damage	
Exhaust system: visual inspection for leaks and damage, check fitting,	
Tires: check condition and tire pressure	
Seals of doors, hoods and roof: remove rubber abrasions. Apply suitable lubricant.	
Check operation of vehicle lighting.	
Windshield washer system, headlight cleaning system: Check fluid level and nozzle adjustment, check antifreeze content in winter season.	
Battery: Check electrolyte level and electrolyte density	30
All other electrical systems and monitor lamps and warning lamps: check operation	
File Status Report for Long-life warranty (first report after 2 years)	
Test drive:	
Brake pedal and parking brake, clutch, automatic speed control, steering, heater, air conditioning and instruments: check operation	
Visual inspection for leaks: oils and fluids	