



**PORSCHE**

## **Technical Manual**

**DME 7.8**

**Group 0**

**Diagnosis**

---

## Table of Contents

### 0 Diagnosis

#### 0 General

2470	INTRODUCTION. . . . .	35
	General. . . . .	35
	Definition of terms. . . . .	39
	Warnings. . . . .	43
	Notes on troubleshooting. . . . .	45
	Troubleshooting procedure. . . . .	47
	Diagnostic conditions. . . . .	47
	Possible causes of faults. . . . .	48
	Diagnosis/troubleshooting. . . . .	49
	Data Output with the Porsche System Tester 2. . . . .	52
	DME. . . . .	52
	Data output with the Porsche System Tester 2 - 911 Carrera (996). . . . .	68
	DME. . . . .	68
	Data output with a scan tool. . . . .	92
	Mode 1. . . . .	93
	Mode 2. . . . .	104
	Mode 3. . . . .	108
	Mode 4. . . . .	109
	Mode 5. . . . .	109
	Mode 6. . . . .	111
	Mode 7. . . . .	115
	Mode 9. . . . .	115
	Data output with a scan tool - 911 Carrera (996). . . . .	116
	Mode 1. . . . .	117
	Mode 2. . . . .	128
	Mode 3. . . . .	133
	Mode 4. . . . .	133
	Mode 5. . . . .	133
	Mode 6. . . . .	135
	Mode 7. . . . .	139
	Mode 9. . . . .	139
	Connector assignment. . . . .	140
	DME control module connector assignment. . . . .	140
	Connector assignment - 911 Carrera (996). . . . .	145

	DME control module connector assignment. . . . .	145
	Engine specifications. . . . .	150
	911 Turbo (996). . . . .	150
	Load values of the 911 Turbo (996). . . . .	153
	Engine specifications. . . . .	154
	911 Carrera (996). . . . .	154
	911 Carrera (996) load values. . . . .	157
	Control module function. . . . .	158
	Fault overview of 911 (996) Turbo models up to model year 2001. . . . .	160
	Fault overview of 911 Carrera (996) as of model year '02. . . . .	176
	Fault overview of 911 Turbo (996) and GT 2 as of model year '02. . . . .	189
1536	P0011. . . . .	203
	Position of Camshaft in Relation to Crankshaft, Bank 1 – Below Limit. . . . .	203
	Diagnosis/Troubleshooting. . . . .	203
1536	P0012. . . . .	204
	Position of Camshaft in Relation to Crankshaft, Bank 1 – Above Limit. . . . .	204
	Diagnosis/Troubleshooting. . . . .	205
1536	P0013. . . . .	207
	Camshaft Adjustment, Bank 1 Output Stage - Open Circuit. . . . .	207
	Diagnosis/Troubleshooting. . . . .	207
	Camshaft Adjustment, Bank 1 Output Stage - Below Limit. . . . .	208
	Diagnosis/Troubleshooting. . . . .	209
	Camshaft Adjustment, Bank 1 Output Stage - Above Limit. . . . .	209
	Diagnosis/Troubleshooting. . . . .	209
1536	P0021. . . . .	210
	Position of Camshaft in Relation to Crankshaft, Bank 2 – Below Limit. . . . .	210
	Diagnosis/Troubleshooting. . . . .	210
1536	P0022. . . . .	211
	Position of Camshaft in Relation to Crankshaft, Bank 2 – Above Limit. . . . .	211
	Diagnosis/Troubleshooting. . . . .	212
1536	P0023. . . . .	214
	Camshaft Adjustment, Bank 2 Output Stage - Open Circuit. . . . .	214
	Diagnosis/Troubleshooting. . . . .	214
	Camshaft Adjustment, Bank 2 Output Stage - Below Limit. . . . .	215
	Diagnosis/Troubleshooting. . . . .	216
	Camshaft Adjustment, Bank 2 Output Stage - Above Limit. . . . .	216
	Diagnosis/Troubleshooting. . . . .	216

3755	P0026. . . . .	217
	Valve lift control, bank 1 output stage - open circuit. . . . .	217
	Diagnosis/troubleshooting. . . . .	217
	Valve lift control, bank 1, output stage - below limit. . . . .	218
	Diagnosis/troubleshooting. . . . .	218
	Valve lift control, bank 1, output stage - above limit. . . . .	219
	Diagnosis/troubleshooting. . . . .	219
3755	P0028. . . . .	220
	Valve lift control, bank 2 output stage - open circuit. . . . .	220
	Diagnosis/troubleshooting. . . . .	220
	Valve lift control, bank 2, output stage - below limit. . . . .	221
	Diagnosis/troubleshooting. . . . .	221
	Valve lift control, bank 2, output stage - above limit. . . . .	222
	Diagnosis/troubleshooting. . . . .	222
2470	P0030. . . . .	223
	HO2S Heater Control Circuit. . . . .	223
	Diagnosis/troubleshooting - all turbo models. . . . .	223
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	224
2470	P0031. . . . .	227
	HO2S Heater Control Circuit Low. . . . .	227
	Diagnosis/troubleshooting - all turbo models. . . . .	227
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	228
2470	P0032. . . . .	231
	HO2S Heater Control Circuit High. . . . .	231
	Diagnosis/troubleshooting - all turbo models. . . . .	231
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	232
2470	P0036. . . . .	234
	HO2S Heater Control Circuit. . . . .	234
	Diagnosis/troubleshooting. . . . .	234
2470	P0037. . . . .	237
	HO2S Heater Control Circuit Low. . . . .	237
	Diagnosis/troubleshooting. . . . .	237
2470	P0038. . . . .	239
	HO2S Heater Control Circuit High. . . . .	239
	Diagnosis/troubleshooting. . . . .	239
2470	P0040. . . . .	241
	Oxygen sensor ahead of catalytic converter – signal implausible (only Turbo). . . . .	241
	Diagnosis/troubleshooting. . . . .	241



2193	P0045. . . . .	245
	Charge Pressure Control Valve Output Stage - Open Circuit. . . . .	245
	Diagnosis/Troubleshooting. . . . .	245
2193	P0047. . . . .	246
	Charge Pressure Control Valve Output Stage - Below Limit. . . . .	246
	Diagnosis/Troubleshooting. . . . .	246
2193	P0048. . . . .	247
	Charge Pressure Control Valve Output Stage - Above Limit. . . . .	247
	Diagnosis/Troubleshooting. . . . .	247
2470	P0050. . . . .	248
	HO2S Heater Control Circuit. . . . .	248
	Diagnosis/troubleshooting - all turbo models. . . . .	248
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	249
2470	P0051. . . . .	252
	HO2S Heater Control Circuit Low. . . . .	252
	Diagnosis/troubleshooting - all turbo models. . . . .	252
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	253
2470	P0052. . . . .	256
	HO2S Heater Control Circuit High. . . . .	256
	Diagnosis/troubleshooting - all turbo models. . . . .	256
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	257
2470	P0056. . . . .	259
	HO2S Heater Control Circuit. . . . .	259
	Diagnosis/troubleshooting. . . . .	259
2470	P0057. . . . .	262
	HO2S Heater Control Circuit Low. . . . .	262
	Diagnosis/troubleshooting. . . . .	262
2470	P0058. . . . .	264
	HO2S Heater Control Circuit High. . . . .	264
	Diagnosis/troubleshooting. . . . .	264
9025	P0071. . . . .	266
	Ambient Temperature (via CAN from instrument cluster) - Signal Implausible. . . . .	266
	Diagnosis/Troubleshooting. . . . .	266
2445	P0102. . . . .	267
	115 Mass air flow sensor – below limit. . . . .	267
	Diagnosis/troubleshooting. . . . .	268
2445	P0103. . . . .	269
	115 Mass Air Flow Sensor - Above Limit. . . . .	269

	Diagnosis/Troubleshooting. . . . .	269
2470	P0107. . . . .	271
	299 Ambient Pressure Sensor - Below Limit. . . . .	271
	Diagnosis/troubleshooting. . . . .	271
2470	P0108. . . . .	272
	299 Ambient Pressure Sensor - Above Limit. . . . .	272
	Diagnosis/troubleshooting. . . . .	272
2488	P0112. . . . .	273
	124 Intake air temperature - below limit. . . . .	273
	Diagnosis/troubleshooting. . . . .	274
2488	P0113. . . . .	275
	124 Intake air temperature sensor - above limit. . . . .	275
	Diagnosis/troubleshooting. . . . .	275
2462	P0115. . . . .	276
	123 Engine temperature - signal implausible. . . . .	276
	Diagnosis/troubleshooting. . . . .	276
2462	P0116. . . . .	280
	Engine Temperature – Signal Implausible. . . . .	280
	Diagnosis/Troubleshooting. . . . .	280
2462	P0117. . . . .	284
	123 Engine temperature - open circuit, below limit. . . . .	284
	Diagnosis/troubleshooting. . . . .	285
2462	P0118. . . . .	287
	123 Engine temperature - above limit. . . . .	287
	Diagnosis/troubleshooting. . . . .	288
2442	P0121. . . . .	290
	117 Throttle valve - signal implausible. . . . .	290
	Diagnosis/troubleshooting. . . . .	291
2078	P0121. . . . .	295
	Accelerator Pedal Potentiometer 1 – Signal Implausible. . . . .	295
2078	P0122. . . . .	296
	Accelerator Pedal Potentiometer 1 – Below Limit. . . . .	296
2078	P0123. . . . .	297
	Accelerator Pedal Potentiometer 1 – Above Limit. . . . .	297
2462	P0125. . . . .	298
	Engine Temperature - Open Circuit. . . . .	298
	Diagnosis/Troubleshooting. . . . .	299

1958	P0128. . . . .	301
	Blocked Thermostat - Signal Implausible. . . . .	301
	Diagnosis/Troubleshooting. . . . .	301
2470	P0129. . . . .	302
	Ambient Pressure Sensor – Below Limit. . . . .	302
	Diagnosis/Troubleshooting. . . . .	302
2470	P0130. . . . .	303
	O2 Sensor Circuit. . . . .	303
	Diagnosis/troubleshooting - all turbo models. . . . .	303
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	307
2470	P0131. . . . .	312
	O2 Sensor Circuit Low Voltage. . . . .	312
	Diagnosis/troubleshooting. . . . .	312
2470	P0132. . . . .	316
	O2 Sensor Circuit High Voltage. . . . .	316
	Diagnosis/troubleshooting - all turbo models. . . . .	316
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	319
2469	P0133. . . . .	325
	10 Oxygen Sensor Ahead of TWC, Bank 1 – Below Limit. . . . .	325
	Diagnosis/Troubleshooting. . . . .	325
2469	P0133. . . . .	327
	O2 Sensor Circuit Slow Response. . . . .	327
	Diagnosis/troubleshooting. . . . .	327
2470	P0134. . . . .	329
	O2 Sensor Circuit No Activity Detected. . . . .	329
	Diagnosis/troubleshooting - all turbo models. . . . .	329
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	330
2470	P0135. . . . .	336
	O2 Sensor Heater Circuit. . . . .	336
	Diagnosis/troubleshooting - all turbo models. . . . .	336
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	338
2470	P0136. . . . .	341
	O2 Sensor Circuit. . . . .	341
	O2 Sensor Circuit Slow Response. . . . .	342
2470	P0137. . . . .	344
	O2 Sensor Circuit Low Voltage. . . . .	344
	Diagnosis/troubleshooting. . . . .	344
2470	P0138. . . . .	347

	O2 Sensor Circuit High Voltage. . . . .	347
	Diagnosis/troubleshooting. . . . .	347
2470	P0139. . . . .	350
	O2 Sensor Circuit Slow Response. . . . .	350
	Diagnosis/troubleshooting. . . . .	350
2470	P0140. . . . .	352
	O2 Sensor Circuit No Activity Detected. . . . .	352
	Diagnosis/troubleshooting. . . . .	352
2470	P0141. . . . .	357
	O2 Sensor Heater Circuit. . . . .	357
	Signal implausible. . . . .	357
	Open circuit. . . . .	358
	Below limit. . . . .	359
	Above limit. . . . .	361
2470	P0150. . . . .	363
	O2 Sensor Circuit. . . . .	363
	Diagnosis/troubleshooting - all turbo models. . . . .	363
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	367
2470	P0151. . . . .	372
	O2 Sensor Circuit Low Voltage. . . . .	372
	Diagnosis/troubleshooting. . . . .	372
2470	P0152. . . . .	376
	O2 Sensor Circuit High Voltage. . . . .	376
	Diagnosis/troubleshooting - all turbo models. . . . .	376
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	379
2469	P0153. . . . .	385
	18 Oxygen Sensor Ahead of TWC, Bank 2 – Below Limit. . . . .	385
	Diagnosis/Troubleshooting. . . . .	385
2469	P0153. . . . .	387
	O2 Sensor Circuit Slow Response. . . . .	387
	Diagnosis/troubleshooting. . . . .	387
2470	P0154. . . . .	389
	O2 Sensor Circuit No Activity Detected. . . . .	389
	Diagnosis/troubleshooting - all turbo models. . . . .	389
	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	390
2470	P0155. . . . .	396
	O2 Sensor Heater Circuit. . . . .	396
	Diagnosis/troubleshooting - all turbo models. . . . .	396

	Diagnosis/troubleshooting - all naturally-aspirated models. . . . .	398
2470	P0156. . . . .	401
	O2 Sensor Circuit. . . . .	401
	O2 Sensor Circuit Slow Response. . . . .	402
2470	P0157. . . . .	404
	O2 Sensor Circuit Low voltage. . . . .	404
	Diagnosis/troubleshooting. . . . .	404
2470	P0158. . . . .	407
	O2 Sensor Circuit High Voltage. . . . .	407
	Diagnosis/troubleshooting. . . . .	407
2470	P0159. . . . .	410
	O2 Sensor Circuit Slow Response. . . . .	410
	Diagnosis/troubleshooting. . . . .	410
2470	P0160. . . . .	412
	O2 Sensor Circuit No Activity Detected. . . . .	412
	Diagnosis/troubleshooting. . . . .	412
2470	P0161. . . . .	417
	O2 Sensor Heater Circuit. . . . .	417
	Signal implausible. . . . .	417
	Open circuit. . . . .	418
	Below limit. . . . .	419
	Above limit. . . . .	421
2469	P0171. . . . .	423
	Oxygen Sensing Adaptation, Idle Range, Bank 1 – Above Limit. . . . .	423
2469	P0172. . . . .	425
	Oxygen Sensing Adaptation, Idle Range, Bank 1 – Below Limit. . . . .	425
	Diagnosis/Troubleshooting. . . . .	425
2469	P0174. . . . .	427
	Oxygen Sensing Adaptation, Idle Range, Bank 2 – Above Limit. . . . .	427
	Diagnosis/Troubleshooting. . . . .	427
2469	P0175. . . . .	429
	Oxygen Sensing Adaptation, Idle Range, Bank 2 – Below Limit. . . . .	429
	Diagnosis/Troubleshooting. . . . .	429
1709	P0197. . . . .	431
	125 Oil temperature sensor - below limit. . . . .	431
	Diagnosis/troubleshooting. . . . .	432
1709	P0198. . . . .	433
	125 Oil temperature sensor - above limit. . . . .	433

	Diagnosis/troubleshooting. . . . .	434
2440	P0201. . . . .	435
	Fuel Injector, Cylinder 1 – Open Circuit. . . . .	435
	Diagnosis/Troubleshooting. . . . .	436
2440	P0202. . . . .	437
	Fuel Injector, Cylinder 2 – Open Circuit. . . . .	437
	Diagnosis/Troubleshooting. . . . .	438
2440	P0203. . . . .	439
	Fuel Injector, Cylinder 3 – Open Circuit. . . . .	439
	Diagnosis/Troubleshooting. . . . .	440
2440	P0204. . . . .	441
	Fuel Injector, Cylinder 4 – Open Circuit. . . . .	441
	Diagnosis/Troubleshooting. . . . .	442
2440	P0205. . . . .	443
	Fuel Injector, Cylinder 5 – Open Circuit. . . . .	443
	Diagnosis/Troubleshooting. . . . .	444
2440	P0206. . . . .	445
	Fuel Injector, Cylinder 6 – Open Circuit. . . . .	445
	Diagnosis/Troubleshooting. . . . .	446
2078	P0221. . . . .	447
	Accelerator Pedal Potentiometer 2 – Signal Implausible. . . . .	447
2078	P0222. . . . .	448
	Accelerator Pedal Potentiometer 2 – Below Limit. . . . .	448
2078	P0223. . . . .	449
	Accelerator pedal potentiometer 2 – above limit. . . . .	449
2472	P0230. . . . .	450
	Fuel Pump Relay Output Stage – Open Circuit. . . . .	450
	Fuel Pump Relay Output Stage – Below Limit. . . . .	451
	Fuel Pump Relay Output Stage – Above Limit. . . . .	452
2102	P0234. . . . .	454
	Boost Pressure Characteristic, Upper Value Exceeded - Above Limit. . . . .	454
	Diagnosis/Troubleshooting. . . . .	454
2190	P0237. . . . .	455
	353 Pressure Sensor - Below Limit. . . . .	455
	Diagnosis/Troubleshooting. . . . .	455
2190	P0238. . . . .	456
	353 Pressure Sensor - Above Limit. . . . .	456

	Diagnosis/Troubleshooting. . . . .	457
2440	P0261. . . . .	458
	Fuel Injector, Cylinder 1 – Below Limit. . . . .	458
	Diagnosis/Troubleshooting. . . . .	458
2440	P0262. . . . .	460
	Fuel Injector, Cylinder 1 – Above Limit. . . . .	460
	Diagnosis/Troubleshooting. . . . .	461
2440	P0264. . . . .	462
	Fuel Injector, Cylinder 2 – Below Limit. . . . .	462
	Diagnosis/Troubleshooting. . . . .	462
2440	P0265. . . . .	464
	Fuel Injector, Cylinder 2 – Above Limit. . . . .	464
	Diagnosis/Troubleshooting. . . . .	465
2440	P0267. . . . .	466
	Fuel Injector, Cylinder 3 – Below Limit. . . . .	466
	Diagnosis/Troubleshooting. . . . .	466
2440	P0268. . . . .	468
	Fuel Injector, Cylinder 3 – Above Limit. . . . .	468
	Diagnosis/Troubleshooting. . . . .	469
2440	P0270. . . . .	470
	Fuel Injector, Cylinder 4 – Below Limit. . . . .	470
	Diagnosis/Troubleshooting. . . . .	470
2440	P0271. . . . .	472
	Fuel Injector, Cylinder 4 – Above Limit. . . . .	472
	Diagnosis/Troubleshooting. . . . .	473
2440	P0273. . . . .	474
	Fuel Injector, Cylinder 5 – Below Limit. . . . .	474
	Diagnosis/Troubleshooting. . . . .	474
2440	P0274. . . . .	476
	Fuel Injector, Cylinder 5 – Above Limit. . . . .	476
	Diagnosis/Troubleshooting. . . . .	477
2440	P0276. . . . .	478
	Fuel Injector, Cylinder 6 – Below Limit. . . . .	478
	Diagnosis/Troubleshooting. . . . .	478
2440	P0277. . . . .	480
	Fuel Injector, Cylinder 6 – Above Limit. . . . .	480
	Diagnosis/Troubleshooting. . . . .	481

2470	P0300. . . . .	482
	507 Misfire detection (sum total). . . . .	482
	Diagnosis/Troubleshooting. . . . .	484
2470	P0301. . . . .	494
	508 Misfire, cylinder 1. . . . .	494
	Diagnosis/Troubleshooting. . . . .	496
2470	P0302. . . . .	506
	509 Misfire, cylinder 2. . . . .	506
	Diagnosis/Troubleshooting. . . . .	508
2470	P0303. . . . .	518
	510 Misfire, cylinder 3. . . . .	518
	Diagnosis/Troubleshooting. . . . .	520
2470	P0304. . . . .	530
	511 Misfire, cylinder 4. . . . .	530
	Diagnosis/Troubleshooting. . . . .	532
2470	P0305. . . . .	542
	512 Misfire, cylinder 5. . . . .	542
	Diagnosis/Troubleshooting. . . . .	544
2470	P0306. . . . .	554
	513 Misfire, cylinder 6. . . . .	554
	Diagnosis/Troubleshooting. . . . .	556
2470	P0324. . . . .	566
	Knock Control Zero Test - Signal Implausible. . . . .	566
	Diagnosis/Troubleshooting. . . . .	566
2872	P0327. . . . .	567
	210 Knock sensor 1 - below limit. . . . .	567
	Diagnosis/troubleshooting. . . . .	567
2872	P0328. . . . .	569
	210 Knock sensor 1 - above limit. . . . .	569
	Diagnosis/troubleshooting. . . . .	569
2872	P0332. . . . .	571
	211 Knock sensor 2 - below limit. . . . .	571
	Diagnosis/troubleshooting. . . . .	571
2872	P0333. . . . .	573
	211 Knock sensor 2 - above limit. . . . .	573
	Diagnosis/troubleshooting. . . . .	573
2873	P0335. . . . .	575
	Engine Speed Sensor Signal – Open Circuit. . . . .	575



	Diagnosis/Troubleshooting. . . . .	575
2873	P0336. . . . .	578
	110 Engine Speed Sensor Signal - Open Circuit. . . . .	578
	Diagnosis/troubleshooting. . . . .	578
2873	P0336. . . . .	581
	Crankshaft Position Sensor, Signal Implausible. . . . .	581
	Diagnosis/Troubleshooting. . . . .	581
2839	P0341. . . . .	583
	112 Camshaft position sensor 1 - signal implausible. . . . .	583
2839	P0342. . . . .	586
	112 Camshaft position sensor 1 - below limit. . . . .	586
	Diagnosis/troubleshooting. . . . .	586
2839	P0343. . . . .	587
	112 Camshaft position sensor 1 - above limit. . . . .	587
	Diagnosis/troubleshooting. . . . .	587
2470	P0344. . . . .	588
	Camshaft position sensor 1 - open circuit. . . . .	588
	Diagnosis/troubleshooting. . . . .	588
2839	P0346. . . . .	589
	Camshaft Position Sensor 2 - Signal Implausible. . . . .	589
2839	P0347. . . . .	592
	Camshaft Position Sensor 2 – Below Limit. . . . .	592
	Diagnosis/Troubleshooting. . . . .	592
2839	P0348. . . . .	593
	Camshaft Position Sensor 2 – Above Limit. . . . .	593
	Diagnosis/Troubleshooting. . . . .	593
2470	P0349. . . . .	594
	Camshaft position sensor 2 - open circuit. . . . .	594
	Diagnosis/troubleshooting. . . . .	594
2665	P0410. . . . .	595
	80 Secondary Air Injection System, Bank 1 – Below Limit. . . . .	595
	Diagnosis/troubleshooting. . . . .	595
2644	P0413. . . . .	598
	85 Electric change-over valve - open circuit. . . . .	598
	Diagnosis/troubleshooting. . . . .	599
2644	P0414. . . . .	600
	85 Electric change-over valve - below limit. . . . .	600

---

	85 Electric change-over valve - above limit. . . . .	600
2665	P0418. . . . .	602
	84 Secondary air injection pump - open circuit. . . . .	602
	84 Secondary air injection pump - below limit. . . . .	603
	84 Secondary air injection pump - above limit. . . . .	604
2673	P0420. . . . .	605
	40 TWC conversion, bank 1 - above limit. . . . .	605
	Diagnosis/troubleshooting. . . . .	605
	Perform system test for small lift. . . . .	606
2673	P0430. . . . .	609
	45 TWC Conversion, Bank 2 - Above Limit. . . . .	609
	Diagnosis/troubleshooting. . . . .	609
	Perform system test for small lift. . . . .	610
2023	P0440. . . . .	613
	93 Fuel Tank Ventilation System (DTESK) - Above Limit. . . . .	613
	Diagnosis/troubleshooting. . . . .	613
2023	P0441. . . . .	617
	93 Fuel Tank Ventilation System - Above Limit. . . . .	617
	Diagnosis/troubleshooting. . . . .	617
2023	P0442. . . . .	619
	97 Fuel Tank Ventilation System (Micro-leak) - Below Limit. . . . .	619
	Diagnosis/troubleshooting. . . . .	619
2023	P0444. . . . .	623
	98 EVAP canister purge valve - open circuit. . . . .	623
	Diagnosis/troubleshooting. . . . .	624
2023	P0445. . . . .	625
	98 EVAP canister purge valve - short circuit to B+. . . . .	625
	98 EVAP canister purge valve - short to ground. . . . .	626
2093	P0446. . . . .	628
	EVAP canister shutoff valve (function) - below limit. . . . .	628
	Diagnosis/troubleshooting. . . . .	629
2093	P0447. . . . .	632
	96 EVAP canister shutoff valve (output stage) - open circuit. . . . .	632
	Diagnosis/troubleshooting. . . . .	633
2093	P0448. . . . .	635
	96 EVAP canister shutoff valve (output stage) - over limit. . . . .	635
	96 EVAP canister shutoff valve (output stage) - under limit. . . . .	636
2004	P0450. . . . .	638

---

	99 Tank pressure sensor - signal implausible. . . . .	638
	Diagnosis/troubleshooting. . . . .	638
2023	P0450. . . . .	639
	Fuel Tank Ventilation System (Major Leak) – Signal Implausible. . . . .	639
	Diagnosis/Troubleshooting. . . . .	639
2004	P0451. . . . .	640
	Tank Pressure Sensor – Signal Implausible. . . . .	640
	Diagnosis/Troubleshooting. . . . .	640
2004	P0452. . . . .	641
	99 Tank pressure sensor - below limit. . . . .	641
	Diagnosis/troubleshooting. . . . .	641
2004	P0453. . . . .	642
	99 Tank pressure sensor - above limit. . . . .	642
	Diagnosis/troubleshooting. . . . .	642
2023	P0455. . . . .	643
	94 Fuel Tank Ventilation System (Major Leak) - Below Limit. . . . .	643
	Diagnosis/troubleshooting. . . . .	643
	94 Fuel Tank Ventilation System (Major Leak) - Signal Implausible. . . . .	646
	Diagnosis/troubleshooting. . . . .	647
2023	P0456. . . . .	648
	Fuel Tank Ventilation System (Minor leak) - Below Limit. . . . .	648
	Diagnosis/Troubleshooting. . . . .	648
1908	P0480. . . . .	652
	494 Fan output stage 1 - open circuit. . . . .	652
	494 Fan output stage 1 - below limit. . . . .	653
	494 Fan output stage 1 - above limit. . . . .	655
1908	P0481. . . . .	657
	495 Fan output stage 2 - open circuit. . . . .	657
	495 Fan output stage 2 - below limit. . . . .	658
	495 Fan output stage 2 - above limit. . . . .	660
1908	P0482. . . . .	662
	591 Fan output stage 3 - open circuit. . . . .	662
	591 Fan output stage 3 - below limit. . . . .	663
	591 Fan output stage 3 - above limit. . . . .	665
2665	P0491. . . . .	667
	Secondary Air Injection System, Bank 1 – Below Limit. . . . .	667
	Diagnosis/Troubleshooting. . . . .	667
2665	P0492. . . . .	670

	Secondary Air Injection System, Bank 2 – Below Limit. . . . .	670
	Diagnosis/Troubleshooting. . . . .	670
4515	P0501. . . . .	673
	120 Vehicle speed - open circuit. . . . .	673
	Diagnosis/Troubleshooting. . . . .	673
2442	P0506. . . . .	675
	32 Idle air control at stop - below limit. . . . .	675
	Diagnosis/troubleshooting. . . . .	675
2442	P0507. . . . .	677
	32 Idle air control at stop - above limit. . . . .	677
	Diagnosis/troubleshooting. . . . .	677
9068	P0513. . . . .	679
	Immobilizer – Signal Implausible. . . . .	679
	Diagnosis/Troubleshooting. . . . .	680
	Immobilizer - Open Circuit. . . . .	681
	Diagnosis/Troubleshooting. . . . .	682
2706	P0560. . . . .	684
	107 Voltage supply - signal implausible. . . . .	684
	Diagnosis/troubleshooting. . . . .	684
2706	P0562. . . . .	685
	107 Voltage supply - below limit. . . . .	685
	Diagnosis/troubleshooting. . . . .	685
2706	P0563. . . . .	687
	Voltage supply - above limit. . . . .	687
	Diagnosis/troubleshooting. . . . .	687
9436	P0571. . . . .	688
	Stop Light Switch – Signal Implausible. . . . .	688
	Diagnosis/Troubleshooting. . . . .	689
	P0600. . . . .	690
	236 CAN timeout Tiptronic - open circuit. . . . .	690
	Diagnosis/troubleshooting. . . . .	690
2470	P0601. . . . .	693
	DME relay/control module faulty (computer monitoring: reset) – signal implausible	693
	Diagnosis/troubleshooting. . . . .	693
2470	P0603. . . . .	695
	105 EEPROM Faulty. . . . .	695
	Diagnosis/troubleshooting. . . . .	695
2470	P0604. . . . .	696

	406 Control module faulty (RAM) - signal implausible. . . . .	696
	Diagnosis/troubleshooting. . . . .	696
2470	P0605. . . . .	697
	405 Control module faulty (ROM) - signal implausible. . . . .	697
	Diagnosis/troubleshooting. . . . .	697
2470	P0607. . . . .	698
	Control Module Faulty (Computer Monitoring: Reset) – Signal Implausible. . . . .	698
	Diagnosis/Troubleshooting. . . . .	698
2442	P0638. . . . .	699
	Throttle Jacking Unit, Position Error – Signal Implausible. . . . .	699
	Diagnosis/Troubleshooting. . . . .	700
8728	P0645. . . . .	702
	A/C Compressor Control – Open Circuit. . . . .	702
	Diagnosis/Troubleshooting. . . . .	702
8728	P0646. . . . .	703
	A/C Compressor Control – Below Limit. . . . .	703
	Diagnosis/Troubleshooting. . . . .	703
9025	P0650. . . . .	704
	661 MIL Lamp (via CAN) - Open Circuit. . . . .	704
	Diagnosis/Troubleshooting. . . . .	704
8728	P0674. . . . .	705
	A/C Compressor Control – Above Limit. . . . .	705
	Diagnosis/Troubleshooting. . . . .	705
3478	P0712. . . . .	706
	Transmission Oil Temperature - Below Limit. . . . .	706
	Diagnosis/Troubleshooting. . . . .	707
3478	P0713. . . . .	709
	Transmission Oil Temperature - Above Limit. . . . .	709
	Diagnosis/Troubleshooting. . . . .	710
2780	P0830. . . . .	711
	Clutch Switch – Signal Implausible. . . . .	711
	Diagnosis/Troubleshooting. . . . .	711
2470	P1101. . . . .	713
	(Input variables, charge measurement - below limit). . . . .	713
	Input variables, charge measurement - above limit. . . . .	713
	Diagnosis/troubleshooting. . . . .	713
2470	P1102. . . . .	715
	Ambient Pressure Sensor – Above Limit. . . . .	715

	Diagnosis/Troubleshooting. . . . .	715
2469	P1105. . . . .	716
	Oxygen Sensing Adaptation, Upper Load Range, Bank 1 – Below Limit. . . . .	716
	Diagnosis/Troubleshooting. . . . .	716
2469	P1106. . . . .	718
	Oxygen Sensing Adaptation, Upper Load Range, Bank 2 – Below Limit. . . . .	718
	Diagnosis/Troubleshooting. . . . .	718
2469	P1107. . . . .	720
	Oxygen Sensing Adaptation, Lower Load Range, Bank 1 – Below Limit. . . . .	720
	Diagnosis/Troubleshooting. . . . .	720
2469	P1108. . . . .	722
	Oxygen Sensing Adaptation, Lower Load Range, Bank 2 – Below Limit. . . . .	722
	Diagnosis/Troubleshooting. . . . .	722
2470	P1109. . . . .	724
	Input variables, charge measurement - above limit. . . . .	724
	Diagnosis/troubleshooting. . . . .	724
	P1110. . . . .	725
	294 Oxygen Sensors Exchanged Ahead of TWC. . . . .	725
	Diagnosis/Troubleshooting. . . . .	725
2469	P1114. . . . .	726
	723 Heating LSU, Inertia Fuel Shutoff - Signal Implausible. . . . .	726
	Diagnosis/Troubleshooting. . . . .	726
2469	P1115. . . . .	729
	13 Oxygen Sensor Ahead of TWC, Bank 1 – Signal Implausible. . . . .	729
	Diagnosis/Troubleshooting. . . . .	729
	13 Oxygen Sensor Heating Ahead of TWC, Bank 1 – Open Circuit. . . . .	731
	Diagnosis/Troubleshooting. . . . .	731
	13 Oxygen Sensor Ahead of TWC, Bank 1 – Below Limit. . . . .	732
	Diagnosis/Troubleshooting. . . . .	733
	13 Oxygen Sensor Heating Ahead of TWC, Bank 1 – Above Limit. . . . .	734
	Diagnosis/Troubleshooting. . . . .	734
2469	P1116. . . . .	737
	724 Heating LSU Bank 2, Inertia Fuel Shutoff - Signal Implausible. . . . .	737
	Diagnosis/Troubleshooting. . . . .	737
2473	P1117. . . . .	740
	14 Oxygen Sensor Heating After TWC, Bank 1 – Signal Implausible. . . . .	740
	Diagnosis/Troubleshooting. . . . .	740
2473	P1118. . . . .	742

	4 Oxygen Sensor Heating After TWC, Bank 2 – Signal Implausible. . . . .	742
	Diagnosis/Troubleshooting. . . . .	742
2469	P1119. . . . .	744
	5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Signal Implausible. . . . .	744
	Diagnosis/Troubleshooting. . . . .	744
	5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Open Circuit. . . . .	746
	Diagnosis/Troubleshooting. . . . .	746
	5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Below Limit. . . . .	747
	Diagnosis/Troubleshooting. . . . .	748
	5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Above Limit. . . . .	749
	Diagnosis/Troubleshooting. . . . .	749
2442	P1120. . . . .	752
	Throttle Valve – Signal Implausible. . . . .	752
	Diagnosis/Troubleshooting. . . . .	753
2442	P1121. . . . .	757
	430 Throttle position sensor 1 - signal implausible. . . . .	757
	430 Throttle position sensor 1 - below limit. . . . .	757
	430 Throttle position sensor 1 - above limit. . . . .	757
	Diagnosis/troubleshooting. . . . .	758
2442	P1122. . . . .	762
	431 Throttle position sensor 2 - signal implausible. . . . .	762
	431 Throttle position sensor 2 - below limit. . . . .	762
	431 Throttle position sensor 2 - above limit. . . . .	762
	Diagnosis/troubleshooting. . . . .	763
2472	P1124. . . . .	767
	167 Fuel pump relay output stage - below limit. . . . .	767
	167 Fuel pump relay output stage - above limit. . . . .	768
	167 Fuel pump relay output stage - open circuit. . . . .	769
2469	P1125. . . . .	771
	357 Oxygen Sensing Adaptation, Upper Load Range, Bank 1 - Below Limit. . . . .	771
	Diagnosis/troubleshooting. . . . .	771
	357 Oxygen Sensing Adaptation, Upper Load Range, Bank 1 - Above Limit. . . . .	773
2469	P1126. . . . .	775
	356 Oxygen Sensing Adaptation, Lower Load Range, Bank 1 - Below Limit. . . . .	775
	Diagnosis/troubleshooting. . . . .	775
	356 Oxygen Sensing Adaptation, Lower Load Range, Bank 1 - Above Limit. . . . .	776
	Diagnosis conditions. . . . .	776
	Possible fault cause. . . . .	776

	Affected terminals. . . . .	777
	Diagnosis/troubleshooting. . . . .	777
2469	P1127. . . . .	778
	418 Oxygen Sensing Error by means of Short Test, Bank 1 - Below Limit. . . . .	778
	Diagnosis/troubleshooting. . . . .	778
	418 Oxygen Sensing Error by means of Short Test, Bank 1 - Above Limit. . . . .	779
	Diagnosis conditions. . . . .	779
	Possible fault cause. . . . .	779
	Affected terminals. . . . .	780
	Diagnosis/troubleshooting. . . . .	780
2469	P1128. . . . .	781
	360 Oxygen Sensing Adaptation, Idle Range, Bank 1 - Below Limit. . . . .	781
	Diagnosis/Troubleshooting. . . . .	781
	360 Oxygen Sensing Adaptation, Idle Range, Bank 1 - Above Limit. . . . .	783
2469	P1130. . . . .	785
	361 Oxygen Sensing Adaptation, Idle Range, Bank 2 - Below Limit. . . . .	785
	Diagnosis/Troubleshooting. . . . .	785
	361 Oxygen Sensing Adaptation, Idle Range, Bank 2 - Above Limit. . . . .	787
2469	P1132. . . . .	789
	359 Oxygen Sensing Adaptation, Upper Load Range, Bank 2 - Below Limit. . . . .	789
	Diagnosis/troubleshooting. . . . .	789
	357 Oxygen Sensing Adaptation, Upper Load Range, Bank 1 - Above Limit. . . . .	791
2469	P1133. . . . .	793
	358 Oxygen Sensing Adaptation, Lower Load Range, Bank 2 - Below Limit. . . . .	793
	Diagnosis/troubleshooting. . . . .	793
	358 Oxygen Sensing Adaptation, Lower Load Range, Bank 2 - Above Limit. . . . .	794
	Diagnosis conditions. . . . .	794
	Possible fault cause. . . . .	794
	Affected terminals. . . . .	795
	Diagnosis/troubleshooting. . . . .	795
2469	P1134. . . . .	796
	419 Oxygen Sensing Error by means of Short Test, Bank 2 - Below Limit. . . . .	796
	Diagnosis/troubleshooting. . . . .	796
	419 Oxygen Sensing Error by means of Short Test, Bank 2 - Above Limit. . . . .	797
	Diagnosis conditions. . . . .	797
	Possible fault cause. . . . .	797
	Affected terminals. . . . .	798
	Diagnosis/troubleshooting. . . . .	798



2190	P1136. ....	799
	Pressure sensors signal comparison charge pressure / ambient pressure - signal implausible. ....	799
	Diagnosis/troubleshooting. ....	799
2780	P1137. ....	801
	446 Clutch Switch - Signal Implausible. ....	801
	Diagnosis/Troubleshooting. ....	801
2442	P1138. ....	803
	Throttle Position Sensor 1 – Above Limit. ....	803
	Diagnosis/Troubleshooting. ....	803
2442	P1139. ....	808
	Throttle Position Sensor 1 – Below Limit. ....	808
	Diagnosis/Troubleshooting. ....	808
2442	P1140. ....	813
	Throttle Position Sensor 2 – Above Limit. ....	813
	Diagnosis/Troubleshooting. ....	813
2442	P1141. ....	818
	Throttle Position Sensor 2 – Below Limit. ....	818
	Diagnosis/Troubleshooting. ....	818
2469	P1142. ....	823
	Oxygen Sensing Error by means of Short Test, Bank 1 – Above Limit. ....	823
	Diagnosis conditions. ....	823
	Possible fault cause. ....	823
	Affected terminals. ....	823
	Diagnosis/Troubleshooting. ....	823
2469	P1143. ....	825
	Oxygen Sensing Error by means of Short Test, Bank 2 – Above Limit. ....	825
	Diagnosis conditions. ....	825
	Possible fault cause. ....	825
	Affected terminals. ....	825
	Diagnosis/Troubleshooting. ....	825
2469	P1145. ....	827
	Oxygen Sensor Ahead of TWC, Bank 1 – Above Limit. ....	827
	Diagnosis/Troubleshooting. ....	829
2469	P1146. ....	831
	Oxygen Sensor Ahead of TWC, Bank 1 – Open Circuit. ....	831
	Diagnosis/Troubleshooting. ....	831
2469	P1155. ....	833

	Oxygen Sensor Ahead of TWC, Bank 2 – Above Limit. . . . .	833
	Diagnosis/Troubleshooting. . . . .	835
2469	P1156. . . . .	837
	Oxygen Sensor Ahead of TWC, Bank 2 – Open Circuit. . . . .	837
	Diagnosis/Troubleshooting. . . . .	837
1914	P1157. . . . .	839
	30 Engine Compartment Temperature Sensor - Below Limit. . . . .	839
	Diagnosis/Troubleshooting. . . . .	839
1914	P1158. . . . .	840
	30 Engine Compartment Temperature Sensor - Above Limit. . . . .	840
	Diagnosis/Troubleshooting. . . . .	840
2470	P1159. . . . .	841
	O2 Sensor Circuit. . . . .	841
	Diagnosis/troubleshooting. . . . .	841
2470	P1160. . . . .	842
	O2 Sensor Circuit. . . . .	842
	Diagnosis/troubleshooting. . . . .	842
2440	P1213. . . . .	843
	150 Fuel Injector, Cylinder 1 - Above Limit. . . . .	843
	Diagnosis/troubleshooting. . . . .	844
2440	P1214. . . . .	845
	151 Fuel Injector, Cylinder 6 - Above Limit. . . . .	845
	Diagnosis/troubleshooting. . . . .	846
2440	P1215. . . . .	847
	152 Fuel Injector, Cylinder 2 - Above Limit. . . . .	847
	Diagnosis/troubleshooting. . . . .	848
2440	P1216. . . . .	849
	153 Fuel Injector, Cylinder 4 - Above Limit. . . . .	849
	Diagnosis/troubleshooting. . . . .	850
2440	P1217. . . . .	851
	154 Fuel injector, cylinder 3 - above limit. . . . .	851
	Diagnosis/troubleshooting. . . . .	852
2440	P1218. . . . .	853
	155 Fuel Injector, Cylinder 5 - Above Limit. . . . .	853
	Diagnosis/troubleshooting. . . . .	854
2078	P1219. . . . .	855
	256 Accelerator pedal - signal implausible. . . . .	855
	Diagnosis/troubleshooting. . . . .	855

2440	P1225. . . . .	856
	150 Fuel Injector, Cylinder 1 - Below Limit. . . . .	856
	Diagnosis/troubleshooting. . . . .	856
2440	P1226. . . . .	858
	151 Fuel Injector, Cylinder 6 - Below Limit. . . . .	858
	Diagnosis/troubleshooting. . . . .	858
2440	P1227. . . . .	860
	152 Fuel Injector, Cylinder 2 - Below Limit. . . . .	860
	Diagnosis/Troubleshooting. . . . .	860
2440	P1228. . . . .	862
	153 Fuel Injector, Cylinder 4 - Below Limit. . . . .	862
	Diagnosis/troubleshooting. . . . .	862
2440	P1229. . . . .	864
	154 Fuel injector, cylinder 3 - below limit. . . . .	864
	Diagnosis/troubleshooting. . . . .	864
2440	P1230. . . . .	866
	155 Fuel Injector, Cylinder 5 - Below Limit. . . . .	866
	Diagnosis/troubleshooting. . . . .	866
2440	P1237. . . . .	868
	150 Fuel Injector, Cylinder 1 - Open Circuit. . . . .	868
	Diagnosis/troubleshooting. . . . .	869
2440	P1238. . . . .	870
	151 Fuel Injector, Cylinder 6 - Open Circuit. . . . .	870
	Diagnosis/troubleshooting. . . . .	871
2440	P1239. . . . .	872
	152 Fuel Injector, Cylinder 2 - Open Circuit. . . . .	872
	Diagnosis/troubleshooting. . . . .	873
2440	P1240. . . . .	874
	153 Fuel Injector, Cylinder 4 - Open Circuit. . . . .	874
	Diagnosis/troubleshooting. . . . .	875
2440	P1241. . . . .	876
	154 Fuel injector, cylinder 3 - open circuit. . . . .	876
	Diagnosis/troubleshooting. . . . .	877
2440	P1242. . . . .	878
	155 Fuel Injector, Cylinder 5 - Open Circuit. . . . .	878
	Diagnosis/troubleshooting. . . . .	879
2102	P1249. . . . .	880
	231 Boost Pressure Control Deviation - Above/Below Limit. . . . .	880

	Diagnosis/troubleshooting. . . . .	880
2102	P1250. . . . .	882
	Boost Pressure Control Deviation - Above Limit. . . . .	882
	Diagnosis/Troubleshooting. . . . .	882
2102	P1255. . . . .	883
	230 Boost Pressure Characteristic, Upper Value Exceeded - Above Limit. . . . .	883
	Diagnosis/troubleshooting. . . . .	883
6953	P1265. . . . .	884
	301 Airbag signal - signal implausible. . . . .	884
	Diagnosis/troubleshooting. . . . .	884
2470	P1266. . . . .	886
	409 Fuel shutoff function monitor - signal implausible. . . . .	886
	Diagnosis/troubleshooting. . . . .	886
1536	P1324. . . . .	887
	325 Position of Camshaft in Relation to Crankshaft, Bank 2 – Below Limit. . . . .	887
	Diagnosis/Troubleshooting. . . . .	887
	325 Position of Camshaft in Relation to Crankshaft, Bank 2 – Above Limit. . . . .	887
	Diagnosis/Troubleshooting. . . . .	889
1536	P1325. . . . .	891
	178 Camshaft Adjustment, Bank 2 – Signal Implausible. . . . .	891
	Diagnosis/Troubleshooting. . . . .	892
	178 Camshaft Adjustment, Bank 2 – Below Limit. . . . .	893
	Diagnosis/Troubleshooting. . . . .	894
	178 Camshaft Adjustment, Bank 2 – Above Limit. . . . .	895
	Diagnosis/Troubleshooting. . . . .	896
1536	P1328. . . . .	898
	Inlet camshaft output stage – open circuit. . . . .	898
	Diagnosis/troubleshooting. . . . .	898
1536	P1331. . . . .	900
	Inlet camshaft output stage, bank 2 - open circuit. . . . .	900
	Diagnosis/troubleshooting. . . . .	900
1536	P1340. . . . .	902
	322 Position of Camshaft in Relation to Crankshaft, Bank 1 – Below Limit. . . . .	902
	Diagnosis/Troubleshooting. . . . .	902
	322 Position of Camshaft in Relation to Crankshaft, Bank 1 – Above Limit. . . . .	902
	Diagnosis/Troubleshooting. . . . .	904
1536	P1341. . . . .	906
	174 Camshaft Adjustment, Bank 1 – Signal Implausible. . . . .	906

---

	Diagnosis/Troubleshooting. . . . .	907
	174 Camshaft Adjustment, Bank 1 – Below Limit. . . . .	908
	Diagnosis/Troubleshooting. . . . .	909
	174 Camshaft Adjustment, Bank 1 – Above Limit. . . . .	910
	Diagnosis/Troubleshooting. . . . .	911
1536	P1342. . . . .	913
	189 Camshaft Adjustment, Bank 1 Output Stage - Open Circuit. . . . .	913
	Diagnosis/Troubleshooting. . . . .	913
	189 Camshaft Adjustment, Bank 1 Output Stage - Below Limit. . . . .	914
	Diagnosis/Troubleshooting. . . . .	915
	189 Camshaft Adjustment, Bank 1 Output Stage - Above Limit. . . . .	915
	Diagnosis/Troubleshooting. . . . .	915
1536	P1343. . . . .	916
	149 Camshaft Adjustment, Bank 2 Output Stage - Open Circuit. . . . .	916
	Diagnosis/Troubleshooting. . . . .	916
	149 Camshaft Adjustment, Bank 2 Output Stage - Below Limit. . . . .	917
	Diagnosis/Troubleshooting. . . . .	918
	149 Camshaft Adjustment, Bank 2 Output Stage - Above Limit. . . . .	918
	Diagnosis/Troubleshooting. . . . .	918
3755	P1344. . . . .	919
	579 Valve Lift Control, Bank 1, Output Stage - Open Circuit. . . . .	919
	Diagnosis/Troubleshooting. . . . .	919
	579 Valve Lift Control, Bank 1, Output Stage - Below Limit. . . . .	920
	Diagnosis/Troubleshooting. . . . .	921
	579 Valve Lift Control, Bank 1, Output Stage - Above Limit. . . . .	921
	Diagnosis/Troubleshooting. . . . .	921
3755	P1345. . . . .	922
	580 Valve Lift Control, Bank 2, Output Stage - Open Circuit. . . . .	922
	Diagnosis/Troubleshooting. . . . .	922
	580 Valve Lift Control, Bank 2, Output Stage - Below Limit. . . . .	923
	Diagnosis/Troubleshooting. . . . .	924
	580 Valve Lift Control, Bank 2, Output Stage - Above Limit. . . . .	924
	Diagnosis/Troubleshooting. . . . .	924
1536	P1348. . . . .	925
	Camshaft Adjustment, Bank 1 – Above Limit. . . . .	925
	Diagnosis/Troubleshooting. . . . .	926
1536	P1349. . . . .	928
	Camshaft Adjustment, Bank 1 – Below Limit. . . . .	928

	Diagnosis/Troubleshooting. . . . .	929
1555	P1350. . . . .	931
	637 Valve lift control checksum error - above limit. . . . .	931
	Diagnosis/troubleshooting. . . . .	931
	637 Valve lift control checksum error - below limit. . . . .	933
	Diagnosis/troubleshooting. . . . .	933
	637 Valve lift control checksum error - signal implausible. . . . .	935
	Diagnosis/troubleshooting. . . . .	936
1555	P1350 - 911 Carrera. . . . .	940
	Valve lift control checksum error - signal implausible. . . . .	940
	Diagnosis/troubleshooting. . . . .	940
1555	P1351. . . . .	942
	627 Valve lift control, cylinder 1 - above limit. . . . .	942
	Diagnosis/troubleshooting. . . . .	942
	627 Valve lift control, cylinder 1 - below limit. . . . .	944
	Diagnosis/troubleshooting. . . . .	944
	627 Valve lift control, cylinder 1 - signal implausible. . . . .	946
	Diagnosis/troubleshooting. . . . .	947
1555	P1351 - 911 Carrera. . . . .	952
	Valve lift control, cylinder 1 - below limit. . . . .	952
	Diagnosis/troubleshooting. . . . .	952
1555	P1352. . . . .	953
	628 Valve lift control, cylinder 6 - above limit. . . . .	953
	Diagnosis/troubleshooting. . . . .	953
	628 Valve lift control, cylinder 6 - below limit. . . . .	955
	Diagnosis/troubleshooting. . . . .	955
	628 Valve lift control, cylinder 6 - signal implausible. . . . .	957
	Diagnosis/troubleshooting. . . . .	958
1555	P1352 - 911 Carrera. . . . .	963
	Valve lift control, cylinder 6 - below limit. . . . .	963
	Diagnosis/troubleshooting. . . . .	963
1555	P1353. . . . .	964
	629 Valve lift control, cylinder 2 - above limit. . . . .	964
	Diagnosis/troubleshooting. . . . .	964
	629 Valve lift control, cylinder 2 - below limit. . . . .	966
	Diagnosis/troubleshooting. . . . .	966
	629 Valve lift control, cylinder 2 - signal implausible. . . . .	968
	Diagnosis/troubleshooting. . . . .	969

1555	P1353 - 911 Carrera. . . . .	974
	Valve lift control, cylinder 2 - below limit. . . . .	974
	Diagnosis/troubleshooting. . . . .	974
1555	P1354. . . . .	975
	630 Valve lift control, cylinder 4 - above limit. . . . .	975
	Diagnosis/troubleshooting. . . . .	975
	630 Valve lift control, cylinder 4 - below limit. . . . .	977
	Diagnosis/troubleshooting. . . . .	977
	630 Valve lift control, cylinder 4 - signal implausible. . . . .	979
	Diagnosis/troubleshooting. . . . .	980
1555	P1354 - 911 Carrera. . . . .	985
	Valve lift control, cylinder 4 - below limit. . . . .	985
	Diagnosis/troubleshooting. . . . .	985
1555	P1355. . . . .	986
	631 Valve lift control, cylinder 3 - above limit. . . . .	986
	Diagnosis/troubleshooting. . . . .	986
	631 Valve lift control, cylinder 3 - below limit. . . . .	988
	Diagnosis/troubleshooting. . . . .	988
	631 Valve lift control, cylinder 3 - signal implausible. . . . .	990
	Diagnosis/troubleshooting. . . . .	991
1555	P1355 - 911 Carrera. . . . .	996
	Valve lift control, cylinder 3 - below limit. . . . .	996
	Diagnosis/troubleshooting. . . . .	996
1555	P1356. . . . .	997
	632 Valve lift control, cylinder 5 - above limit. . . . .	997
	Diagnosis/troubleshooting. . . . .	997
	632 Valve lift control, cylinder 5 - below limit. . . . .	999
	Diagnosis/troubleshooting. . . . .	999
	632 Valve lift control, cylinder 5 - signal implausible. . . . .	1001
	Diagnosis/troubleshooting. . . . .	1002
1555	P1356 - 911 Carrera. . . . .	1007
	Valve lift control, cylinder 5 - below limit. . . . .	1007
	Diagnosis/troubleshooting. . . . .	1007
1536	P1357. . . . .	1008
	Camshaft Adjustment, Bank 2– Above Limit. . . . .	1008
	Diagnosis/Troubleshooting. . . . .	1009
1536	P1358. . . . .	1011
	Camshaft Adjustment, Bank 2– Below Limit. . . . .	1011

	Diagnosis/Troubleshooting. . . . .	1012
1555	P1359. . . . .	1014
	Valve Lift Control, Cylinder 1 - Above Limit. . . . .	1014
	Diagnosis/Troubleshooting. . . . .	1014
1555	P1359 - 911 Carrera. . . . .	1017
	Valve lift control, cylinder 1 - above limit. . . . .	1017
	Diagnosis/troubleshooting. . . . .	1017
1555	P1360. . . . .	1019
	Valve Lift Control, Cylinder 6 - Above Limit. . . . .	1019
	Diagnosis/Troubleshooting. . . . .	1019
1555	P1360 - 911 Carrera. . . . .	1022
	Valve lift control, cylinder 6 - above limit. . . . .	1022
	Diagnosis/troubleshooting. . . . .	1022
1555	P1361. . . . .	1024
	Valve Lift Control, Cylinder 2 - Above Limit. . . . .	1024
	Diagnosis/Troubleshooting. . . . .	1024
1555	P1361 - 911 Carrera. . . . .	1027
	Valve lift control, cylinder 2 - above limit. . . . .	1027
	Diagnosis/Troubleshooting. . . . .	1027
1555	P1362. . . . .	1029
	Valve Lift Control, Cylinder 4 - Above Limit. . . . .	1029
	Diagnosis/Troubleshooting. . . . .	1029
1555	P1362 - 911 Carrera. . . . .	1032
	Valve lift control, cylinder 4 - above limit. . . . .	1032
	Diagnosis/troubleshooting. . . . .	1032
1555	P1363. . . . .	1034
	Valve Lift Control, Cylinder 3 - Above Limit. . . . .	1034
	Diagnosis/Troubleshooting. . . . .	1034
1555	P1363 - 911 Carrera. . . . .	1037
	Valve lift control, cylinder 3 - above limit. . . . .	1037
	Diagnosis/troubleshooting. . . . .	1037
1555	P1364. . . . .	1039
	Valve Lift Control, Cylinder 5 - Above Limit. . . . .	1039
	Diagnosis/Troubleshooting. . . . .	1039
1555	P1364 - 911 Carrera. . . . .	1042
	Valve lift control, cylinder 5 - above limit. . . . .	1042
	Diagnosis/troubleshooting. . . . .	1042



1555	P1371. . . . .	1044
	Valve Lift Control Checksum Error - Above Limit. . . . .	1044
	Diagnosis/Troubleshooting. . . . .	1044
1555	P1371 - 911 Carrera. . . . .	1047
	Valve lift control checksum error - above limit. . . . .	1047
	Diagnosis/troubleshooting. . . . .	1047
1555	P1374. . . . .	1049
	Valve Lift Control Checksum Error - Below Limit. . . . .	1049
	Diagnosis/Troubleshooting. . . . .	1049
1555	P1374 - 911 Carrera. . . . .	1052
	Valve lift control checksum error - below limit. . . . .	1052
	Diagnosis/troubleshooting. . . . .	1052
2470	P1384. . . . .	1053
	220 Knock control zero test - signal implausible. . . . .	1053
	Diagnosis/troubleshooting. . . . .	1053
2470	P1385. . . . .	1054
	221 Knock control offset - signal implausible. . . . .	1054
	Diagnosis/troubleshooting. . . . .	1054
2470	P1386. . . . .	1055
	222 Knock control test pulse - signal implausible. . . . .	1055
	Diagnosis/troubleshooting. . . . .	1055
2839	P1397. . . . .	1056
	113 Camshaft position sensor 2 - signal implausible. . . . .	1056
	113 Camshaft position sensor 2 - below limit. . . . .	1059
	Diagnosis/troubleshooting. . . . .	1060
	113 Camshaft position sensor 2 - above limit. . . . .	1060
	Diagnosis/troubleshooting. . . . .	1061
2665	P1411. . . . .	1062
	208 Secondary Air Injection System, Bank 2 – Below Limit. . . . .	1062
	Diagnosis/troubleshooting. . . . .	1062
8728	P1455. . . . .	1065
	170 A/C compressor control - open circuit. . . . .	1065
	Diagnosis/troubleshooting. . . . .	1065
8728	P1456. . . . .	1066
	170 A/C compressor control - above limit. . . . .	1066
	Diagnosis/troubleshooting. . . . .	1066
8728	P1457. . . . .	1067
	170 A/C compressor control - below limit. . . . .	1067

	Diagnosis/troubleshooting. . . . .	1067
2470	P1501. . . . .	1068
	403 Throttle jacking unit, output stage - signal implausible. . . . .	1068
	Diagnosis/troubleshooting. . . . .	1068
2442	P1502. . . . .	1069
	412 Throttle jacking unit, spring test - above limit. . . . .	1069
	Diagnosis/troubleshooting. . . . .	1069
2442	P1503. . . . .	1070
	402 Throttle Jacking Unit, Position Error - Signal Implausible. . . . .	1070
	Diagnosis/Troubleshooting. . . . .	1071
2442	P1504. . . . .	1073
	410 Throttle jacking unit, emergency air position - signal implausible. . . . .	1073
	Diagnosis/troubleshooting. . . . .	1073
2470	P1505. . . . .	1074
	404 Throttle Jacking Unit, Control Range - Open Circuit. . . . .	1074
	404 Throttle Jacking Unit, Control Range - Below Limit. . . . .	1075
	404 Throttle Jacking Unit, Control Range - Above Limit. . . . .	1076
2442	P1506. . . . .	1078
	413 Throttle jacking unit lower mechanical stop - signal implausible. . . . .	1078
	Diagnosis/troubleshooting. . . . .	1078
2470	P1507. . . . .	1079
	411 Throttle jacking unit, gain adjustment - signal implausible. . . . .	1079
	Diagnosis/troubleshooting. . . . .	1079
2470	P1508. . . . .	1080
	408 Torque comparison function monitor - signal implausible. . . . .	1080
	Diagnosis/troubleshooting. . . . .	1080
2470	P1509. . . . .	1081
	429 Torque Limiter. . . . .	1081
	Diagnosis/Troubleshooting. . . . .	1081
2470	P1510. . . . .	1082
	542 Throttle jacking unit - exchange detection without adaptation - signal implausible. . . . .	1082
	Diagnosis/troubleshooting. . . . .	1082
2442	P1511. . . . .	1083
	543 Throttle jacking unit - abortion of test due to negative influence on ambient condition. . . . .	1083
	Diagnosis/troubleshooting. . . . .	1083
9025	P1512. . . . .	1084

	76 Ambient Temperature (via CAN from instrument cluster) - Signal Implausible.	1084
	Diagnosis/Troubleshooting. . . . .	1084
2442	P1513. . . . .	1085
	541 Throttle jacking unit, spring test - above limit/below limit. . . . .	1085
	Diagnosis/troubleshooting. . . . .	1085
2442	P1514. . . . .	1086
	540 Throttle jacking unit lower mechanical stop - signal implausible. . . . .	1086
	Diagnosis/troubleshooting. . . . .	1086
2442	P1515. . . . .	1087
	Throttle Jacking Unit, Spring Test – Above Limit. . . . .	1087
	Diagnosis/Troubleshooting. . . . .	1087
2470	P1516. . . . .	1088
	Throttle Jacking Unit, Control Range - Above Limit. . . . .	1088
2442	P1517. . . . .	1089
	Throttle Jacking Unit, Abortion of Test due to Negative Influence on Ambient Condition - Above Limit. . . . .	1089
	Diagnosis/Troubleshooting. . . . .	1089
2470	P1518. . . . .	1090
	Throttle Jacking Unit, Control Range – Below Limit. . . . .	1090
2193	P1546. . . . .	1091
	171 Charge Pressure Control Valve Output Stage - Above Limit. . . . .	1091
	Diagnosis/Troubleshooting. . . . .	1091
2193	P1547. . . . .	1092
	171 Charge Pressure Control Valve Output Stage - Below Limit. . . . .	1092
	Diagnosis/Troubleshooting. . . . .	1092
2193	P1548. . . . .	1093
	171 Charge Pressure Control Valve Output Stage - Open Circuit. . . . .	1093
	Diagnosis/Troubleshooting. . . . .	1093
9068	P1570. . . . .	1094
	39 Immobilizer - signal implausible. . . . .	1094
	Diagnosis/troubleshooting. . . . .	1095
9068	P1571. . . . .	1097
	39 Immobilizer - open circuit/no signal. . . . .	1097
	Diagnosis/troubleshooting. . . . .	1098
9436	P1574. . . . .	1100
	364 Stop light switch - signal implausible. . . . .	1100
	Diagnosis/troubleshooting. . . . .	1101
2078	P1575. . . . .	1102

	Pedal Sensor Movement - Signal Implausible. . . . .	1102
9025	P1576. . . . .	1103
	662 Cruise Control Standby Lamp via CAN - Open Circuit. . . . .	1103
	Diagnosis/Troubleshooting. . . . .	1103
2078	P1577. . . . .	1104
	427 Accelerator pedal position sensor 1 - signal implausible. . . . .	1104
	427 Accelerator pedal position sensor 1 - below limit. . . . .	1104
	427 Accelerator pedal position sensor 1 - above limit. . . . .	1105
2078	P1578. . . . .	1107
	428 Accelerator pedal position sensor 2 - signal implausible. . . . .	1107
	428 Accelerator pedal position sensor 2 - below limit. . . . .	1107
	428 Accelerator pedal position sensor 2 - above limit. . . . .	1108
2873	P1579. . . . .	1110
	111 Crankshaft Position Sensor Signal Implausible. . . . .	1110
	Diagnosis/Troubleshooting. . . . .	1110
	P1600. . . . .	1112
	216 CAN timeout PSM - open circuit. . . . .	1112
	Diagnosis/troubleshooting. . . . .	1112
	P1601. . . . .	1116
	CAN timeout instrument cluster - signal implausible. . . . .	1116
	660 CAN timeout instrument cluster - open circuit. . . . .	1116
	P1602. . . . .	1120
	CAN Timeout Instrument Cluster - Signal Implausible. . . . .	1120
	Diagnosis/Troubleshooting. . . . .	1120
	P1654. . . . .	1121
	Cooling Water Shutoff Valve - Above Limit. . . . .	1121
	P1655. . . . .	1122
	Cooling Water Shutoff Valve - Below Limit. . . . .	1122
	P1656. . . . .	1124
	575 Coolant shutoff valve - open circuit. . . . .	1124
	575 Coolant shutoff valve - below limit. . . . .	1125
	575 Coolant shutoff valve - above limit. . . . .	1126
2138	P1657. . . . .	1128
	274 Overrun Recirculating Air Valve Output Stage - Open Circuit. . . . .	1128
	Diagnosis/Troubleshooting. . . . .	1128
	274 Overrun Recirculating Air Valve Output Stage - Below Limit. . . . .	1129
	Diagnosis/Troubleshooting. . . . .	1130
	274 Overrun Recirculating Air Valve Output Stage - Above Limit. . . . .	1130

	Diagnosis/Troubleshooting. . . . .	1130
2138	P1658. . . . .	1132
	Overrun Recirculating Air Valve Output Stage - Above Limit. . . . .	1132
	Diagnosis/Troubleshooting. . . . .	1132
2138	P1659. . . . .	1133
	Overrun Recirculating Air Valve Output Stage - Below Limit. . . . .	1133
	Diagnosis/Troubleshooting. . . . .	1133
2470	P1671. . . . .	1134
	DME relay/control module faulty (computer monitoring: reset) – signal implausible	1134
	Diagnosis/troubleshooting. . . . .	1134
1981	P1674. . . . .	1136
	497 Engine compartment purge fan output stage - open circuit. . . . .	1136
	497 Engine compartment purge fan output stage - short circuit to ground. . . . .	1137
	497 Engine compartment purge fan output stage - short circuit to B+. . . . .	1139
1981	P1675. . . . .	1141
	658 Engine Purge Fan Fault - Above Limit. . . . .	1141
	Diagnosis/Troubleshooting. . . . .	1141
1981	P1676. . . . .	1142
	Engine Compartment Purge Fan Output Stage – Above Limit. . . . .	1142
1981	P1677. . . . .	1144
	Engine Compartment Purge Fan Output Stage – Below Limit. . . . .	1144
1536	P2088. . . . .	1146
	Inlet camshaft output stage - below limit. . . . .	1146
	Diagnosis/troubleshooting. . . . .	1146
1536	P2089. . . . .	1147
	Inlet camshaft output stage - above limit. . . . .	1147
	Diagnosis/troubleshooting. . . . .	1147
1536	P2092. . . . .	1148
	Inlet camshaft output stage, bank 2 - below limit. . . . .	1148
	Diagnosis/troubleshooting. . . . .	1148
1536	P2093. . . . .	1149
	Inlet camshaft output stage, bank 2 - above limit. . . . .	1149
	Diagnosis/troubleshooting. . . . .	1149
2469	P2096. . . . .	1150
	Signal Delay Time for Oxygen Sensor Ageing - Above Limit. . . . .	1150
	Diagnosis/Troubleshooting. . . . .	1150
2469	P2097. . . . .	1152

---

	Signal Delay Time for Oxygen Sensor Ageing - Below Limit. . . . .	1152
	Diagnosis/Troubleshooting. . . . .	1152
2469	P2098. . . . .	1154
	Signal Delay Time for Oxygen Sensor Ageing, Bank 2 – Above Limit. . . . .	1154
	Diagnosis/Troubleshooting. . . . .	1154
2469	P2099. . . . .	1156
	Signal Delay Time for Oxygen Sensor Ageing, Bank 2 Below Limit . . . . .	1156
	Diagnosis/Troubleshooting. . . . .	1156
2078	P2135. . . . .	1158
	Accelerator Pedal - Signal Implausible. . . . .	1158
	Diagnosis/Troubleshooting. . . . .	1158

# DME 7.8

## INTRODUCTION

### General

**The target group of this manual is trained automotive workshop personnel who have successfully taken part in Porsche technical training on the systems concerned and possess the necessary theoretical and practical knowledge to be able to carry out work on complex systems.**

**The basic requirement of all DME work is awareness and observance of safety instructions and warnings; these can be found in the "Notes" on the following pages.**



#### Note!

*The following troubleshooting diagnosis is aimed exclusively at left-hand drive vehicles and describes only these vehicle types. In some cases, specified plugs and sockets may be assigned differently in right-hand drive vehicles, which can lead to incorrect interpretations during troubleshooting and to unforeseen accidents. Therefore, no work should be performed on right-hand drive vehicles without the correct wiring diagram and troubleshooting diagnosis description.*

This OBDII Manual DME 7.8 applies to the following vehicles:

- ◆ 911 (996) with turbo engine as of model year 2001
- ◆ 911 (996FL) with aspirated engine as of model year 2002
- ◆ Boxster (9^86FL) with aspirated engine as of model year 2003

The manual describes the diagnosis and troubleshooting for the engine control module installed in Porsche sports cars (OBD = On-Board Diagnosis). Described are the naturally aspirated engine and Turbo OBD II versions (USA), which cover the full scope of diagnosis. This includes the EOBD (European OBD) and RoW (Rest of World) versions, which have been adapted to the respective laws and regulations from the point of view of diagnostics.

The main differences of versions OBD II and EOBD are the tank leak test legally required in den USA and the criteria for fault memory entry and activation of the CHECK ENGINE lamp (hereafter abbreviated CE), which is also designated as MIL (Malfunction Indication Light).

The following functions are guaranteed by the OBD II system:

- ◆ Detection of misfires

- ◆ Monitoring of catalytic converter efficiency
- ◆ Monitoring of tank ventilation system
- ◆ Monitoring of tank system for leaks
- ◆ Monitoring of secondary air injection
- ◆ Monitoring of adaptation limits (e.g. of oxygen sensor closed-loop control, boost pressure control)
- ◆ Monitoring of oxygen sensors
- ◆ Monitoring of thermostat and water temperature sensor
- ◆ Monitoring of positive crankcase ventilation (via oxygen control adaptation)
- ◆ Monitoring of Tiptronic transmission control unit
- ◆ Monitoring of emission-relevant sensors and actuators used in conjunction with DME (earlier OBD 1 scope)
- ◆ Activation of Check Engine lamp and fault storage
- ◆ Display of inspection readiness (readiness codes)
- ◆ Output of fault codes present
- ◆ Storage of defined operating parameters in the event of a fault (incl. freeze frame)
- ◆ Functional tests of OBD system (warm-up cycle, driving cycle)
- ◆ Communication with a standardised control module tester (scan tool) in the specified modes (see chapter "Fault output using a scan tool")
- ◆ Standardised output of operating data such as engine speed, temperature etc.

The digital engine control module DME 7.8

The DME 7.8 is a proven and highly reliable engine control module, which has been specially adapted to Porsche requirements.

In the event of an open circuit in the voltage supply 'terminal 30', the following values are deleted from the control module:

- ◆ All fault memory entries
- ◆ Stored freeze frames of the faults (for environmental conditions, see the next chapter)
- ◆ All adaptation values
- ◆ The learned values of the throttle adjustment unit
- ◆ Ready statuses of individual diagnosis routines (see next chapter)

Please note that programming the DME control module (e.g. reading in a new data record) also deletes the values referred to above.



### Note on adaptation

The DME control module must perform a learning and adaptation routine for the throttle adjustment unit if:

- ◆ The power supply to the DME control module is interrupted
- ◆ The DME control module plugs are disconnected
- ◆ A new DME control module is installed
- ◆ The throttle adjustment unit is replaced
- ◆ The DME is programmed.

To do this:

1. Switch the ignition on for 1 minute without starting the engine.  
Do not actuate the accelerator pedal (for instance, make sure that there is not a carpet pressing on the pedal).
2. Switch off ignition for at least 10 seconds.

The following conditions must also be observed, otherwise learning is not possible:

- ◆ Vehicle is stationary
- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Engine temperature between 5 °C and 100 °C
- ◆ Intake air temperature between 10 °C and 100 °C

Standard fault codes in accordance with ISO 15031

Diagnostic fault codes, which can be issued by the control module, are standardised in accordance with ISO 15031. This ISO standard is based on SAE J 2012.

The fault code (DTC = Diagnostic Trouble Code) is always a 5-character alphanumeric value, e.g. "P0100".

The first character of the code (a letter) identifies the system that set the code. In all, there are four system types:

- ◆ P for Powertrain (all OBD2 fault codes begin with this)
- ◆ C for Chassis
- ◆ B for Body
- ◆ U for future systems.

The P codes for powertrain are divided into two main categories in accordance with ISO 15031:

- ◆ Uniformly standardised codes: P0XXX and P2XXX; these are the same for all manufacturers
- ◆ Manufacturer codes: P1XXX and P3XXX; only the first three characters are standardised here (example: P13XX for ignition system diagnosis or misfire detection); the last two digits can be selected freely by the manufacturer.

Only the P codes are required for OBD II.

The standardised codes are subdivided as follows:

P0001 to P0299	Fuel and air proportioning
P03xx	Ignition system and misfire detection
P04xx	Additional exhaust regulations
P05xx	Speed and idle speed control
P06xx	Computer and output signals
P0700 to P0999	Transmission
P2000 to P2299	Fuel and air proportioning
P23XX	Ignition system and misfire detection
P24XX	Additional exhaust regulations
P25XX	Additional input signals
P26XX	Computer and output signals
P27XX	Transmission
P28XX	Reserved
P29XX	Fuel and air proportioning

## Definition of terms

### Warm-up cycle

Warm-up cycle means the warm-up phase of the engine. To satisfy the 'warm-up cycle' condition, the engine temperature must not exceed a certain value during starting (presently 44 °C). The operating phase of the engine must last long enough to achieve a certain temperature increase (presently 21 °K, although the temperature reached must be at least 54°C). The warm-up cycle condition is required in order to decrement the deletion counter for faults that are registered as "remedied" (on this see the paragraph 'Remedying faults').

## Driving cycle

A driving cycle consists of the engine start, an arbitrary journey (with idling, part load, constant-speed driving and trailing throttle phase components) and the time after switching off the engine until a new start. For faults to be frozen/remedied, the driving cycle must also partly include the procedure of the respective diagnosis.

## Ready status

The menu item "Ready status" displays whether the required fault checks of the OBD system have been performed since the last 'Clear fault memory' or 'Reset'. If a check is OK, testing for a Ready status once is sufficient; if the system is faulty, the Ready status is reached after testing twice.

The Ready status is important for example when testing the exhaust; it detects if the fault memory has been cleared before testing a faulty vehicle without remedying the cause(s) for the fault entry.

The Ready status is displayed for the following subsystems:

- ◆ Catalytic conversion
- ◆ Tank ventilation system
- ◆ Secondary air system
- ◆ Oxygen sensor
- ◆ Oxygen sensor heating

Once a subsystem has attained the Ready status, this is maintained until the next 'Clear fault memory'.



### Note!

- ◆ *In some countries (currently USA, Canada), after intervention on the DME, it is necessary to reset the Ready status before delivering the vehicle to the customer.*
- ◆ *To do this, perform the short tests recommended in the 9588 Porsche System Tester II or a test drive to obtain the relevant diagnostic conditions (these can be found for each system at the beginning of the instructions for finding P codes in this manual).*
- ◆ *Please refer any questions on this to your importer.*

Freeze frames ('frozen fault boundary conditions' specified by the authorities)

Freeze frame data is standardised and records operating conditions in the event of a (first) fault. Freeze frames have different priorities.

This may be important in the case of output to a scan tool, as there may be only one freeze frame that can be displayed, although several faults are stored (misfires or fuel supply faults override the freeze frames of other faults).

Freeze frames can, for example, be examined in the "extended fault memory" of the 9588 Porsche System Tester II.

The control module must be able to output the following freeze frame data to a standard diagnostic unit (scan tool):

- ◆ Fault codes causing this freeze frame to be stored
- ◆ Engine load
- ◆ Engine speed
- ◆ Coolant temperature
- ◆ Oxygen control status (open or closed loop)
- ◆ Mixture adaptation values
- ◆ Fuel pressure (if available - not the case for DME 7.8)
- ◆ Intake pipe pressure (if available - in the case of DME 7.8 for turbo vehicles only)
- ◆ Vehicle speed

In the case of DME 7.8, a freeze frame is stored for each initial occurrence of a fault that contains all the actual values referred to above with the exception of fuel pressure. See also the next section.

#### Further environmental conditions

In addition with DME 7.8, for every occurrence of a fault, three further operating conditions (actual values at time of fault occurrence) as well as operating hours and total mileage since model year 2002 are also stored. There is a memory entry for the first occurrence of the fault (remains stored) and a further entry for each last occurrence of the fault (updated for each new occurrence). This data can provide reference points to the cause of the fault in difficult diagnoses and can only be viewed in the "extended fault memory" of the 9588 Porsche System Tester II. The list of possible environmental conditions partly covers more than one freeze frame so that important environmental conditions can also be stored after the first fault occurrence.

#### Fault persistence (confirmation of a suspected fault)

When a fault occurs for the first time during a diagnostic routine, it is stored as a suspected fault. At the same time a fault persistence counter is started with a certain value (e.g. 2). In the course of fur-

ther diagnostic operations, if the fault is present in the same range window the counter is decremented by 1. If the persistence counter has the value 0, the fault is assessed as persistent and registered accordingly. If provided for by the fault category, the CE lamp is also activated.

#### Remedying faults (CE lamp OUT)

When a fault occurs for the first time during a diagnostic routine, it is stored as a suspected fault. In the subsequent driving cycle, the suspicion is either confirmed (fault recurs) or cancelled (fault does not recur, no indication on a scan tool). If the fault activates the CE lamp, a fault correction counter is started at the same time with a certain value (e.g. 5). In the course of further diagnostic routines, if the fault is not present in the same range window the correction counter is decremented by 1. If the correction counter has the value 0, the fault is assessed as remedied. If the fault activated the Check Engine warning light, this will be switched off if not prevented by any further fault. The fault remains in the fault memory for the time being and is only deleted after a number of further warm-up cycles (defined in the fault deletion counter) (workshop assistance if for example the tank cap is temporarily not correctly screwed in).

#### Fault deletion counter

A separate deletion counter is run for every fault detected. It contains the specified number of GO checks until deletion of the corresponding fault from the fault memory.

When a fault is first detected, the deletion counter is, for example, set to 80 (suspected fault).

If a non-persistent fault is detected as remedied, the deletion counter (only visible for the PST2) is set to 10 (workshop assistance if fault very sporadic).

Whenever a persistent fault is detected (= CE lamp ON), the deletion counter is set to 40, for example. This value is retained until the fault is detected as having been remedied.

The deletion counter is decremented by 1 after every warm-up cycle if the fault is non-persistent fault or detected as remedied. Confirmed faults not detected as remedied are not decremented in the deletion counter. If the deletion counter reaches the value 0, the fault is deleted from the memory.

#### Fault frequency counter

This counter shows how often a fault has recurred since its first occurrence. If the frequency value is 1, the fault has only occurred

once. It can now be either "present" or "not present". Every time the fault status changes from "not present" to "present", the number in the frequency counter is increased by 1. A rather high value in the fault frequency counter may therefore indicate a loose contact. It should be noted that the environmental conditions apply only to the first and the last occurrence of each fault.

## Warning notes

### Warning notes

#### **Danger!**

- ◆ ***Danger of accident when operating test and diagnostic equipment (PST2, scan tool etc.) while the vehicle is in motion !***
- ***While the vehicle is in motion always get a second person to operate test and diagnostic equipment***
- ***This also applies to the "smaller valve lift" system check for the 'VarioCam Plus' adjustment***
- ***Many tests or system checks can impair the drivability of the vehicle, so only perform these in areas closed to road traffic!***

#### **Danger!**

- ◆ ***Gasoline is toxic!***
- ***Inhaling vapours can lead to irritation of the mucous membranes and eyes***
- ***It represents a serious risk to health when inhaled, touched or swallowed over longer periods***
- ***Wear a breathing mask with active charcoal filter; do not breathe in any fuel vapours***
- ***Wear protective gloves that are fuel-resistant***
- ***Only work on the fuel system in well-ventilated spaces***
- ***Before opening the fuel lines or fuel hoses, relieve the fuel pressure***

- **Collect escaping fuel, absorb it if necessary with a suitable binding material and dispose of properly (special-category waste!)**
- **Pay attention to cleanliness when working on the fuel system**

 **Danger!**

- ◆ **Danger of fire and explosion when handling gasoline**
- **Keep clear of ignition sources**
- **Do not smoke**
- **Danger of fire due to naked flame and flying sparks, e.g. during welding or grinding work**
- **Danger of fire due to escaping fuel (e.g. on hot engine components) and/or electrostatic charge**
- **Make the vehicle safe, e.g. with a warning sign**
- **Change any clothing soaked with fuel immediately**
- **In case of fire, use CO<sub>2</sub> or dry powder fire extinguishers**

 **Warning!**

- ◆ **Risk of injury due to hot and/or rotating parts!**
- ◆ **Never work on the engine when it is running or hot or on a hot exhaust system!**
- ◆ **Danger of injury due to rotating fan! Fans can suddenly start if the air conditioning system is switched on or the engine compartment is hot. Never work in this area if the engine is running.**

 **Caution!**

**Danger of damage due to improper handling of batteries and control module plug connections!**

- ◆ **Never disconnect battery with engine running.**
- ◆ **Never start engine if battery terminal clamps are not connected securely.**
- ◆ **Never pull off or push on plug connections for the control modules or other electronic components when the ignition is switched on.**
- ◆ **Observe the warnings in the body manual before carrying out welding on vehicles.**

Notes on troubleshooting

Working on the oxygen sensors



**Note!**


*Oxygen sensors used with the DME 7.8*

Component		Use	
Oxygen sensor	Number of pins	Before catalytic converter	After catalytic converter
LSU Wide band sensor	6	all models with turbo engine	/
LSF Jump sensor	4	all models with aspirated engine	all models

The LSU (Lambda sensor Universal) is able to determine the lambda value in a wide range window

The LSF (Lambda sensor Flat) is only able to determine lambdas greater or less than 1 (the rich/lean jump)

**Arrangement of oxygen sensors for 996 Turbo**





### Arrangement of oxygen sensors for 996 aspirated engine


- 1 - Oxygen sensor in front of catalytic converter
- 2 - Oxygen sensor after catalytic converter

**i Note!**

Do not interchange oxygen sensors before and after the catalytic converter, otherwise implausible error entries will arise. This information refers to the possibility of installing a sensor before the cat in the installation position of a sensor after the cat in the exhaust line. The plugs themselves are coded and cannot be interchanged.

**i Note!**

Do not use contact spray on the plug connections of the oxygen sensor, otherwise irreparable damage will be caused to the lines (contamination of the oxygen sensor via the reference air duct).



### Troubleshooting procedure

Troubleshooting can only be performed when the fault is present. In other words, specific troubleshooting can only be performed in accordance with instructions (given under Diagnosis/troubleshooting for each fault code) if the entry has the status 'present' in the fault memory.

If the fault is currently 'not present', please check the following:

- Is the fault correction counter and perhaps the deletion counter decremented? This would provide information on a remedied fault (however achieved)
- Is the fault an old one? Read out the extended fault memory (operating time and mileage at last fault entry)
- Are the diagnostic conditions satisfied? If necessary, perform a short test or test drive
- Are officially approved plug connections and ground points of the affected current path OK?
- Set all wiring harnesses of the affected current path to a state that corresponds to driving by pulling and shaking them (loose contact)
- Condition/gas tightness of catalytic converter
- For the tank system: Condition/gas tightness of hoses and the tank cap, if applicable

## Diagnostic conditions

**Note!**

*Important! All unnecessary electrical loads must be switched off before the diagnosis. When working on the vehicle with the ignition switched on for fairly long periods (above approx. 15 minutes), a suitable battery charging unit must be connected.*

**Note!**

*The control module can only detect the fault if the requirements listed under 'Diagnostic conditions' are met. For this reason, the specified procedure must be observed after a fault is repaired:*

1. Clear the fault memory after printing out or saving
2. Satisfy the requirements listed under 'Diagnostic conditions' or perform a short test with the 9588 Porsche System Tester II. It should be noted here that, owing to reset adaptation values (in particular for fuel supply and misfire detection), fault detection by the DME control module is only possible after a fairly long driving time. It may be necessary to observe the relevant adaptation values ("actual values") during a subsequent test drive to be able to identify any trend
3. Read out fault memory again.

## Possible causes of fault

**Note!**

*The 'possible causes of fault' that are responsible for the fault are listed here. Please note that in certain circumstances further faults may be stored in the fault memory after troubleshooting (e.g. if plugs are disconnected). After repairs, read out the fault memory of all control units and delete the faults appearing as a result of the troubleshooting and repairs.*

## DME faults



### Note!

- ◆ A faulty control module is extremely rare! Although in theory almost any fault can also be caused by a faulty control module, it has been shown in the past that, particularly in the case of DME control modules, even control modules sent in for checking were OK.
- ◆ At this point we again stress that before exchanging a DME control module (the final logical step at the end of unsuccessful troubleshooting), all other possible fault causes must be rigorously checked; if necessary, delete the fault entry and perform a test drive or short test.
- ◆ If other faults are entered, then remedy these first as instructed (An example: a fault in adjusting the inlet camshaft may under certain circumstances also lead to an oxygen sensor fault being output).
- ◆ Fault entries solely in connection with the troubleshooting, repair or programming of control units (e.g. CAN timeout faults) should be deleted.

## Diagnosis/troubleshooting



### Note!

The fault memory Info key (F8) on 9588 Porsche System Tester II can be used to access the 'extended fault memory'. Besides the freeze frames and environmental conditions, this also includes information on the fault type

## Fault type

The following fault types are possible for the DME


- ◆ Above upper limit (Max)
- ◆ Below lower limit (Min)
- ◆ No signal/no communication (Sig)
- ◆ Signal implausible (Plaus)

Several fault types may be stored at the same time.

## Fault status

The following status types are possible:

- ◆ present
- ◆ not present

This information should be saved using the Save key  and printed out.

**Note!**

- ◆ *Faults "not present": Where faults are entered but not actually present, after obtaining or adjusting the diagnostic conditions, wiring positions connected to moving parts on and in the vehicle must be checked systematically. Various statuses that can cause a fault to occur must be simulated with the aid of the wiring diagram. It should be noted that the 9588 Porsche System Tester II shows the current fault status only conditionally. The fault frequency counter gives information on operating time and mileage at last fault occurrence*
- ◆ *In difficult cases where faults are currently not present, it is recommended to clear the fault memory (after printing out) and to observe whether the fault is re-entered whilst simulating a loose contact.*

**Note!**

- ◆ *Visual inspection of plug connections: As part of troubleshooting, it must be ensured that the pins of affected plug connections, both on the wiring side and component side, are neither damaged nor corroded. Furthermore, the wiring and plugs must be checked for external damage (cracks, etc.) and proper contact (pins not bent, spread or pushed into the housing). Repair damaged or corroded pins if possible, otherwise replace them. Repair or replace damaged wires. If wiring to the oxygen sensors is damaged, always replace the complete sensor.*
- ◆ *Visual inspection of components: As part of troubleshooting, it must be ensured that there are no signs of visible damage (e.g. cracks, deformation or chafed areas) on the affected components and wiring harnesses. This is particularly important for components that cannot be tested with a multimeter, e.g. bar ignition modules, or components that can cause sporadic faults due to penetrating moisture.*

**Note!**

*Battery voltage and signals: A battery voltage of between 11.4 and 14.5 V is generally required for diagnosis/troubleshooting. This must be checked and, if necessary, guaranteed by means of a battery charging unit.*

**Note!**

*Specified resistance values are based on an ambient temperature of 20°C unless otherwise stated.*

End of troubleshooting (→ End)

→ End marks the end of the described diagnosis/troubleshooting in the troubleshooting tables. The procedure for repair can be taken from the relevant workshop manual for the particular repair group. After successful repair, the fault memory of the DME control module must be cleared and, if necessary, adaptation of the throttle adjustment unit performed, followed by a short test or test drive to achieve the diagnostic conditions for the particular fault. Afterwards the fault memory must be read out again. Depending on the country, Ready statuses must be generated.



## DME 7.8

### Data Output with the Porsche System Tester 2

DME

Main Menu



#### Note!

*Online help can be called up with the F1 key.*

- ◆ Identification
- ◆ Fault Memory
- ◆ Erase Fault Memory
- ◆ Actual Values
- ◆ Input Signals
- ◆ Ready Status
- ◆ Drive Links
- ◆ Drive Link Active
- ◆ Vehicle Data
- ◆ System Test
- ◆ Short Test
- ◆ Coding
- ◆ Control Module Programming

Identification

Control module identification data can be read out with this menu item.

The display shows:

- ◆ Diagnosis software number
- ◆ Porsche part number

Press F8 key.

The display shows:

- ◆ 1. block - vehicle identification number
- ◆ 2. block - control modules hardware number
- ◆ 3. block - control modules hardware version number
- ◆ 4. block - control modules software number
- ◆ 5. block - control modules software version number

- ◆ 6. block - control modules data version number
- ◆ 7. block - control modules ROM version number
- ◆ 8. block - control modules hardware number, unprogrammed

### Fault Memory

The number of faults, the fault texts and the Porsche Diagnostic Trouble Code (DTC) are displayed in the Fault Memory menu item. In order to obtain additional information about a fault, select the fault item (reverse-video display) and press the double arrow key (>>) or the F8 key.

The following additional information on the fault is then displayed:

- ◆ Static or sporadic
- ◆ Present or not present
- ◆ Check Engine warning light switched on or off
- ◆ Fault type (e.g. above or below limit value). If several fault types occur (e.g. short to B+ or short to ground), then 1st state will display the fault type which was present first. The fault type which last occurred is stored under Last state.
- ◆ Frequency (how often did the fault occur)
- ◆ Fault erasing counter
- ◆ Fault time
- ◆ Which conditions must be fulfilled and how often, in order to switch the Check Engine warning light on or off
- ◆ 4 ambient conditions (e.g. ambient pressure, intake air temperature, engine temperature and operating hours counter)
- ◆ OBD fault code
- ◆ Freeze frame data
- ◆ Fault entry made by (e.g. own diagnosis or Tester)

### Erase Fault Memory



#### Note!

*The fault memory can be erased only if it has first been read out at least once. The entire fault memory is always erased. When the fault memory is erased, the adaptation values are also reset.*

### Actual Values

Values present at the moment of the test can be read out with this menu item.



It is possible to use a filter function to select certain actual values only. In this case, not all actual values are available for selection.

Press F5 key.

The following predetermined filters then appear:

- ◆ Engine values
- ◆ Oxygen sensing, bank 1
- ◆ Oxygen sensing, bank 2
- ◆ OBD II
- ◆ Misfire detection
- ◆ Knock control
- ◆ Throttle adjusting unit
- ◆ Analog/digital converter
- ◆ Charge pressure control

It is now possible to create your own filters in this menu item.

Press F5 key.

Mark the required actual values and press the double arrow key (>>). A field then appears where the name of the filter can be entered.

Enter the filter name and confirm.

The newly created filter then appears in the selection list in block capitals. Filters you have created can be deleted or changed.

The following values can be called up:

- ◆ Engine speed
- ◆ Engine load
- ◆ Actual engine torque
- ◆ Ambient pressure
- ◆ Mass air flow (HFM) [mass air flow without tank ventilation]
- ◆ Correction factor, height
- ◆ Power supply
- ◆ Intake air temperature
- ◆ Engine temperature
- ◆ Engine compartment temperature
- ◆ Oil temperature
- ◆ Exhaust temperature after TWC (three-way catalytic converter) [value calculated by ECM]
- ◆ Ignition angle

- ◆ Specified rpm
- ◆ Idle loss adaptation
- ◆ Injection time
- ◆ Camshaft position 1 deviation [adapted value - deviation from the required position]
- ◆ Camshaft position 2 deviation [adapted value - deviation from the required position]
- ◆ Actual angle for camshaft, bank 1 [the function of the VarioCam can be checked with the actual angle. VarioCam not activated - display approx. 0° crk; VarioCam activated - display approx. 30° crk]
- ◆ Actual angle for camshaft, bank 2 [the function of the VarioCam can be checked with the actual angle. VarioCam not activated - display approx. 0° crk; VarioCam activated - display approx. 30° crk]
- ◆ Mass air flow [mass air flow with tank ventilation]
- ◆ Loading of activated carbon filter [value range 0 to 30⇒ 0 - activated carbon filter empty 30 - activated carbon filter saturated]
- ◆ Outside temperature
- ◆ Oxygen sensing, bank 1
- ◆ Adaptation, range 1 (FRA) bank 2 [lower and upper load range - displays the value currently travelled]
- ◆ Adaptation, range 1 (RKAT) bank 1 [range close to idling]
- ◆ Fuel quantity, tank ventilation, bank 1 [deviation from the anticipatory control due to fuel tank ventilation]
- ◆ Resistance of oxygen sensor after catalytic converter, bank 1 [the resistance must amount to approx. 100 Ω after 3 to 4 minutes of travel. As the incrementation stands at 64 Ω (value increase 64 Ω), the Tester displays 64 or 128 Ω. However, if the display is in the kΩ-range (more than 1000 Ω), the heating of the oxygen sensor is faulty.]
- ◆ Oxygen sensor voltage after catalytic converter, bank 1
- ◆ Corrected sensor voltage ahead of catalytic converter, bank 1
- ◆ Oxygen sensing, bank 1
- ◆ Oxygen sensing delay, bank 1
- ◆ Oxygen required value, bank 1
- ◆ Sensor voltage ahead of catalytic converter, bank 1
- ◆ Dynamic value of the oxygen sensor, bank 1
- ◆ Number of dynamic measurements LSU, bank 1
- ◆ Oxygen sensing, bank 2

- ◆ Adaptation, range 2 (FRA) bank 2 [lower and upper load range - displays the value currently travelled]
- ◆ Adaptation, range 1 (RKAT) bank 2 [range close to idling]
- ◆ Fuel quantity, tank ventilation, bank 2 [deviation from the anticipatory control due to fuel tank ventilation]
- ◆ Resistance of oxygen sensor after catalytic converter, bank 2 [the resistance must amount to approx. 100  $\Omega$  after 3 to 4 minutes of travel. As the incrementation stands at 64  $\Omega$  (value increase 64  $\Omega$ ), the Tester displays 64 or 128  $\Omega$ . However, if the display is in the k $\Omega$ -range (more than 1000  $\Omega$ ), the heating of the oxygen sensor is faulty.]
- ◆ Oxygen sensor voltage after catalytic converter, bank 2
- ◆ Corrected sensor voltage ahead of catalytic converter, bank 2
- ◆ Oxygen sensing, bank 2
- ◆ Oxygen sensing delay, bank 2
- ◆ Oxygen required value, bank 2
- ◆ Sensor voltage ahead of catalytic converter, bank 2
- ◆ Dynamic value of the oxygen sensor, bank 2
- ◆ Number of dynamic measurements LSU, bank 2
- ◆ Charge pressure of sensor
- ◆ Required air content
- ◆ Required charge pressure
- ◆ Charge pressure control deviation
- ◆ Pulse/duty ratio, charge pressure control
- ◆ Charge pressure adaptation, range 0
- ◆ Charge pressure adaptation, range 1
- ◆ Charge pressure adaptation, range 2
- ◆ Charge pressure adaptation, range 3
- ◆ Charge pressure adaptation, range 4
- ◆ Correction factor LDR through charged air temperature
- ◆ Correction factor LDR through knock control
- ◆ Charge pressure limitation in case of failure of coolant system
- ◆ Charge pressure limitation in case of extreme exhaust temperatures
- ◆ Tank pressure difference
- ◆ Leakage volumetric flow
- ◆ Control deviation, tank diagnosis
- ◆ Mean amplitude after catalytic converter, bank 1


- ◆ Catalytic converter monitoring time, bank 1 [cumulated time in which the rpm/load range was reached for testing the catalytic converter]
- ◆ Mean amplitude after catalytic converter, bank 2
- ◆ Catalytic converter monitoring time, bank 2 [cumulated time in which the rpm/load range was reached for testing the catalytic converter]
- ◆ Period counter, bank 1 [monitoring of oxygen sensor aging - 16 periods are necessary for the OK measurement]
- ◆ Period counter, bank 2 [monitoring of oxygen sensor aging - 16 periods are necessary for the OK measurement]
- ◆ Distance since power failure
- ◆ Distance with Check Engine on
- ◆ Rough running reference [limit value for rough running, cylinders 1 to 6]
- ◆ State: adaptation 1 [the adaptation is reset to 0 after the battery has been disconnected. In order to carry out adaptation, the vehicle must be driven in overrun between 3.500 rpm and 1.800 rpm. 4 rpm ranges are displayed per load range (the fourth rpm range is not used). The ranges are bit coded and are given as a decimal number.

**Figure 1**

- 1 - r1 - Load
- 2 - n - Speed
- 3 - e.g. -2/1 means the second rpm range (field 2) of load range 1

1 = Field 1 has been adapted
2 = Field 2 has been adapted
3 = Fields 1 and 2 have been adapted
4 = Field 3 has been adapted
5 = Fields 1 and 3 have been adapted
6 = Fields 2 and 3 have been adapted
7 = Fields 1, 2 and 3 have been adapted

The fields have different priorities



**Figure 2**



- 1 - Priority I - Field 1/1
- 2 - Priority II - Fields 1/2, 2/2 and 3/2
- 3 - Priority III - Fields 2/1, 2/3, 3/1 and 3/3

Fields following one another can be adapted within one rpm range if the fields with priority I and II have already been completely adapted, e.g. field 1/2 can be adapted after field 1/1. Field 1/3 is blocked.

- ◆ Status, adaptation 2 [range under positive load between approx. 40 % and approx. 60 %. See status, adaptation 1]
- ◆ Status, adaptation 3 [range under positive load between 60 % and approx. 95 %. See status, adaptation 1]
- ◆ Misfire counter, cylinder 1 [fault counter for exhaust-related faults. Counts the number of misfires.]
- ◆ Misfire counter, cylinder 6 [fault counter for exhaust-related faults. Counts the number of misfires.]
- ◆ Misfire counter, cylinder 2 [fault counter for exhaust-related faults. Counts the number of misfires.]
- ◆ Misfire counter, cylinder 4 [fault counter for exhaust-related faults. Counts the number of misfires.]
- ◆ Misfire counter, cylinder 3 [fault counter for exhaust-related faults. Counts the number of misfires.]
- ◆ Misfire counter, cylinder 5 [fault counter for exhaust-related faults. Counts the number of misfires.]
- ◆ Ignition counter, diagnosis [interval counter of exhaust-related faults - counts the ignitions if the diagnosis is active. Remains still when misfire detection is disabled. Counts from 0 to 3000.]

**Figure 3**

- 1 - A - Load
  - 2 - B - Rpm
  - 3 - C - Operating status (rpm/load range) with misfire
  - 4 - 1 - Minimum speed of range with misfire operation, e.g. 3000 rpm
  - 5 - 2 - Maximum speed of the range with misfire operation, e.g. 4000 rpm
  - 6 - 3 - Minimum load of the range with misfire operation, e.g. 20 %
  - 7 - 4 - Maximum load of the range with misfire operation, e.g. 50 %
- ◆ Range of misfires, minimum speed [see Figure 3.]



- ◆ Range of misfires, maximum speed [see Figure 3.]
- ◆ Range of misfires, minimum load [see Figure 3.]
- ◆ Range of misfires, maximum load [see Figure 3.]
- ◆ Rough running, cylinder 1
- ◆ Rough running, cylinder 6
- ◆ Rough running, cylinder 2
- ◆ Rough running, cylinder 4
- ◆ Rough running, cylinder 3
- ◆ Rough running, cylinder 5
- ◆ Cylinder 1 retardation [ignition angle retarded due to knocking combustion. Retardation in steps from 0.75° to a maximum of 15°]
- ◆ Cylinder 6 retardation [ignition angle retarded due to knocking combustion. Retardation in steps from 0.75° to a maximum of 15°]
- ◆ Cylinder 2 retardation [ignition angle retarded due to knocking combustion. Retardation in steps from 0.75° to a maximum of 15°]
- ◆ Cylinder 4 retardation [ignition angle retarded due to knocking combustion. Retardation in steps from 0.75° to a maximum of 15°]
- ◆ Cylinder 3 retardation [ignition angle retarded due to knocking combustion. Retardation in steps from 0.75° to a maximum of 15°]
- ◆ Cylinder 5 retardation [ignition angle retarded due to knocking combustion. Retardation in steps from 0.75° to a maximum of 15°]
- ◆ Safety retardation [ignition angle of all cylinders retarded in case of failure of camshaft position sensors or knock sensors. 0 - Retardation not active 1 - retardation active]
- ◆ Pedal value [display reads 100 % when accelerator is fully depressed, adjust if necessary, otherwise full power cannot be achieved.]
- ◆ Pedal encoder potentiometer 1
- ◆ Pedal encoder potentiometer 2
- ◆ Throttle valve angle, required
- ◆ Throttle actual value [display > 99 % with a pedal value of 100 %.]
- ◆ Throttle position sensor 1
- ◆ Throttle position sensor 2
- ◆ Target speed, cruise control

- ◆ Vehicle speed
- ◆ Throttle angle potentiometer 1
- ◆ Throttle angle potentiometer 2
- ◆ Mass air flow sensor [voltage value]
- ◆ Power supply
- ◆ Ambient pressure

### Input Signals

Input signals of the DME can be read in by the Porsche System Tester 2 with this menu item. In this way, the function of the input signals can be assessed very quickly.

The following input signals can be read in:

- ◆ Full load detection
- ◆ Press accelerator idle detection
- ◆ Medium pressure switch
- ◆ A/C request
- ◆ Start enable switch
- ◆ Disturbance switch
- ◆ Stop light switch
- ◆ Brake switch
- ◆ Immobilizer
- ◆ Fuel reserve signal
- ◆ Cruise control readiness
- ◆ Clutch switch
- ◆ Cruise-control store/accelerate
- ◆ Cruise-control decelerate/resume

### Ready Status

This menu item allows the interrogation of statuses (fulfilled/not fulfilled) of the DME. The following statuses can be checked:

- ◆ TWC conversion
- ◆ Fuel tank ventilation
- ◆ Secondary air system
- ◆ Oxygen sensors
- ◆ Oxygen sensor heating

To receive a ready message, allow the vehicle to warm up (engine temperature > 80 °C) and then activate all diagnostic routines which have not yet been carried out under the menu item "Short test."

### Drive Links

Drive links (actuators) of the DME can be activated by the Porsche System Tester 2 with this menu item. This permits the electric function of the drive links to be assessed very quickly.

The following drive links can be activated:

- ◆ A/C compressor
- ◆ EVAP canister purge valve
- ◆ Engine compartment purge fan
- ◆ Secondary air pump
- ◆ Switch-over valve (secondary air)
- ◆ EVAP canister shutoff valve
- ◆ Frequency valve, boost pressure control
- ◆ Fan
- ◆ Fuel pump relay (fuel pump)
- ◆ Cooling water shutoff valve
- ◆ Overrun recirculating air valve
- ◆ Valve lift control, bank 1 and 2

### Drive Link Active

With this menu item, drive links of the DME can be triggered by the Porsche System Tester 2 when the engine is running. This permits the function of the drive links to be assessed very quickly.

The following drive links can be activated:

- ◆ Cylinder 1 injection valve off
- ◆ Cylinder 2 injection valve off
- ◆ Cylinder 3 injection valve off
- ◆ Cylinder 4 injection valve off
- ◆ Cylinder 5 injection valve off
- ◆ Cylinder 6 injection valve off
- ◆ Valve lift control, bank 1 and 2
- ◆ Camshaft adjustment, bank 1
- ◆ Camshaft adjustment, bank 2



## Vehicle Data

With this menu item, specific vehicle data can be read out with the Porsche System Tester 2.

The following vehicle data can be read out:

- ◆ Number of ignitions, range 1
- ◆ Number of ignitions, range 2
- ◆ Operating hours counter
- ◆ Vehicle Identification Number
- ◆ Classification number
- ◆ Order type
- ◆ Country code
- ◆ Engine type
- ◆ Engine number
- ◆ Transmission type
- ◆ Transmission number
- ◆ Radio/PCM code
- ◆ Body colour/convertible-top colour
- ◆ Interior equipment
- ◆ No. of programming operations
- ◆ Navigation system (code)
- ◆ Total distance covered
- ◆ M numbers
- ◆ Z numbers
- ◆ Exclusive numbers

## System Test

With the system test, it is possible to detect faults in the valve lift control with both large lift and small lift.

The procedure is described under Troubleshooting.

## Short Test

This menu item allows the checking of all diagnostic paths, i.e. the vehicle does not have to be driven in order to achieve a "trip".

In the Short Test menu item, diagnostic routines can be processed which would actually only be achieved while driving and, in some cases, only after a long period.

The following diagnostic routines can be activated with the Porsche System Tester 2:

- ◆ Constant oxygen sensing LSU
- ◆ Basic mixture adaptation
- ◆ Fuel tank ventilation
- ◆ Secondary air
- ◆ Oxygen sensor readiness behind catalytic converter
- ◆ Oxygen sensor ageing behind catalytic converter
- ◆ TWC conversion

### Coding

Under this menu item, the DME control module can be coded for operation with cruise control (cruise control system).

### Control Module Programming

Four sub-menus are offered with this menu item:

#### 1. Read out control module (vehicle data)

The menu item 'Read out control module' can be used to read out data from the old control module, e.g. engine number, M numbers, etc., in order to adopt the data in a new control module.



#### Note!

*Only one control module at a time can be read out in order then to adopt the data in a new control module during control module programming.*

#### 2. Program control module (new control module)



#### Note!

- ◆ *The DME programming code and immobilizer code are required to program control modules. These codes can be obtained from the Porsche IPAS system.*
- ◆ *All electrical consumers must be switched off for programming control modules.*
- ◆ *Switch heater to OFF.*
- ◆ *The vehicle battery must be fully charged.*
- ◆ Enter vehicle identification number and confirm.
- ◆ Enter and confirm 'new programming code'.

**i Note!**

*The new programming code must match the DME programming code from the IPAS, otherwise the control module can no longer be programmed later.*

- ◆ Enter and confirm 'New immobilizer code'.

**i Note!**

*The new immobilizer code must match the immobilizer code from the IPAS, otherwise the control module can no longer be programmed later.*

- ◆ Select data record.

**i Note!**

- ◆ *If the data record OBD II was selected in the old control module, the tester automatically preselects "Data record OBDII".*
- ◆ *The selection must then simply be confirmed. Programming commences after this confirmation.*
- ◆ When programming is complete, switch off the ignition.
- ◆ Switch on the ignition.
- ◆ Switch off the tester.

**i Note!**

*In Tiptronic vehicles, the fault memory of the Tiptronic must be erased following the programming of a DME control module, as the fault "CAN timeout" is entered in the memory during programming.*

### 3. Program map/data

The data record can be changed, e.g. from RoW to OBD II, with this menu item. Only the DME programming code is required.

### 4. Program immobilizer code

The immobilizer code is transferred to a new DME control module with this menu item.



## Data output with a scan tool

The output of data relevant to OBD from the control modules was stipulated by law for the USA. It is described in SAE J 1979.

Data output is subdivided into different modes.

### Mode 1

Output of:

- ◆ Input signals
- ◆ Output signals
- ◆ System status information
- ◆ Values calculated by the control module

### Mode 2

Output of operating conditions (Freeze Frame), if a fault has been stored.

### Mode 3

Output of stored faults.

### Mode 4

Erase the fault memory.

### Mode 5

Output of oxygen sensor data.

### Mode 6

Output of test results of non-continuous tests.

### Mode 7

Output of test results of continuous tests.

Output of suspected faults.

The data sets in the modes are referred to as Parameter Identification (PID).

After being stimulated by a generic scan tool, all systems relevant to OBD log on with their address. In vehicles with ME 7.8, this is the DME with the address \$11 and in Tiptronic vehicles it is the transmission control module with the address \$1A.



#### Note!

*The \$ symbol means that a hexadecimal number is involved.*

When the control module provides data, it also states the mode, the PID number and the address of the control module.

For example:

Mode 41 PID \$01 address \$11

Engine control

Number of faults: 0

Check Engine: off

The output of data is carried out:

in Mode 1 with Mode 41,

in Mode 2 with Mode 42,

in Mode 3 with Mode 43, etc.

### Mode 8

Activation of drive links (is not supported)

### Mode 9

Output of vehicle information (as of model year 2002)

### Mode 1

The following PIDs are supported:

\$00 Supported PIDs

The PIDs supported in this mode are output.

PIDs 01 to 08

1	0	1	1	1	1	1	1	
7	6	5	4	3	2	1	0	Bit
01	02	03	04	05	06	07	08	PID

PIDs 09 to 10

1	0	0	1	1	1	1	1	
7	6	5	4	3	2	1	0	Bit
09	0A	0B	0C	0D	0E	0F	10	PID

PIDs 11 to 18

1	1	1	0	1	0	0	0	
7	6	5	4	3	2	1	0	Bit
11	12	13	14	15	16	17	18	PID

PIDs 19 to 20

1	0	0	1	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
19	1A	1B	1C	1D	1E	1F	20	PID

PIDs 21 to 28

0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
21	22	23	24	25	26	27	28	PID

PIDs 29 to 30

0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
29	2A	2B	2C	2D	2E	2F	30	PID

PIDs 31 to 38

0	0	0	1	0	0	0	1	
7	6	5	4	3	2	1	0	Bit
31	32	33	34	35	36	37	38	PID

0 - PID number not supported.

1 - PID number supported.

\$01 Status of diagnostic system

The system status is output in a 4-byte word (Data A, B, C and D).

For example:

Data	A:	1000	0001
	B:	0000	0111
	C:	0110	1101
	D:	0110	1101

**Data A**

1	0	0	0	0	0	0	1	
7	6	5	4	3	2	1	0	Bit

Bits 0 to 6

Number of faults in binary format

Bit 7

0 - Check Engine MIL was not switched on by this control module.

1 - Check Engine MIL was switched on by this control module.

**Data B**

0	0	0	0	0	1	1	1	
7	6	5	4	3	2	1	0	Bit

Data byte B displays all the sub-systems which are monitored continuously, i.e. at least twice per second.

Bit 0 Misfire detection

Bit 1 Fuel system

Bit 2 Other components

Bit 3 Not used

Bit 4 Not used

Bit 5 Not used

Bit 6 Not used

Bit 7 Not used

0 - System not supported.

1 - System supported.

**Data C**

0	1	1	0	1	1	0	1	
7	6	5	4	3	2	1	0	Bit

Data byte C displays the sub-systems which are monitored at least once per driving cycle.



Bit 0	TWC
Bit 1	TWC heating
Bit 2	Fuel tank ventilation
Bit 3	Secondary air system
Bit 4	A/C system
Bit 5	Oxygen sensor
Bit 6	Oxygen sensor heating
Bit 7	Exhaust gas circulation

0 - Sub-system not available.

1 - Sub-system available.

#### Data D

0	1	1	0	1	1	0	1	
7	6	5	4	3	2	1	0	Bit

In data byte D, the readiness codes of the sub-systems from data byte C are displayed.

Bits 0 to 7

0 - Sub-system check completed or sub-system not installed.

1 - Sub-system check not yet complete.



#### Note!

- ◆ *After the fault memory has been erased, the bits of the installed sub-systems are set to 1.*
- ◆ *The bits are reset to 0:*
  - ◆ in the case of a fault-free check after 1 driving cycle
  - ◆ in the case of a detected fault after 2 driving cycles

\$03 Status of injection system

Data	A:	0000	0010
	B:	0000	0010

Data A - Status for bank 1

Data B - Status for bank 2

0	0	0	0	0	0	1	0	
7	6	5	4	3	2	1	0	Bit

- Bit 0 Open-loop control; the conditions for oxygen sensing are not yet fulfilled.
- Bit 1 Closed-loop control; the signal from the oxygen sensor is used to control injection.
- Bit 2 Open-loop control through conditions such as full load, etc.
- Bit 3 Open-loop control due to fault in system.
- Bit 4 Closed-loop control, but faults from at least one oxygen sensor.

Bits 5 to 7 not used.



**Note!**

*Only one bit at a time can be set to 1 to indicate the status.*

**\$04** Calculated load value

Output of calculated load as a percentage of the maximum load.

Display between 0% and 100%.

In the case of decimal output, conversion factor = 0.3921568

The decimal value displayed multiplied by 0.3921568 gives the load as a percentage.

**\$05** Engine coolant temperature

Output of the momentary engine coolant temperature.

Display between -40 °C and 215 °C.

In the case of decimal output, conversion factor = 1

Offset = -40 °C

Decimal value displayed multiplied by 1 minus 40 °C gives the coolant temperature.

**\$06** HO2S integrator, bank 1

Output of the control value FR of the oxygen sensor closed-loop control, bank 1.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$07 HO2S adaptation, bank 1

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 1.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.

\$08 HO2S integrator, bank 2

Output of the control value FR of the oxygen sensor closed-loop control, bank 2.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$09 HO2S adaptation, bank 2

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 2.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.

\$0C Engine speed

Output of the momentary engine speed.

Display of engine speed in rpm.

In the case of decimal output, conversion factor = 0.25

Decimal value displayed multiplied by 0.25 gives the engine speed.

\$0D Vehicle speed

Output of the speed currently travelled.

Display of speed in  $\text{km}/\text{h}$  up to a maximum of 255  $\text{km}/\text{h}$ .

In the case of decimal output, conversion factor = 1

\$0E Ignition timing, cylinder 1

Output of the ignition angle of cylinder 1.

Display:           After TDC up to  $-64^\circ$  crk  
                      Before TDC up to  $63.5^\circ$  crk

$^\circ$  crk - degrees on crankshaft

In the case of decimal output, conversion factor = 0.5

Offset =  $-64^\circ$  crk

Decimal value displayed multiplied by 0.5 minus  $64^\circ$  crk gives the ignition timing.

\$0F Intake air temperature

Output of intake air temperature.

Display between  $-40^\circ\text{C}$  and  $215^\circ\text{C}$ .

In the case of decimal output, conversion factor = 1

Offset =  $-40^\circ\text{C}$

Decimal value displayed multiplied by 1 minus  $40^\circ\text{C}$  gives the intake air temperature.

**\$10 Air mass**

Output of the intake air mass.

Display between 0 and 655.35 g/s

g/s - grams per second

In the case of decimal output, conversion factor = 0.01

Decimal value displayed multiplied by 0.01 gives the air mass.

**\$11 Throttle valve position**

Output of the absolute throttle angle.

Display between 0% and 100%.

In the case of decimal output, conversion factor = 0.3921568

The decimal value displayed multiplied by 0.3921568 gives the throttle angle as a percentage.

**\$12 Status of secondary air system****Data A**

0	0	0	0	0	1	0	0	
7	6	5	4	3	2	1	0	Bit

Bit 0 Secondary air is injected ahead of the TWC.

Bit 1 Not used

Bit 2 Secondary-air pump is switched off.

Bits 3 to 7 not used.

 **Note!**

*Only one bit at a time can be set to 1 to indicate the status.*

**\$13 Number of oxygen sensors**

Output of the number and location of oxygen sensors.

0	0	1	1	0	0	1	1	
7	6	5	4	3	2	1	0	Bit

Bit 0	Bank 1, sensor 1 (ahead of TWC, cylinders 1 - 3)
Bit 1	Bank 1, sensor 2 (after TWC, cylinders 1 - 3)
Bit 2	Bank 1, sensor 3 not installed
Bit 3	Bank 1, sensor 4 not installed
Bit 4	Bank 2, sensor 1 (ahead of TWC, cylinders 4 - 6)
Bit 5	Bank 2, sensor 2 (after TWC, cylinders 4 - 6)
Bit 6	Bank 2, sensor 3 not installed
Bit 7	Bank 2, sensor 4 not installed

0 – Sensor not available.

1 – Sensor available.

\$15 Oxygen sensor signal, bank 1, sensor 2

Output of oxygen sensor voltage and associated oxygen sensor.

Display of sensor voltage between 0 V and 1.275 V and of the oxygen sensor in percent.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

**Note!**

*Since the sensor behind the catalytic converter is not included in the closed-loop control, no value for the oxygen sensor is displayed.*

\$19 Oxygen sensor signal, bank 2, sensor 2

Output of oxygen sensor voltage and associated oxygen sensor.

Display of sensor voltage between 0 V and 1.275 V and of the oxygen sensor in percent.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

**Note!**

*Since the sensor behind the catalytic converter is not included in the closed-loop control, no value for the oxygen sensor is displayed.*

### \$1C OBD requirements

Output of system classification.

01	OBD II for California
02	OBD for EPA
03	OBD II for California and EPA
04	OBD I
05	Fulfills no OBD requirements
06	EOBD (European OBD)

### \$34 Oxygen sensing value (bank 1 - sensor 1)

Output of the oxygen sensing value

Display between 0 and 1.999.

In the case of decimal output, conversion factor = 0.0000305

Decimal value displayed multiplied by 0.0000305 gives the oxygen sensing value.

### \$34 Oxygen sensor current (bank 1 - sensor 1)

Output of the oxygen sensor current

Display between -128 mA and 127.996 mA.

In the case of decimal output, conversion factor = 0.00390625

Offset = -128 mA

Decimal value displayed multiplied by 0.00390625 minus 128 mA gives the oxygen sensor current.

### \$38 Oxygen sensing value (bank 2 - sensor 1)

Output of the oxygen sensing value

Display between 0 and 1.999.

In the case of decimal output, conversion factor = 0.0000305

Decimal value displayed multiplied by 0.0000305 gives the oxygen sensing value.

### \$38 Oxygen sensor current (bank 2 - sensor 1)

Output of the oxygen sensor current

Display between -128 mA and 127.996 mA.

In the case of decimal output, conversion factor = 0.00390625

Offset = -128 mA

Decimal value displayed multiplied by 0.00390625 minus 128 mA gives the oxygen sensor current.

## Mode 2

In mode 2 the operating conditions (freeze frame data) at the time of fault entry are output. The operating conditions of the fault which occurred first are stored.

If a fuel system fault or misfiring fault occurs after this, the data of the fault which occurred first are overwritten.

The following PIDs are supported:

### \$00 Supported PIDs

The PIDs supported in this mode are output in a 4-byte word.

#### Data A

0	1	1	1	1	1	1	1	
7	6	5	4	3	2	1	0	Bit
01	02	03	04	05	06	07	08	PID

#### Data B

1	0	1	1	1	0	0	0	
7	6	5	4	3	2	1	0	Bit
09	0A	0B	0C	0D	0E	0F	10	PID

#### Data C

0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
11	12	13	14	15	16	17	18	PID

#### Data D

0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
19	1A	1B	1C	1D	1E	1F	20	PID



 **Note!**

The Data A and B bytes indicate that PIDs 02, 03, 04, 05, 06, 07, 08, 09, 0B, 0C and 0D are supported.

\$02 Fault code

The fault code which caused the storage of freeze frame data is displayed.

\$03 Status of injection system

Data	A:	0000	0010
	B:	0000	0010

Data A - Status for bank 1

Data B - Status for bank 2

0	0	0	0	0	0	1	0	
7	6	5	4	3	2	1	0	Bit

- Bit 0 Open-loop control; the conditions for oxygen sensing are not yet fulfilled.
- Bit 1 Closed-loop control; the signal from the oxygen sensor is used to control injection.
- Bit 2 Open-loop control through conditions such as full load, etc.
- Bit 3 Open-loop control due to fault in system.
- Bit 4 Closed-loop control, but faults from at least one oxygen sensor.

Bits 5 to 7 not used.

 **Note!**

Only one bit at a time can be set to 1 to indicate the status.

\$04 Calculated load value

Output of calculated load as a percentage of the maximum load.

Display between 0% and 100%.

In the case of decimal output, conversion factor = 0.3921568

The decimal value displayed multiplied by 0.3921568 gives the load as a percentage.

#### \$05 Engine coolant temperature

Output of the engine coolant temperature.

Display between -40 °C and 215 °C.

In the case of decimal output, conversion factor = 1

Offset = -40 °C

Decimal value displayed multiplied by 1 minus 40 °C gives the coolant temperature.

#### \$06 HO2S integrator, bank 1

Output of the control value FR of the oxygen sensor closed-loop control, bank 1.

Display:           Lean to -100 %  
                      Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

#### \$07 HO2S adaptation, bank 1

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 1.

Display:           Lean to -100 %  
                      Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.

#### \$08 HO2S integrator, bank 2

Output of the control value FR of the oxygen sensor closed-loop control, bank 2.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$09 HO2S adaptation, bank 2

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 2.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.

\$0B Intake manifold pressure (absolute)

Output of the intake manifold pressure.

Display:       0 kPa to 255 kPa

In the case of decimal output, conversion factor = 1

\$0C Engine speed

Output of the engine speed.

Display in rpm

In the case of decimal output, conversion factor = 0.25

Decimal value displayed multiplied by 0.25 gives the engine speed.

\$0D Vehicle speed

Output of the speed.

In the case of decimal output, conversion factor = 1

### Mode 3

Output of stored faults.

The fault codes of all shedded, officially relevant\* faults are displayed in Mode 3.

**\* Faults which switch on the Check Engine warning light**

### Mode 4

In Mode 4, the fault memory can be erased.



**Note!**

- ◆ *The fault memories of all systems relevant to OBD are erased.*
- ◆ *If the fault memory is erased, Mode 5 and Mode 6 values are also reset. Furthermore, the adaptation values are neutralised.*

### Mode 5

Output of oxygen sensor data.

The values of the last oxygen sensor test carried out (test identification TID) can be read out for every oxygen sensor with its nominal values.

**For the oxygen sensors ahead of the TWC (bank 1/2, sensor 1), the following TIDs are supported:**

\$81 Oxygen sensing actual value

Output of the oxygen sensing actual value.

Display between 0 and 1.99.

In the case of decimal output, conversion factor = 0.00781

Decimal value displayed multiplied by 0.00781 gives the oxygen sensing actual value.

\$82 Oxygen sensing nominal value

Output of the oxygen sensing nominal value.

Display between 0 and 1.99.

In the case of decimal output, conversion factor = 0.00781

Decimal value displayed multiplied by 0.00781 gives the oxygen sensing nominal value.

\$83 Dynamic value of the oxygen sensor

Output of the dynamic value.

Display between 0 and 5.0.

In the case of decimal output, conversion factor = 0.0195

Decimal value displayed multiplied by 0.0195 gives the dynamic value.

\$84 Oxygen sensing displacement

Oxygen sensing displacement (current share) due to pilot control.

Display between -0.05 and 0.05.

In the case of decimal output, conversion factor = 0.00039

Offset = -128

Decimal value displayed multiplied by 0.00039 minus 128 gives the oxygen sensing displacement.

**For the oxygen sensors after the TWC (bank 1/2, sensor 2), the following TIDs are supported:**

\$01 Rich-lean threshold voltage

Programmed fixed value: e.g. 0.575 V.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the threshold voltage.

\$02 Lean-rich threshold voltage

Programmed fixed value: e.g. 0.575 V.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the threshold voltage.

\$07 Minimum voltage of oxygen sensor during the test

Minimum: e.g. 0.000 V

Maximum: e.g. 0.480 V

Test value: e.g. 0.280 V

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the threshold voltage.

\$08 Maximum voltage of oxygen sensor during the test

Minimum: e.g. 0.480 V  
Maximum: e.g. 1.245 V  
Test value: e.g. 0.685 V

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the threshold voltage.

## Mode 6

The test results of components or systems which are not continuously monitored are output in mode 6. At the same time, limit values are provided. The test results are referred to as TIDs (Test Identification). The components or systems are distinguished by CIDs (Component Identification).

The following components or systems are supported:

### TID \$01 Catalytic converter monitoring

The catalytic converters (bank 1/bank 2) are monitored individually and for the sum of the emissions. There are two threshold values for individual monitoring:

- ◆ AHKATMN for the OK detection and
- ◆ AHKATMX for the defect detection.

For the sum of the emissions, there is the AHKATSB threshold value. A number (ahkat) which is between 0 and 1 is used as a measure for the aging of the catalytic converters.

0 - good

1 - poor


**AHKATS**-Sum total of ahkat + ahkat2

**A** - Symmetry line

**HC** - HC emissions

The cases for catalytic converter bank 1 are shown in the graphic.  
The same applies for bank 2.

- |   |                                       |
|---|---------------------------------------|
| 1 | TWC 1 OK                              |
| 2 | TWC 1 OK                              |
| 3 | TWC 1 OK                              |
| 4 | TWC 1 faulty (P0420)                  |
| 5 | TWCs 1 and 2 faulty (P0420 and P0430) |
| 6 | TWC 1 faulty (P0420)                  |



In the case of the individual CIDs, the limit values (maximum) and the test value of the last test are output.

Maximum: fault, if the test value is greater than the limit value.

The following CIDs can be displayed:

### **\$00 Test not yet carried out**

### **\$05 Conversion bank 1**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **\$06 Conversion bank 2**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **Note!**

*CID \$05 and \$06 are displayed if the test was completed without faults. The values provide information as to how far the catalytic converters still are from the limit values.*

### **\$07 Checksum error, bank 1 and bank 2**

DTC P0420 and P0430 in memory.

The values displayed can be multiplied by the factor 0.0078 to find the ahkat and ahkat2 or AHKATS values.

### **\$08 Checksum range error, bank 1**

DTC P0420 in memory.

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATSB values.

### **\$09 Checksum range error, bank 2**

DTC P0430 in memory.

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATSB values.

### **\$0A Conversion, bank 1**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **\$0B Conversion, bank 2**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.



#### **Note!**

*CID \$0A and \$0B are displayed if the function was carried out with the Porsche System Tester 2 in the Short test menu.*

TID \$03 Secondary air system

The following CIDs can be displayed:

### **\$00 Test not yet carried out**

### **\$01 Secondary air system, bank 1**

Relative secondary air mass

### **\$04 Secondary air system, bank 2**

Relative secondary air mass



#### **Note!**

- ◆ *The relative secondary air mass is the measured secondary air mass relative to the expected nominal value (optimal value) in this operating point. The optimal value is detected with a faultless system. The nominal value is primarily dependent on exhaust backpressure, geographical altitude and voltage supply.*
- ◆ *A fault is present if the relative secondary air mass does not exceed the diagnosis threshold value.*
- ◆ *The values displayed can be multiplied by the factor 0.0078 to find the applied values.*



### TID \$05 Fuel tank ventilation system

For the fuel tank ventilation system, several tests are carried out consecutively but only one test value is output. This means that the subsequent test overwrites the preceding test value.

When all tests have been carried out, \$0D (minor leak test) is displayed.

If a different CID is displayed, the test was interrupted - either because a fault was present or, for example, the EVAP canister was excessively loaded.

The following CIDs can be displayed:

- ◆ \$00 Test not yet carried out
- ◆ \$0A Canister purge valve (leaking)
- ◆ \$0B Shut-off valve, EVAP canister (blocked)
- ◆ \$0C Major leak (pressure increase)
- ◆ \$0D Minor leak (leakage volumetric flow)
- ◆ \$11 Shut-off valve, EVAP canister (pressure reduction)
- ◆ \$12 Major leak (pressure sensor)
- ◆ \$13 Major leak (pressure sensor)
- ◆ \$14 Tank vent valve (constantly open)

### Mode 7

The fault codes of all non-shedded, officially relevant\* faults are displayed in Mode 7. This mode has the same structure as Mode 3.

**\* Faults which switch on the Check Engine warning light**

### Mode 9

The following vehicle information is displayed in Mode 9:

- ◆ Vehicle Identification Number
- ◆ Programme status (Calibration Identification Number)
- ◆ Control unit checksum (Calibration Verification Number)



## Data output with a scan tool - 911 Carrera (996)

The output of data relevant to OBD from the control modules was stipulated by law for the USA. It is described in SAE J 1979.

Data output is subdivided into different modes.

### Mode 1

Output of:

- ◆ Input signals
- ◆ Output signals
- ◆ System status information
- ◆ Values calculated by the control module

### Mode 2

Output of operating conditions (Freeze Frame), if a fault has been stored.

### Mode 3

Output of stored faults.

### Mode 4

Erase the fault memory.

### Mode 5

Output of oxygen sensor data.

### Mode 6

Output of test results of non-continuous tests.

### Mode 7

Output of test results of continuous tests.

Output of suspected faults.

The data sets in the modes are referred to as Parameter Identification (PID).

After being stimulated by a generic scan tool, all systems relevant to OBD log on with their address. In vehicles with ME 7.8, this is the DME with the address \$11 and in Tiptronic vehicles it is the transmission control module with the address \$1A.



### Note!

*The \$ symbol means that a hexadecimal number is involved.*

When the control module provides data, it also states the mode, the PID number and the address of the control module.

For example:

Mode 41 PID \$01 address \$11

Engine control

Number of faults: 0

Check Engine: off

The output of data is carried out:

in Mode 1 with Mode 41,

in Mode 2 with Mode 42,

in Mode 3 with Mode 43, etc.

### Mode 8

Activation of drive links (is not supported)

### Mode 9

Output of vehicle information (as of model year 2002)

### Mode 1

The following PIDs are supported:

\$00 Supported PIDs

The PIDs supported in this mode are output.

PIDs 01 to 08

1	0	1	1	1	1	1	1	
7	6	5	4	3	2	1	0	Bit
01	02	03	04	05	06	07	08	PID

PIDs 09 to 10

1	0	0	1	1	1	1	1	
7	6	5	4	3	2	1	0	Bit
09	0A	0B	0C	0D	0E	0F	10	PID

PIDs 11 to 18

1	1	1	1	1	0	0	1	
7	6	5	4	3	2	1	0	Bit
11	12	13	14	15	16	17	18	PID

PIDs 19 to 20

1	0	0	1	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
19	1A	1B	1C	1D	1E	1F	20	PID

PIDs 21 to 28

0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
21	22	23	24	25	26	27	28	PID

PIDs 29 to 30

0	0	0	0	0	0	0	1	
7	6	5	4	3	2	1	0	Bit
29	2A	2B	2C	2D	2E	2F	30	PID

PIDs 31 to 38

1	1	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
31	32	33	34	35	36	37	38	PID

0 - PID number not supported.

1 - PID number supported.

\$01 Status of diagnostic system

The system status is output in a 4-byte word (Data A, B, C and D).

For example:

Data	A:	1000	0001
	B:	0000	0111
	C:	0110	1101
	D:	0110	1101

**Data A**

1	0	0	0	0	0	0	1	
7	6	5	4	3	2	1	0	Bit

Bits 0 to 6

Number of faults in binary format

Bit 7

0 - Check Engine MIL was not switched on by this control module.

1 - Check Engine MIL was switched on by this control module.

**Data B**

0	0	0	0	0	1	1	1	
7	6	5	4	3	2	1	0	Bit

Data byte B displays all the sub-systems which are monitored continuously, i.e. at least twice per second.

Bit 0 Misfire detection

Bit 1 Fuel system

Bit 2 Other components

Bit 3 Not used

Bit 4 Not used

Bit 5 Not used

Bit 6 Not used

Bit 7 Not used

0 - System not supported.

1 - System supported.

**Data C**

0	1	1	0	1	1	0	1	
7	6	5	4	3	2	1	0	Bit

Data byte C displays the sub-systems which are monitored at least once per driving cycle.

Bit 0	TWC
Bit 1	TWC heating
Bit 2	Fuel tank ventilation
Bit 3	Secondary air system
Bit 4	A/C system
Bit 5	Oxygen sensor
Bit 6	Oxygen sensor heating
Bit 7	Exhaust gas circulation

0 - Sub-system not available.

1 - Sub-system available.

#### Data D

0	1	1	0	1	1	0	1	
7	6	5	4	3	2	1	0	Bit

In data byte D, the readiness codes of the sub-systems from data byte C are displayed.

Bits 0 to 7

0 - Sub-system check completed or sub-system not installed.

1 - Sub-system check not yet complete.



#### Note!

- ◆ *After the fault memory has been erased, the bits of the installed sub-systems are set to 1.*
- ◆ *The bits are reset to 0:*
  - ◆ in the case of a fault-free check after 1 driving cycle
  - ◆ in the case of a detected fault after 2 driving cycles

\$03 Status of injection system

Data	A:	0000	0010
	B:	0000	0010

Data A - Status for bank 1

Data B - Status for bank 2

0	0	0	0	0	0	1	0	
7	6	5	4	3	2	1	0	Bit

Bit 0 Open-loop control; the conditions for oxygen sensing are not yet fulfilled.

Bit 1 Closed-loop control; the signal from the oxygen sensor is used to control injection.

Bit 2 Open-loop control through conditions such as full load, etc.

Bit 3 Open-loop control due to fault in system.

Bit 4 Closed-loop control, but faults from at least one oxygen sensor.

Bits 5 to 7 not used.



### Note!

*Only one bit at a time can be set to 1 to indicate the status.*

#### \$04 Calculated load value

Output of calculated load as a percentage of the maximum load.

Display between 0% and 100%.

In the case of decimal output, conversion factor = 0.3921568

The decimal value displayed multiplied by 0.3921568 gives the load as a percentage.

#### \$05 Engine coolant temperature

Output of the momentary engine coolant temperature.

Display between -40 °C and 215 °C.

In the case of decimal output, conversion factor = 1

Offset = -40 °C

Decimal value displayed multiplied by 1 minus 40 °C gives the coolant temperature.

#### \$06 HO2S integrator, bank 1

Output of the control value FR of the oxygen sensor closed-loop control, bank 1.



Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$07 HO2S adaptation, bank 1

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 1.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.

\$08 HO2S integrator, bank 2

Output of the control value FR of the oxygen sensor closed-loop control, bank 2.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$09 HO2S adaptation, bank 2

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 2.

Display:       Lean to -100 %  
                  Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.

\$0C Engine speed

Output of the momentary engine speed.

Display of engine speed in rpm.

In the case of decimal output, conversion factor = 0.25

Decimal value displayed multiplied by 0.25 gives the engine speed.

\$0D Vehicle speed

Output of the speed currently travelled.

Display of speed in  $\text{km/h}$  up to a maximum of 255  $\text{km/h}$ .

In the case of decimal output, conversion factor = 1

\$0E Ignition timing, cylinder 1

Output of the ignition angle of cylinder 1.

Display:           After TDC up to  $-64^\circ$  crk  
                      Before TDC up to  $63.5^\circ$  crk

$^\circ$  crk - degrees on crankshaft

In the case of decimal output, conversion factor = 0.5

Offset =  $-64^\circ$  crk

Decimal value displayed multiplied by 0.5 minus  $64^\circ$  crk gives the ignition timing.

\$0F Intake air temperature

Output of intake air temperature.

Display between  $-40^\circ\text{C}$  and  $215^\circ\text{C}$ .

In the case of decimal output, conversion factor = 1

Offset =  $-40^\circ\text{C}$

Decimal value displayed multiplied by 1 minus  $40^\circ\text{C}$  gives the intake air temperature.

**\$10 Air mass**

Output of the intake air mass.

Display between 0 and 655.35 g/s

g/s - grams per second

In the case of decimal output, conversion factor = 0.01

Decimal value displayed multiplied by 0.01 gives the air mass.

**\$11 Throttle valve position**

Output of the absolute throttle angle.

Display between 0% and 100%.

In the case of decimal output, conversion factor = 0.3921568

The decimal value displayed multiplied by 0.3921568 gives the throttle angle as a percentage.

**\$12 Status of secondary air system****Data A**

0	0	0	0	0	1	0	0	
7	6	5	4	3	2	1	0	Bit

Bit 0 Secondary air is injected ahead of the TWC.

Bit 1 Not used

Bit 2 Secondary-air pump is switched off.

Bits 3 to 7 not used.

 **Note!**

*Only one bit at a time can be set to 1 to indicate the status.*

**\$13 Number of oxygen sensors**

Output of the number and location of oxygen sensors.

0	0	1	1	0	0	1	1	
7	6	5	4	3	2	1	0	Bit

Bit 0	Bank 1, sensor 1 (ahead of TWC, cylinders 1 - 3)
Bit 1	Bank 1, sensor 2 (after TWC, cylinders 1 - 3)
Bit 2	Bank 1, sensor 3 not installed
Bit 3	Bank 1, sensor 4 not installed
Bit 4	Bank 2, sensor 1 (ahead of TWC, cylinders 4 - 6)
Bit 5	Bank 2, sensor 2 (after TWC, cylinders 4 - 6)
Bit 6	Bank 2, sensor 3 not installed
Bit 7	Bank 2, sensor 4 not installed

0 – Sensor not available.

1 – Sensor available.

\$14 Oxygen sensor signal, bank 1, sensor 1

Output of oxygen sensor voltage and associated oxygen sensor.

Display of sensor voltage between 0 V and 1.275 V and of the oxygen sensor in percent.

In the case of decimal output, conversion factor = 0.005 (voltage of oxygen sensor)

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

Oxygen sensor display:

Lean to -100 %

Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$15 Oxygen sensor signal, bank 1, sensor 2

Output of oxygen sensor voltage and associated oxygen sensor.

Display of sensor voltage between 0 V and 1.275 V and of the oxygen sensor in percent.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

 **Note!**

*Since the sensor behind the catalytic converter is not included in the closed-loop control, no value for the oxygen sensor is displayed.*

\$18 Oxygen sensor signal, bank 2, sensor 1

Output of oxygen sensor voltage and associated oxygen sensor.

Display of sensor voltage between 0 V and 1.275 V and of the oxygen sensor in percent.

In the case of decimal output, conversion factor = 0.005 (voltage of oxygen sensor)

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

Oxygen sensor display:

Lean to -100 %

Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$19 Oxygen sensor signal, bank 2, sensor 2

Display of oxygen sensor voltage and associated oxygen sensor.

Display of sensor voltage between 0 V and 1.275 V and of the oxygen sensor in percent.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

 **Note!**

*Since the sensor behind the catalytic converter is not included in the closed-loop control, no value for the oxygen sensor is displayed.*

\$1C OBD requirements

Output of system classification.

01	OBD II for California
02	OBD for EPA
03	OBD II for California and EPA
04	OBD I
05	Fulfills no OBD requirements
06	EOBD (European OBD)

## Mode 2

In mode 2 the operating conditions (freeze frame data) at the time of fault entry are output. The operating conditions of the fault which occurred first are stored.

If a fuel system fault or misfiring fault occurs after this, the data of the fault which occurred first are overwritten.

The following PIDs are supported:

### \$00 Supported PIDs

The PIDs supported in this mode are output in a 4-byte word.

#### Data A

0	1	1	1	1	1	1	1	
7	6	5	4	3	2	1	0	Bit
01	02	03	04	05	06	07	08	PID

#### Data B

1	0	1	1	1	0	0	0	
7	6	5	4	3	2	1	0	Bit
09	0A	0B	0C	0D	0E	0F	10	PID

#### Data C

0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
11	12	13	14	15	16	17	18	PID

#### Data D

0	0	0	0	0	0	0	0	
7	6	5	4	3	2	1	0	Bit
19	1A	1B	1C	1D	1E	1F	20	PID

**Note!**

The Data A and B bytes indicate that PIDs 02, 03, 04, 05, 06, 07, 08, 09, 0B, 0C and 0D are supported.

**\$02 Diagnostic Trouble Code**

The Diagnostic Trouble Code which caused the storage of freeze frame data is displayed.

**\$03 Status of injection system**

Data	A:	0000	0010
	B:	0000	0010

Data A - Status for bank 1

Data B - Status for bank 2

0	0	0	0	0	0	1	0	
7	6	5	4	3	2	1	0	Bit

- Bit 0 Open-loop control; the conditions for oxygen sensing are not yet fulfilled.
  - Bit 1 Closed-loop control; the signal from the oxygen sensor is used to control injection.
  - Bit 2 Open-loop control through conditions such as full load, etc.
  - Bit 3 Open-loop control due to fault in system.
  - Bit 4 Closed-loop control, but faults from at least one oxygen sensor.
- Bits 5 to 7 not used.

**Note!**

Only one bit at a time can be set to 1 to indicate the status.

**\$04 Calculated load value**

Output of calculated load as a percentage of the maximum load.

Display between 0% and 100%.

In the case of decimal output, conversion factor = 0.3921568

The decimal value displayed multiplied by 0.3921568 gives the load as a percentage.

\$05 Engine coolant temperature

Output of the engine coolant temperature.

Display between -40 °C and 215 °C.

In the case of decimal output, conversion factor = 1

Offset = -40 °C

Decimal value displayed multiplied by 1 minus 40 °C gives the coolant temperature.

\$06 HO2S integrator, bank 1

Output of the control value FR of the oxygen sensor closed-loop control, bank 1.

Display:           Lean to -100 %  
                      Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

\$07 HO2S adaptation, bank 1

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 1.

Display:           Lean to -100 %  
                      Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.



### \$08 HO2S integrator, bank 2

Output of the control value FR of the oxygen sensor closed-loop control, bank 2.

Display:           Lean to -100 %  
                      Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S integrator.

### \$09 HO2S adaptation, bank 2

Output of the adaptation value FRA of the oxygen sensor closed-loop control, bank 2.

Display:           Lean to -100 %  
                      Rich to 99.22 %

In the case of decimal output, conversion factor = 0.78125

Offset = -100 %

Decimal value displayed multiplied by 0.78125 minus 100% gives the HO2S adaptation value.

### \$0B Intake manifold pressure (absolute)

Output of the intake manifold pressure.

Display:           0 kPa to 255 kPa

In the case of decimal output, conversion factor = 1

### \$0C Engine speed

Output of the engine speed.

Display in rpm

In the case of decimal output, conversion factor = 0.25

Decimal value displayed multiplied by 0.25 gives the engine speed.

\$0D Vehicle speed

Output of the speed.

In the case of decimal output, conversion factor = 1

### Mode 3

Output of stored faults.

The Diagnostic Trouble Codes of all shedded, officially relevant\* faults are displayed in Mode 3.

**\* Faults which switch on the Check Engine warning light**

### Mode 4

In Mode 4, the fault memory can be erased.



#### Note!

- ◆ *The fault memories of all systems relevant to OBD are erased.*
- ◆ *If the fault memory is erased, Mode 5 and Mode 6 values are also reset. Furthermore, the adaptation values are neutralised.*

### Mode 5

Output of oxygen sensor data.

The values of the last oxygen sensor test carried out (test identification TID) can be read out for every oxygen sensor with its nominal values.

\$01 Rich-lean threshold voltage

Programmed fixed value: e.g. 0.430 V.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the threshold voltage.

\$02 Lean-rich threshold voltage

Programmed fixed value: e.g. 0.430 V.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the threshold voltage.

### \$07 Minimum voltage of oxygen sensor during the test

Minimum: e.g. 0.000 V.

Maximum: e.g. 0.385 V.

Test value: e.g. 0.180 V.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

### \$08 Maximum voltage of oxygen sensor during the test

Minimum: e.g. 0.480 V.

Maximum: e.g. 0.960 V.

Test value: e.g. 0.855 V.

In the case of decimal output, conversion factor = 0.005

Decimal value displayed multiplied by 0.005 gives the voltage of oxygen sensor.

### \$09 Time between two transitions

Minimum: e.g. 0.00 s

Maximum: e.g. 1.52 s

Test value: e.g. 0.40 s

In the case of decimal output, conversion factor = 0.04

Decimal value displayed multiplied by 0.04 gives the time.

### \$30 Shift in oxygen sensor characteristic towards rich

Minimum: e.g. 0.00 s

Maximum: e.g. 1.20 s

Test value: e.g. 0.12 s

In the case of decimal output, conversion factor = 0.04

Decimal value displayed multiplied by 0.04 gives the time.

\$31 Shift in oxygen sensor characteristic towards lean

Minimum: e.g. 0.00 s

Maximum: e.g. 1.20 s

Test value: e.g. 0.00 s

In the case of decimal output, conversion factor = 0.04

Decimal value displayed multiplied by 0.04 gives the time.

\$32 Averaged period

Minimum: e.g. 0.00 s

Maximum: e.g. 3.00 s

Test value: e.g. 0.40 s

In the case of decimal output, conversion factor = 0.04

Decimal value displayed multiplied by 0.04 gives the time.

## Mode 6

The test results of components or systems which are not continuously monitored are output in mode 6. At the same time, limit values are provided. The test results are referred to as TIDs (Test Identification). The components or systems are distinguished by CIDs (Component Identification).

The following components or systems are supported:

### TID \$01 Catalytic converter monitoring

The catalytic converters (bank 1/bank 2) are monitored individually and for the sum of the emissions. There are two threshold values for individual monitoring:

- ◆ AHKATMN for the OK detection and
- ◆ AHKATMX for the defect detection.

For the sum of the emissions, there is the AHKATSB threshold value. A number (ahkat) which is between 0 and 1 is used as a measure for the aging of the catalytic converters.

0 - good

1 - poor


**AHKATS**-Sum total of ahkat + ahkat2

**A** - Symmetry line

**HC** - HC emissions

The cases for catalytic converter bank 1 are shown in the graphic.  
The same applies for bank 2.

- |   |                                       |
|---|---------------------------------------|
| 1 | TWC 1 OK                              |
| 2 | TWC 1 OK                              |
| 3 | TWC 1 OK                              |
| 4 | TWC 1 faulty (P0420)                  |
| 5 | TWCs 1 and 2 faulty (P0420 and P0430) |
| 6 | TWC 1 faulty (P0420)                  |



In the case of the individual CIDs, the limit values (maximum) and the test value of the last test are output.

Maximum: fault, if the test value is greater than the limit value.

The following CIDs can be displayed:

### **\$00 Test not yet carried out**

### **\$05 Conversion bank 1**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **\$06 Conversion bank 2**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **Note!**

*CID \$05 and \$06 are displayed if the test was completed without faults. The values provide information as to how far the catalytic converters still are from the limit values.*

### **\$07 Checksum error, bank 1 and bank 2**

DTC P0420 and P0430 in memory.

The values displayed can be multiplied by the factor 0.0078 to find the ahkat and ahkat2 or AHKATS values.

### **\$08 Checksum range error, bank 1**

DTC P0420 in memory.

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **\$09 Checksum range error, bank 2**

DTC P0430 in memory.

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **\$0A Conversion, bank 1**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.

### **\$0B Conversion, bank 2**

The values displayed can be multiplied by the factor 0.0039 to find the ahkat or AHKATMX values.



#### **Note!**

*CID \$0A and \$0B are displayed if the function was carried out with the Porsche System Tester 2 in the Short test menu.*

TID \$03 Secondary air system

The following CIDs can be displayed:

### **\$00 Test not yet carried out**

### **\$01 Secondary air system, bank 1**

Relative secondary air mass

### **\$04 Secondary air system, bank 2**

Relative secondary air mass



#### **Note!**

- ◆ *The relative secondary air mass is the measured secondary air mass relative to the expected nominal value (optimal value) in this operating point. The optimal value is detected with a faultless system. The nominal value is primarily dependent on exhaust backpressure, geographical altitude and voltage supply.*
- ◆ *A fault is present if the relative secondary air mass does not exceed the diagnosis threshold value.*
- ◆ *The values displayed can be multiplied by the factor 0.0078 to find the applied values.*

### TID \$05 Fuel tank ventilation system

For the fuel tank ventilation system, several tests are carried out consecutively but only one test value is output. This means that the subsequent test overwrites the preceding test value.

When all tests have been carried out, \$0D (micro-leak test) is displayed.

If a different CID is displayed, the test was interrupted - either because a fault was present or, for example, the EVAP canister was excessively loaded.

In the case of decimal output the conversion factor = 0.00003876

The following CIDs can be displayed:

- ◆ \$00 Test not yet carried out
- ◆ \$0A Canister purge valve (leaking)
- ◆ \$0B Shut-off valve, EVAP canister (blocked)
- ◆ \$0C Major leak (pressure increase)
- ◆ \$0D Minor leak (leakage volumetric flow)
- ◆ \$0E Micro leak
- ◆ \$11 Shut-off valve, EVAP canister (pressure reduction)
- ◆ \$12 Major leak (pressure sensor)
- ◆ \$13 Major leak (pressure sensor)
- ◆ \$14 Tank vent valve (constantly open)

### TID \$09 coolant thermostat

Output of engine temperature

Display between -48 °C and 143.25 °C

In the case of decimal output, conversion factor = 1

Offset = -48 °C

Decimal value displayed multiplied by 0.75 minus 48 °C gives the coolant temperature.

### Mode 7

The Diagnostic Trouble Codes of all non-shedded, officially relevant\* faults are displayed in Mode 7. This mode has the same structure as Mode 3.

**\* Faults which switch on the Check Engine warning light**

## Mode 9


The following vehicle information is displayed in Mode 9:

- ◆ Vehicle Identification Number
- ◆ Programme status (Calibration Identification Number)
- ◆ Control unit checksum (Calibration Verification Number)



## Connector assignment

### DME control module connector assignment



**I - Connector I, 9-pole**

**II - Connector II, 24-pole**

**III - Connector III, 52-pole**

**IV - Connector IV, 40-pole**

**V - Connector V, 9-pole**

#### Connector I, 9-pole

Pin	Designation	Pin	Designation
1	Terminal 15	6	Ground, output stages
2	Terminal 30	7	Throttle motor actuator
3	W-wire	8	DME relay terminal 87
4	Ground, electronics	9	Throttle motor actuator
5	Ground, fuel injectors		

**Connector II, 24-pole**

Pin	Designation	Pin	Designation
1	Oxygen sensor heating 2 after catalytic converter	13	Oxygen sensor heating 2 ahead of catalytic converter
2	Pump current regulator of oxygen sensor 1 ahead of catalytic converter	14	Signal, oxygen sensor 2 after catalytic converter
3	CAN low (Tiptronic)	15	Signal, oxygen sensor 1 ahead of TWC
4	CAN high (Tiptronic)	16	Signal, oxygen sensor 2 ahead of catalytic converter
5	Pump current regulator of oxygen sensor 1 ahead of catalytic converter	17	Signal, oxygen sensor 1 after catalytic converter
6	Pump current regulator of oxygen sensor 1 ahead of catalytic converter	18	not assigned
7	Oxygen sensor heating 1 after catalytic converter	19	Oxygen sensor heating 1 ahead of catalytic converter
8	Ground, oxygen sensor 2 after catalytic converter	20	not assigned
9	Ground, oxygen sensor 1 after catalytic converter	21	Engine compartment temperature sensor
10	Ground, oxygen sensor 2 after catalytic converter	22	5 V supply for mass air flow sensor
11	Ground, oxygen sensor 1 after catalytic converter	23	not assigned
12	not assigned	24	Pump current regulator of oxygen sensor 2 ahead of catalytic converter

**Connector III, 52-pole**

Pin	Designation	Pin	Designation
1	Valve lift control, cylinder 1 - 3	27	Fuel injector, cylinder 4
2	Fuel injector, cylinder 5	28	Fuel injector, cylinder 6
3	EVAP canister purge valve (closed without flow)	29	not assigned
4	Frequency valve, charge pressure	30	not assigned
5	Oil temperature sensor	31	not assigned
6	not assigned	32	Ground
7	5 V supply for camshaft position? sensor and differential pressure sensor	33	not assigned
8	Signal, throttle position sensor 2	34	Intake air temperature sensor
9	Ground, mass air flow sensor	35	not assigned
10	5 V supply for throttle actuation	36	Input, knock sensor 2

**Connector III, 52-pole**

<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
11	Triggering of secondary air pump relay (terminal 85)	37	Ground, knock sensor 2
12	Signal, camshaft position sensor 1	38	not assigned
13	Start enable, Tiptronic (P + N)	39	Charge pressure sensor
14	Secondary air valve	40	Fuel injector, cylinder 2
15	Fuel injector, cylinder 3	41	Fuel injector, cylinder 1
16	Overrun recirculating air valve	42	not assigned
17	Ground, sensors	43	not assigned
18	Signal, camshaft position sensor 2	44	not assigned
19	Charge control	45	Signal A, speed sensor
20	not assigned	46	
21	not assigned	47	not assigned
22	Engine coolant temperature sensor	48	not assigned
23	Signal, mass air flow sensor	49	Signal B, speed sensor
24	Signal, throttle position sensor 1	50	Ground, knock sensor 1
25	Ground, throttle position sensors 1 + 2	51	not assigned
26	Valve lift control, cylinder 4 - 6	52	Speed signal from ABS control module

**Connector IV, 40-pole**

<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
1	Interlock clutch switch	21	Signal, differential pressure sensor
2	not assigned	22	not assigned
3	not assigned	23	not assigned
4	Coolant fan, stage 1	24	Automatic I/M test
5	not assigned	25	Triggering of engine compartment fan relay (terminal 85)
6	not assigned	26	Triggering of DME relay (terminal 85)
7	Ground, pedal sensor 1	27	Triggering of A/C compressor fan relay (terminal 85)
8	Signal, pedal sensor 1	28	not assigned
9	5 V supply, pedal sensor 1	29	Knocking signal
10	Triggering of fuel pump relay (terminal 85)	30	EVAP canister shutoff valve
11	not assigned	31	Coolant fan, stage 3
12	Ground, pedal sensor 2	32	not assigned
13	Signal, pedal sensor 2	33	Manual transmission start enable

**Connector assignment**

**Connector IV, 40-pole**


<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
14	5 V supply, pedal sensor 2	34	Air conditioning medium pressure switch
15	Ground, differential pressure sensor	35	not assigned
16	Crash signal (airbag)	36	CAN high (PSM and instrument cluster)
17	Speed signal output	37	CAN low (PSM and instrument cluster)
18	not assigned	38	not assigned
19	not assigned	39	not assigned
20	Coolant fan, stage 2	40	Tiptronic coolant shutoff valve

**Connector V, 9-pole**

<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
1	Ignition coil, cylinder 6	6	Ignition coil, cylinder 1
2	Ignition coil, cylinder 4	7	Camshaft adjustment, bank 1
3	Ignition coil, cylinder 2	8	Camshaft adjustment, bank 2
4	Ignition coil, cylinder 5	9	Ignition coil, cylinder 3
5	Ground		

## Connector assignment - 911 Carrera (996)

### DME control module connector assignment



**I - Connector I, 9-pole**

**II - Connector II, 24-pole**

**III - Connector III, 52-pole**

**IV - Connector IV, 40-pole**

**V - Connector V, 9-pole**

#### Connector I, 9-pole

Pin	Designation	Pin	Designation
1	Terminal 15	6	Ground, output stages
2	Terminal 30	7	Throttle motor actuator
3	W-wire	8	DME relay terminal 87
4	Ground, electronics	9	Throttle motor actuator
5	Ground, fuel injectors		

**Connector II, 24-pole**

Pin	Designation	Pin	Designation
1	Oxygen sensor heating 2 after catalytic converter	13	Oxygen sensor heating 2 ahead of catalytic converter
2	not assigned	14	Signal, oxygen sensor 2 after catalytic converter
3	CAN low (Tiptronic)	15	Signal, oxygen sensor 1 ahead of TWC
4	CAN high (Tiptronic)	16	Signal, oxygen sensor 2 ahead of catalytic converter
5	not assigned	17	Signal, oxygen sensor 1 after catalytic converter
6	not assigned	18	not assigned
7	Oxygen sensor heating 1 after catalytic converter	19	Oxygen sensor heating 1 ahead of catalytic converter
8	Ground, oxygen sensor 2 after catalytic converter	20	not assigned
9	Ground, oxygen sensor 1 after catalytic converter	21	Engine compartment temperature sensor
10	Ground, oxygen sensor 2 after catalytic converter	22	5 V supply for mass air flow sensor
11	Ground, oxygen sensor 1 after catalytic converter	23	not assigned
12	not assigned	24	not assigned

**Connector III, 52-pole**

Pin	Designation	Pin	Designation
1	Valve lift control, cylinder 1 - 3	27	Fuel injector, cylinder 4
2	Fuel injector, cylinder 5	28	Fuel injector, cylinder 6
3	EVAP canister purge valve (closed without flow)	29	not assigned
4	not assigned	30	not assigned
5	Oil temperature sensor	31	not assigned
6	not assigned	32	Ground/shield, speed sensor
7	5 V supply for camshaft position sensor and differential pressure sensor	33	not assigned
8	Signal, throttle position sensor 2	34	Intake air temperature sensor
9	Ground, mass air flow sensor	35	not assigned
10	5 V supply for throttle actuation	36	Input, knock sensor 2
11	Triggering of secondary air pump relay (terminal 85)	37	Ground, knock sensor 2

**Connector III, 52-pole**

<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
12	Signal, camshaft position sensor 1	38	not assigned
13	Start enable, Tiptronic (P + N)	39	not assigned
14	Secondary air valve	40	Fuel injector, cylinder 2
15	Fuel injector, cylinder 3	41	Fuel injector, cylinder 1
16	Fuel pump control module	42	not assigned
17	Ground, sensors	43	not assigned
18	Signal, camshaft position sensor 2	44	not assigned
19	not assigned	45	Signal, speed sensor
20	not assigned	46	Ground, speed sensor
21	not assigned	47	not assigned
22	Engine coolant temperature sensor	48	not assigned
23	Signal, mass air flow sensor	49	Signal, knock sensor 1
24	Signal, throttle position sensor 1	50	Ground, knock sensor 1
25	Ground, throttle position sensors 1 + 2	51	not assigned
26	Valve lift control, cylinder 4 - 6	52	Speed signal from ABS control module

**Connector IV, 40-pole**

<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
1	Interlock clutch switch	21	Signal, differential pressure sensor
2	not assigned	22	not assigned
3	not assigned	23	not assigned
4	Coolant fan, stage 1	24	Automatic I/M test
5	not assigned	25	Triggering of engine compartment fan relay (terminal 85)
6	not assigned	26	Triggering of DME relay (terminal 85)
7	Ground, pedal sensor 1	27	Triggering of A/C compressor fan relay (terminal 85)
8	Signal, pedal sensor 1	28	not assigned
9	5 V supply, pedal sensor 1	29	not assigned
10	Triggering of fuel pump relay (terminal 85)	30	EVAP canister shutoff valve
11	not assigned	31	not assigned
12	Ground, pedal sensor 2	32	not assigned
13	Signal, pedal sensor 2	33	Manual transmission start enable
14	5 V supply, pedal sensor 2	34	Air conditioning medium pressure switch

**Connector IV, 40-pole**

<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
15	Ground, differential pressure sensor	35	not assigned
16	Crash signal (airbag)	36	CAN high (PSM and instrument cluster)
17	Speed signal output	37	CAN low (PSM and instrument cluster)
18	not assigned	38	not assigned
19	not assigned	39	not assigned
20	Coolant fan, stage 2	40	Tiptronic coolant shutoff valve

**Connector V, 9-pole**

<b>Pin</b>	<b>Designation</b>	<b>Pin</b>	<b>Designation</b>
1	Ignition coil, cylinder 6	6	Ignition coil, cylinder 1
2	Ignition coil, cylinder 4	7	Camshaft adjustment, bank 1
3	Ignition coil, cylinder 2	8	Camshaft adjustment, bank 2
4	Ignition coil, cylinder 5	9	Ignition coil, cylinder 3
5	Ground		



## Engine specifications

### 911 Turbo (996)

#### Engine

Engine type		M 96/70
Number of cylinders		6
Bore	mm	100
Stroke	mm	76.4
Displacement	cm <sup>3</sup>	3,600
Compression ratio		9.4 : 1
Max. engine power		
as per 80/1269/EWG	kW (HP)	309 (421)
at engine speed	rpm	6,000
Max. torque		
as per 80/1269/EWG	Nm (ftlb.)	560 (414)
at engine speed	rpm	4,600
Max. litre output		
as per 80/1269/EWG	kW/l (HP/l)	85.8 (116.6)
Engine speed limitation		
by		E-gas, ignition control
at	rpm	6,750
Engine idle speed		
Manual transmission	rpm	740 +/- 40
Tiptronic	rpm	740 +/- 40

#### Engine design

Type	6-cylinder aluminium opposed-cylinder engine, water-cooled, bi-turbo
Valve arrangement	2 intake, 2 exhaust, suspended in parallel V arrangement
Valve control	Via flat-base tappets
Valve clearance	Hydraulic valve clearance compensation

Valve timing with 1 mm valve lift and zero clearance, basic inlet camshaft setting early

Inlet opens	10° before TDC
Inlet closes	20° after BDC
Exhaust opens	41° before BDC
Exhaust closes	9° before TDC

#### Engine cooling

Type	Liquid cooling, three radiators (Tiptronic additional radiator) two electric fans, three-stage control
------	---

#### Engine lubrication

Type	Dry sump lubrication with separate tank	
Oil cooling	Via oil-water heat exchanger	
Oil pressure	rpm	Approx. 6.5 bar at 90 °C
Oil consumption	Up to 1.0 l/1,000 km	

#### Emission control

EURO III	Stereo oxygen sensor closed-loop control and 3-way catalytic converter system with one 2-stage catalytic converter each on the left and right, secondary-air system and European OBD
USA LEV	Stereo oxygen sensor closed-loop control and 3-way catalytic converter system with one 2-stage catalytic converter each on the left and right, secondary-air system and OBD II and ORVR

#### Fuel system

Fuel injection	ME 7.8 (digital engine electronics) Triggering of injection sequential
Fuel supply	1 electrical internal gear pump with 2 additional sucking jet pumps

## Required fuel

Fuel quality (RON) 98 unleaded

## Electrical system

Nominal voltage	V	12
Battery capacity	Ah	80
Generator output	W	1,680 (three-phase generator)
Ignition		DME with stationary high-voltage distribution and cylinder-selective knock control
Firing order		1 - 6 - 2 - 4 - 3 - 5
Ignition angle control		Via DME
Spark plugs		Bosch FR5 LDC Beru 14 FR 5 LDU
Electrode gap	mm	1.6 +/- 0.2

## Load values of the 911 Turbo (996)

	Mass air flow ML in kg/h	CLV in %
Idle speed	16 - 20	1.45 - 1.82
No load, n=3,000 rpm	60 - 80	5.45 - 7.27

CLV = ML/MLMAX \* 100, with MLMAX = 1100 kg/h

## Test conditions

- ◆ Engine temperature higher than 90 °C
- ◆ Ambient temperature 20 °C
- ◆ No loads switched on



## Engine specifications

### 911 Carrera (996)

#### Engine

Engine type		M 96/03
Number of cylinders		6
Bore	mm	96
Stroke	mm	82.8
Displacement	cm <sup>3</sup>	3,596
Compression ratio		11.3 : 1
Max. engine power		
as per 80/1269/EWG	kW (HP)	235 (320)
at engine speed	rpm	6,800
Max. torque		
as per 80/1269/EWG	Nm (ftlb.)	370 (274)
at engine speed	rpm	4,250
Max. litre output		
as per 80/1269/EWG	kW/l (HP/l)	65.4 (88.9)
Engine speed limitation		
by		E-gas, fuel cutoff
at	rpm	7,300
Engine idle speed	rpm	670 +/- 40 without air conditioning

#### Engine design

Type		6-cylinder aluminium opposed-cylinder engine, water-cooled
Valve arrangement		2 intake, 2 exhaust, suspended in parallel V arrangement
Valve control	Inlet	via switchable flat-base tappets
	Exhaust	via flat-base tappets
Valve clearance		Hydraulic valve clearance compensation
Valve timing in late position with 1 mm valve lift and zero clearance		

	large valve	small valve lift
Inlet opens	9° after TDC	39° after TDC
Inlet closes	61° after BDC	19° after BDC
Exhaust opens	50° before BDC	
Exhaust closes	4° before TDC	
Engine cooling		
Type		Liquid cooling, two radiators (Tiptronic additional radiator) two electric fans, two-stage control
Engine lubrication		
Type		integrated dry sump lubrication
Oil cooling		via oil-water heat exchanger
Oil pressure	n=5,000 rpm	Approx. 6.5 bar at 90 °C
Oil consumption		Up to 0.5 l/1,000 km
Emission control		
EURO II		Oxygen sensing with 2 sensors before the catalytic converter, 3-way catalytic converter system with one TWC each on the left and the right (RoW)
EURO III		Additional secondary air system and sensing after the TWC (4 sensors) European OBD
USA LEV	OBD II + ORVR	Oxygen sensing and sensing after the TWC (4 sensors), 3-way catalytic converter system with one cascade catalytic converter each on the left and right (with two metal carriers), secondary-air system, OBD II and ORVR
Fuel system		
Fuel injection		ME 7.8 (digital engine electronics) Triggering of injection sequential
Fuel supply		1 electric pump, non-return

## Required fuel

Fuel quality (RON) 98 unleaded

## Electrical system

Nominal voltage	V	12
Battery capacity	Ah	80
Generator output	W	1,680 (three-phase generator)
Ignition		DME, single-spark coil, cylinder-selective knock control
Firing order		1 - 6 - 2 - 4 - 3 - 5
Ignition angle control		Via DME
Spark plugs		Bosch FGR 6 KQC Beru? 14-FGR 6 KQU
Electrode gap	mm	1.6 +/- 0.2

## 911 Carrera (996) load values

	Mass air flow ML in kg/h	CLV in %
Idle speed	15 - 20	1.74 - 2.33
No load, n=3,000 rpm	50 - 70	5.81 - 8.14

CLV = ML/MLMAX \* 100, with MLMAX = 860 kg/h

## Test conditions

- ◆ Engine temperature higher than 90 °C
- ◆ Ambient temperature 20 °C
- ◆ No loads switched on
- ◆ Vehicle adapted





## Control module function

### CONTROL UNIT PROGRAMMING

Four sub-menus are offered with this menu item:

#### 1. Read out control unit (vehicle data)

- ◆ The menu item "Read out control unit" can be used to read out data from the old control module, e.g. engine number, M numbers etc., in order to adopt the data in a new control module.



#### Note!

*Only one control module at a time can be read out in order to then adopt the data in a new control module during control module programming.*



#### Note!

*The DME programming code and immobilizer code are required to program control modules. These codes can be obtained from the Porsche IPAS system. All electrical consumers must be switched off for programming control modules. Switch heater to OFF. The vehicle battery must be fully charged.*

#### 2. Program control unit (new control unit)

- ◆ Enter vehicle identification number and confirm.
- ◆ Enter and confirm new programming code.



#### Note!

*The new programming code must match the DME programming code from the IPAS, otherwise the control module can no longer be programmed later.*

- ◆ Enter and confirm new immobilizer code.



#### Note!

*The new immobilizer code must match the immobilizer code from the IPAS, otherwise the control module can no longer be programmed later.*

- ◆ Select data record.
- ◆ When programming is complete, switch off the ignition.
- ◆ Switch on the ignition.
- ◆ Switch off the tester.

**Note!**

*In Tiptronic vehicles, the fault memory of the Tiptronic must be erased following the programming of a DME control module, as the fault "CAN timeout" is entered in the memory during programming.*

**3. Program map/data**

- ◆ The data record can be changed, e.g. from RoW to OBD II, with this menu item. Only the DME programming code is required.

**4. Program immobilizer code**

- ◆ The immobilizer code is transferred to a new DME control module with this menu item.

Data record M150 must be programmed for the following countries:

- ◆ Russia
- ◆ Cyprus
- ◆ Brazil
- ◆ Equador
- ◆ Middle East (for all connected markets)
- ◆ Costa Rica
- ◆ Venezuela
- ◆ Columbia
- ◆ Peru
- ◆ Mexico
- ◆ China

## Fault overview of 911 (996) Turbo model year 2001 only



### Note!

- ◆ Please note: This fault code overview only applies to the 911 (996) Turbo model year 2001.
- ◆ For the Turbo as of model year 2002, some fault codes have been renamed in order to implement the changed standards of the Californian environmental agency.
- ◆ The model year allocation refers to the program and data status in the DME control module.
- To be certain that a fault is no longer present after a repair or clearing of the fault memory, a short test or test drive should be carried out. This is the only way of ensuring that all diagnosis routines of the DME control module have been performed.
- In the case of Tiptronic faults, the fault memory of the Tiptronic must also be read out for diagnosis/troubleshooting.
- After a repair, the fault memory must always be cleared.

Fault type 1: Signal implausible/implausible operating range/malfunction

Fault type 2: Open circuit/no signal

Fault type 3: Ground short/below lower limit/lean limit

Fault type 4: Short circuit to B+ /above upper limit/rich limit

\*: In the case of misfire faults, the fault types have a different meaning.

Fault type 1: Emission-related fault after starting

Fault type 3: Emission-related fault during journey

Fault type 4: Fault damaging to catalytic converter

\*\* : In the case of oxygen sensor faults, the fault types have a different meaning.

Fault type 1: All electrical faults (open circuit, short circuit to B+ or ground) cause this fault output

Fault type 2: Interference from the oxygen sensor heater in the sensor signal

Fault type 3: Oxygen sensor aging fault, sensor dynamic response

Fault type 4: Oxygen sensor aging fault, sensor contamination and shift of characteristic

CE	Check Engine warning light
0	Function switched off
1	CE flashes, fault damaging to catalytic converter
2	CE ON, emission-related fault
3	CE ON after two driving cycles
6	CE OFF, fault not emission-related
7	Fault caused by short test
11	Fuel supply fault, CE ON after two driving cycles, higher freeze frame priority
30	CE ON after three driving cycles
31	CE ON after three driving cycles with misfires
33	Fuel supply fault, CE ON after three driving cycles, higher freeze frame priority

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Hot film mass air flow meter			P0102	P0103	3/6/6
Ambient pressure sensor			P0107	P0108	3/6/6
Air intake temperature sensor			P0112	P0113	3/6/6
Engine temperature sensor	P0115	P0117	P0117	P0118	3/6/6
Throttle	P0121				6/6/6
Oxygen sensor in front of catalytic converter, bank 1	P0130**	P0134**	P0133**	P0132**	3/30/6
Oxygen sensor after catalytic converter, bank 1	P0136	P0140		P0138	3/6/6
Oxygen sensor aging after catalytic converter, bank 1			P0139	P0139	3/6/6
Oxygen sensor heater after catalytic converter, bank 1		P0141	P0141	P0141	3/6/6
Oxygen sensor in front of catalytic converter Bank 2	P0150**	P0154**	P0153**	P0152**	3/30/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Oxygen sensor after catalytic converter, bank 2	P0156	P0160		P0158	3/6/6
Oxygen sensor aging after catalytic converter, bank 2			P0159	P0159	3/6/6
Oxygen sensor heater after catalytic converter, bank 2		P0161	P0161	P0161	3/6/6
Oil temperature sensor			P0197	P0198	6/6/6
Pressure sensor, boost			P0237	P0238	6/6/6
Misfire detection (total)	P0300*		P0300*	P0300*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 1	P0301*		P0301*	P0301*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 2	P0302*		P0302*	P0302*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 3	P0303*		P0303*	P0303*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 4	P0304*		P0304*	P0304*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 5	P0305*		P0305*	P0305*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 6	P0306*		P0306*	P0306*	1 - 2/1 - 31/1 - 31
Knock sensor 1			P0327	P0328	6/6/6
Knock sensor 2			P0332	P0333	6/6/6
Engine speed sensor signal		P0336			3/6/6
Hall sensor 1	P0341	P0344	P0342	P0343	3/6/6
Secondary air system Bank 1	P0410				3/6/0
Electric switch-over valve		P0413	P0414	P0414	3/6/0
Secondary air pump		P0418	P0418	P0418	3/6/0
Catalytic conversion Bank 1				P0420	3/30/0
Catalytic conversion Bank 2				P0430	3/30/0

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Fuel tank ventilation system (DTE SK)				P0440	3/-/-
Fuel tank ventilation system (DTE V)				P0441	-/6/6
Fuel tank ventilation system (fine leak)			P0442		3/0/0
Tank vent valve		P0444	P0445	P0445	3/30/6
Activated charcoal filter shutoff valve (function)			P0446		3/0/0
Activated charcoal filter shutoff valve (driver)		P0447	P0448	P0448	3/0/0
Pressure sensor, tank	P0450		P0452	P0453	3/0/0
Fuel tank ventilation system (big leak)	P0455		P0455		3/0/0
Driver for blower 1		P0480	P0480	P0480	6/6/6
Driver for blower 2		P0481	P0481	P0481	6/6/6
Driver for blower 3		P0482	P0482	P0482	6/6/6
Vehicle speed		P0501			3/6/6
Idle speed control at the stop			P0506	P0507	3/6/6
Supply voltage	P0560		P0562	P0563	3/6/3
CAN timeout Tiptronic		P0600			3/6/6
EEPROM fault	P0603	P0603	P0603	P0603	6/30/6
Control module faulty (RAM)	P0604				3/30/6
Control module faulty (ROM)	P0605				3/30/6
Check Engine lamp, open circuit (via CAN)		P0650			6/6/6
Tiptronic (CAN transfer box setting implausible)	P0700				3/6/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Tiptronic (Gear implausible/transmission slips)	P0701				3/6/6
Tiptronic control unit faulty	P0702				3/6/6
Tiptronic (Selector lever position implausible)	P0706				3/32/6
Tiptronic (Supply voltage of speed sensors)	P0715				3/6/6
Tiptronic (CAN: wheel speed rear right)	P0720				3/6/6
Tiptronic (Gear comparison negative)	P0730				3/6/6
Tiptronic (Converter lockup clutch)	P0740				6/6/6
Tiptronic (Converter lockup solenoid valve)	P0743				3/6/6
Tiptronic (Control solenoid valve, modulating pressure)	P0748				3/6/6
Tiptronic (Solenoid valve, 1-2/4-5 gearshift)	P0753				3/6/6
Tiptronic (Solenoid valve, 2-3 gearshift)	P0758				3/6/6
Tiptronic (Solenoid valve 3-4 gearshift)	P0763				3/ 6/ 6
Input values, cylinder fill measurement			P1101	P1101	3/6/6
Oxygen sensors interchanged in front of catalytic converter	P1110				3/30/6
LSU heater, load interruption	P1114				3/6/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Oxygen sensor heater in front of catalytic con- verter, bank 1	P1115	P1115	P1115	P1115	3/30/6
LSU heater, bank 2 Load interruption	P1116				3/6/6
Oxygen sensor heater after catalytic con- verter, bank 1	P1117				3/6/0
Oxygen sensor heater after catalytic con- verter, bank 2	P1118				3/6/0
Oxygen sensor heater in front of catalytic con- verter, bank 2	P1119	P1119	P1119	P1119	3/30/6
Throttle potentiometer 1	P1121		P1121	P1121	6/6/6
Throttle potentiometer 2	P1122		P1122	P1122	6/6/6
Fuel pump relay driver		P1124	P1124	P1124	6/6/6
Oxygen sensor closed- loop control adapta- tion upper load range, bank 1			P1125	P1125	11/33/6
Oxygen sensor closed- loop control adapta- tion lower load range, bank 1			P1126	P1126	11/33/6
Oxygen control devia- tion by short test, bank 1			P1127	P1127	7/7/7
Oxygen sensor closed- loop control adapta- tion Idle speed range, bank 1			P1128	P1128	11/33/6
Oxygen sensor closed- loop control adapta- tion Idle speed range, bank 2			P1130	P1130	11/33/6
Oxygen sensor closed- loop control upper load range, bank 2			P1132	P1132	11/33/6



<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Oxygen sensor closed-loop control lower load range, bank 2			P1133	P1133	11/33/6
Oxygen control deviation by short test, bank 2			P1134	P1134	7/7/7
Pressure comparison Boost pressure v. ambient	P1136				6/6/6
Clutch switch	P1137				6/6/6
Engine compartment temperature sensor			P1157	P1158	6/6/6
Injection valve of cylinder 1		P1237	P1225	P1213	3/30/6
Injection valve of cylinder 6		P1238	P1226	P1214	3/30/6
Injection valve of cylinder 2		P1239	P1227	P1215	3/30/6
Injection valve of cylinder 4		P1240	P1228	P1216	3/30/6
Injection valve of cylinder 3		P1241	P1229	P1217	3/30/6
Injection valve of cylinder 5		P1242	P1230	P1218	3/30/6
Accelerator pedal	P1219				6/6/6
Boost pressure control			P1249	P1249	6/6/6
Boost pressure characteristic, Above Upper Limit				P1255	6/6/6
Signal from airbag	P1265				6/6/6
Function monitoring Fuel cutoff	P1266				3/30/6
Position of camshaft relative to crankshaft, bank 2			P1324	P1324	3/6/6
Camshaft adjustment Bank 2	P1325		P1325	P1325	3/6/6
Position of camshaft relative to crankshaft, bank 1			P1340	P1340	3/6/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Camshaft adjustment Bank 1	P1341		P1341	P1341	3/6/6
Camshaft adjustment bank 1 driver		P1342	P1342	P1342	3/6/6
Camshaft adjustment bank 2 driver		P1343	P1343	P1343	3/6/6
Valve lift control driver Bank 1		P1344	P1344	P1344	3/6/6
Valve lift control driver Bank 2		P1345	P1345	P1345	3/6/6
Valve lift control parity check error	P1350		P1350	P1350	6/6/6
Valve lift control, cylin- der 1	P1351		P1351	P1351	6/6/6
Valve lift control, cylin- der 6	P1352		P1352	P1352	6/6/6
Valve lift control, cylin- der 2	P1353		P1353	P1353	6/6/6
Valve lift control, cylin- der 4	P1354		P1354	P1354	6/6/6
Valve lift control, cylin- der 3	P1355		P1355	P1355	6/6/6
Valve lift control, cylin- der 5	P1356		P1356	P1356	6/6/6
Knock control zero test	P1384				6/6/6
Knock control offset	P1385				6/6/6
Knock control test pulse	P1386				6/6/6
Hall sensor 2	P1397		P1397	P1397	3/6/6
Secondary air system Bank 2	P1411				3/6/0
Air conditioning com- pressor control		P1455	P1457	P1456	6/6/6
Throttle adjusting unit Driver	P1501				3/30/6
Throttle adjusting unit Spring check				P1502	3/30/6
Throttle adjusting unit Positional deviation	P1503				3/30/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
Throttle adjusting unit Emergency air position	P1504				6/6/6
Throttle adjusting unit Control range		P1505	P1505	P1505	3/30/6
Throttle adjusting unit Lower mechanical stop	P1506				3/30/6
Throttle adjusting unit Amplifier balance	P1507				6/30/6
Function monitoring Torque comparison	P1508				3/6/6
Torque limitation				P1509	6/6/6
Throttle adjusting unit Replacement detec- tion without adapta- tion	P1510				6/30/6
Throttle adjustment unit Abortion of test through violation of environmen- tal condition			P1511	P1511	3/6/30
Ambient temperature (from instrument cluster via CAN)	P1512				6/6/6
Throttle adjusting unit Spring test opening			P1513	P1513	3/30/6
Throttle adjusting unit Relearn lower mechani- cal stop	P1514				6/30/6
Boost pressure control valve Driver		P1548	P1547	P1546	6/6/6
Immobilizer	P1570	P1571			6/6/6
Stop light switch	P1574				6/6/6
Cruise control standby light via CAN		P1576			6/6/6
Accelerator pedal Potentiometer 1	P1577		P1577	P1577	6/6/6
Accelerator pedal Potentiometer 2	P1578		P1578	P1578	6/6/6
Reference mark sensor	P1579				3/6/6
CAN timeout PSM		P1600			3/6/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/ EU3/ M150</b>
CAN timeout Instrument cluster	P1601	P1601			6/6/6
Coolant shutoff valve		P1656	P1656	P1656	6/6/6
Driver for ambient air valve		P1657	P1657	P1657	6/6/6
Control module faulty (watchdog: Reset)	P1671				3/30/6
Driver for engine com- partment purge fan		P1674	P1674	P1674	6/6/6
Engine scavenge blower fault				P1675	6/6/6
Tiptronic (Supply voltage of valves or selector lever)	P1702				3/6/6
Tiptronic (Control solenoid valve, shifting pressure)	P1748				3/6/6

## Fault overview of 911 Carrera (996) as of model year '02



### Note!

- ◆ *This fault code overview is for the 911 (996) Carrera as of model year 2002 and the Boxster (986) as of model year 2003.*
- ◆ *The turbo versions for model year 2001 and as of model year 2002 have separate fault code tables which differ in some respects from this table.*
- To be certain that a fault is no longer present after a repair or clearing of the fault memory, a short test or test drive should be carried out. This is the only way of ensuring that all diagnosis routines of the DME control module have been performed.
- For Boxster (986) Tiptronic vehicles, the fault memory of the Tiptronic control unit must also be read out, because switching on of the Check Engine warning light may also have been initiated by the Tiptronic.
- After a repair, the fault memory must always be cleared.

Fault type 1: Signal implausible/implausible operating range/malfunction

Fault type 2: Open circuit/no signal

Fault type 3: Ground short/below lower limit/lean limit

Fault type 4: Short circuit to B+ /above upper limit/rich limit

\*: In the case of misfire faults, the fault types have a different meaning.

Fault type 1: Emission-related fault after starting

Fault type 3: Emission-related fault during journey

Fault type 4: Fault damaging to catalytic converter

CE Check Engine warning light

0 Function switched off

1 CE flashes, fault damaging to catalytic converter

2 CE ON, emission-related fault

3 CE ON after two driving cycles

4 CE ON after five seconds

5 CE OFF, fault output on scan tool

6	CE OFF, fault not emission-related
7	Fault caused by short test
11	Fuel supply fault, CE ON after two driving cycles, higher freeze frame priority
30	CE ON after three driving cycles
31	CE ON after three driving cycles with misfires
32	CE OFF, fault output on scan tool after three driving cycles
33	Fuel supply fault, CE ON after three driving cycles, higher freeze frame priority

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Position of camshaft relative to crankshaft, bank 1			P0011	P0012	3/32/32
Position of camshaft relative to crankshaft, bank 2			P0021	P0022	3/32/32
Valve lift control driver Bank 1		P0026	P0026	P0026	3/30/32
Valve lift control driver Bank 2		P0028	P0028	P0028	3/30/32
Oxygen sensor heater in front of catalytic converter, bank 1		P0030	P0031	P0032	3/30/0
Oxygen sensor heater after catalytic converter, bank 1		P0036	P0037	P0038	3/6/0
Oxygen sensor heater in front of catalytic converter, bank 2		P0050	P0051	P0052	3/30/0
Oxygen sensor heater after catalytic converter, bank 2		P0056	P0057	P0058	3/6/0
Ambient temperature (from instrument cluster via CAN)	P0071				6/6/6
Hot film mass air flow meter			P0102	P0103	3/32/32
Air intake temperature sensor			P0112	P0113	3/32/32
Engine temperature sensor	P0116	P0125	P0117	P0118	3/32/32
Accelerator pedal Potentiometer 1	P0121		P0122	P0123	5/32/32
Blocked thermostat	P0128				3/32/32
Oxygen sensor in front of catalytic converter, bank 1	P0130	P0134	P0131	P0132	3/30/6
Oxygen sensor aging period, bank 1				P0133	3/30/6
Oxygen sensor heater in front of catalytic converter, bank 1	P0135				

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Oxygen sensor aging after catalytic converter, bank 1			P0139	P0136	3/30/0
Oxygen sensor after catalytic converter, bank 1		P0140	P0137	P0138	3/30/0
Oxygen sensor heater after catalytic converter, bank 1	P0141				3/30/0
Oxygen sensor in front of catalytic converter Bank 2	P0150	P0154	P0151	P0152	3/30/6
Oxygen sensor aging period, bank 2				P0153	3/30/6
Oxygen sensor heater in front of catalytic converter, bank 2	P0155				
Oxygen sensor aging after catalytic converter, bank 2			P0159	P0156	3/30/0
Oxygen sensor after catalytic converter, bank 2		P0160	P0157	P0158	3/30/0
Oxygen sensor heater after catalytic converter, bank 2	P0161				3/30/0
Oxygen sensor closed-loop control adaptation Idle speed range, bank 1			P0172	P0171	11/33/6
Oxygen sensor closed-loop control adaptation Idle speed range, bank 2			P0175	P0174	11/33/6
Oil temperature sensor			P0197	P0198	6/6/6
Injection valve of cylinder 1		P0201	P0261	P0262	3/30/32
Injection valve of cylinder 2		P0202	P0264	P0265	3/30/32
Injection valve of cylinder 3		P0203	P0267	P0268	3/30/32
Injection valve of cylinder 4		P0204	P0270	P0271	3/30/32
Injection valve of cylinder 5		P0205	P0273	P0274	3/30/32
Injection valve of cylinder 6		P0206	P0276	P0277	3/30/32
Accelerator pedal Potentiometer 2	P0221		P0222	P0223	5/32/32
Fuel pump relay driver		P0230	P0230	P0230	6/6/6
Misfire detection (total)	P0300*		P0300*	P0300*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 1	P0301*		P0301*	P0301*	1 - 2/1 - 31/1 - 31

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Misfire detection Cylinder 2	P0302*		P0302*	P0302*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 3	P0303*		P0303*	P0303*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 4	P0304*		P0304*	P0304*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 5	P0305*		P0305*	P0305*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 6	P0306*		P0306*	P0306*	1 - 2/1 - 31/1 - 31
Knock control zero test	P0324				5/6/6
Knock sensor 1			P0327	P0328	5/6/6
Knock sensor 2			P0332	P0333	5/6/6
Engine speed sensor signal		P0335			3/32/32
Reference mark sensor	P0336				3/32/6
Hall sensor 1	P0341	P0344	P0342	P0343	3/32/32
Hall sensor 2	P0346	P0349	P0347	P0348	3/32/32
Electric switch-over valve		P0413	P0414	P0414	3/32/0
Secondary air pump		P0418	P0418	P0418	3/32/0
Catalytic conversion Bank 1				P0420	3/30/0
Catalytic conversion Bank 2				P0430	3/30/0
Fuel tank ventilation system (DTESK)				P0440	3/0/0
Fuel tank ventilation system (DTEV)			P0441	P0441	0/32/32
Fuel tank ventilation system (fine leak)			P0442		3/0/0
Tank vent valve		P0444	P0445	P0445	3/30/32
Activated charcoal filter shutoff valve (function)			P0446		3/0/0
Activated charcoal filter shutoff valve (driver)		P0447	P0448	P0448	3/0/0
Fuel tank ventilation system (big leak)	P0450		P0455		3/0/0
Pressure sensor tank	P0451		P0452	P0453	3/0/0



<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Fuel tank ventilation system (small leak)			P0456		3/0/0
Driver for blower 1		P0480	P0480	P0480	6/6/6
Driver for blower 2		P0481	P0481	P0481	6/6/6
Secondary air system Bank 1			P0491		3/32/0
Secondary air system Bank 2			P0492		3/32/0
Vehicle speed		P0503			3/6/6
Idle speed control at the stop			P0506	P0507	3/32/32
Immobilizer	P0513	P0513			6/6/6
Supply voltage	P0560		P0562	P0563	3/6/6
Stop light switch	P0571				6/6/6
CAN timeout Tiptronic		P0600			3/32/6
DME relay/control module faulty (watchdog: Reset)	P0601				6/6/6
EEPROM fault	P0603	P0603	P0603	P0603	6/6/6
Control module faulty (RAM)	P0604				5/32/32
Control module faulty (ROM)	P0605				5/32/32
Control module faulty (watchdog: Reset)	P0607				5/32/32
Throttle adjusting unit Positional deviation	P0638				4/4/4
Air conditioning compressor control		P0645	P0646	P0674	6/6/6
Check Engine lamp, open circuit (via CAN)		P0650			5/32/32
Electric switch-over valve for intake pipe switching		P0660	P0661	P0662	6/6/6
Tiptronic (CAN transfer box setting implausible)	P0700				3/32/6
Tiptronic (Gear implausible/transmission slips)	P0701				3/32/6
Tiptronic control unit faulty	P0702				3/32/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Tiptronic (Supply voltage of speed sensors)	P0715				3/32/6
Tiptronic (CAN: wheel speed rear right)	P0720				3/32/6
Tiptronic (Gear comparison negative)	P0730				3/32/6
Tiptronic (Converter lockup clutch)	P0740				6/32/6
Tiptronic (Converter lockup clutch solenoid valve)	P0743				3/32/6
Tiptronic (Control solenoid valve, modulating pressure)	P0748				3/32/6
Tiptronic (Solenoid valve, 1-2/4-5 gearshift)	P0753				3/32/6
Tiptronic (Solenoid valve, 2-3 gearshift)	P0758				3/32/6
Tiptronic (Solenoid valve 3-4 gearshift)	P0763				3/32/6
Tiptronic (Control solenoid valve, shifting pressure)	P0778				3/32/6
Clutch switch	P0830				6/6/6
Input values, cylinder fill measurement			P1101	P1109	6/6/6
Ambient pressure sensor			P1103	P1102	3/32/32
Oxygen sensor closed-loop control adaptation upper load range, bank 1			P1105	P1125	11/33/32
Oxygen sensor closed-loop control upper load range, bank 2			P1106	P1132	11/33/32
Oxygen sensor closed-loop control adaptation lower load range, bank 1			P1107	P1126	11/33/32
Oxygen sensor closed-loop control lower load range, bank 2			P1108	P1133	11/33/32
Throttle	P1120				5/32/32
Throttle potentiometer 1	P1121		P1139	P1138	5/32/32
Throttle potentiometer 2	P1122		P1141	P1140	5/32/32

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Oxygen control deviation by short test, bank 1			P1127	P1142	7/7/7
Oxygen control deviation by short test, bank 2			P1134	P1143	7/7/7
Engine compartment temperature sensor			P1157	P1158	6/6/6
Oxygen sensor after catalytic converter, bank 1	P1159				
Oxygen sensor after catalytic converter, bank 2	P1160				
Signal from airbag	P1265				6/6/6
Function monitoring Fuel cutoff	P1266				4/4/4
Inlet camshaft, bank 2	P1325				5/32/32
Inlet camshaft driver		P1328	P2088	P2089	3/30/32
Inlet camshaft driver, bank 2		P1331	P2092	P2093	3/30/32
Inlet camshaft	P1341				5/32/32
Valve lift control parity check error	P1350		P1374	P1371	6/6/6
Valve lift control, cylinder 1			P1351	P1359	6/6/6
Valve lift control, cylinder 6			P1352	P1360	6/6/6
Valve lift control, cylinder 2			P1353	P1361	6/6/6
Valve lift control, cylinder 4			P1354	P1362	6/6/6
Valve lift control, cylinder 3			P1355	P1363	6/6/6
Valve lift control, cylinder 5			P1356	P1364	6/6/6
Knock control offset	P1385				5/6/6
Knock control test pulse	P1386				5/6/6
Throttle adjusting unit Driver	P1501				4/4/4
Throttle adjusting unit Spring check				P1502	4/4/4
Throttle adjusting unit Emergency air position	P1504				6/6/6
Throttle adjusting unit Control range		P1505	P1518	P1516	4/4/4
Throttle adjusting unit Lower mechanical stop	P1506				4/4/4
Throttle adjusting unit Amplifier balance	P1507				6/6/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Function monitoring Torque comparison	P1508				4/4/4
Torque limitation				P1509	5/32/32
Throttle adjusting unit Replacement detection without adaptation	P1510				4/4/4
Throttle adjustment unit Abortion of test through violation of environmental condition			P1511	P1517	6/6/6
Throttle adjusting unit Spring test opening			P1513	P1515	4/4/4
Throttle adjusting unit Relearn lower mechanical stop	P1514				6/6/6
Pedal value sensor movement	P1575				6/6/6
Cruise control standby light via CAN		P1576			6/6/6
CAN timeout PSM		P1600			6/6/6
CAN timeout Instrument cluster	P1602	P1601			6/6/6
Coolant shutoff valve		P1656	P1655	P1654	6/6/6
Driver for engine compartment purge fan		P1674	P1677	P1676	6/6/6
Engine scavenge blower fault				P1675	6/6/6
Tiptronic (Supply voltage of valves or selector lever)	P1702				3/32/6
Oxygen sensor aging delay time, bank 1			P2097	P2096	3/30/0
Oxygen sensor aging delay time, bank 2			P2099	P2098	3/30/0
Accelerator pedal	P2135				5/32/32

## Fault overview of 911 Turbo (996) and GT 2 as of model year '02

### **Note!**

- ◆ *Please note: This fault code overview only applies to the 911 (996) Turbo and GT2 as of model year 2002.*
- ◆ *For the Turbo up to and including model year 2001, there are separate fault code tables, which differ in some respects from this table. Some fault codes have been renamed in order to implement the changed standards of the Californian environmental agency.*
- ◆ *The model year allocation refers to the program and data status in the DME control module.*
- To be certain that a fault is no longer present after a repair or clearing of the fault memory, a short test or test drive should be carried out. This is the only way of ensuring that all diagnosis routines of the DME control module have been performed.
- In the case of Tiptronic faults, the fault memory of the Tiptronic must also be read out for diagnosis/troubleshooting.
- After a repair, the fault memory must always be cleared.

Fault type 1: Signal implausible/implausible operating range/malfunction

Fault type 2: Open circuit/no signal

Fault type 3: Ground short/below lower limit/lean limit

Fault type 4: Short circuit to B+ /above upper limit/rich limit

\*: In the case of misfire faults, the fault types have a different meaning.

Fault type 1: Emission-related fault after starting

Fault type 3: Emission-related fault during journey

Fault type 4: Fault damaging to catalytic converter

\*\*:

In the case of oxygen sensor faults, the fault types have a different meaning.

Fault type 1: All electrical faults (open circuit, short circuit to B+ or ground) cause this fault output

Fault type 2: Interference from the oxygen sensor heater in the sensor signal

Fault type 3: Oxygen sensor aging fault, sensor dynamic response

Fault type 4: Oxygen sensor aging fault, sensor contamination and shift of characteristic

CE	Check Engine warning light
0	Function switched off
1	CE flashes, fault damaging to catalytic converter
2	CE ON, emission-related fault
3	CE ON after two driving cycles
4	CE ON after five seconds
5	CE OFF, fault output on Scan Tool
6	CE OFF, fault not emission-related
7	Fault caused by short test
11	Fuel supply fault, CE ON after two driving cycles, higher freeze frame priority
30	CE ON after three driving cycles
31	CE ON after three driving cycles with misfires
32	CE OFF, fault output on Scan Tool after three driving cycles
33	Fuel supply fault, CE ON after three driving cycles, higher freeze frame priority

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Position of camshaft relative to crankshaft, bank 1			P0011	P0012	3/32/32
Inlet camshaft driver		P0013	P0013	P0013	3/32/32
Position of camshaft relative to crankshaft, bank 2			P0021	P0022	3/32/32
Inlet camshaft driver, bank 2		P0023	P0023	P0023	3/32/32
Valve lift control driver Bank 1	P0026		P0026	P0026	3/30/32
Valve lift control driver Bank 2	P0028		P0028	P0028	3/30/32
Oxygen sensor heater in front of catalytic converter, bank 1		P0030	P0031	P0032	3/30/0
Oxygen sensor heater after catalytic converter, bank 1		P0036	P0037	P0038	3/30/0
Oxygen sensors interchanged in front of catalytic converter	P0040				
Boost pressure control valve Driver		P0045	P0047	P0048	5/32/32
Oxygen sensor heater in front of catalytic converter, bank 2		P0050	P0051	P0052	3/30/0

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Oxygen sensor heater after catalytic converter, bank 2		P0056	P0057	P0058	3/30/0
Ambient temperature (from instrument cluster via CAN)	P0071				6/6/6
Hot film mass air flow meter			P0102	P0103	3/32/32
Air intake temperature sensor			P0112	P0113	3/32/32
Engine temperature sensor	P0116	P0125	P0117	P0118	3/32/32
Accelerator pedal Potentiometer 1	P0121		P0122	P0123	5/32/32
Blocked thermostat	P0128				3/32/32
Ambient pressure sensor			P0129		3/32/32
Oxygen sensor in front of catalytic converter, bank 1	P0130**		P0133**		3/30/6
Oxygen sensor heater in front of catalytic converter, bank 1	P0135				3/30/0
Oxygen sensor aging after catalytic converter, bank 1			P0136	P0136	3/30/0
Oxygen sensor after catalytic converter, bank 1		P0140	P0137	P0138	3/30/6
Oxygen sensor heater after catalytic converter	P0141				3/6/0
Oxygen sensor in front of catalytic converter Bank 2	P0150**		P0153**		3/30/6
Oxygen sensor heater in front of catalytic converter, bank 2	P0155				3/30/0
Oxygen sensor aging after catalytic converter, bank 2			P0156	P0156	3/30/0
Oxygen sensor after catalytic converter, bank 2		P0160	P0157	P0158	3/30/6
Oxygen sensor heater after catalytic converter, bank 2	P0161				3/6/0
Oxygen sensor closed-loop control adaptation Idle speed range, bank 1			P0172	P0171	11/33/6
Oxygen sensor closed-loop control adaptation Idle speed range, bank 2			P0175	P0174	11/33/6
Oil temperature sensor			P0197	P0198	6/6/6
Injection valve of cylinder 1		P0201	P0261	P0262	3/30/32

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Injection valve of cylinder 2		P0202	P0264	P0265	3/30/32
Injection valve of cylinder 3		P0203	P0267	P0268	3/30/32
Injection valve of cylinder 4		P0204	P0270	P0271	3/30/32
Injection valve of cylinder 5		P0205	P0273	P0274	3/30/32
Injection valve of cylinder 6		P0206	P0276	P0277	3/30/32
Accelerator pedal Potentiometer 2	P0221		P0222	P0223	5/32/32
Fuel pump relay driver		P0230	P0230	P0230	6/6/6
Boost pressure characteristic, Above Upper Limit				P0234	5/32/32
Pressure sensor, boost			P0237	P0238	5/32/32
Misfire detection (total)	P0300*		P0300*	P0300*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 1	P0301*		P0301*	P0301*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 2	P0302*		P0302*	P0302*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 3	P0303*		P0303*	P0303*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 4	P0304*		P0304*	P0304*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 5	P0305*		P0305*	P0305*	1 - 2/1 - 31/1 - 31
Misfire detection Cylinder 6	P0306*		P0306*	P0306*	1 - 2/1 - 31/1 - 31
Knock control zero test	P0324				5/6/6
Knock sensor 1			P0327	P0328	5/6/6
Knock sensor 2			P0332	P0333	5/6/6
Engine speed sensor signal		P0335			3/32/32
Reference mark sensor	P0336				3/32/6
Hall sensor 1	P0341	P0344	P0342	P0343	3/ 32/ 32
Hall sensor 2	P0346	P0349	P0347	P0348	3/32/32
Electric switch-over valve		P0413	P0414	P0414	3/32/0
Secondary air pump		P0418	P0418	P0418	3/32/0
Catalytic conversion Bank 1				P0420	3/30/0
Catalytic conversion Bank 2				P0430	3/30/0



<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Fuel tank ventilation system (DTE SK)				P0440	3/0/0
Fuel tank ventilation system (DTE V)			P0441	P0441	0/32/32
Fuel tank ventilation system (fine leak)			P0442		3/0/0
Tank vent valve		P0444	P0445	P0445	3/30/32
Activated charcoal filter shutoff valve (function)			P0446		3/0/0
Activated charcoal filter shutoff valve (driver)		P0447	P0448	P0448	3/0/0
Fuel tank ventilation system (big leak)	P0450		P0455		3/0/0
Pressure sensor tank	P0451				3/0/0
Fuel tank ventilation system (small leak)			P0456		3/0/0
Driver for blower 1		P0480	P0480	P0480	6/6/6
Driver for blower 2		P0481	P0481	P0481	6/6/6
Driver for blower 3		P0482	P0482	P0482	6/6/6
Secondary air system Bank 1			P0491		3/32/0
Secondary air system Bank 2			P0492		3/32/0
Vehicle speed		P0501			3/6/6
Idle speed control at the stop			P0506	P0507	3/32/32
Immobilizer	P0513	P0513			6/6/6
Supply voltage	P0560		P0562	P0563	3/6/6
Stop light switch	P0571				6/6/6
CAN timeout Tiptronic		P0600			3/32/6
DME relay/control module faulty (watchdog: Reset)	P0601				6/6/6
EEPROM fault	P0603	P0603	P0603	P0603	6/6/6
Control module faulty (RAM)	P0604				5/32/32
Control module faulty (ROM)	P0605				5/32/32

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Control module faulty (watchdog: Reset)	P0607				5/32/32
Throttle adjusting unit Positional deviation	P0638				4/4/4
Air conditioning compressor control		P0645	P0646	P0674	6/6/6
Check Engine lamp, open circuit (via CAN)		P0650			5/32/32
Tiptronic (CAN transfer box setting implausible)	P0700				3/32/6
Tiptronic (Gear implausible/transmission slips)	P0701				3/32/6
Tiptronic control unit faulty	P0702				3/32/6
Tiptronic (Selector lever position implausible)	P0706				3/32/6
Transmission oil temperature GT 2			P0712	P0713	6/6/6
Tiptronic (Supply voltage of speed sensors)	P0715				3/32/6
Tiptronic (CAN: wheel speed rear right)	P0720				3/32/6
Tiptronic (Gear comparison negative)	P0730				3/32/6
Tiptronic (Converter lockup clutch)	P0740				6/32/6
Tiptronic (Converter lockup solenoid valve)	P0743				3/32/6
Tiptronic (Control solenoid valve, modulating pressure)	P0748				3/32/6
Tiptronic (Solenoid valve, 1-2/4-5 gearshift)	P0753				3/32/6
Tiptronic (Solenoid valve, 2-3 gearshift)	P0758				3/32/6
Tiptronic (Solenoid valve 3-4 gearshift)	P0763				3/32/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Tiptronic (Control solenoid valve, shifting pressure)	P0778				3/32/6
Clutch switch	P0830				6/6/6
Input values, cylinder fill measurement			P1101	P1109	3/6/6
Ambient pressure sensor				P1102	3/32/32
Oxygen sensor closed-loop control adaptation upper load range, bank 1			P1105	P1125	11/33/32
Oxygen sensor closed-loop control upper load range, bank 2			P1106	P1132	11/33/32
Oxygen sensor closed-loop control adaptation lower load range, bank 1			P1107	P1126	11/33/32
Oxygen sensor closed-loop control lower load range, bank 2			P1108	P1133	11/33/32
Throttle	P1120				5/32/32
Throttle potentiometer 1	P1121		P1139	P1138	5/32/32
Throttle potentiometer 2	P1122		P1141	P1140	5/32/32
Oxygen control deviation by short test, bank 1			P1127	P1142	7/7/7
Oxygen control deviation by short test, bank 2			P1134	P1143	7/7/7
Pressure comparison Boost pressure v. ambient	P1136				5/32/32
Oxygen sensor in front of catalytic converter, bank 1		P1146**		P1145**	3/ 30/ 6
Engine compartment temperature sensor			P1157	P1158	6/6/6
Boost pressure control			P1249	P1250	5/32/32
Oxygen sensor in front of catalytic converter Bank 2		P1156**		P1155**	3/30/6
Signal from airbag	P1265				6/6/6
Function monitoring Fuel cutoff	P1266				4/4/4
Camshaft adjustment Bank 2	P1325		P1358	P1357	3/32/32
Camshaft adjustment Bank 1	P1341		P1349	P1348	3/32/32

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
Valve lift control parity check error	P1350		P1374	P1371	6/6/6
Valve lift control, cylinder 1			P1351	P1359	6/6/6
Valve lift control, cylinder 6			P1352	P1360	6/6/6
Valve lift control, cylinder 2			P1353	P1361	6/6/6
Valve lift control, cylinder 4			P1354	P1362	6/6/6
Valve lift control, cylinder 3			P1355	P1363	6/6/6
Valve lift control, cylinder 5			P1356	P1364	6/6/6
Knock control offset	P1385				5/6/6
Knock control test pulse	P1386				5/6/6
Throttle adjusting unit Driver	P1501				4/4/4
Throttle adjusting unit Spring check				P1502	4/4/4
Throttle adjusting unit Emergency air position	P1504				6/6/6
Throttle adjusting unit Control range		P1505	P1518	P1516	4/4/4
Throttle adjusting unit Lower mechanical stop	P1506				4/4/4
Throttle adjusting unit Amplifier balance	P1507				6/6/6
Function monitoring Torque comparison	P1508				4/4/4
Torque limitation				P1509	5/32/32
Throttle adjusting unit Replacement detection without adaptation	P1510				4/4/4
Throttle adjustment unit Abortion of test through violation of environmental condition			P1511	P1517	6/6/6
Throttle adjusting unit Spring test opening			P1513	P1515	4/4/4
Throttle adjusting unit Relearn lower mechanical stop	P1514				6/6/6
Pedal value sensor movement	P1575				6/6/6
Cruise control standby light via CAN		P1576			6/6/6
CAN timeout PSM		P1600			6/6/6

<b>Fault text</b>	<b>Fault type 1 (Plaus)</b>	<b>Fault type 2 (Sig)</b>	<b>Fault type 3 (Min)</b>	<b>Fault type 4 (Max)</b>	<b>CE USA/EU3/ EU2</b>
CAN timeout Instrument cluster	P1602	P1601			6/6/6
Coolant shutoff valve		P1656	P1655	P1654	5/32/6
Driver for ambient air valve		P1657	P1659	P1658	6/6/6
Driver for engine compartment purge fan		P1674	P1677	P1676	6/6/6
Engine scavenge blower fault				P1675	6/6/6
Tiptronic (Supply voltage of valves or selector lever)	P1702				3/32/6
Accelerator pedal	P2135				5/32/32



## P0011

### Position of Camshaft in Relation to Crankshaft, Bank 1 – Below Limit

#### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- Reference mark OK
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

#### Possible fault cause

- ◆ Allocation of camshaft to inlet camshaft incorrect

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### **Note!**

*This fault is stored if the engine was disassembled and the allocation of the camshaft to the inlet camshaft was incorrectly set.*

Work instruction		Display OK	If not OK
1	Set camshafts	◆ To adjust the camshafts, please refer to the 911 Turbo (996) or 911 Carrera (996) Technical Manual.	





## P0012

### Position of Camshaft in Relation to Crankshaft, Bank 1 – Above Limit

#### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- Reference mark OK
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

#### Possible fault cause

- ◆ Solenoid hydraulic valve camshaft adjustment faulty
- ◆ Allocation of camshaft to inlet camshaft incorrect

#### Affected terminals

-

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End
	<ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>		

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



Work instruction		Display OK	If not OK
2	Set camshafts	◆ To adjust the camshafts, please refer to the 911 Turbo (996) or 911 Carrera (996) Technical Manual.	

## P0013

### Camshaft Adjustment, Bank 1 Output Stage - Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

V/7

### Diagnosis/Troubleshooting



#### Note!

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 14*

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/7 and solenoid hydraulic valve connector pin 2.</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery voltage.	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pin 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C.	

## Camshaft Adjustment, Bank 1 Output Stage - Below Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short to ground triggering wire
- ◆ Solenoid hydraulic valve faulty

### Affected terminals

V/7

## Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/7 and ground</li> </ul>	$\infty \Omega$
2	Replace solenoid hydraulic valve		

## Camshaft Adjustment, Bank 1 Output Stage - Above Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short circuit to B+ triggering wire

### Affected terminals

V/7

## Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check triggering wire for short circuit to B+.	<ul style="list-style-type: none"><li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li><li>◆ Remove connector on the solenoid hydraulic valve</li><li>◆ Switch on the ignition.</li><li>◆ Measure voltage between V/7 and ground</li></ul>	0 V.	Repair wiring harness.



## P0021

### Position of Camshaft in Relation to Crankshaft, Bank 2 – Below Limit

#### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- Reference mark OK
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

#### Possible fault cause

- ◆ Allocation of camshaft to inlet camshaft incorrect

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### **Note!**

*This fault is stored if the engine was disassembled and the allocation of the camshaft to the inlet camshaft was incorrectly set.*

Work instruction		Display OK	If not OK
1	Set camshafts	◆ To adjust the camshafts, please refer to the 911 Turbo (996) or 911 Carrera (996) Technical Manual.	





## P0022

### Position of Camshaft in Relation to Crankshaft, Bank 2 – Above Limit

#### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- No fault with reference mark
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

#### Possible fault cause

- ◆ Solenoid hydraulic valve camshaft adjustment faulty
- ◆ Allocation of camshaft to inlet camshaft incorrect

#### Affected terminals

-

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment <ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



Work instruction		Display OK	If not OK
2	Set camshafts <ul style="list-style-type: none"> <li>◆ To adjust the camshafts, please refer to the 911 Turbo (996) or 911 Carrera (996) Technical Manual.</li> </ul>		

## P0023

### Camshaft Adjustment, Bank 2 Output Stage - Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

V/8

### Diagnosis/Troubleshooting



#### Note!

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 15*

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/8 and solenoid hydraulic valve connector pin 2.</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery voltage.	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pin 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C.	

## Camshaft Adjustment, Bank 2 Output Stage - Below Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short to ground triggering wire
- ◆ Solenoid hydraulic valve faulty

### Affected terminals

V/8

## Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/8 and ground</li> </ul>	$\infty \Omega$
2	Replace solenoid hydraulic valve		

## Camshaft Adjustment, Bank 2 Output Stage - Above Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short circuit to B+ triggering wire

### Affected terminals

V/8

## Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check triggering wire for short circuit to B+.	<ul style="list-style-type: none"><li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li><li>◆ Remove connector on the solenoid hydraulic valve</li><li>◆ Switch on the ignition.</li><li>◆ Measure voltage between V/8 and ground</li></ul>	0 V.	Repair wiring harness.



## P0026

Valve lift control, bank 1 output stage - open circuit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

Affected terminals

III/1

Diagnosis/troubleshooting

 **Note!**

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/2 pin 8*

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/1 and solenoid hydraulic valve connector pin 2</li> </ul>	0 - 5 $\Omega$	Repair wiring harness
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery positive voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pin 1 and 2</li> </ul>	11 - 15 $\Omega$ at 20° C.	Replace solenoid hydraulic valve

## Valve lift control, bank 1, output stage - below limit

## Diagnosis conditions

- Engine running

## Possible fault cause

- ◆ Triggering wire short to ground
- ◆ Solenoid hydraulic valve faulty

## Affected terminals

III/1

## Diagnosis/troubleshooting

**Note!**

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/2 pin 8*

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/1 and ground</li> </ul>	$\infty \Omega$
2	Replace solenoid hydraulic valve		

## Valve lift control, bank 1, output stage - above limit

## Diagnosis conditions

- Engine running

## Possible fault cause

- ◆ Triggering wire short to B+

## Affected terminals

III/1



## Diagnosis/troubleshooting

**i** **Note!**

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/2 pin 8*

Work instruction		Display OK	If not OK
1	Check triggering wire for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Ill/1 and ground</li> </ul>	0 V	Repair wiring harness



## P0028

Valve lift control, bank 2 output stage - open circuit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

Affected terminals

III/26

Diagnosis/troubleshooting



**Note!**

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 11*

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/26 and solenoid hydraulic valve connector pin 2</li> </ul>	0 - 5 $\Omega$	Repair wiring harness
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pins 1 and 2</li> </ul>	11 - 15 $\Omega$ at 20° C.	Replace solenoid hydraulic valve

## Valve lift control, bank 2, output stage - below limit

## Diagnosis conditions

- Engine running

## Possible fault cause

- ◆ Triggering wire short to ground
- ◆ Solenoid hydraulic valve faulty

## Affected terminals

III/26

## Diagnosis/troubleshooting

**Note!**

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 11*

Work instruction			Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/26 and ground</li> </ul>	$\infty \Omega$	
2	Replace solenoid hydraulic valve			

## Valve lift control, bank 2, output stage - above limit

## Diagnosis conditions

- Engine running

## Possible fault cause

- ◆ Triggering wire short to B+

## Affected terminals

III/26

## Diagnosis/troubleshooting

**Note!**

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 11*

Work instruction		Display OK	If not OK
1	Check triggering wire for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Ill/26 and ground</li> </ul>	0 V	Repair wiring harness



## P0030

### H02S Heater Control Circuit

**i** Note!

The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines

### Diagnosis/troubleshooting - all turbo models

#### Diagnostic conditions

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

#### Possible cause of fault

- ◆ Open circuit

#### Affected terminals

DME control module, connector II, pin 19 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 4

### Diagnosis/troubleshooting

**i** Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection of all affected plug connections	⇒ Step 2	Repair or replace faulty component → End
2	Check oxygen sensor heating	◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1  ◆ Check resistance between pins 3 and 4 towards the oxygen sensor	2.5 to 4 Ω at 20°C ⇒ Step 3	Replace oxygen sensor → End

Work instruction		Display OK	If not OK
3	Check voltage supply	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pin 3 of oxygen sensor jack towards the DME control module and ground</li> </ul>	Battery positive voltage ⇒ Step 4  Repair voltage supply (wiring, jumper plugs...) → End
4	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and pin II/19</li> </ul>	<2 Ω  Repair faulty wiring → End

## Diagnosis/troubleshooting - all naturally-aspirated models

### Diagnostic conditions

- Engine running

### Possible cause of fault

- ◆ Resistance of oxygen sensor heating too high
- ◆ Open circuit
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

### Affected terminals

DME control module, connector II, pin 19 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 2

### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*



Work instruction			Display OK	If not OK
1	Evaluate fault memory	<ul style="list-style-type: none"> <li>◆ Check whether only this fault or faults on other oxygen sensors have been recorded</li> </ul>	Only this fault was recorded ⇒ Step 2	There are open circuits in other oxygen sensor heating units Boxster ⇒ Step 1a 996 naturally-aspirated ⇒ Step 1b
1 a	Boxster	Repair faulty wiring between relay carrier 2, relay 2 and oxygen sensor jack pin 1; correct cause of damage, if necessary. Observe current distributors VS 22 and VS 42 → End		
1 b	996 naturally-aspirated	Remove jumper plug BS 21/1 from relay carrier 2 connector, relay position 6 and repair according to findings → End		
2	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connection</li> </ul>	8 to 11 $\Omega$ at 20°C ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check voltage supply	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between oxygen sensor jack, pin 1 and ground</li> <li>◆ Switch off ignition</li> </ul>	Battery positive voltage ⇒ Step 4	Repair voltage supply (wiring, jumper plugs, if necessary...) → End
4	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between adapter pin II/19 and pin 2 of oxygen sensor jack</li> </ul>	< 2 $\Omega$ ⇒ Step 5	Repair faulty wiring, correct cause of damage if necessary → End
5	Check whether additional faults have been recorded		⇒ Step 6	Correct faults in accordance with instructions → End
6	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0031

### H02S Heater Control Circuit Low

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

#### Possible cause of fault

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector, e.g. caused by moisture in the connector, etc.
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected pins

DME control module connector II, pin 19 and oxygen sensor connector ahead of catalytic converter, bank 1, pin 4

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	<p>Check oxygen sensor heating for short circuit to ground in casing</p> <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> </ul> <p>Measure resistance between pin 4 of oxygen sensor connector and:</p> <ul style="list-style-type: none"> <li>◆ Casing of oxygen sensor</li> <li>◆ Pin 1</li> <li>◆ Pin 2</li> <li>◆ Pin 5</li> </ul>	$\infty \Omega$ ⇒ Step 2	<p>Oxygen sensor faulty            ⇒ Replace oxygen sensor            → End</p>
2	<p>Check triggering wire of oxygen sensor heating</p> <ul style="list-style-type: none"> <li>◆ Remove connector II from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between DME control module connector II, pin 19 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	<p>Repair triggering wire; correct cause of damage, if necessary            → End</p>
3	<p>Check whether additional faults have been recorded</p>	⇒ Step 4	<p>Correct faults in accordance with instructions            → End</p>
4	<p>Replace DME control module</p>	<p>To do this, please observe the notes on possible causes of faults in the introduction!</p>	

## Diagnosis/troubleshooting - all naturally-aspirated models

### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

### Possible cause of fault

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

**Affected terminals**

DME control module, connector II, pin 19 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 2

**Diagnosis/troubleshooting**** Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction			Display OK	If not OK
1	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check oxygen sensor for short circuit to ground	Measure resistance between oxygen sensor connector: <ul style="list-style-type: none"> <li>◆ Pin 2 and pin 3</li> <li>◆ Pin 2 and oxygen sensor casing</li> </ul>	∞ Ω ⇒ Step 4	Replace oxygen sensor; correct cause of damage, if necessary → End
4	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 5	Replace faulty component; correct cause of damage, if necessary → End
5	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/19 and pin II/9</li> <li>◆ Pin II/19 and ground</li> </ul>	∞ Ω ⇒ Step 6	Repair wiring; correct cause of damage, if necessary → End
6	Check whether additional faults have been recorded		⇒ Step 7	Correct faults in accordance with instructions → End
7	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0032

### H02S Heater Control Circuit High

The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.

### Diagnosis/troubleshooting - all turbo models

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

#### Possible cause of fault

- ◆ Short circuit to B+ in triggering wire

#### Affected terminals

DME control module, connector II, pin 19 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 4

### Diagnosis/troubleshooting

#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Check resistance between pins 3 and 4 towards the oxygen sensor</li> </ul>	2.5 $\Omega$ to 4.0 $\Omega$ at 20°C	Replace oxygen sensor → End
		<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor casing</li> <li>◆ Check resistance between pin 1 and pin 4</li> <li>◆ Check resistance between pin 2 and pin 4</li> <li>◆ Check resistance between pin 5 and pin 4</li> <li>◆ Check resistance between pin 6 and pin 4</li> </ul>	$\infty \Omega$	
2	Check wiring	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pin 4 and vehicle ground towards DME control module</li> </ul>	0 V	Repair wiring harness → End

## Diagnosis/troubleshooting - all naturally-aspirated models

### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

### Possible cause of fault

- ◆ Short circuit to B+ in triggering wire
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

### Affected terminals

DME control module, connector II, pin 19 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 2

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Measure oxygen sensor heating resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 2	Replace oxygen sensor; correct cause of damage, if necessary → End
2	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between adapter pin II/19 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 3	Repair faulty wiring; correct cause of damage, if necessary → End
3	Check whether additional faults have been recorded		⇒ Step 4	Correct faults in accordance with instructions → End
4	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0036

### H02S Heater Control Circuit

#### Diagnosis/troubleshooting

##### Diagnostic conditions

- Engine running

##### Possible cause of fault

- ◆ Open circuit
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

##### Affected terminals

DME control module, connector II, pin 7 and oxygen sensor jack after catalytic converter, bank 1, pin 2

#### Diagnosis/troubleshooting



##### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Evaluate fault memory	◆ Check whether only this fault or faults on other oxygen sensors have been recorded	Only this fault was recorded ⇒ Step 2
			There are open circuits in other oxygen sensor heating units Boxster ⇒ Step 1a 996 naturally-aspirated ⇒ Step 1b
1 a	Boxster	Repair faulty wiring between relay carrier 2, relay 2 and oxygen sensor jack pin 1; correct cause of damage, if necessary. Observe current distributors VS 22 and VS 42 → End	
1 b	996 naturally-aspirated	Remove jumper plug BS 21/1 from relay carrier 2 connector, relay position 6 and repair according to findings → End	



Work instruction		Display OK	If not OK
2	Check oxygen sensor heating <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 to 11 $\Omega$ at 20°C ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check voltage supply <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between oxygen sensor jack, pin 1 and ground</li> <li>◆ Switch off ignition</li> </ul>	Battery positive voltage ⇒ Step 4	Repair voltage supply (wiring, jumper plugs, if necessary...) → End
4	Check triggering wire <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between adapter pin II/7 and pin 2 of oxygen sensor jack</li> </ul>	< 2 $\Omega$ ⇒ Step 5	Repair faulty wiring; correct cause of damage, if necessary → End
5	Check whether additional faults have been recorded	⇒ Step 6	Correct faults in accordance with instructions → End
6	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0037

### H02S Heater Control Circuit Low

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

#### Possible cause of fault

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected terminals

DME control module, connector II, pin 7 and oxygen sensor jack after catalytic converter, bank 1, pin 2

#### Diagnosis/troubleshooting



#### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Check oxygen sensor plug connection	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	8 Ω to 11 Ω ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check oxygen sensor for short circuit to ground	∞ Ω ⇒ Step 4	Replace oxygen sensor; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
4	Check DME control module plug connection <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 5	Replace faulty component; correct cause of damage, if necessary → End
5	Check triggering wire <ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/7 and pin II/11</li> <li>◆ Pin II/7 and ground</li> </ul>	∞ Ω ⇒ Step 6	Repair wiring; correct cause of damage, if necessary → End
6	Check whether additional faults have been recorded	⇒ Step 7	Correct faults in accordance with instructions → End
7	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0038

### H02S Heater Control Circuit High

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

#### Possible cause of fault

- ◆ Short circuit to B+ in triggering wire
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected terminals

DME control module, connector II, pin 7 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 2

#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor	8 Ω to 11 Ω ⇒ Step 2	Replace oxygen sensor; correct cause of damage, if necessary → End
2	Check triggering wire	0 V ⇒ Step 3	Repair faulty wiring; correct cause of damage, if necessary → End

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Check whether additional faults have been recorded	⇒ Step 4	Correct faults in accordance with instructions → End
4	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0040

### Oxygen sensor ahead of catalytic converter – signal implausible (only Turbo)

#### Diagnosis conditions

- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds
- Oxygen sensing system active

#### Possible fault cause

- ◆ Oxygen sensors ahead of catalytic converter exchanged
- ◆ Line polarity reversal in wiring harness
- ◆ Simultaneous occurrence of leaking fuel injector on the one bank and leaking intake distributor on the other bank

#### Affected terminals

DME control module connector II, pins 2, 5, 6, 9, 10, 15, 16, 24 and oxygen sensor jacks ahead of catalytic converter, pins 1, 2, 5 and 6

#### Diagnosis/troubleshooting

##### Note!

- ◆ *Diagnosis detects oxygen sensor - regulators running contrary to the adaptation limitation.*
- ◆ *For example: The regulator for bank 1 detects an excessively rich mixture and wants to make it leaner. At the same time, the regulator on bank 2 detects an excessively lean mixture and wants to make it richer. If the oxygen sensors or their signal wires have been exchanged, the detected bank 1 continues to make the mixture richer and bank 2 continues to make the mixture leaner. Only when both oxygen sensors remain on the opposing stops for a certain period of time will this fault be recorded.*

##### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check that oxygen sensors are allocated correctly	<ul style="list-style-type: none"> <li>◆ Check if the oxygen sensors were exchanged due to incorrect installation of or tampering with the wiring harness</li> </ul> ⇒ Step 2	Install the oxygen sensors correctly, eliminate cause of damage if necessary → End	
2	Check oxygen sensor wiring harness ahead of catalytic converter, bank 1	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Remove control module connector B</li> <li>◆ Visual inspection</li> </ul> Check following wiring for continuity <ul style="list-style-type: none"> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 1 and DME control module connector B pin 15</li> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 5 and DME control module connector B pin 9</li> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 2 and DME control module connector B pin 2</li> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 6 and DME control module connector B pin 5</li> </ul>	< 2 Ω ⇒ Step 4	Continue with finding damage ⇒ Step 3 → End

Work instruction		Display OK	If not OK
3	<p>Check oxygen sensor wiring harness ahead of catalytic converter, bank 2</p> <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> </ul> <p>Check following wiring for continuity</p> <ul style="list-style-type: none"> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 1 and DME control module connector B pin 16</li> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 5 and DME control module connector B pin 10</li> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 2 and DME control module connector B pin 6</li> <li>◆ Oxygen sensor connector ahead of catalytic converter pin 6 and DME control module connector B pin 24</li> </ul>	<p>&lt; 2 <math>\Omega</math>  <math>\Rightarrow</math> Step 4</p>	<p>Using the findings from Step 2, repair or replace wiring harness  <math>\rightarrow</math> End</p>
4	<p>Check engine</p>	<p>After reading out the oxygen sensor values, search for a leaking fuel injector on the bank with the lean threshold and search for false air on the bank with the rich threshold.</p>	<p>Repair according to findings</p>



## P0045

### Charge Pressure Control Valve Output Stage - Open Circuit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Charge pressure control valve (coil) open circuit
- ◆ Open circuit in wiring

#### Affected terminals

III/4

#### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check charge pressure control valve.	◆ Measure resistance at the charge pressure control valve.	20 - 26 $\Omega$ at 20 °C.	
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool to wiring harness (DME control module plug).</li> <li>◆ Remove connector of charge pressure control valve.</li> <li>◆ Measure resistance between special tool 9637 pin III/4 and charge pressure control valve plug pin 2.</li> </ul>	0 - 5 $\Omega$	Repair wiring harness → End.



## P0047

### Charge Pressure Control Valve Output Stage - Below Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Short circuit to ground

#### Affected terminals

III/4

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring harness for short to ground.	$\infty \Omega$	Repair wiring harness.
	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of charge pressure control valve.</li> <li>◆ Measure resistance between special tool 9637 pin III/4 and ground.</li> </ul>		



## P0048

### Charge Pressure Control Valve Output Stage - Above Limit

#### Diagnosis conditions

- Charge pressure control active

#### Possible fault cause

- ◆ Charge pressure control valve (coil) short circuit
- ◆ Short circuit to B+

#### Affected terminals

III/4

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check charge pressure control valve.	◆ Measure resistance at the charge pressure control valve.	20 - 26 $\Omega$ at 20 °C.
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of charge pressure control valve.</li> <li>◆ Ignition on</li> <li>◆ Measure voltage between special tool 9637 pin III/4 and ground.</li> </ul>	0 V.  Repair wiring harness.



## P0050

### H02S Heater Control Circuit

**i** Note!

The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines

### Diagnosis/troubleshooting - all turbo models

#### Diagnostic conditions

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

#### Possible cause of fault

- ◆ Open circuit

#### Affected terminals

DME control module, connector II, pin 13 and oxygen sensor jack ahead of catalytic converter, bank 2, pin 4

### Diagnosis/troubleshooting

**i** Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection of all affected plug connections ⇒ Step 2	Repair or replace faulty component → End
2	Check oxygen sensor heating	◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2 ◆ Check resistance between pins 3 and 4 towards the oxygen sensor 2.5 to 4 Ω at 20°C ⇒ Step 3	Replace oxygen sensor → End

Work instruction		Display OK	If not OK
3	Check voltage supply <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pin 3 of oxygen sensor jack towards the DME control module and ground</li> </ul>	Battery positive voltage ⇒ Step 4	Repair voltage supply (wiring, jumper plugs...) → End
4	Check triggering wire <ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and pin II/13</li> </ul>	<2 Ω	Repair faulty wiring → End

## Diagnosis/troubleshooting - all naturally-aspirated models

### Diagnostic conditions

- Engine running

### Possible cause of fault

- ◆ Resistance of oxygen sensor heating too high
- ◆ Open circuit
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

### Affected terminals

DME control module, connector II, pin 13 and oxygen sensor jack ahead of catalytic converter, bank 2, pin 2

### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*



Work instruction			Display OK	If not OK
1	Evaluate fault memory	<ul style="list-style-type: none"> <li>◆ Check whether only this fault or faults on other oxygen sensors have been recorded</li> </ul>	Only this fault was recorded ⇒ Step 2	There are open circuits in other oxygen sensor heating units Boxster ⇒ Step 1a⇒ 996 naturally-aspirated ⇒ Step 1b
1 a	Boxster	Repair faulty wiring between relay carrier 2, relay 2 and oxygen sensor jack pin 1; correct cause of damage, if necessary. Observe current distributors VS 22 and VS 42 → End		
1 b	996 naturally-aspirated	Remove jumper plug BS 21/1 from relay carrier 2 connector, relay position 6 and repair according to findings → End		
2	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 to 11 Ω at 20°C ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check voltage supply	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between oxygen sensor jack, pin 1 and ground</li> <li>◆ Switch off ignition</li> </ul>	Battery positive voltage ⇒ Step 4	Repair voltage supply (wiring, jumper plugs, if necessary...) → End
4	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between adapter pin II/13 and pin 2 of oxygen sensor jack</li> </ul>	< 2 Ω ⇒ Step 5	Repair faulty wiring; correct cause of damage, if necessary → End
5	Check whether additional faults have been recorded		⇒ Step 6	Correct faults in accordance with instructions → End
6	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0051

### H02S Heater Control Circuit Low

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

#### Possible cause of fault

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector, e.g. caused by moisture in the connector, etc.
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected pins

DME control module connector II, pin 13 and oxygen sensor connector ahead of catalytic converter, bank 2, pin 4

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	<p>Check oxygen sensor heating for short circuit to ground in casing</p> <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> </ul> <p>Measure resistance between pin 4 of oxygen sensor connector and:</p> <ul style="list-style-type: none"> <li>◆ Casing of oxygen sensor</li> <li>◆ Pin 1</li> <li>◆ Pin 2</li> <li>◆ Pin 5</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 2	<p>Oxygen sensor faulty  <math>\Rightarrow</math> Replace oxygen sensor  <math>\rightarrow</math> End</p>
2	<p>Check triggering wire of oxygen sensor heating</p> <ul style="list-style-type: none"> <li>◆ Remove connector II from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between DME control module connector II, pin 13 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 3	<p>Repair triggering wire; correct cause of damage, if necessary  <math>\rightarrow</math> End</p>
3	<p>Check whether additional faults have been recorded</p>	$\Rightarrow$ Step 4	<p>Correct faults in accordance with instructions  <math>\rightarrow</math> End</p>
4	<p>Replace DME control module</p>	<p>To do this, please observe the notes on possible causes of faults in the introduction!</p>	

## Diagnosis/troubleshooting - all naturally-aspirated models

### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

### Possible cause of fault

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

**Affected terminals**

DME control module, connector II, pin 13 and oxygen sensor jack ahead of catalytic converter, bank 2, pin 2

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check oxygen sensor for short circuit to ground	Measure resistance between oxygen sensor connector: <ul style="list-style-type: none"> <li>◆ Pin 2 and pin 3</li> <li>◆ Pin 2 and oxygen sensor casing</li> </ul>	∞ Ω ⇒ Step 4	Replace oxygen sensor; correct cause of damage, if necessary → End
4	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 5	Replace faulty component; correct cause of damage, if necessary → End
5	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/13 and pin II/10</li> <li>◆ Pin II/13 and ground</li> </ul>	∞ Ω ⇒ Step 6	Repair wiring; correct cause of damage, if necessary → End
6	Check whether additional faults have been recorded		⇒ Step 7	Correct faults in accordance with instructions → End
7	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0052

### H02S Heater Control Circuit High

The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.

### Diagnosis/troubleshooting - all turbo models

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

#### Possible cause of fault

- ◆ Short circuit to B+ in triggering wire

#### Affected terminals

DME control module, connector II, pin 13 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 4

### Diagnosis/troubleshooting

#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Check resistance between pins 3 and 4 towards the oxygen sensor</li> </ul>	2.5 $\Omega$ to 4.0 $\Omega$ at 20°C	Replace oxygen sensor → End
		<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor casing</li> <li>◆ Check resistance between pin 1 and pin 4</li> <li>◆ Check resistance between pin 2 and pin 4</li> <li>◆ Check resistance between pin 5 and pin 4</li> <li>◆ Check resistance between pin 6 and pin 4</li> </ul>	$\infty \Omega$	
2	Check wiring	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pin 4 and vehicle ground towards DME control module</li> </ul>	0 V	Repair wiring harness → End

## Diagnosis/troubleshooting - all naturally-aspirated models

### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

### Possible cause of fault

- ◆ Short circuit to B+ in triggering wire
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

### Affected terminals

DME control module, connector II, pin 13 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 2

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Measure oxygen sensor heating resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 $\Omega$ to 11 $\Omega$ ⇒ Step 2	Replace oxygen sensor; correct cause of damage, if necessary → End
2	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between adapter pin II/13 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 3	Repair faulty wiring; correct cause of damage, if necessary → End
3	Check whether additional faults have been recorded		⇒ Step 4	Correct faults in accordance with instructions → End
4	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0056

### H02S Heater Control Circuit

#### Diagnosis/troubleshooting

##### Diagnostic conditions

- Engine running

##### Possible cause of fault

- ◆ Open circuit
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

##### Affected terminals

DME control module, connector II, pin 1 and oxygen sensor jack after catalytic converter, bank 2, pin 2

#### Diagnosis/troubleshooting



##### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Evaluate fault memory	◆ Check whether only this fault or faults on other oxygen sensors have been recorded	Only this fault was recorded ⇒ Step 2
1 a	Boxster	◆ There are open circuits in other oxygen sensor heating units Boxster ⇒ Step 1a 996 naturally-aspirated ⇒ Step 1b	Repair faulty wiring between relay carrier 2, relay 2 and oxygen sensor jack pin 1; correct cause of damage, if necessary. Observe current distributors VS 22 and VS 42 → End
1 b	996 naturally-aspirated	Remove jumper plug BS 21/1 from relay carrier 2 connector, relay position 6 and repair according to findings → End	



Work instruction		Display OK	If not OK
2	Check oxygen sensor heating <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 to 11 $\Omega$ at 20°C ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check voltage supply <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between oxygen sensor jack, pin 1 and ground</li> <li>◆ Switch off ignition</li> </ul>	Battery positive voltage ⇒ Step 4	Repair voltage supply (wiring, jumper plugs, if necessary...) → End
4	Check triggering wire <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between adapter pin II/1 and pin 2 of oxygen sensor jack</li> </ul>	< 2 $\Omega$ ⇒ Step 5	Repair faulty wiring; correct cause of damage, if necessary → End
5	Check whether additional faults have been recorded	⇒ Step 6	Correct faults in accordance with instructions → End
6	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0057

### H02S Heater Control Circuit Low

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

#### Possible cause of fault

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected terminals

DME control module, connector II, pin 1 and oxygen sensor jack after catalytic converter, bank 2, pin 2

#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor plug connection	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	8 Ω to 11 Ω ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check oxygen sensor for short circuit to ground	∞ Ω ⇒ Step 4	Replace oxygen sensor; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
4	Check DME control module plug connection <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 5	Replace faulty component; correct cause of damage, if necessary → End
5	Check triggering wire <ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/1 and pin II/8</li> <li>◆ Pin II/1 and ground</li> </ul>	∞ Ω ⇒ Step 6	Repair wiring; correct cause of damage, if necessary → End
6	Check whether additional faults have been recorded	⇒ Step 7	Correct faults in accordance with instructions → End
7	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0058

### H02S Heater Control Circuit High

#### Diagnostic conditions

- Battery positive voltage between 10 V and 16 V
- Engine running

#### Possible cause of fault

- ◆ Short circuit to B+ in triggering wire
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected terminals

DME control module, connector II, pin 1 and oxygen sensor jack ahead of catalytic converter, bank 2, pin 2

#### Diagnosis/troubleshooting



#### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Measure oxygen sensor heating resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 2	Replace oxygen sensor; correct cause of damage, if necessary → End
2	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between adapter pin II/1 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 3	Repair faulty wiring; correct cause of damage, if necessary → End

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Check whether additional faults have been recorded	⇒ Step 4	Correct faults in accordance with instructions → End
4	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0071

Ambient Temperature (via CAN from instrument cluster) - Signal Implausible

Diagnosis conditions

- Ignition on

Possible fault cause

- ◆ Instrument cluster

Affected terminals

### Diagnosis/Troubleshooting



#### Note!

*With an outside temperature of less than or equal to -40° C, this fault is stored because no lower temperatures can be displayed in the instrument cluster. In this case, a fault status is not present.*

Work instruction		Display OK	If not OK
1	Replace instrument cluster.		



## P0102

### 115 Mass air flow sensor – below limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 8 V

#### Possible fault cause

- ◆ Open circuit
- ◆ Short circuit to ground
- ◆ Mass air flow sensor faulty



#### Note!

In the case of a fault, the PSM is switched off.

#### Affected terminals

Terminal III/23

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from MAF sensor to DME control module for continuity.	<ul style="list-style-type: none"> <li>◆ Remove connector of MAF sensor</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module connector).</li> <li>◆ Measure resistance between special tool 9637 Pin III/23 and MAF sensor plug Pin 5</li> </ul>	0 - 5 $\Omega$ ⇒ Step 2  Repair wiring harness → End
2	Check wiring from MAF sensor to DME control module for short to ground	<ul style="list-style-type: none"> <li>◆ Remove connector of MAF sensor</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module connector).</li> <li>◆ Measure resistance between special tool 9637 Pin III/23 and ground</li> </ul>	∞ $\Omega$ ⇒ Step 3  Repair wiring harness → End



Work instruction			Display OK	If not OK
3	Check signal from MAF sensor	<ul style="list-style-type: none"> <li>◆ Check voltage signal from MAF sensor with 'Ignition on' (with Porsche System Tester 2 in the 'Actual values/mass air flow' menu, or with a voltmeter and special tool 9637).</li> <li>◆ Start the engine</li> </ul>	0.9 to 1.1 V  1.2 to 1.5 V (at idle speed) → End	Replace MAF sensor ⇒ Step 4
4	Clean air cleaner and replace filter element	<ul style="list-style-type: none"> <li>◆ Clean pure air side of air cleaner (extract dirt, do not blow out with compressed air with mass air flow sensor installed)</li> <li>◆ Replace filter element</li> </ul>	→ End	

## P0103

### 115 Mass Air Flow Sensor - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 8 V

#### Possible fault cause

- ◆ Intake air system on pressure side (between turbocharger and engine) leaks
- ◆ Short circuit to B+
- ◆ Mass air flow sensor faulty
- ◆ Throttle jacking unit faulty



#### Note!

In the case of a fault, the PSM is switched off.

#### Affected terminals

Terminal III/23

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check intake air system for leaks.	⇒ Step 2.	Repair intake air system → End.
2	Check wiring from MAF sensor to DME control module for short to B+. <ul style="list-style-type: none"> <li>◆ Remove connector of MAF sensor.</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure voltage between special tool 9637 pin III/23 and ground.</li> <li>◆ Switch on the ignition.</li> </ul>	0 V ⇒ Step 3.	
3	Check signal from MAF sensor. <ul style="list-style-type: none"> <li>◆ Check voltage signal from MAF sensor with 'Ignition on' (with Porsche System Tester 2 in the 'Actual values/mass air flow' menu, or with a voltmeter and special tool 9637).</li> </ul>	0.9 to 1.1 V.	Replace MAF sensor ⇒ Step 5.

Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Start the engine.</li> </ul>	1.2 to 1.5 V (at idle speed) ⇒ Step 4.	
4	Check and clean throttle jacking unit.	<ul style="list-style-type: none"> <li>◆ Read out throttle actual value at idling speed (engine at operating temperature, air conditioning switched off).</li> </ul>	Less than 4 % → End.
5	Clean air cleaner and replace filter element.	<ul style="list-style-type: none"> <li>◆ Clean pure air side of air cleaner (extract dirt, do not blow out with compressed air with mass air flow sensor installed).</li> <li>◆ Replace filter element.</li> </ul>	

**P0107****299 Ambient Pressure Sensor - Below Limit****Diagnosis conditions**

- Ignition on

**Possible fault cause**

- ◆ DME control module

**Affected terminals**

-

**Diagnosis/troubleshooting****Note!**

*If no fault is present, erase the fault memory.*

Work instruction		Display OK	If not OK
1	Replace DME control module		
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>		



## P0108

### 299 Ambient Pressure Sensor - Above Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ DME control module

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

If no fault is present, erase the fault memory.

Work instruction		Display OK	If not OK
1	Replace DME control module		
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>		



## P0112

### 124 Intake air temperature - below limit

#### Diagnosis conditions

- Idle speed
- Time elapsed after engine start-up greater than 5 minutes

#### Possible fault cause

- ◆ Temperature sensor faulty
- ◆ Short circuit to B+
- ◆ Open circuit



#### Note!

A substitute value (approx. 60 °C) is used in the event of a fault.

#### Affected terminals

Terminal III/34

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check temperature sensor <ul style="list-style-type: none"> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure resistance between temperature sensor Pin 1 and Pin 2</li> </ul>	2.3 - 2.7 kΩ (at 20 °C) ⇒ Step 2	Replace temperature sensor → End



Work instruction		Display OK	If not OK	
2	Check wiring from DME control module to temperature sensor for continuity	<ul style="list-style-type: none"> <li>◆ Remove plug of temperature sensor</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module connector).</li> <li>◆ Measure resistance between special tool 9637 Pin III/34 and temperature sensor plug Pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End
3	Check wiring from DME control module to temperature sensor for short to B+	<ul style="list-style-type: none"> <li>◆ Remove plug of temperature sensor</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module connector).</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 Pin III/34 and ground</li> </ul>	0 V → End	Repair wiring harness → End

## P0113

### 124 Intake air temperature sensor - above limit

#### Diagnosis conditions

- Idle speed
- Time elapsed after engine start-up greater than 2 seconds

#### Possible fault cause

- ◆ Short circuit to ground



#### Note!

A substitute value (approx. 60 °C) is used in the event of a fault.

#### Affected terminals

Terminal III/34

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check wiring from DME control module to temperature sensor for short to ground	<ul style="list-style-type: none"> <li>◆ Remove plug of temperature sensor</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module connector).</li> <li>◆ Measure resistance between special tool 9637 Pin III/34 and ground</li> </ul>	<ul style="list-style-type: none"> <li>◆ ∞ Ω</li> <li>→ End</li> </ul>	<ul style="list-style-type: none"> <li>◆ Repair wiring harness</li> <li>→ End</li> </ul>



## P0115

### 123 Engine temperature - signal implausible

#### Diagnosis conditions

- A temperature model is formed. If the measured temperature deviates too much from the calculated temperature, a fault is detected.



#### Note!

*A thermostat which is constantly open can cause the fault P0115.*

#### Possible fault cause

- ◆ Thermostat (permanently open)
- ◆ Open coolant shutoff valve (only Tiptronic vehicles)
- ◆ Wiring
- ◆ Temperature sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal III/22 and III/17

#### Resistance values

0 °C	5.0 - 7.0 kΩ
20 °C	2.0 - 3.0 kΩ
60 °C	0.4 - 0.8 kΩ

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check thermostat	⇒ Step 2	Replace thermostat → End
2	Check coolant shutoff valve in Tiptronic vehicles	⇒ Step 3	Replace coolant shutoff valve in Tiptronic vehicles → End

Work instruction		Display OK	If not OK
3	Check temperature sensor	<ul style="list-style-type: none"> <li>◆ Remove plug connection in engine compartment</li> <li>◆ Measure resistance between temperature sensor Pin 1 and Pin 4</li> </ul>	Approx. 2 - 3 k $\Omega$ ⇒ Step 4 Replace temperature sensor → End
4	Check output voltage of DME control module	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637. Do not connect connector III of vehicle wiring harness.</li> <li>◆ Measure voltage between Pin III/22 and III/17</li> <li>◆ Ignition on</li> </ul>	Approx. 5 V → End ⇒ Step 5
5	Check wiring from DME control module to temperature sensor for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure resistance between special tool 9637 Pin III/17 and temperature sensor plug connection Pin 4</li> <li>◆ Measure resistance between special tool 9637 Pin III/22 and temperature sensor plug connection Pin 1</li> </ul>	0 - 5 $\Omega$ ⇒ Step 6 Repair wiring harness → End
6	Check wiring from DME control module to temperature sensor for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure resistance between special tool 9637 Pin III/22 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 7 Repair wiring harness → End
7	Check wiring from DME control module to temperature sensor for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure voltage between Pin III/22 and ground</li> </ul>	Approx. 5 V ⇒ Step 8 Repair wiring harness → End
8	Replace DME control module		⇒ Step 9 → End
9	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute. Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory</li> </ul>	→ End → End





## P0116

### Engine Temperature – Signal Implausible

#### Diagnosis conditions

- A temperature model is formed. If the measured temperature deviates too much from the calculated temperature, a fault is detected.



#### Note!

*A thermostat which is constantly open can cause the fault P0115.*

#### Possible fault cause

- ◆ Thermostat (permanently open)
- ◆ Open coolant shutoff valve (only Tiptronic vehicles)
- ◆ Wiring
- ◆ Temperature sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal III/22 and III/17

#### Resistance values

0 °C	5.0 -7.0 kΩ
20 °C	2.0 - 3.0 kΩ
60 °C	0.4 -0.8 kΩ

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check thermostat	⇒ Step 2.	Replace thermostat → End
2	Check coolant shutoff valve in Tiptronic vehicles	⇒ Step 3.	Replace coolant shutoff valve in Tiptronic vehicles → End



Work instruction		Display OK	If not OK
3	Check temperature sensor.	<ul style="list-style-type: none"> <li>◆ Remove plug connection in engine compartment</li> <li>◆ Measure resistance between temperature sensor Pin 1 and Pin 4</li> </ul>	Approx. 2 - 3 k $\Omega$ ⇒ Step 4  Replace temperature sensor → End
4	Check output voltage of DME control module	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637. Do not connect connector III of vehicle wiring harness.</li> <li>◆ Measure voltage between Pin III/22 and III/17</li> <li>◆ Ignition on</li> </ul>	Approx. 5 V → End  ⇒ Step 5.
5	Check wiring from DME control module to temperature sensor for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure resistance between special tool 9637 Pin III/17 and temperature sensor plug connection Pin 4</li> <li>◆ Measure resistance between special tool 9637 Pin III/22 and temperature sensor plug connection Pin 1</li> </ul>	0 - 5 $\Omega$ ⇒ Step 6.  Repair wiring harness → End.
6	Check wiring from DME control module to temperature sensor for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure resistance between special tool 9637 pin III/22 and ground.</li> </ul>	$\infty \Omega$ ⇒ Step 7.  Repair wiring harness → End
7	Check wiring from DME control module to temperature sensor for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure voltage between Pin III/22 and ground.</li> </ul>	Approx. 5 V ⇒ Step 8  Repair wiring harness → End.
8	Replace DME control module.		⇒ Step 9.  → End.
9	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute. Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.  → End.





## P0117

### 123 Engine temperature - open circuit, below limit

#### Diagnosis conditions

- A fault is recorded after a debounce time of 0.4 seconds if an engine temperature of less than -45 °C is measured.

#### Possible fault cause

- ◆ Wiring
- ◆ Temperature sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal III/22 and III/17

#### Resistance values

0 °C	5.0 - 7.0 kΩ
20 °C	2.0 - 3.0 kΩ
60 °C	0.4 - 0.8 kΩ

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check temperature sensor	◆ Remove plug connection in engine compartment ◆ Measure resistance between temperature sensor Pin 1 and Pin 4	Approx. 2 - 3 kΩ ⇒ Step 2
2	Check output voltage of DME control module	◆ Connect special tool 9637. Do not connect connector III of vehicle wiring harness. ◆ Measure voltage between Pin III/22 and III/17 ◆ Ignition on	Approx. 5 V → End
			Replace temperature sensor → End
			⇒ Step 3

Work instruction		Display OK	If not OK
3	<p>Check wiring from DME control module to temperature sensor for continuity</p> <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure resistance between special tool 9637 Pin III/17 and temperature sensor plug connection Pin 4</li> <li>◆ Measure resistance between special tool 9637 Pin III/22 and temperature sensor plug connection Pin 1</li> </ul>	<p>0 - 5 <math>\Omega</math> ⇒ Step 4</p>	<p>Repair wiring harness → End</p>
4	<p>Check wiring from DME control module for short to B+</p> <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure voltage between Pin III/22 and ground</li> <li>◆ Switch on the ignition</li> </ul>	<p>Approx. 5 V ⇒ Step 5</p>	<p>Repair wiring harness → End</p>
5	<p>Replace DME control module</p>	<p>⇒ Step 6</p>	<p>→ End</p>
6	<p>Perform adaptation</p> <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute. Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory</li> </ul>	<p>→ End</p>	<p>→ End</p>

## P0118

### 123 Engine temperature - above limit

#### Diagnosis conditions

- A fault is recorded after a debounce time of 0.4 seconds if an engine temperature of more than 140°C is measured.

#### Possible fault cause

- ◆ Wiring
- ◆ Temperature sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal III/22 and III/17

#### Resistance values

0 °C	5.0 - 7.0 kΩ
20 °C	2.0 - 3.0 kΩ
60 °C	0.4 - 0.8 kΩ

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check temperature sensor	◆ Remove plug connection in engine compartment ◆ Measure resistance between temperature sensor Pin 1 and Pin 4	Approx. 2 - 3 kΩ ⇒ Step 1
2	Check output voltage of DME control module	◆ Connect special tool 9637. Do not connect connector III of vehicle wiring harness. ◆ Measure voltage between Pin III/22 and III/17 ◆ Ignition on	Approx. 5 V ⇒ End
			Replace temperature sensor → End
			⇒ Step 3

Work instruction		Display OK	If not OK
3	<p>Check wiring from DME control module to temperature sensor for continuity</p> <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure resistance between special tool 9637 Pin III/17 and temperature sensor plug connection Pin 4</li> <li>◆ Measure resistance between special tool 9637 Pin III/22 and temperature sensor plug connection Pin 1</li> </ul>	<p>0 - 5 <math>\Omega</math> ⇒ Step 4</p>	<p>Repair wiring harness → End</p>
4	<p>Check wiring from DME control module to temperature sensor for short to ground</p> <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug of temperature sensor</li> <li>◆ Measure resistance between special tool 9637 Pin III/22 and ground</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 5</p>	<p>Repair wiring harness → End</p>
5	Replace DME control module	⇒ Step 6	→ End
6	<p>Perform adaptation</p> <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute. Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End

## P0121

### 117 Throttle valve - signal implausible

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit or short circuit in the wiring
- ◆ Throttle position sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal I/7, I/9, III/8, III/10, III/24 and III/25



#### Note!

- ◆ *Fault P0121 only appears in conjunction with fault P1121 or P1122.*
- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The opening angle of the throttle valve is limited to 30 %.*
- ◆ *The dynamic of the throttle valve is restricted.*

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply to throttle motor actuator	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Connect motor tester (oscilloscope) to Pin I/7 and Pin I/9</li> <li>◆ Use special input</li> <li>◆ Switch on the ignition</li> <li>◆ Fully depress accelerator pedal</li> </ul> See Figure 1  See Figure 2 ⇒ Step 2	⇒ Step 5



Figure 1:





Figure 2:



Work instruction		Display OK	If not OK	
2	Check TP voltage supply.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> <li>◆ Switch on the ignition</li> </ul>	Approx. 5 V ⇒ Step 3	⇒ Step 4
3	Check voltage values of throttle position sensors.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> </ul>	Approx. 0.7 - 0.9 V  Approx. 4.1 - 4.5 V Approx. 4.0 - 4.4 V	Replace throttle part → End
		<ul style="list-style-type: none"> <li>◆ Fully depress accelerator pedal</li> </ul>	Approx. 0.5 V → End	
4	Check wiring from throttle part to DME control module for continuity or short circuit to B+ and ground	<ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> </ul>		


Work instruction	Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 5 and special tool 9637 Pin III/8</li> <li>◆ Measure resistance between disconnection point Pin 6 and special tool 9637 Pin III/24</li> <li>◆ Measure resistance between disconnection point Pin 4 and ground</li> <li>◆ Measure resistance between disconnection point Pin 5 and ground</li> <li>◆ Measure resistance between disconnection point Pin 6 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between disconnection point Pin 4 and ground</li> <li>◆ Measure voltage between disconnection point Pin 5 and ground</li> <li>◆ Measure voltage between disconnection point Pin 6 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p><math>\infty</math> <math>\Omega</math></p> <p><math>\infty</math> <math>\Omega</math></p> <p><math>\infty</math> <math>\Omega</math></p> <p>0 V</p> <p>0 V</p> <p>0 V</p> <p>0 V ⇒ Step 5</p> <p>Repair wiring harness ⇒ End</p>

Disconnection point throttle part:



**Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module	⇒ Step 6	
6	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End

## P0121

### Accelerator Pedal Potentiometer 1 – Signal Implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Pedal sensor

#### Affected terminals

-



#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace pedal sensor	→ End.	→ End.



## P0122

### Accelerator Pedal Potentiometer 1 – Below Limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground
- ◆ Pedal sensor

#### Affected terminals

Terminal IV/8

#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, Pin IV/8, to pedal sensor, Pin 2, for short circuit to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool Pin IV/8 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 2.	Repair wiring harness → End.
2	Replace pedal sensor	→ End.	→ End.



## P0123

### Accelerator Pedal Potentiometer 1 – Above Limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to B+
- ◆ Pedal sensor

#### Affected terminals

Terminal IV/8

#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module IV/8 to pedal sensor, Pin 2, for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between special tool Pin IV/8 and ground</li> </ul>	0 V ⇒ Step 2.	Repair wiring harness → End.
2	Replace pedal sensor	→ End.	→ End.





## P0125

### Engine Temperature - Open Circuit

#### Diagnosis conditions

- A fault is recorded after a debounce time of 0.4 seconds if an engine temperature of less than -45 °C is measured.

#### Possible fault cause

- ◆ Wiring
- ◆ Temperature sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal III/22 and III/17

#### Resistance values

0 °C	5.0 -7.0 kΩ
20 °C	2.0 -3.0 kΩ
60 °C	0,4 -0,8 kΩ

### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check temperature sensor.	<ul style="list-style-type: none"> <li>◆ Remove plug connection in engine compartment</li> <li>◆ Measure resistance between temperature sensor Pin 1 and Pin 4</li> </ul>	Approx. 2 - 3 kΩ ⇒ Step 2	Replace temperature sensor → End
2	Check output voltage of DME control module	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637. Do not connect connector III of vehicle wiring harness.</li> <li>◆ Measure voltage between Pin III/22 and III/17</li> <li>◆ Ignition on</li> </ul>	Approx. 5 V → End	⇒ Step 3.

Work instruction		Display OK	If not OK	
3	Check wiring from DME control module to temperature sensor for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure resistance between special tool 9637 Pin III/17 and temperature sensor plug connection Pin 4</li> <li>◆ Measure resistance between special tool 9637 Pin III/22 and temperature sensor plug connection Pin 1</li> </ul>	0 - 5 $\Omega$ ⇒ Step 4.	Repair wiring harness → End.
4	Check wiring from DME control module for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure voltage between pin III/22 and ground.</li> <li>◆ Switch on the ignition.</li> </ul>	Approx. 5 V ⇒ Step 5	Repair wiring harness → End.
5	Replace DME control module.	⇒ Step 6.	→ End.	
6	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute. Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.

## P0128

### Blocked Thermostat - Signal Implausible

#### Diagnosis conditions

- Engine starting temperature between -10° C and +45° C
- Idle speed

#### Possible fault cause



#### Note!

- ◆ *Fault P0128 is only stored in conjunction with fault P0116 (Engine temperature).*
- ◆ *If the coolant shutoff valve or the transmission oil temperature sensor are stored, remedy the fault first.*
- ◆ Open coolant control
- ◆ Open coolant shutoff valve

#### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check engine temperature sensor.	◆ see P0115 or P0116	
2	Check coolant control		
3	Check coolant shutoff valve.		



## P0129

### Ambient Pressure Sensor – Below Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ DME control module

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

*If no fault is present, erase the fault memory.*

Work instruction		Display OK	If not OK
1	Replace DME control module.		
2	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>		



## P0130

### 02 Sensor Circuit

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*The DTC (diagnostic trouble code) covers all electrical faults here.*

### Diagnostic conditions

- Engine temperature greater than 60°C
- 3 minutes idle speed, then 30 seconds increased idle speed

### Possible cause of fault

- ◆ Short circuit to B+
- ◆ Short circuit to ground
- ◆ Open circuit
- ◆ Oxygen sensor faulty
- ◆ Control module faulty

### Affected pins

DME control module connector II, pin 9 and oxygen sensor jack, bank 1, pin 5

DME control module connector II, pin 15 and oxygen sensor jack, bank 1, pin 1

DME control module connector II, pin 2 and pin 5

### Diagnosis/troubleshooting

 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*



Work instruction		Display OK	If not OK	
1	Check reference voltage on component	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 1 and 5 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV Oxygen sensor faulty ⇒ Replace oxygen sensor → End	⇒ Step 2
2	Check reference voltage on control module	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between test adapter pin II/9 and pin II/15</li> </ul>	Approx. 450 mV ⇒ Step 3	⇒ Step 6
3	Check wiring for short circuit to B+	Measure voltage between test adapter: <ul style="list-style-type: none"> <li>◆ Pin II/9 and ground</li> <li>◆ Pin II/15 and ground</li> <li>◆ Pin II/2 and ground</li> <li>◆ Pin II/5 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 4	Repair wiring; correct cause of damage, if necessary → End
4	Check wiring for short circuit to ground	Measure resistance between test adapter: <ul style="list-style-type: none"> <li>◆ Pin II/9 and ground</li> <li>◆ Pin II/15 and ground</li> <li>◆ Pin II/2 and ground</li> <li>◆ Pin II/5 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 5	Repair wiring; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
5	Check wiring for open circuit  Measure resistance between test adapter: <ul style="list-style-type: none"> <li>◆ Pin II/9 and pin 5 of oxygen sensor jack</li> <li>◆ Pin II/15 and pin 1 of oxygen sensor jack</li> <li>◆ Pin II/2 and pin 2 of oxygen sensor jack</li> <li>◆ Pin II/5 and pin 6 of oxygen sensor jack</li> </ul>	$< 2 \Omega$ $\Rightarrow$ Step 6	Repair wiring; correct cause of damage, if necessary $\rightarrow$ End
6	Check whether additional faults have been recorded	$\Rightarrow$ Step 7	Correct faults in accordance with instructions $\rightarrow$ End
7	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## Diagnosis/troubleshooting - all naturally-aspirated models



### Note!

The DTC relates only to implausible signals here.

### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensor heating switched on for at least 60 seconds
- ◆ Exhaust temperature less than 800°C

### Possible cause of fault

- High-resistance short circuit to B+ in signal wire
- Heater coupling
- Oxygen sensor faulty
- Control module faulty

### Affected pins


DME control module connector II, pin 9 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 15 and oxygen sensor jack, bank 1, pin 4

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Check oxygen sensor signal using data logger <ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> Complete the following steps on the PST II <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 1'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 1' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	<ul style="list-style-type: none"> <li>◆ If fault appears as "not present" in the "extended fault memory", erase the fault memory (healed reference air contamination)</li> <li>◆ If fault appears as "present" in the "extended fault memory" ⇒ Step 7</li> </ul>	⇒ Step 2



Work instruction			Display OK	If not OK
2	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 3	Replace faulty component; correct cause of damage, if necessary → End
3	Check oxygen sensor for internal short circuit	Measure resistance between oxygen sensor: <ul style="list-style-type: none"> <li>◆ Pin 4 and pin 2</li> <li>◆ Pin 4 and pin 3</li> <li>◆ Pin 4 and oxygen sensor casing</li> <li>◆ Pin 3 and pin 2</li> </ul>	∞ Ω ⇒ Step 4	Replace oxygen sensor; correct cause of damage, if necessary → End
4	Check plug connection between DME control module and oxygen sensor wires	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 5	Replace faulty component; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
5	Check for short circuits in wiring between DME control module and oxygen sensor jack <ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>Measure resistance between adapter pins:               <ul style="list-style-type: none"> <li>◆ II/9 and pin II/15</li> <li>◆ II/9 and pin II/19</li> <li>◆ II/15 and pin II/19</li> <li>◆ II/15 and ground</li> </ul> </li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 6	Repair faulty wiring; correct cause of damage, if necessary $\rightarrow$ End
6	Check wiring for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>Measure voltage between adapter pins:               <ul style="list-style-type: none"> <li>◆ II/9 and ground</li> <li>◆ II/15 and ground</li> </ul> </li> </ul>	0 V $\Rightarrow$ Step 7	Repair faulty wiring; correct cause of damage, if necessary $\rightarrow$ End
7	Check whether additional faults have been recorded	$\Rightarrow$ Step 8	Correct faults in accordance with instructions $\rightarrow$ End
8	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0131

### 02 Sensor Circuit Low Voltage

#### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensing system active
- ◆ No secondary air
- ◆ No diagnosis of secondary air system
- ◆ No fuel tank ventilation

#### Possible cause of fault

- Short circuit to ground in signal wire
- Oxygen sensor faulty
- Control module faulty

#### Affected pins

DME control module connector II, pin 9 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 15 and oxygen sensor jack, bank 1, pin 4


#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check oxygen sensor signal using data logger	<ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> Complete the following steps on the PST II <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 1'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 1' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	⇒ Step 4	⇒ Step 2



Work instruction			Display OK	If not OK
2	Check oxygen sensor for internal short circuit	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> </ul> Measure resistance between oxygen sensor: <ul style="list-style-type: none"> <li>◆ Pin 4 and pin 3</li> <li>◆ Pin 4 and pin 2</li> <li>◆ Pin 4 and oxygen sensor casing</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 3	Replace oxygen sensor; correct cause of damage, if necessary $\rightarrow$ End
3	Check for short circuits in wiring between DME control module and oxygen sensor jack	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/9 and pin II/15</li> <li>◆ Pin II/15 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 4	Repair faulty wiring; correct cause of damage, if necessary $\rightarrow$ End
4	Check whether additional faults have been recorded		$\Rightarrow$ Step 5	Correct faults in accordance with instructions $\rightarrow$ End
5	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	



## P0132

### 02 Sensor Circuit High Voltage

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*The DTC here also covers the possibility of a mechanical malfunction in the valve drive.*

### Diagnostic conditions

 **Note!**

*It takes a very long time (several driving cycles) to detect a fault.*

### Possible cause of fault

- ◆ Valve lift fault
- ◆ False air on the oxygen sensor after catalytic converter
- ◆ Oxygen sensor faulty

### Affected terminals

 **Note!**

- ◆ *As this fault can be caused by a faulty flat-base tappet, a system test for a small lift has to be performed initially. The fault can occur sporadically; the test should therefore be performed at least three times when the engine is at operating temperature.*
- ◆ *First indication of a valve lift fault can be provided by the adaptation values at idle speed (RKAT) and in the lower part load (FRAU) if they differ by more than 10 %.*

## Perform system test for small lift



**Warning!**


**The test is carried out while driving. Get a second person to operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.


A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1****B - Oxygen sensing, bank 2****1 - Select System test.****2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the  key immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

** Note!**

*If 'Request small lift' appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4000 rpm) appears.**

At speeds above 4000 rpm, misfires may be stored. Erase the fault memory and repeat the test.

** Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**Diagnosis/troubleshooting**** Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check exhaust system for leaks		Repair exhaust system → End
2	Replace oxygen sensor		

## Diagnosis/troubleshooting - all naturally-aspirated models



### Note!

*The DTC only covers electrical faults here.*

### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Exhaust temperature less than 800°C
- ◆ Oxygen sensor heating switched on for at least 120 seconds



### Note!

*DTC P0132 is stored by the DME control module when the sensor voltage is continuously above 1.5 V for more than 5 seconds*

### Possible cause of fault

- Short circuit to B+ in signal wire
- Oxygen sensor faulty
- Control module faulty

### Affected pins

DME control module connector II, pin 9 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 15 and oxygen sensor jack, bank 1, pin 4


### Diagnosis/troubleshooting



### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	<p>Check oxygen sensor signal using data logger</p> <ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> <p>Complete the following steps on the PST II</p> <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 1'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 1' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	⇒ Step 4	⇒ Step 2



Work instruction		Display OK	If not OK
2	<p>Check oxygen sensor for internal short circuit</p> <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> </ul> <p>Measure resistance between oxygen sensor connector</p> <ul style="list-style-type: none"> <li>◆ Pin 1 and pin 4</li> <li>◆ Pin 1 and pin 3</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 3</p>	<p>Replace oxygen sensor; correct cause of damage, if necessary → End</p>
3	<p>Check for short circuit to B+ in wiring between DME control module and oxygen sensor jack</p> <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> </ul> <p>Measure voltage between adapter:</p> <ul style="list-style-type: none"> <li>◆ Pin II/9 and ground</li> <li>◆ Pin II/15 and ground</li> <li>◆ Switch off ignition</li> </ul>	<p>0 V ⇒ Step 4</p>	<p>Repair faulty wiring; correct cause of damage, if necessary → End</p>
4	<p>Check whether additional faults have been recorded</p>	<p>⇒ Step 5</p>	<p>Correct faults in accordance with instructions → End</p>
5	<p>Replace DME control module</p>	<p>To do this, please observe the notes on possible causes of faults in the introduction!</p>	

## P0133

### 10 Oxygen Sensor Ahead of TWC, Bank 1 – Below Limit

#### Diagnosis conditions

- Vehicle at operating temperature, after this 3 minutes idle speed, then approx. 30 seconds increased idle speed.

#### Possible fault cause

- ◆ Oxygen sensor is dynamically inert

#### Affected terminals

-

#### Diagnosis/Troubleshooting

##### Note!

*Do not use contact spray on the connectors to oxygen sensors.*


Work instruction		Display OK	If not OK
1	Replace oxygen sensor		

##### Note!

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter





## P0134

### 02 Sensor Circuit No Activity Detected

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*The DTC here covers the coupling of oxygen sensor heating into the sensor signal.*

### Diagnostic conditions

- Vehicle at operating temperature, then 3 minutes idle speed followed by 30 seconds increased idle speed

### Possible cause of fault

- ◆ Short circuit in oxygen sensor wiring
- ◆ Oxygen sensor faulty (heater coupling or heating)
- ◆ DME control module faulty

### Affected terminals

DME control module connector II, pin 9 and oxygen sensor connector after catalytic converter, bank 1, pin 5

DME control module connector II, pin 15 and oxygen sensor connector after catalytic converter, bank 1, pin 1

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Visual inspection</li> </ul> Measure resistance between oxygen sensor connector: <ul style="list-style-type: none"> <li>◆ Pin 1 and pin 4</li> <li>◆ Pin 4 and pin 5</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 2	Oxygen sensor faulty $\Rightarrow$ Replace oxygen sensor $\rightarrow$ End
2	Check wiring harness between DME control module and oxygen sensor jack <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/9 and pin II/19</li> <li>◆ Pin II/15 and pin II/19</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 3	Repair wiring; correct cause of damage, if necessary $\rightarrow$ End
3	Check whether additional faults have been recorded	$\Rightarrow$ Step 4	Correct faults in accordance with instructions $\rightarrow$ End
4	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## Diagnosis/troubleshooting - all naturally-aspirated models



### Note!

The DTC covers electrical open circuits here.

### Diagnostic conditions

- Exhaust temperature between 400°C and 800°C
- Battery positive voltage between 10 V and 16 V
- Oxygen sensor heating switched on for at least 120 seconds

**Possible cause of fault**

- ◆ Loose contact in connector
- ◆ Open circuit in the oxygen sensor signal wire
- ◆ Open circuit in the oxygen sensor ground wire
- ◆ Oxygen sensor faulty (also heating)
- ◆ DME control module faulty

**Affected terminals**


DME control module connector II, pin 9 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 15 and oxygen sensor jack, bank 1, pin 4

**Diagnosis/troubleshooting****Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor signal using data logger <ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> Complete the following steps on the PST II <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 1'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 1' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	⇒ Step 7	⇒ Step 2



Work instruction		Display OK	If not OK
2	Check oxygen sensor plug connection <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 1</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 3	Replace faulty component; correct cause of damage, if necessary → End
3	Check oxygen sensor heating <p>Measure resistance between pins 1 and 2 of oxygen sensor connector</p>	8 to 11 Ω ⇒ Step 4	Replace oxygen sensor → End
4	Check reference voltage on the oxygen sensor <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Oxygen sensor faulty → Replace oxygen sensor	⇒ Step 5
5	Check DME control module plug connection <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 6	Replace faulty component; correct cause of damage, if necessary → End

Work instruction			Display OK	If not OK
6	Check reference voltage on DME control module	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Step 7	⇒ Step 8
7	Check for open circuit in wiring between DME control module and oxygen sensor jack	Measure resistance between: <ul style="list-style-type: none"> <li>◆ Adapter pin II/9 and pin 3 of oxygen sensor jack</li> <li>◆ Adapter pin II/15 and pin 4 of oxygen sensor jack</li> </ul>	< 2 Ω ⇒ Sporadic fault; localise the fault as far as possible and then correct it; correct cause of damage, if necessary → End	Repair faulty wiring; correct cause of damage, if necessary → End
8	Check whether additional faults have been recorded		⇒ Step 9	Correct faults in accordance with instructions → End
9	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0135

### 02 Sensor Heater Circuit

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*This fault can be detected in two different operating states. To find out whether the fault was recorded under load or with inertia fuel shutoff, refer to the "extended fault memory".*

#### Diagnostic conditions for fault detection under load

- Mass air flow above 16 kg/h
- No other oxygen sensor faults
- Battery positive voltage between 10 V and 16 V

#### Diagnostic conditions for fault detection with inertia fuel shutoff

- Exhaust temperature above 250°C
- Battery positive voltage greater than 10 V
- Time elapsed after start-up greater than 60 seconds
- No oxygen sensor faults
- Inertia fuel shutoff for more than 4 seconds

#### Possible cause of fault

- ◆ Open circuit
- ◆ Oxygen sensor faulty (heating)
- ◆ DME control module faulty

#### Affected terminals

DME control module, connector II, pin 19 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 4

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection	
2	Check oxygen sensor heating	◆ Remove oxygen sensor connector ahead of catalytic converter Bank 1 ◆ Check resistance between pins 3 and 4 towards the oxygen sensor	3.0 to 3.5 $\Omega$ at 20°C  Replace oxygen sensor
3	Check voltage supply for oxygen sensor heating	◆ Start the engine ◆ Measure voltage between pin 3 towards the DME control module and ground	Battery positive voltage ⇒ Step 4  ⇒ Repair voltage supply
4	Check wiring	◆ Check resistance between pin 4 and pin II/19	<2 $\Omega$  ⇒ Repair wiring
5	Check oxygen sensor	◆ Check resistance between pin 4 and the oxygen sensor casing ◆ Check resistance between pin 1 and the oxygen sensor casing ◆ Check resistance between pin 2 and the oxygen sensor casing ◆ Check resistance between pin 5 and the oxygen sensor casing ◆ Check resistance between pin 6 and the oxygen sensor casing	$\infty$ $\Omega$ If fault was recorded during inertia fuel shutoff ⇒ Check engine oil consumption  Replace oxygen sensor

**Diagnosis/troubleshooting - all naturally-aspirated models****Diagnostic conditions**

- Exhaust temperature between 250°C and 550°C
- No other oxygen sensor faults
- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 200 seconds

**Possible cause of fault**

- ◆ High resistance in connector or triggering wire

**Affected terminals**

DME control module, connector II, pin 19 and oxygen sensor jack ahead of catalytic converter, bank 1, pin 2

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Remove oxygen sensor connector</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 4	Replace faulty component; correct cause of damage, if necessary → End
4	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between adapter pin II/19 and pin 2 of oxygen sensor jack</li> </ul>	< 2 Ω ⇒ Step 5	Repair faulty wiring; correct cause of damage, if necessary → End
5	Check whether additional faults have been recorded		⇒ Step 6	Correct faults in accordance with instructions → End
6	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	



## P0136



### Note!

- ◆ *Signal implausible: Turbo models up to model year 01 only*
- ◆ *Below limit: Turbo only*
- ◆ *Above limit: All models*

## 02 Sensor Circuit

### Diagnostic conditions

- Exhaust temperature between 250°C and 750°C
- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 200 seconds
- No secondary air
- No diagnosis of secondary air system
- No fuel tank ventilation
- No diagnosis of fuel tank ventilation system
- No other oxygen sensor faults

### Possible cause of fault

- ◆ Short circuit to ground in signal wire
- ◆ Intercore short circuit

### Affected terminals

DME control module connector II, pin 11 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 17 and oxygen sensor jack, bank 1, pin 4

### Diagnosis/troubleshooting



### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check wiring harness	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 4 and 3 towards the control module</li> </ul>	Approx. 450 mV ⇒ Step 3	⇒ Step 2
2		<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Measure resistance at pin 4 and ground towards the control module</li> <li>◆ Measure resistance at pin 4 and pin 3 towards the control module</li> </ul>	∞ Ω	Repair wiring harness
3	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Measure resistance at pins 2 and 3</li> <li>◆ Measure resistance at pins 2 and 4</li> <li>◆ Measure resistance at pin 3 and ground</li> <li>◆ Measure resistance at pin 4 and ground</li> <li>◆ Measure resistance at pins 3 and 4</li> </ul>	∞ Ω	Replace oxygen sensor

## 02 Sensor Circuit Slow Response

### Diagnostic conditions

- Air mass between 25 kg/h and 120 kg/h
- Oxygen sensing after catalytic converter is active
- Basic adaptation has reached steady condition
- No secondary air diagnosis
- No fuel tank ventilation diagnosis
- EVAP canister not highly loaded
- No other oxygen sensor faults

### Possible cause of fault

- ◆ Oxygen sensor faulty

**Affected terminals**

-

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Erase fault memory, then road test vehicle or perform short test	<ul style="list-style-type: none"> <li>◆ Erase fault memory</li> <li>◆ Heat the oxygen sensors (road test car under load, run engine without load at high rpm)</li> <li>◆ Road test vehicle or perform short test, ensuring that the diagnostic conditions are met</li> </ul>	⇒ Step 2
2	Read out the fault memory	No fault stored → End	Replace oxygen sensor

## P0137

### 02 Sensor Circuit Low Voltage

#### Diagnostic conditions

- ◆ Exhaust temperature between 250°C and 750°C
- ◆ Time elapsed after engine start-up greater than 200 seconds
- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensing system active
- ◆ No other oxygen sensor faults
- ◆ No secondary air
- ◆ No diagnosis of secondary air system
- ◆ No fuel tank ventilation
- ◆ No diagnosis of fuel tank ventilation system

#### Possible cause of fault

- Short circuit to ground in signal wire
- Oxygen sensor faulty
- Control module faulty

#### Affected pins

DME control module connector II, pin 11 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 17 and oxygen sensor jack, bank 1, pin 4

#### Diagnosis/troubleshooting

##### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check voltage supply	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Measure voltage between pins 4 and 3 towards the control module</li> </ul>	<p>Approx. 450 mV ⇒ Step 2</p> <p>⇒ Step 3</p>
2	Check oxygen sensor for internal short circuit	<p>Measure resistance between oxygen sensor:</p> <ul style="list-style-type: none"> <li>◆ Pin 4 and pin 3</li> <li>◆ Pin 2 and pin 3</li> <li>◆ Pin 2 and pin 4</li> <li>◆ Pin 4 and oxygen sensor casing</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 3</p> <p>Replace oxygen sensor; correct cause of damage, if necessary → End</p>
3	Check for short circuit in wiring between DME control module and oxygen sensor jack	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> <p>Measure resistance between adapter:</p> <ul style="list-style-type: none"> <li>◆ Pin II/11 and pin II/17</li> <li>◆ Pin II/17 and ground</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 4</p> <p>Repair faulty wiring; correct cause of damage, if necessary → End</p>
4	Check whether additional faults have been recorded	⇒ Step 5	Correct faults in accordance with instructions → End
5	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0138

### 02 Sensor Circuit High Voltage

#### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Exhaust temperature less than 800°C
- ◆ Oxygen sensor heating switched on for at least 120 seconds

#### Possible cause of fault

- Short circuit to B+ in signal wire
- Oxygen sensor faulty
- Control module faulty

#### Affected pins

DME control module connector II, pin 11 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 17 and oxygen sensor jack, bank 1, pin 4

#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check voltage supply	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Measure voltage between pins 4 and 3 towards the control module</li> </ul>	Approx. 450 mV ⇒ Step 2	⇒ Step 3
2	Check oxygen sensor for internal short circuit	Measure resistance between oxygen sensor connector <ul style="list-style-type: none"> <li>◆ Pin 1 and pin 4</li> <li>◆ Pin 1 and pin 3</li> </ul>	$\infty \Omega$ ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check for short circuit to B+ in wiring between DME control module and oxygen sensor jack	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> </ul> Measure voltage between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/11 and ground</li> <li>◆ Pin II/17 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 4	Repair faulty wiring; correct cause of damage, if necessary → End
4	Check whether additional faults have been recorded	⇒ Step 5	Correct faults in accordance with instructions → End	
5	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!		

## P0139

### 02 Sensor Circuit Slow Response

#### Diagnostic conditions

- Air mass between 25 kg/h and 120 kg/h
- Oxygen sensing after catalytic converter is active
- Basic adaptation has reached steady condition
- No secondary air diagnosis
- No fuel tank ventilation diagnosis
- EVAP canister not highly loaded
- No other oxygen sensor faults

#### Possible cause of fault

- ◆ Oxygen sensor faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Erase fault memory, then road test vehicle or perform short test	<ul style="list-style-type: none"> <li>◆ Erase fault memory</li> <li>◆ Heat the oxygen sensors (road test car under load, run engine without load at high rpm)</li> <li>◆ Road test vehicle or perform short test, ensuring that the diagnostic conditions are met</li> </ul>	⇒ Step 2
2	Read out the fault memory	No fault stored → End	Replace oxygen sensor



## P0140

### 02 Sensor Circuit No Activity Detected

#### Diagnostic conditions

- Exhaust temperature between 250°C and 750°C
- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 200 seconds
- Oxygen sensor heating switched on for at least 120 seconds

#### Possible cause of fault

- ◆ Loose contact or corrosion in connector
- ◆ Open circuit in the oxygen sensor signal wire
- ◆ Open circuit in the oxygen sensor ground wire
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected terminals

DME control module connector II, pin 11 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 17 and oxygen sensor jack, bank 1, pin 4


#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	<p>Check oxygen sensor signal using data logger</p> <ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> <p>Complete the following steps on the PST II</p> <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 1'</li> <li>◆ Highlight 'U Oxygen sensor after TWC, bank 1' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	⇒ Step 7	⇒ Step 2



Work instruction			Display OK	If not OK
2	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 3	Replace faulty component; correct cause of damage, if necessary → End
3	Check oxygen sensor heating	Measure resistance between pins 1 and 2 of oxygen sensor connector	8 to 11 Ω ⇒ Step 4	→ Replace oxygen sensor
4	Check reference voltage on the oxygen sensor	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Oxygen sensor faulty	⇒ Step 5
5	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 6	Replace faulty component; correct cause of damage, if necessary → End
6	Check reference voltage on DME control module	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Step 7	⇒ Step 8
7	Check for open circuit in wiring between DME control module and oxygen sensor jack	Measure resistance between: <ul style="list-style-type: none"> <li>◆ Adapter pin II/11 and pin 3 of oxygen sensor jack</li> <li>◆ Adapter pin II/17 and pin 4 of oxygen sensor jack</li> </ul>	< 2 Ω ⇒ Sporadic fault; localise the fault as far as possible and then correct it; correct cause of damage, if necessary → End	Repair faulty wiring; correct cause of damage, if necessary → End
8	Check whether additional faults have been recorded		⇒ Step 9	Correct faults in accordance with instructions → End
9	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0141

### 02 Sensor Heater Circuit

#### Signal implausible

##### Diagnostic conditions

- Exhaust temperature between 300°C and 600°C
- Battery positive voltage between 10 V and 16 V

##### Possible cause of fault

- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty

##### Affected terminals

DME control module connector II, pin 7 and oxygen sensor jack, bank 1, pin 2

##### Diagnosis/troubleshooting



##### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection of all affected plug connections	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check oxygen sensor heating	◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1 ◆ Check resistance between pins 1 and 2 towards the oxygen sensor	8 to 11 Ω at 20°C ⇒ Step 3	Replace oxygen sensor → End
3	Check oxygen sensor	◆ Check resistance between pin 1 and the oxygen sensor casing ◆ Check resistance between pins 1 and 3	∞ Ω	

## Open circuit

### Diagnostic conditions

- Engine running

### Possible cause of fault

- ◆ Resistance of oxygen sensor heating too high
- ◆ Open circuit

### Affected terminals

DME control module connector II, pin 7 and oxygen sensor jack, bank 1, pin 2

### Diagnosis/troubleshooting



#### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Check resistance between pins 1 and 2 towards the oxygen sensor</li> </ul>	8 to 11 $\Omega$ at 20°C	Replace oxygen sensor
2	Check B+ supply	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage at pin 1 towards the DME control module and ground</li> </ul>	Battery positive voltage	Repair wiring harness
3	Check connection to ground	<ul style="list-style-type: none"> <li>◆ Check wire from pin 2 to DME control module pin II/7 for continuity</li> </ul>	< 2 $\Omega$	

## Below limit

### Diagnostic conditions

- Engine running

**Possible cause of fault**

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

**Affected terminals**

DME control module connector II, pin 7 and oxygen sensor jack, bank 1, pin 2

**Diagnosis/troubleshooting**
 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 2  Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 3  Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check oxygen sensor for short circuit to ground	Measure resistance between oxygen sensor connector: <ul style="list-style-type: none"> <li>◆ Pin 2 and pin 3</li> <li>◆ Pin 2 and oxygen sensor casing</li> </ul>	∞ Ω ⇒ Step 4  Replace oxygen sensor; correct cause of damage, if necessary → End
4	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 5  Replace faulty component; correct cause of damage, if necessary → End
5	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/7 and pin II/11</li> <li>◆ Pin II/7 and ground</li> </ul>	∞ Ω ⇒ Step 6  Repair wiring; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
6	Check whether additional faults have been recorded	⇒ Step 7	Correct faults in accordance with instructions → End
7	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## Above limit

### Diagnostic conditions

- Engine running

### Possible cause of fault

- ◆ Oxygen sensor faulty (heating)
- ◆ Short circuit to B+
- ◆ DME control module faulty

### Affected terminals

DME control module connector II, pin 7 and oxygen sensor jack, bank 1, pin 2

### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction			Display OK	If not OK
1	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 1</li> <li>◆ Visual inspection</li> <li>◆ Measure oxygen sensor heating resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 $\Omega$ to 11 $\Omega$ ⇒ Step 2	Replace oxygen sensor; correct cause of damage, if necessary → End
2	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between adapter pin II/7 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 3	Repair faulty wiring; correct cause of damage, if necessary → End
3	Check whether additional faults have been recorded		⇒ Step 4	Correct faults in accordance with instructions → End
4	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	



## P0150

### 02 Sensor Circuit

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*The DTC (diagnostic trouble code) covers all electrical faults here.*

### Diagnostic conditions

- Engine temperature greater than 60°C
- 3 minutes idle speed, then 30 seconds increased idle speed

### Possible cause of fault

- ◆ Short circuit to B+
- ◆ Short circuit to ground
- ◆ Open circuit
- ◆ Oxygen sensor faulty
- ◆ Control module faulty

### Affected pins

DME control module connector II, pin 10 and oxygen sensor jack, bank 2, pin 5

DME control module connector II, pin 16 and oxygen sensor jack, bank 2, pin 1

DME control module connector II, pin 6 and pin 24

### Diagnosis/troubleshooting

 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check reference voltage on component	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 1 and 5 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV Oxygen sensor faulty ⇒ Replace oxygen sensor → End	⇒ Step 2
2	Check reference voltage on control module	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between test adapter pin II/10 and pin II/16</li> </ul>	Approx. 450 mV ⇒ Step 3	⇒ Step 6
3	Check wiring for short circuit to B+	Measure voltage between test adapter: <ul style="list-style-type: none"> <li>◆ Pin II/10 and ground</li> <li>◆ Pin II/16 and ground</li> <li>◆ Pin II/6 and ground</li> <li>◆ Pin II/24 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 4	Repair wiring; correct cause of damage, if necessary → End
4	Check wiring for short circuit to ground	Measure resistance between test adapter: <ul style="list-style-type: none"> <li>◆ Pin II/10 and ground</li> <li>◆ Pin II/16 and ground</li> <li>◆ Pin II/6 and ground</li> <li>◆ Pin II/24 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 5	Repair wiring; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
5	Check wiring for open circuit  Measure resistance between test adapter: <ul style="list-style-type: none"> <li>◆ Pin II/10 and pin 5 of oxygen sensor jack</li> <li>◆ Pin II/16 and pin 1 of oxygen sensor jack</li> <li>◆ Pin II/6 and pin 2 of oxygen sensor jack</li> <li>◆ Pin II/24 and pin 6 of oxygen sensor jack</li> </ul>	$< 2 \Omega$ $\Rightarrow$ Step 6	Repair wiring; correct cause of damage, if necessary $\rightarrow$ End
6	Check whether additional faults have been recorded	$\Rightarrow$ Step 7	Correct faults in accordance with instructions $\rightarrow$ End
7	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## Diagnosis/troubleshooting - all naturally-aspirated models



### Note!

The DTC relates only to implausible signals here.

### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensor heating switched on for at least 60 seconds
- ◆ Exhaust temperature less than 800°C

### Possible cause of fault

- High-resistance short circuit to B+ in signal wire
- Heater coupling
- Oxygen sensor faulty
- Control module faulty

### Affected pins


DME control module connector II, pin 10 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 16 and oxygen sensor jack, bank 2, pin 4

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Check oxygen sensor signal using data logger <ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> Complete the following steps on the PST II <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 2'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 2' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	<ul style="list-style-type: none"> <li>◆ If fault appears as "not present" in the "extended fault memory", erase the fault memory (healed reference air contamination)</li> <li>◆ If fault appears as "present" in the "extended fault memory" ⇒ Step 7</li> </ul>	⇒ Step 2



Work instruction			Display OK	If not OK
2	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 3	Replace faulty component; correct cause of damage, if necessary → End
3	Check oxygen sensor for internal short circuit	Measure resistance between oxygen sensor: <ul style="list-style-type: none"> <li>◆ Pin 4 and pin 2</li> <li>◆ Pin 4 and pin 3</li> <li>◆ Pin 4 and oxygen sensor casing</li> <li>◆ Pin 3 and pin 2</li> </ul>	∞ Ω ⇒ Step 4	Replace oxygen sensor; correct cause of damage, if necessary → End
4	Check plug connection between DME control module and oxygen sensor wires	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 5	Replace faulty component; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
5	<p>Check for short circuit in wiring between DME control module and oxygen sensor jack</p> <ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> <p>Measure resistance between adapter pins:</p> <ul style="list-style-type: none"> <li>◆ II/10 and pin II/16</li> <li>◆ II/10 and pin II/13</li> <li>◆ II/16 and pin II/13</li> <li>◆ II/16 and ground</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 6</p>	<p>Repair faulty wiring; correct cause of damage, if necessary → End</p>
6	<p>Check wiring for short circuit to B+</p> <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> </ul> <p>Measure voltage between adapter pins:</p> <ul style="list-style-type: none"> <li>◆ II/10 and ground</li> <li>◆ II/16 and ground</li> </ul>	<p>0 V ⇒ Step 7</p>	<p>Repair faulty wiring; correct cause of damage, if necessary → End</p>
7	<p>Check whether additional faults have been recorded</p>	<p>⇒ Step 8</p>	<p>Correct faults in accordance with instructions → End</p>
8	<p>Replace DME control module</p>	<p>To do this, please observe the notes on possible causes of faults in the introduction!</p>	

## P0151

### 02 Sensor Circuit Low Voltage

#### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensing system active
- ◆ No secondary air
- ◆ No diagnosis of secondary air system
- ◆ No fuel tank ventilation

#### Possible cause of fault

- Short circuit to ground in signal wire
- Oxygen sensor faulty
- Control module faulty

#### Affected pins

DME control module connector II, pin 10 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 16 and oxygen sensor jack, bank 2, pin 4


#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor signal using data logger	⇒ Step 4	⇒ Step 2
	<ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> Complete the following steps on the PST II <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 2'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 2' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>		





Work instruction			Display OK	If not OK
2	Check oxygen sensor for internal short circuit	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> </ul> Measure resistance between oxygen sensor: <ul style="list-style-type: none"> <li>◆ Pin 4 and pin 3</li> <li>◆ Pin 4 and pin 2</li> <li>◆ Pin 4 and oxygen sensor casing</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 3	Replace oxygen sensor; correct cause of damage, if necessary $\rightarrow$ End
3	Check for short circuit in wiring between DME control module and oxygen sensor jack	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/10 and pin II/16</li> <li>◆ Pin II/16 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 4	Repair faulty wiring; correct cause of damage, if necessary $\rightarrow$ End
4	Check whether additional faults have been recorded		$\Rightarrow$ Step 5	Correct faults in accordance with instructions $\rightarrow$ End
5	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0152

### 02 Sensor Circuit High Voltage

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*The DTC here also covers the possibility of a mechanical malfunction in the valve drive.*

### Diagnostic conditions

 **Note!**

*It takes a very long time (several driving cycles) to detect a fault.*

### Possible cause of fault

- ◆ Valve lift fault
- ◆ False air on the oxygen sensor after catalytic converter
- ◆ Oxygen sensor faulty

### Affected terminals

 **Note!**

- ◆ *As this fault can be caused by a faulty flat-base tappet, a system test for a small lift has to be performed initially. The fault can occur sporadically; the test should therefore be performed at least three times when the engine is at operating temperature.*
- ◆ *First indication of a valve lift fault can be provided by the adaptation values at idle speed (RKAT) and in the lower part load (FRAU) if they differ by more than 10 %.*

## Perform system test for small lift



**Warning!**


**The test is carried out while driving. Get a second person to operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**


**B - Oxygen sensor, bank 2**

**1 - Select System test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the  key immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

 **Note!**

*If 'Request small lift' appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4000 rpm) appears.**

At speeds above 4000 rpm, misfires may be stored. Erase the fault memory and repeat the test.

 **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

### Diagnosis/troubleshooting

 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check exhaust system for leaks		Repair exhaust system → End
2	Replace oxygen sensor		

## Diagnosis/troubleshooting - all naturally-aspirated models



### Note!

The DTC only covers electrical faults here.

### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Exhaust temperature less than 800°C
- ◆ Oxygen sensor heating switched on for at least 120 seconds



### Note!

DTC P0132 is stored by the DME control module when the sensor voltage is continuously above 1.5 V for more than 5 seconds

### Possible cause of fault

- Short circuit to B+ in signal wire
- Oxygen sensor faulty
- Control module faulty

### Affected pins

DME control module connector II, pin 10 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 16 and oxygen sensor jack, bank 2, pin 4


### Diagnosis/troubleshooting



### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	<p>Check oxygen sensor signal using data logger</p> <ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> <p>Complete the following steps on the PST II</p> <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 2'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 2' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	⇒ Step 4	⇒ Step 2



Work instruction		Display OK	If not OK
2	<p>Check oxygen sensor for internal short circuit</p> <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> </ul> <p>Measure resistance between oxygen sensor connector</p> <ul style="list-style-type: none"> <li>◆ Pin 1 and pin 4</li> <li>◆ Pin 1 and pin 3</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 3</p>	<p>Replace oxygen sensor; correct cause of damage, if necessary → End</p>
3	<p>Check for short circuit to B+ in wiring between DME control module and oxygen sensor jack</p> <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> </ul> <p>Measure voltage between adapter:</p> <ul style="list-style-type: none"> <li>◆ Pin II/10 and ground</li> <li>◆ Pin II/16 and ground</li> <li>◆ Switch off ignition</li> </ul>	<p>0 V ⇒ Step 4</p>	<p>Repair faulty wiring; correct cause of damage, if necessary → End</p>
4	<p>Check whether additional faults have been recorded</p>	<p>⇒ Step 5</p>	<p>Correct faults in accordance with instructions → End</p>
5	<p>Replace DME control module</p>	<p>To do this, please observe the notes on possible causes of faults in the introduction!</p>	

## P0153

### 18 Oxygen Sensor Ahead of TWC, Bank 2 – Below Limit

#### Diagnosis conditions

- Vehicle at operating temperature, after this 3 minutes idle speed, then approx. 30 seconds increased idle speed.

#### Possible fault cause

- ◆ Oxygen sensor is dynamically inert

#### Affected terminals

-

#### Diagnosis/Troubleshooting

##### Note!

*Do not use contact spray on the connectors to oxygen sensors.*

Work instruction		Display OK	If not OK
1	Check exhaust system for leaks		Repair exhaust system → End
2	Replace oxygen sensor		


##### Note!

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*



**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P0153

### O2 Sensor Circuit Slow Response

#### Diagnostic conditions

- Engine speed between 1000 rpm and 3000 rpm
- Engine load (relative air charge) between 12 % and 70 %
- Calculated TWC temperature greater than 350°C
- Oxygen sensing system active

#### Possible cause of fault

- ◆ Oxygen sensor is dynamically inert

#### Affected terminals

II/10 and II/16

#### Diagnosis/troubleshooting

#### **Note!**

*Do not use contact spray on the plug connections to the oxygen sensor.*


Work instruction		Display OK	If not OK
1	Read out the fault memory	◆ If there are additional faults in the memory, correct these first	
2	Read out period for sensor signal bank 2 with scan tool in Mode 5 or PST 2	Less than 3 seconds	Replace oxygen sensor

#### **Note!**

*Do not confuse oxygen sensor ahead of catalytic converter and oxygen sensor after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P0154

### 02 Sensor Circuit No Activity Detected

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*The DTC here covers the coupling of oxygen sensor heating into the sensor signal.*

### Diagnostic conditions

- Vehicle at operating temperature, then 3 minutes idle speed followed by 30 seconds increased idle speed

### Possible cause of fault

- ◆ Short circuit in oxygen sensor wiring
- ◆ Oxygen sensor faulty (heater coupling or heating)
- ◆ DME control module faulty

### Affected terminals

DME control module connector II, pin 10 and oxygen sensor connector ahead of catalytic converter, bank 2, pin 5

DME control module connector II, pin 16 and oxygen sensor connector ahead of catalytic converter, bank 2, pin 1

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Visual inspection</li> </ul> Measure resistance between oxygen sensor connector: <ul style="list-style-type: none"> <li>◆ Pin 1 and pin 4</li> <li>◆ Pin 4 and pin 5</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 2	Oxygen sensor faulty $\Rightarrow$ Replace oxygen sensor $\rightarrow$ End
2	Check wiring harness between DME control module and oxygen sensor jack <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/10 and pin II/13</li> <li>◆ Pin II/16 and pin II/13</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 3	Repair wiring; correct cause of damage, if necessary $\rightarrow$ End
3	Check whether additional faults have been recorded	$\Rightarrow$ Step 4	Correct faults in accordance with instructions $\rightarrow$ End
4	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## Diagnosis/troubleshooting - all naturally-aspirated models



### Note!

The DTC covers electrical open circuits here.

### Diagnostic conditions

- Exhaust temperature between 400°C and 800°C
- Battery positive voltage between 10 V and 16 V
- Oxygen sensor heating switched on for at least 120 seconds

**Possible cause of fault**

- ◆ Loose contact in connector
- ◆ Open circuit in the oxygen sensor signal wire
- ◆ Open circuit in the oxygen sensor ground wire
- ◆ Oxygen sensor faulty (also heating)
- ◆ DME control module faulty

**Affected terminals**


DME control module connector II, pin 10 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 16 and oxygen sensor jack, bank 2, pin 4

**Diagnosis/troubleshooting****Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor signal using data logger <ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> Complete the following steps on the PST II <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 2'</li> <li>◆ Highlight 'U Oxygen sensor ahead of TWC, bank 2' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>	⇒ Step 7	⇒ Step 2



Work instruction		Display OK	If not OK
2	<p>Check oxygen sensor plug connection</p> <ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection ahead of catalytic converter, bank 2</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 3	Replace faulty component; correct cause of damage, if necessary → End
3	<p>Check oxygen sensor heating</p> <p>Measure resistance between pins 1 and 2 of oxygen sensor connector</p>	8 to 11 Ω ⇒ Step 4	Replace oxygen sensor → End
4	<p>Check reference voltage on the oxygen sensor</p> <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Oxygen sensor faulty → Replace oxygen sensor	⇒ Step 5
5	<p>Check DME control module plug connection</p> <ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 6	Replace faulty component; correct cause of damage, if necessary → End

Work instruction			Display OK	If not OK
6	Check reference voltage on DME control module	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Step 7	⇒ Step 8
7	Check for open circuit in wiring between DME control module and oxygen sensor jack	Measure resistance between: <ul style="list-style-type: none"> <li>◆ Adapter pin II/10 and pin 3 of oxygen sensor jack</li> <li>◆ Adapter pin II/16 and pin 4 of oxygen sensor jack</li> </ul>	< 2 Ω ⇒ Sporadic fault; localise the fault as far as possible and then correct it; correct cause of damage, if necessary → End	Repair faulty wiring; correct cause of damage, if necessary → End
8	Check whether additional faults have been recorded		⇒ Step 9	Correct faults in accordance with instructions → End
9	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	



## P0155

### 02 Sensor Heater Circuit

 **Note!**

*The diagnosis for this fault is different for models with turbo engines and models with naturally-aspirated engines.*

### Diagnosis/troubleshooting - all turbo models

 **Note!**

*This fault can be detected in two different operating states. To find out whether the fault was recorded under load or with inertia fuel shutoff, refer to the "extended fault memory".*

#### Diagnostic conditions for fault detection under load

- Mass air flow above 16 kg/h
- No other oxygen sensor faults
- Battery positive voltage between 10 V and 16 V

#### Diagnostic conditions for fault detection with inertia fuel shutoff

- Exhaust temperature above 250°C
- Battery positive voltage greater than 10 V
- Time elapsed after start-up greater than 60 seconds
- No oxygen sensor faults
- Inertia fuel shutoff for more than 4 seconds

#### Possible cause of fault

- ◆ Open circuit
- ◆ Oxygen sensor faulty (heating)
- ◆ DME control module faulty

#### Affected terminals

DME control module, connector II, pin 13 and oxygen sensor jack ahead of catalytic converter, bank 2, pin 4

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check connector for corrosion	<ul style="list-style-type: none"> <li>◆ Visual inspection</li> </ul>		
2	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Remove oxygen sensor connector ahead of catalytic converter, bank 2</li> <li>◆ Check resistance between pin 3 and 4 towards the oxygen sensor</li> </ul>	3.0 to 3.5 $\Omega$ at 20°C	Replace oxygen sensor
3	Check voltage supply for oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Start the engine</li> <li>◆ Measure voltage between pin 3 towards the DME control module and ground</li> </ul>	Battery positive voltage ⇒ Step 4	⇒ Repair voltage supply
4	Check wiring	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and pin II/13</li> </ul>	<2 $\Omega$	⇒ Repair wiring
5	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor casing</li> <li>◆ Check resistance between pin 1 and the oxygen sensor casing</li> <li>◆ Check resistance between pin 2 and the oxygen sensor casing</li> <li>◆ Check resistance between pin 5 and the oxygen sensor casing</li> <li>◆ Check resistance between pin 6 and the oxygen sensor casing</li> </ul>	$\infty$ $\Omega$ If fault was recorded during inertia fuel shutoff ⇒ Check engine oil consumption	Replace oxygen sensor

**Diagnosis/troubleshooting - all naturally-aspirated models****Diagnostic conditions**

- Exhaust temperature between 250°C and 550°C
- No other oxygen sensor faults
- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 200 seconds

**Possible cause of fault**

- ◆ High resistance in connector or triggering wire

**Affected terminals**

DME control module, connector II, pin 13 and oxygen sensor jack ahead of catalytic converter, bank 2, pin 2

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 4	Replace faulty component; correct cause of damage, if necessary → End
4	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Measure resistance between adapter pin II/13 and pin 2 of oxygen sensor jack</li> </ul>	< 2 Ω ⇒ Step 5	Repair faulty wiring; correct cause of damage, if necessary → End
5	Check whether additional faults have been recorded		⇒ Step 6	Correct faults in accordance with instructions → End
6	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0156



### Note!

- ◆ *Signal implausible: Turbo models up to model year 01 only*
- ◆ *Below limit: Turbo only*
- ◆ *Above limit: All models*

## 02 Sensor Circuit

### Diagnostic conditions

- Exhaust temperature between 250°C and 750°C
- Battery voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 200 seconds
- No secondary air
- No diagnosis of secondary air system
- No fuel tank ventilation
- No diagnosis of fuel tank ventilation system
- No other oxygen sensor faults

### Possible cause of fault

- ◆ Short circuit to ground in signal wire
- ◆ Intercore short circuit

### Affected terminals

DME control module connector II, pin 8 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 14 and oxygen sensor jack, bank 1, pin 4

### Diagnosis/troubleshooting



### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK	
1	Check wiring harness	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 4 and 3 towards the control module</li> </ul>	Approx. 450 mV ⇒ Step 3	⇒ Step 2
2		<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Measure resistance at pin 4 and ground towards the control module</li> <li>◆ Measure resistance at pin 4 and pin 3 towards the control module</li> </ul>	$\infty \Omega$	Repair wiring harness
3	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Measure resistance at pins 2 and 3</li> <li>◆ Measure resistance at pins 2 and 4</li> <li>◆ Measure resistance at pin 3 and ground</li> <li>◆ Measure resistance at pin 4 and ground</li> <li>◆ Measure resistance at pins 3 and 4</li> </ul>	$\infty \Omega$	Replace oxygen sensor

## 02 Sensor Circuit Slow Response

### Diagnostic conditions

- Air mass between 25 kg/h and 120 kg/h
- Oxygen sensing after catalytic converter is active
- Basic adaptation has reached steady condition
- No secondary air diagnosis
- No fuel tank ventilation diagnosis
- EVAP canister not highly loaded
- No other oxygen sensor faults

### Possible cause of fault

- ◆ Oxygen sensor faulty

**Affected terminals**

-

**Diagnosis/troubleshooting****Note!**

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction		Display OK	If not OK
1	Erase fault memory, then road test vehicle or perform short test	<ul style="list-style-type: none"> <li>◆ Erase fault memory</li> <li>◆ Heat the oxygen sensors (road test car under load, run engine without load at high rpm)</li> <li>◆ Road test vehicle or perform short test, ensuring that the diagnostic conditions are met</li> </ul>	⇒ Step 2
2	Read out the fault memory	No fault stored → End	Replace oxygen sensor

## P0157

### 02 Sensor Circuit Low voltage

#### Diagnostic conditions

- ◆ Exhaust temperature between 250°C and 750°C
- ◆ Time elapsed after engine start-up greater than 200 seconds
- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensing system active
- ◆ No other oxygen sensor faults
- ◆ No secondary air
- ◆ No diagnosis of secondary air system
- ◆ No fuel tank ventilation
- ◆ No diagnosis of fuel tank ventilation system

#### Possible cause of fault

- Short circuit to ground in signal wire
- Oxygen sensor faulty
- Control module faulty

#### Affected pins

DME control module connector II, pin 8 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 14 and oxygen sensor jack, bank 2, pin 4

#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction			Display OK	If not OK
1	Check voltage supply	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Measure voltage between pins 4 and 3 towards the control module</li> </ul>	Approx. 450 mV ⇒ Step 2	⇒ Step 3
2	Check oxygen sensor for internal short circuit	Measure resistance between oxygen sensor: <ul style="list-style-type: none"> <li>◆ Pin 4 and pin 3</li> <li>◆ Pin 2 and pin 3</li> <li>◆ Pin 2 and pin 4</li> <li>◆ Pin 4 and oxygen sensor casing</li> </ul>	$\infty \Omega$ ⇒ Step 3	Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check for short circuit in wiring between DME control module and oxygen sensor jack	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/8 and pin II/14</li> <li>◆ Pin II/14 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 4	Repair faulty wiring; correct cause of damage, if necessary → End
4	Check whether additional faults have been recorded		⇒ Step 5	Correct faults in accordance with instructions → End
5	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	



## P0158

### 02 Sensor Circuit High Voltage

#### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Exhaust temperature less than 800°C
- ◆ Oxygen sensor heating switched on for at least 120 seconds

#### Possible cause of fault

- Short circuit to B+ in signal wire
- Oxygen sensor faulty
- Control module faulty

#### Affected pins

DME control module connector II, pin 8 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 14 and oxygen sensor jack, bank 2, pin 4

#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check voltage supply	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Measure voltage between pins 4 and 3 towards the control module</li> </ul>	<p>Approx. 450 mV ⇒ Step 2</p> <p>⇒ Step 3</p>
2	Check oxygen sensor for internal short circuit	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> </ul> <p>Measure resistance between oxygen sensor connector</p> <ul style="list-style-type: none"> <li>◆ Pin 1 and pin 4</li> <li>◆ Pin 1 and pin 3</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 3</p> <p>Replace oxygen sensor; correct cause of damage, if necessary → End</p>
3	Check for short circuit to B+ in wiring between DME control module and oxygen sensor jack	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> </ul> <p>Measure voltage between adapter:</p> <ul style="list-style-type: none"> <li>◆ Pin II/8 and ground</li> <li>◆ Pin II/14 and ground</li> <li>◆ Switch off ignition</li> </ul>	<p>0 V ⇒ Step 4</p> <p>Repair faulty wiring; correct cause of damage, if necessary → End</p>
4	Check whether additional faults have been recorded	⇒ Step 5	Correct faults in accordance with instructions → End
5	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## P0159

### 02 Sensor Circuit Slow Response

#### Diagnostic conditions

- Air mass between 25 kg/h and 120 kg/h
- Oxygen sensing after catalytic converter is active
- Basic adaptation has reached steady condition
- No secondary air diagnosis
- No fuel tank ventilation diagnosis
- EVAP canister not highly loaded
- No other oxygen sensor faults

#### Possible cause of fault

- ◆ Oxygen sensor faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

##### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Erase fault memory, then road test vehicle or perform short test	<ul style="list-style-type: none"> <li>◆ Erase fault memory</li> <li>◆ Heat the oxygen sensors (road test car under load, run engine without load at high rpm)</li> <li>◆ Road test vehicle or perform short test, ensuring that the diagnostic conditions are met</li> </ul>	⇒ Step 2
2	Read out the fault memory	No fault stored → End	Replace oxygen sensor

## P0160

### 02 Sensor Circuit No Activity Detected

#### Diagnostic conditions

- Exhaust temperature between 250°C and 750°C
- Battery positive voltage between 10 V and 16 V
- Time elapsed after engine start-up greater than 200 seconds
- Oxygen sensor heating switched on for at least 120 seconds

#### Possible cause of fault

- ◆ Loose contact or corrosion in connector
- ◆ Open circuit in the oxygen sensor signal wire
- ◆ Open circuit in the oxygen sensor ground wire
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

#### Affected terminals

DME control module connector II, pin 8 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 14 and oxygen sensor jack, bank 2, pin 4


#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor signal using data logger	⇒ Step 7	⇒ Step 2
	<ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester II No. 9588</li> <li>◆ Start the engine</li> </ul> Complete the following steps on the PST II <ul style="list-style-type: none"> <li>◆ Select 'DME'</li> <li>◆ Select 'Actual values'</li> <li>◆ Select 'Filter' using <b>F5</b></li> <li>◆ Select 'Oxygen sensing, bank 2'</li> <li>◆ Highlight 'U Oxygen sensor after TWC, bank 2' using the <b>&gt;</b> key</li> <li>◆ Call up 'Data logger' using <b>F3</b></li> <li>◆ Compare the signal with the graph shown below</li> </ul>		



Work instruction			Display OK	If not OK
2	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 3	Replace faulty component; correct cause of damage, if necessary → End
3	Check oxygen sensor heating	Measure resistance between pins 1 and 2 of oxygen sensor connector	8 to 11 $\Omega$ ⇒ Step 4	→ Replace oxygen sensor
4	Check reference voltage on the oxygen sensor	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Oxygen sensor faulty → Replace oxygen sensor	⇒ Step 5
5	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for corrosion and loose contacts</li> </ul>	⇒ Step 6	Replace faulty component; correct cause of damage, if necessary → End
6	Check reference voltage on DME control module	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pins 3 and 4 of the oxygen sensor jack</li> <li>◆ Switch off ignition</li> </ul>	Approx. 450 mV ⇒ Step 7	⇒ Step 8
7	Check for open circuit in wiring between DME control module and oxygen sensor jack	Measure resistance between: <ul style="list-style-type: none"> <li>◆ Adapter pin II/8 and pin 3 of oxygen sensor jack</li> <li>◆ Adapter pin II/14 and pin 4 of oxygen sensor jack</li> </ul>	< 2 $\Omega$ ⇒ Sporadic fault; localise the fault as far as possible and then correct it; correct cause of damage, if necessary → End	Repair faulty wiring; correct cause of damage, if necessary → End
8	Check whether additional faults have been recorded		⇒ Step 9	Correct faults in accordance with instructions → End
9	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0161

### 02 Sensor Heater Circuit

#### Signal implausible

##### Diagnostic conditions

- Exhaust temperature between 300°C and 600°C
- Battery positive voltage between 10 V and 16 V

##### Possible cause of fault

- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty

##### Affected terminals

DME control module connector II, pin 1 and oxygen sensor jack, bank 2, pin 2

##### Diagnosis/troubleshooting



##### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check connector for corrosion	<ul style="list-style-type: none"> <li>◆ Visual inspection of all affected plug connections</li> </ul>	⇒ Step 2	Replace faulty component; correct cause of damage, if necessary → End
2	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Check resistance between pins 1 and 2 towards the oxygen sensor</li> </ul>	8 to 11 Ω at 20°C ⇒ Step 3	Replace oxygen sensor → End
3	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 1 and the oxygen sensor casing</li> <li>◆ Check resistance between pins 1 and 3</li> </ul>	∞ Ω	

## Open circuit

### Diagnostic conditions

- Engine running

### Possible cause of fault

- ◆ Resistance of oxygen sensor heating too high
- ◆ Open circuit

### Affected terminals

DME control module connector II, pin 1 and oxygen sensor jack, bank 2, pin 2

### Diagnosis/troubleshooting



#### Note!

Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).

Work instruction			Display OK	If not OK
1	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Check resistance between pins 1 and 2 towards the oxygen sensor</li> </ul>	8 to 11 $\Omega$ at 20°C	Replace oxygen sensor
2	Check B+ supply	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage at pin 1 towards the DME control module and ground</li> </ul>	Battery positive voltage	Repair wiring harness
3	Check connection to ground	<ul style="list-style-type: none"> <li>◆ Check wire from pin 2 to DME control module pin II/1 for continuity</li> </ul>	< 2 $\Omega$	

## Below limit

### Diagnostic conditions

- Engine running



**Possible cause of fault**

- ◆ Short circuit to ground in triggering wire
- ◆ Corrosion in connector
- ◆ Oxygen sensor faulty
- ◆ DME control module faulty

**Affected terminals**

DME control module connector II, pin 1 and oxygen sensor jack, bank 2, pin 2

**Diagnosis/troubleshooting**
 **Note!**

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Check oxygen sensor plug connection	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 2  Replace faulty component; correct cause of damage, if necessary → End
2	Check resistance of oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Measure resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 3  Replace oxygen sensor; correct cause of damage, if necessary → End
3	Check oxygen sensor for short circuit to ground	Measure resistance between oxygen sensor connector: <ul style="list-style-type: none"> <li>◆ Pin 2 and pin 3</li> <li>◆ Pin 2 and oxygen sensor casing</li> </ul>	∞ Ω ⇒ Step 4  Replace oxygen sensor; correct cause of damage, if necessary → End
4	Check DME control module plug connection	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Check visually for loose contacts and corrosion</li> </ul>	⇒ Step 5  Replace faulty component; correct cause of damage, if necessary → End
5	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Connect 134-pin test adapter No. 9637</li> </ul> Measure resistance between adapter: <ul style="list-style-type: none"> <li>◆ Pin II/1 and pin II/8</li> <li>◆ Pin II/1 and ground</li> </ul>	∞ Ω ⇒ Step 6  Repair wiring; correct cause of damage, if necessary → End

Work instruction		Display OK	If not OK
6	Check whether additional faults have been recorded	⇒ Step 7	Correct faults in accordance with instructions → End
7	Replace DME control module	To do this, please observe the notes on possible causes of faults in the introduction!	

## Above limit

### Diagnostic conditions

- Engine running

### Possible cause of fault

- ◆ Oxygen sensor faulty (heating)
- ◆ Short circuit to B+
- ◆ DME control module faulty

### Affected terminals

DME control module connector II, pin 1 and oxygen sensor jack, bank 2, pin 2

### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction			Display OK	If not OK
1	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Disconnect oxygen sensor plug connection after catalytic converter, bank 2</li> <li>◆ Visual inspection</li> <li>◆ Measure oxygen sensor heating resistance between pins 1 and 2 of oxygen sensor connector</li> </ul>	8 Ω to 11 Ω ⇒ Step 2	Replace oxygen sensor; correct cause of damage, if necessary → End
2	Check triggering wire	<ul style="list-style-type: none"> <li>◆ Remove connector from DME control module</li> <li>◆ Visual inspection</li> <li>◆ Connect 134-pin test adapter No. 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between adapter pin II/1 and ground</li> <li>◆ Switch off ignition</li> </ul>	0 V ⇒ Step 3	Repair faulty wiring; correct cause of damage, if necessary → End
3	Check whether additional faults have been recorded		⇒ Step 4	Correct faults in accordance with instructions → End
4	Replace DME control module		To do this, please observe the notes on possible causes of faults in the introduction!	

## P0171

### Oxygen Sensing Adaptation, Idle Range, Bank 1 – Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled
- ◆ PCV valve leaks
- ◆ Cap of oil filler neck not closed correctly or seal is damaged

#### Affected terminals

-

#### Diagnosis/Troubleshooting



#### Note!

- ◆ *Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.*
- ◆ *Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.*
- ◆ *If the fuel tank reserve light is switched on, no fault is entered.*

Work instruction		Display OK	If not OK
1	Close cap of oil filler neck properly or replace the seal		

Work instruction			Display OK	If not OK
2	Check signal from MAF sensor.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition.</li> </ul>	0.9 to 1.1 V.	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine.</li> </ul>	Approx. 1.4 V	
3	Check exhaust system for leaks			
4	Check for air leaks in intake air system			
5	Check PCV valve for leaks			
6	Check fuel pressure			
7	Check volume supply of fuel pump			
8	Fuel injectors fouled	<ul style="list-style-type: none"> <li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li> <li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li> </ul>		

## P0172

### Oxygen Sensing Adaptation, Idle Range, Bank 1 – Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1.4 V
2	Check fuel pressure		

Work instruction		Display OK	If not OK
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> <li>◆</li> </ul>	0.4 - 0.6 bar  Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>	Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes
5	Check fuel injectors for leaks		

## P0174

### Oxygen Sensing Adaptation, Idle Range, Bank 2 – Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled
- ◆ PCV valve leaks
- ◆ Cap of oil filler neck not closed correctly or seal is damaged

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ *Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.*
- ◆ *Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.*
- ◆ *If the fuel tank reserve light is switched on, no fault is entered.*

Work instruction		Display OK	If not OK
1	Close cap of oil filler neck properly or replace the seal		



Work instruction			Display OK	If not OK
2	Check signal from MAF sensor.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition.</li> </ul>	0.9 to 1.1 V.	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine.</li> </ul>	Approx. 1.4 V	
3	Check exhaust system for leaks			
4	Check for air leaks in intake air system			
5	Check PCV valve for leaks			
6	Check fuel pressure			
7	Check volume supply of fuel pump			
8	Fuel injectors fouled	<ul style="list-style-type: none"> <li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li> <li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li> </ul>		

## P0175

### Oxygen Sensing Adaptation, Idle Range, Bank 2 – Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1.4 V
2	Check fuel pressure		

Work instruction		Display OK	If not OK
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> <li>◆</li> </ul>	0.4 - 0.6 bar  Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>	Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes
5	Check fuel injectors for leaks		

## P0197

### 125 Oil temperature sensor - below limit

#### Diagnosis conditions

- Idle speed
- Time elapsed after engine start-up greater than 5 minutes

#### Possible fault cause

- ◆ Temperature sensor faulty
- ◆ Wiring harness
- ◆ DME control module faulty

#### Affected terminals

Terminal III/5 and III/17

#### Resistance values

60 °C	2.8 - 3.5 kΩ
90 °C	1.0 - 1.3 kΩ
120 °C	0.4 - 0.6 kΩ

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check temperature sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between Pin III/17 and Pin III/5</li> </ul>	2.8 - 3.5 k $\Omega$ (at 60 °C) ⇒ Step 2  Replace temperature sensor → End
2	Check wiring from DME control module to temperature sensor for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug connection of temperature sensor</li> <li>◆ Measure resistance between special tool 9637 Pin III/17 and temperature sensor plug Pin 2</li> <li>◆ Measure resistance between special tool 9637 Pin III/5 and temperature sensor plug Pin 1</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3  Repair wiring harness → End
3	Check wiring from DME control module to temperature sensor for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug connection of temperature sensor</li> <li>◆ Measure resistance between Pin III/5 and ground</li> </ul>	$\infty$ $\Omega$ ⇒ Step 4  Repair wiring harness → End
4	Replace DME control module	⇒ Step 5	
5	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End

## P0198

### 125 Oil temperature sensor - above limit

#### Diagnosis conditions

- Idle speed
- Time elapsed after engine start-up greater than 5 minutes

#### Possible fault cause

- ◆ Temperature sensor faulty
- ◆ Wiring harness
- ◆ DME control module faulty

#### Affected terminals

Terminal III/5 and III/17

#### Resistance values

60 °C	2.8 - 3.5 kΩ
90 °C	1.0 - 1.3 kΩ
120 °C	0.4 - 0.6 kΩ

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check temperature sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between Pin III/17 and Pin III/5</li> </ul>	2.8 - 3.5 kΩ (at 60 °C) ⇒ Step 2	Replace temperature sensor → End
2	Check wiring from DME control module to temperature sensor for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove plug connection of temperature sensor</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin III/5 and ground</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P0201

### Fuel Injector, Cylinder 1 – Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/41

#### Note!

*Open circuit causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 1</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/41 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.



<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0202

### Fuel Injector, Cylinder 2 – Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/40

#### Note!

*Open circuit causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 2</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/40 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0203

### Fuel Injector, Cylinder 3 – Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/15



#### Note!

*Open circuit causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 3</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/15 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0204

### Fuel Injector, Cylinder 4 – Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/27



#### Note!

*Open circuit causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 4</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/27 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0205

### Fuel Injector, Cylinder 5 – Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/2



#### Note!

*Open circuit causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 5</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/2 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.



<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0206

### Fuel Injector, Cylinder 6 – Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/28

#### Note!

*Open circuit causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 6</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/28 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0221

### Accelerator Pedal Potentiometer 2 – Signal Implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Pedal sensor

#### Affected terminals

-



#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace pedal sensor	→ End.	→ End.



## P0222

### Accelerator Pedal Potentiometer 2 – Below Limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground
- ◆ Pedal sensor

#### Affected terminals

Terminal IV/13

#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, Pin IV/13, to pedal sensor, Pin 2, for short circuit to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool Pin IV/13 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 2.	Repair wiring harness $\rightarrow$ End.
2	Replace pedal sensor	$\rightarrow$ End.	$\rightarrow$ End.



## P0223

### Accelerator pedal potentiometer 2 – above limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to B+ in signal wire
- ◆ Pedal sensor faulty

#### Affected terminals

Terminal IV/13

#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module IV/13 to pedal sensor, pin 2, for short circuit to B+. <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool pin IV/13 and ground</li> </ul>	0 V ⇒ Step 2	Repair wiring harness → End.
2	Replace pedal sensor	→ End	



## P0230

## Fuel Pump Relay Output Stage – Open Circuit

## Diagnosis conditions

- Engine started

**Note!**

The triggering wire for the fuel pump relay, terminal 85, is monitored.

## Possible fault cause

- ◆ Fuel pump relay
- ◆ Open circuit
- ◆ DME control module

## Affected terminals

Terminal IV/10

## Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check fuel pump relay	<ul style="list-style-type: none"> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 Ω ⇒ Step 2 Replace fuel pump relay → End
2	Check wiring from DME control module, Pin IV/10, to fuel pump relay for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between special tool 9637, Pin IV/10, and fuel pump relay slot, Pin 6 (terminal 85)</li> </ul>	0 - 5 Ω ⇒ Step 3. Check plug connection X 2/3 and wiring harness → End
3	Replace DME control module.	⇒ Step 4.	
4	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.

## Fuel Pump Relay Output Stage – Below Limit

### Diagnosis conditions

- Engine started



### Note!

The triggering wire for the fuel pump relay, terminal 85, is monitored.

### Possible fault cause

- ◆ Fuel pump relay
- ◆ Short circuit to ground
- ◆ DME control module

### Affected terminals

Terminal IV/10

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check fuel pump relay	<ul style="list-style-type: none"> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2 Replace fuel pump relay → End
2	Check wiring from DME control module, Pin IV/10, to fuel pump relay for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between special tool 9637 Pin IV/10 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3. Repair wiring harness → End.
3	Replace DME control module.	⇒ Step 4.	
4	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.

## Fuel Pump Relay Output Stage – Above Limit

### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

### Note!

The triggering wire for the fuel pump relay, terminal 85, is monitored.

### Possible fault cause

- ◆ Fuel pump relay
- ◆ Short circuit to B+
- ◆ DME control module

### Affected terminals

Terminal IV/10

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel pump relay	◆ Remove fuel pump relay ◆ Measure resistance between Pin 85 and Pin 86	Approx. 75 Ω ⇒ Step 2	Replace fuel pump relay → End
2	Check wiring from DME control module, Pin IV/10, to fuel pump relay for short circuit to B+	◆ Connect special tool 9637 to wiring harness (DME control module plug). ◆ Remove fuel pump relay ◆ Measure voltage between special tool Pin IV/10 and ground ◆ Ignition on	0 V ⇒ Step 3.	Repair wiring harness → End.
3	Replace DME control module.	⇒ Step 4.		
4	Perform adaptation.	◆ Switch on the ignition. ◆ Wait one minute. ◆ Do not press the accelerator. ◆ Switch off the ignition for at least 10 seconds. ◆ Read out the fault memory.	→ End.	



## P0234

### Boost Pressure Characteristic, Upper Value Exceeded - Above Limit

#### Diagnosis conditions

- Charge pressure control active

#### Possible fault cause

- ◆ Leakage at pressure hoses from frequency valve to the bypass flaps
- ◆ Frequency valve faulty
- ◆ Vacuum modulators for bypass flaps leaking
- ◆ Bypass flaps incorrectly adjusted

#### Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check frequency valve		Replace frequency valve
2	Check pressure hoses for leaks		Replace pressure hoses or eliminate leaks
3	Check vacuum modulators for bypass flaps for leaks		Replace vacuum modulators
4	Check adjustment of bypass flaps		Adjust bypass flaps



**P0237****353 Pressure Sensor - Below Limit****Diagnosis conditions**

- Ignition on

**Possible fault cause**

- ◆ Short circuit to ground
- ◆ Pressure sensor faulty

**Affected terminals**

III/39

**Diagnosis/Troubleshooting**

Work instruction		Display OK	If not OK
1	Check wiring from pressure sensor to DME control module for short to ground. <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector from pressure sensor.</li> <li>◆ Measure resistance between special tool 9637 pin III/39 and ground.</li> </ul>	$\infty \Omega$	
2	Replace pressure sensor.		





## P0238

### 353 Pressure Sensor - Above Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Short circuit to B+
- ◆ Open circuit
- ◆ Pressure sensor faulty


#### Affected terminals

III/39

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from pressure sensor to DME control module for short to B+.	0 V.	Repair wiring harness.
	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of pressure sensor.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between pin III/39 and ground.</li> </ul>		
2	Check wiring from pressure sensor to DME control module for continuity.	0 - 5 Ω	
3	Check pressure sensor voltage.	Depending on ambient pressure: See Figure 1.	Replace pressure sensor.
	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between special tool 9637 pin III/39 and ground.</li> <li>◆ Or read out voltage value with the PST2.</li> </ul>		

Figure 1:



## P0261

### Fuel Injector, Cylinder 1 – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/41

#### Note!

*Short to ground causes the fuel injector to be permanently open.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 1</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/41 and ground.</li> </ul>	$\infty \Omega$ ⇒ Step 3.	Repair wiring harness → End.

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0262

### Fuel Injector, Cylinder 1 – Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/41



#### Note!

*Short to B+ causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 1</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/41 and ground.</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0264

### Fuel Injector, Cylinder 2 – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/40



#### Note!

*Short to ground causes the fuel injector to be permanently open.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 2</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/28 and ground.</li> </ul>	$\infty \Omega$ ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	



## P0265

### Fuel Injector, Cylinder 2 – Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/40



#### Note!

*Short to B+ causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 2</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/40 and ground.</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0267

### Fuel Injector, Cylinder 3 – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/15



#### Note!

*Short to ground causes the fuel injector to be permanently open.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 3</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/15 and ground.</li> </ul>	$\infty \Omega$ ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0268

### Fuel Injector, Cylinder 3 – Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/15



#### Note!

*Short to B+ causes the fuel injector to be continually closed.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 3</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/15 and ground.</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3.	Repair wiring harness → End.

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0270

### Fuel Injector, Cylinder 4 – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/27



#### Note!

*Short to ground causes the fuel injector to be permanently open.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 4</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/27 and ground.</li> </ul>	$\infty \Omega$ ⇒ Step 3.	Repair wiring harness → End.

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	



## P0271

## Fuel Injector, Cylinder 4 – Above Limit

## Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

## Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

## Affected terminals

Terminal III/27

**Note!**

*Short to B+ causes the fuel injector to be continually closed.*

## Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 4</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/27 and ground.</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0273

### Fuel Injector, Cylinder 5 – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/2



#### Note!

*Short to ground causes the fuel injector to be permanently open.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 5</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/2 and ground.</li> </ul>	$\infty \Omega$ ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0274

## Fuel Injector, Cylinder 5 – Above Limit

## Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

## Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

## Affected terminals

Terminal III/2

**Note!**

*Short to B+ causes the fuel injector to be continually closed.*

## Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 5</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/2 and ground.</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0276

### Fuel Injector, Cylinder 6 – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/28



#### Note!

*Short to ground causes the fuel injector to be permanently open.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 6</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/28 and ground.</li> </ul>	$\infty \Omega$ ⇒ Step 3.	Repair wiring harness → End.

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	



## P0277

## Fuel Injector, Cylinder 6 – Above Limit

## Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

## Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

## Affected terminals

Terminal III/28

 **Note!**

*Short to B+ causes the fuel injector to be continually closed.*

## Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 6</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 Ω (at 20 °C) ⇒ Step 2.	Replace fuel injector → End
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/28 and ground.</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0300

### 507 Misfire detection (sum total)

#### Diagnosis conditions

- A cycle of 1,000 crankshaft revolutions is evaluated (for misfire damaging to the TWC, 200 crankshaft revolutions). The misfire rates are compared with a threshold value. If the misfire rate is greater than the threshold value, a fault is recorded in the memory.
- The Check Engine Malfunction Indicator Lamp (MIL) is switched on and stays on when the misfire rate lies above the threshold value at which the emission limit values are exceeded during two consecutive driving cycles (in the case of EOBD 3 driving cycles).
- If the misfire rate may lead to permanent damage to the TWC, the Check Engine MIL flashes. If the misfire rate is no longer reached during the first journey, the MIL goes out. If the rate is reached during the next journey, the MIL flashes. If this misfire rate is subsequently no longer reached, the MIL changes to a continuous light.



#### Note!

- ◆ *When using a block heater (for heating coolant), start and driving off difficulties or misfiring can occur if the block heater was connected for less than 4 hours.*
- ◆ *When the fuel tank is driven to empty, misfiring can occur. For this reason the fuel level in the tank is also stored in the memory when misfiring occurs. If the tank was nearly empty, there was probably no fault. Erase fault memory and road test vehicle.*
- ◆ *In the event of a short circuit to B+ or ground in the oxygen sensors ahead of the TWC, the mixture becomes too lean or too rich. This can cause misfiring. If, in addition, an oxygen sensor signal fault ahead of the TWC is stored in memory, first correct this fault and then road test the vehicle.*

#### Possible fault cause

- ◆ Fault in ignition system
- ◆ Fault in injection system
- ◆ Flat-base tappets (valve lift fault)
- ◆ Mixture too rich
- ◆ Mixture too lean

- ♦ Mechanical causes:

### **Valve lifter chattering**

This is caused by dirt in the valve lifter.

When the Check Engine MIL lights up, a chattering valve lifter may also occur for a certain time. The DME control module registers (sporadic) misfiring at one or more cylinders. The mixture adaptation values are normal.

Remedy:

- 1 - Remove lifter bores, check for damage and blow out oil passages.**
- 2 - Replace all valve lifters.**
- 3 - During the test drive, listen for valve lifter noises.**

### **Camshaft control times adjusted**

The camshaft control times have changed. No chattering noises occur. The DME control module indicates misfiring for the entire cylinder bank 1 or 2. The mixture adaptation values in the idle speed range differ in bank 1 and bank 2, the mixture adaptation values in the upper and lower load ranges are generally normal.

Remedy:

- 1 - Carry out raw emission measurement:**
  1. Reset mixture adaptation values (disconnect battery)
  2. Disconnect oxygen sensors

If the difference between bank 1 and bank 2 is greater than approx. 0.8 %, then

- 1 - Set the camshaft control times again.**
- 2 - Road test vehicle. The mixture adaptation values must be normal.**

### **VarioCam does not switch over completely**

The VarioCam does not switch over completely from power to torque valve timing.

An indication of this problem is misfiring detected by the DME control module in the range of 1200 - 1500 rpm occurring in an entire bank.

The mixture adaptation values are normal.

Remedy:

**1 - Replace VarioCam.****2 - Road test vehicle.**

Other possible fault causes

- ◆ worn camshafts
- ◆ leaking valves
- ◆ faulty piston rings

If opposing cylinders have misfiring, the cause could be the sensor wheel.

If valve lift faults are suspected, perform the system test for large lift and the system test for small lift with the Porsche System Tester 2.

**Note!**

*If the battery was disconnected, at least range 1 of sensor wheel adaptation must be adapted before troubleshooting is carried out; see actual values explanation.*

Affected terminals

-

## Diagnosis/Troubleshooting

**Note!**

*If there is a lot of oil in the engine, check that the oil filler tube and cap are tight.*

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	⇒ Step 2.	Repair intake air system → End.
2	Carry out pressure loss test	⇒ Step 3.	Repair engine → End
3	Check spark plugs. Specified spark plugs: Electrode gap: 1.6 mm ± 0.2 mm. Check appearance of spark plugs	⇒ Step 4.	Replace faulty spark plug(s). → End
4	Check spark plug connectors	Approx. 2 kΩ ⇒ Step 5	Replace faulty spark plug connectors. → End

Work instruction		Display OK	If not OK
5	Check ignition coil(s) ◆ Measure resistance between Pin 1 and Pin 15	0,3 to 0,7 $\Omega$ (at 20 °C) ⇒ Step 6.	Replace ignition coil(s) → End
6	Check all connectors for secure fastening and corrosion	⇒ Step 7.	Clean plug connections and connect securely. → End
7	Check fuel pressure ◆ Undo and remove the closure cap of the fuel collection pipe test connection (A/F 13 mm) ◆ Connect pressure gauge (special tool P 378a) to connecting line (special tool 9559) and connect to test connection. ◆ Actuate fuel pump, either with the Porsche System Tester or via a fuel pump relay without tester ◆ Nominal test value, stationary engine ◆ Nominal test value, engine idling	3,8 ± 0.2 bar  3,3 ± 0.2 bar ⇒ Step 9	⇒ Step 8.

**Note!**

The seal or sealing ring in the brass closure cap is not exchangeable. It must therefore be used only once.

**Tightening torque of new brass closure cap 2.5 ± 0.5 Nm  
(2.0 ± 0.5 ftlb.)**

Work instruction		Display OK	If not OK
8	<p>Check volume supply of fuel pump. (Fuel filter and electrical supply OK)</p> <ul style="list-style-type: none"> <li>◆ Relieve pressure in fuel tank by opening tank cap.</li> <li>◆ Connect Porsche System Tester 2</li> <li>◆ Remove complete air filter system</li> <li>◆ Detach fuel return line (A/F 17 mm) from the engine compartment (left), taking care to hold it fast (A/F 17 mm).</li> <li>◆ Collect residual fuel</li> <li>◆ Observe safety regulations</li> <li>◆ Connect fuel hose (shop-made, approx. 1.5 metres long) to the fitting and hold in a measuring container</li> <li>◆ Actuate fuel pump with the Porsche System Tester 2 and allow fuel to flow into the measuring container for 30 seconds</li> <li>◆ Volume supply must be at least 850 cm<sup>3</sup>/ 30 s, i.e. after 30 seconds at least 850 cm<sup>3</sup> of fuel must be in the measuring container.</li> </ul>	→ End.	

**Note!**


*It is essential to observe safety regulations for handling fuel.*

Work instruction		Display OK	If not OK
9	Check triggering of fuel injectors	The engine idle speed decreases if triggering is OK	Check triggering ⇒ Step 9a
9a	B+ supply	> 11 V ⇒ Step 9b	Check wiring according to wiring diagram for continuity or short circuit → End
9b	Coil resistance of fuel injectors	11 - 13 Ω ⇒ Step 9c	

Work instruction			Display OK	If not OK
9c	Injection output stage (negative supply)	<ul style="list-style-type: none"><li>◆ Connect special tool V.A.G 1315 A/1 between fuel injector and connector</li><li>◆ Connect engine tester according to manufacturer's instructions. Connect cable for special input to special tool</li><li>◆ Start the engine.</li></ul>	See Figure ⇒ Step 9d	
9d	◆ Perform system test for large lift		→ End.	



Figure:



**Warning!**

**Tester cables must not be connected to ground.**

**Note!**

*If the engine does not start, or if the idling speed drops, replace tester cable connected to special tool.*

Perform system test for large lift

**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**i Note!**

- ◆ If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).
- ◆ It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.

**Continue by performing the system test for small lift**

Perform system test for small lift

**Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type "below limit" is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.


A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1****B - Oxygen sensing, bank 2****1 - Select system test.****2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

 **Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

 **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**End**

## P0301

### 508 Misfire, cylinder 1

#### Diagnosis conditions

- A cycle of 1,000 crankshaft revolutions is evaluated (for misfire damaging to the TWC, 200 crankshaft revolutions). The misfire rates are compared with a threshold value. If the misfire rate is greater than the threshold value, a fault is recorded in the memory.
- The Check Engine Malfunction Indicator Lamp (MIL) is switched on and stays on when the misfire rate lies above the threshold value at which the emission limit values are exceeded during two consecutive driving cycles (in the case of EOBD 3 driving cycles).
- If the misfire rate may lead to permanent damage to the TWC, the Check Engine MIL flashes. If the misfire rate is no longer reached during the first journey, the MIL goes out. If the rate is reached during the next journey, the MIL flashes. If this misfire rate is subsequently no longer reached, the MIL changes to a continuous light.



#### Note!

- ◆ *When using a block heater (for heating coolant), start and driving off difficulties can occur or misfiring if the block heater was connected for less than 4 hours.*
- ◆ *When the fuel tank is driven to empty, misfiring can occur. For this reason the fuel level in the tank is also stored in the memory when misfiring occurs. If the tank was nearly empty, there was probably no fault. Erase fault memory and road test vehicle.*
- ◆ *In the event of a short circuit to B+ or ground in the oxygen sensors ahead of the TWC, the mixture becomes too lean or too rich. This can cause misfiring. If, in addition, an oxygen sensor signal fault ahead of the TWC is stored in memory, first correct this fault and then road test the vehicle.*

#### Possible fault cause

- ◆ Fault in ignition system
- ◆ Fault in injection system
- ◆ Flat-base tappets (valve lift fault)
- ◆ Mixture too rich
- ◆ Mixture too lean

- ♦ Mechanical causes:

### **Valve lifter chattering**

This is caused by dirt in the valve lifter.

When the Check Engine MIL lights up, a chattering valve lifter may also occur for a certain time. The DME control module registers (sporadic) misfiring at one or more cylinders. The mixture adaptation values are normal.

Remedy:

- 1 - Remove lifter bores, check for damage and blow out oil passages.**
- 2 - Replace all valve lifters.**
- 3 - During the test drive, listen for valve lifter noises.**

### **Camshaft control times adjusted**

The camshaft control times have changed. No chattering noises occur. The DME control module indicates misfiring for the entire cylinder bank 1 or 2. The mixture adaptation values in the idle speed range differ in bank 1 and bank 2, the mixture adaptation values in the upper and lower load ranges are generally normal.

Remedy:

- 1 - Carry out raw emission measurement:**
  1. Reset mixture adaptation values (disconnect battery)
  2. Disconnect oxygen sensors

If the difference between bank 1 and bank 2 is greater than approx. 0.8 %, then

- 1 - Set the camshaft control times again.**
- 2 - Road test vehicle. The mixture adaptation values must be normal.**

### **VarioCam does not switch over completely**

The VarioCam does not switch over completely from power to torque valve timing.

An indication of this problem is misfiring detected by the DME control module in the range of 1200 - 1500 rpm occurring in an entire bank.

The mixture adaptation values are normal.

Remedy:

**1 - Replace VarioCam.****2 - Road test vehicle.**

Other possible fault causes

- ◆ worn camshafts
- ◆ leaking valves
- ◆ faulty piston rings

If opposing cylinders have misfiring, the cause could be the sensor wheel.

If valve lift faults are suspected, perform the system test for large lift and the system test for small lift with the Porsche System Tester 2.

 **Note!**

*If the battery was disconnected, at least range 1 of sensor wheel adaptation must be adapted before troubleshooting is carried out; see actual values explanation.*

Affected terminals

-

## Diagnosis/Troubleshooting

 **Note!**

*If there is a lot of oil in the engine, check that the oil filler tube and cap are tight.*

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	⇒ Step 2.	Repair intake air system → End.
2	Carry out pressure loss test	⇒ Step 3.	Repair engine → End
3	Check spark plugs. Specified spark plugs: Electrode gap: 1.6 mm ± 0.2 mm. Check appearance of spark plugs	⇒ Step 4.	Replace faulty spark plug(s). → End
4	Check spark plug connectors	Approx. 2 kΩ ⇒ Step 5	Replace faulty spark plug connectors. → End

Work instruction		Display OK	If not OK
5	Check ignition coil(s) ◆ Measure resistance between Pin 1 and Pin 15	0,3 to 0,7 $\Omega$ (at 20 °C) ⇒ Step 6.	Replace ignition coil(s) → End
6	Check all connectors for secure fastening and corrosion	⇒ Step 7.	Clean plug connections and connect securely. → End
7	Check fuel pressure ◆ Undo and remove the closure cap of the fuel collection pipe test connection (A/F 13 mm) ◆ Connect pressure gauge (special tool P 378a) to connecting line (special tool 9559) and connect to test connection. ◆ Actuate fuel pump, either with the Porsche System Tester or via a fuel pump relay without tester ◆ Nominal test value, stationary engine ◆ Nominal test value, engine idling	3,8 ± 0.2 bar  3,3 ± 0.2 bar ⇒ Step 9	⇒ Step 8.

**Note!**

*The seal or sealing ring in the brass closure cap is not exchangeable. It must therefore be used only once.*

**Tightening torque of new brass closure cap 2.5 ± 0.5 Nm  
(2.0 ± 0.5 ftlb.)**



Work instruction			Display OK	If not OK
8	Check volume supply of fuel pump. (Fuel filter and electrical supply OK)	<ul style="list-style-type: none"> <li>◆ Relieve pressure in fuel tank by opening tank cap.</li> <li>◆ Connect Porsche System Tester 2</li> <li>◆ Remove complete air filter system</li> <li>◆ Detach fuel return line (A/F 17 mm) from the engine compartment (left), taking care to hold it fast (A/F 17 mm).</li> <li>◆ Collect residual fuel</li> <li>◆ Observe safety regulations</li> <li>◆ Connect fuel hose (shop-made, approx. 1.5 metres long) to the fitting and hold in a measuring container</li> <li>◆ Actuate fuel pump with the Porsche System Tester 2 and allow fuel to flow into the measuring container for 30 seconds</li> <li>◆ Volume supply must be at least 850 cm<sup>3</sup>/ 30 s, i.e. after 30 seconds at least 850 cm<sup>3</sup> of fuel must be in the measuring container.</li> </ul>	→ End.	


**Note!**

*It is essential to observe safety regulations for handling fuel.*

Work instruction			Display OK	If not OK
9	Check triggering of fuel injectors	<ul style="list-style-type: none"> <li>◆ The fuel injectors can be individually suppressed with the Porsche System Tester 2 in the menu 'Drive link active'</li> </ul>	The engine idle speed decreases if triggering is OK	Check triggering ⇒ Step 9a
9a	B+ supply	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector to be checked</li> <li>◆ Measure voltage between valve plug contact Pin 1 and ground</li> <li>◆ Switch on the ignition.</li> </ul>	> 11 V ⇒ Step 9b	Check wiring according to wiring diagram for continuity or short circuit → End
9b	Coil resistance of fuel injectors	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector to be checked</li> <li>◆ Measure resistance between the terminals of the fuel injector</li> </ul>	11 - 13 Ω ⇒ Step 9c	

Work instruction			Display OK	If not OK
9c	Injection output stage (negative supply)	<ul style="list-style-type: none"><li>◆ Connect special tool V.A.G 1315 A/1 between fuel injector and connector</li><li>◆ Connect engine tester according to manufacturer's instructions. Connect cable for special input to special tool</li><li>◆ Start the engine.</li></ul>	See Figure ⇒ Step 9d	
9d	◆ Perform system test for large lift		→ End.	

Figure:



**Warning!**

**Tester cables must not be connected to ground.**

**Note!**

*If the engine does not start, or if the idling speed drops, replace tester cable connected to special tool.*

Perform system test for large lift

**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**i Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**Continue by performing the system test for small lift**

Perform system test for small lift

**Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type "below limit" is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1**


**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.



**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**End**

## P0302

### 509 Misfire, cylinder 2

#### Diagnosis conditions

- A cycle of 1,000 crankshaft revolutions is evaluated (for misfire damaging to the TWC, 200 crankshaft revolutions). The misfire rates are compared with a threshold value. If the misfire rate is greater than the threshold value, a fault is recorded in the memory.
- The Check Engine Malfunction Indicator Lamp (MIL) is switched on and stays on when the misfire rate lies above the threshold value at which the emission limit values are exceeded during two consecutive driving cycles (in the case of EOBD 3 driving cycles).
- If the misfire rate may lead to permanent damage to the TWC, the Check Engine MIL flashes. If the misfire rate is no longer reached during the first journey, the MIL goes out. If the rate is reached during the next journey, the MIL flashes. If this misfire rate is subsequently no longer reached, the MIL changes to a continuous light.



#### Note!

- ◆ *When using a block heater (for heating coolant), start and driving off difficulties or misfiring can occur if the block heater was connected for less than 4 hours.*
- ◆ *When the fuel tank is driven to empty, misfiring can occur. For this reason the fuel level in the tank is also stored in the memory when misfiring occurs. If the tank was nearly empty, there was probably no fault. Erase fault memory and road test vehicle.*
- ◆ *In the event of a short circuit to B+ or ground in the oxygen sensors ahead of the TWC, the mixture becomes too lean or too rich. This can cause misfiring. If, in addition, an oxygen sensor signal fault ahead of the TWC is stored in memory, first correct this fault and then road test the vehicle.*

#### Possible fault cause

- ◆ Fault in ignition system
- ◆ Fault in injection system
- ◆ Flat-base tappets (valve lift fault)
- ◆ Mixture too rich
- ◆ Mixture too lean

- ♦ Mechanical causes:

### **Valve lifter chattering**

This is caused by dirt in the valve lifter.

When the Check Engine MIL lights up, a chattering valve lifter may also occur for a certain time. The DME control module registers (sporadic) misfiring at one or more cylinders. The mixture adaptation values are normal.

Remedy:

- 1 - Remove lifter bores, check for damage and blow out oil passages.**
- 2 - Replace all valve lifters.**
- 3 - During the test drive, listen for valve lifter noises.**

### **Camshaft control times adjusted**

The camshaft control times have changed. No chattering noises occur. The DME control module indicates misfiring for the entire cylinder bank 1 or 2. The mixture adaptation values in the idle speed range differ in bank 1 and bank 2, the mixture adaptation values in the upper and lower load ranges are generally normal.

Remedy:

- 1 - Carry out raw emission measurement:**
  1. Reset mixture adaptation values (disconnect battery)
  2. Disconnect oxygen sensors

If the difference between bank 1 and bank 2 is greater than approx. 0.8 %, then

- 1 - Set the camshaft control times again.**
- 2 - Road test vehicle. The mixture adaptation values must be normal.**

### **VarioCam does not switch over completely**

The VarioCam does not switch over completely from power to torque valve timing.

An indication of this problem is misfiring detected by the DME control module in the range of 1200 - 1500 rpm occurring in an entire bank.

The mixture adaptation values are normal.

Remedy:



**1 - Replace VarioCam.****2 - Road test vehicle.**

Other possible fault causes

- ◆ worn camshafts
- ◆ leaking valves
- ◆ faulty piston rings

If opposing cylinders have misfiring, the cause could be the sensor wheel.

If valve lift faults are suspected, perform the system test for large lift and the system test for small lift with the Porsche System Tester 2.

 **Note!**

*If the battery was disconnected, at least range 1 of sensor wheel adaptation must be adapted before troubleshooting is carried out; see actual values explanation.*

Affected terminals

-

## Diagnosis/Troubleshooting

 **Note!**

*If there is a lot of oil in the engine, check that the oil filler tube and cap are tight.*

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	⇒ Step 2.	Repair intake air system → End.
2	Carry out pressure loss test	⇒ Step 3.	Repair engine → End
3	Check spark plugs. Specified spark plugs: Electrode gap: 1.6 mm ± 0.2 mm. Check appearance of spark plugs	⇒ Step 4.	Replace faulty spark plug(s). → End
4	Check spark plug connectors	Approx. 2 kΩ ⇒ Step 5	Replace faulty spark plug connectors. → End

Work instruction		Display OK	If not OK
5	Check ignition coil(s) ◆ Measure resistance between Pin 1 and Pin 15	0,3 to 0,7 $\Omega$ (at 20 °C) ⇒ Step 6.	Replace ignition coil(s) → End
6	Check all connectors for secure fastening and corrosion	⇒ Step 7.	Clean plug connections and connect securely. → End
7	Check fuel pressure ◆ Undo and remove the closure cap of the fuel collection pipe test connection (A/F 13 mm) ◆ Connect pressure gauge (special tool P 378a) to connecting line (special tool 9559) and connect to test connection. ◆ Actuate fuel pump, either with the Porsche System Tester or via a fuel pump relay without tester ◆ Nominal test value, stationary engine ◆ Nominal test value, engine idling	3,8 ± 0.2 bar  3,3 ± 0.2 bar ⇒ Step 9	⇒ Step 8.

**Note!**

*The seal or sealing ring in the brass closure cap is not exchangeable. It must therefore be used only once.*

**Tightening torque of new brass closure cap 2.5 ± 0.5 Nm  
(2.0 ± 0.5 ftlb.)**

Work instruction			Display OK	If not OK
8	Check volume supply of fuel pump. (Fuel filter and electrical supply OK)	<ul style="list-style-type: none"> <li>◆ Relieve pressure in fuel tank by opening tank cap.</li> <li>◆ Connect Porsche System Tester 2</li> <li>◆ Remove complete air filter system</li> <li>◆ Detach fuel return line (A/F 17 mm) from the engine compartment (left), taking care to hold it fast (A/F 17 mm).</li> <li>◆ Collect residual fuel</li> <li>◆ Observe safety regulations</li> <li>◆ Connect fuel hose (shop-made, approx. 1.5 metres long) to the fitting and hold in a measuring container</li> <li>◆ Actuate fuel pump with the Porsche System Tester 2 and allow fuel to flow into the measuring container for 30 seconds</li> <li>◆ Volume supply must be at least 850 cm<sup>3</sup>/ 30 s, i.e. after 30 seconds at least 850 cm<sup>3</sup> of fuel must be in the measuring container.</li> </ul>	→ End.	


**Note!**

*It is essential to observe safety regulations for handling fuel.*

Work instruction			Display OK	If not OK
9	Check triggering of fuel injectors	<ul style="list-style-type: none"> <li>◆ The fuel injectors can be individually suppressed with the Porsche System Tester 2 in the menu 'Drive link active'</li> </ul>	The engine idle speed decreases if triggering is OK	Check triggering ⇒ Step 9a
9a	B+ supply	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector to be checked</li> <li>◆ Measure voltage between valve plug contact Pin 1 and ground</li> <li>◆ Switch on the ignition.</li> </ul>	> 11 V ⇒ Step 9b	Check wiring according to wiring diagram for continuity or short circuit → End
9b	Coil resistance of fuel injectors	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector to be checked</li> <li>◆ Measure resistance between the terminals of the fuel injector</li> </ul>	11 - 13 Ω ⇒ Step 9c	

Work instruction			Display OK	If not OK
9c	Injection output stage (negative supply)	<ul style="list-style-type: none"><li>◆ Connect special tool V.A.G 1315 A/1 between fuel injector and connector</li><li>◆ Connect engine tester according to manufacturer's instructions. Connect cable for special input to special tool</li><li>◆ Start the engine.</li></ul>	See Figure ⇒ Step 9d	
9d	◆ Perform system test for large lift		→ End.	

Figure:



**Warning!**

**Tester cables must not be connected to ground.**

**Note!**

*If the engine does not start, or if the idling speed drops, replace tester cable connected to special tool.*

Perform system test for large lift

**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**i Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**Continue by performing the system test for small lift**

Perform system test for small lift

**Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type "below limit" is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.


A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1****B - Oxygen sensing, bank 2****1 - Select system test.****2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

 **Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

 **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**End**



## P0303

### 510 Misfire, cylinder 3

#### Diagnosis conditions

- A cycle of 1,000 crankshaft revolutions is evaluated (for misfire damaging to the TWC, 200 crankshaft revolutions). The misfire rates are compared with a threshold value. If the misfire rate is greater than the threshold value, a fault is recorded in the memory.
- The Check Engine Malfunction Indicator Lamp (MIL) is switched on and stays on when the misfire rate lies above the threshold value at which the emission limit values are exceeded during two consecutive driving cycles (in the case of EOBD 3 driving cycles).
- If the misfire rate may lead to permanent damage to the TWC, the Check Engine MIL flashes. If the misfire rate is no longer reached during the first journey, the MIL goes out. If the rate is reached during the next journey, the MIL flashes. If this misfire rate is subsequently no longer reached, the MIL changes to a continuous light.



#### Note!

- ◆ *When using a block heater (for heating coolant), start and driving off difficulties or misfiring can occur if the block heater was connected for less than 4 hours.*
- ◆ *When the fuel tank is driven to empty, misfiring can occur. For this reason the fuel level in the tank is also stored in the memory when misfiring occurs. If the tank was nearly empty, there was probably no fault. Erase fault memory and road test vehicle.*
- ◆ *In the event of a short circuit to B+ or ground in the oxygen sensors ahead of the TWC, the mixture becomes too lean or too rich. This can cause misfiring. If, in addition, an oxygen sensor signal fault ahead of the TWC is stored in memory, first correct this fault and then road test the vehicle.*

#### Possible fault cause

- ◆ Fault in ignition system
- ◆ Fault in injection system
- ◆ Flat-base tappets (valve lift fault)
- ◆ Mixture too rich
- ◆ Mixture too lean

- ♦ Mechanical causes:

### **Valve lifter chattering**

This is caused by dirt in the valve lifter.

When the Check Engine MIL lights up, a chattering valve lifter may also occur for a certain time. The DME control module registers (sporadic) misfiring at one or more cylinders. The mixture adaptation values are normal.

Remedy:

- 1 - Remove lifter bores, check for damage and blow out oil passages.**
- 2 - Replace all valve lifters.**
- 3 - During the test drive, listen for valve lifter noises.**

### **Camshaft control times adjusted**

The camshaft control times have changed. No chattering noises occur. The DME control module indicates misfiring for the entire cylinder bank 1 or 2. The mixture adaptation values in the idle speed range differ in bank 1 and bank 2, the mixture adaptation values in the upper and lower load ranges are generally normal.

Remedy:

- 1 - Carry out raw emission measurement:**
  1. Reset mixture adaptation values (disconnect battery)
  2. Disconnect oxygen sensors

If the difference between bank 1 and bank 2 is greater than approx. 0.8 %, then

- 1 - Set the camshaft control times again.**
- 2 - Road test vehicle. The mixture adaptation values must be normal.**

### **VarioCam does not switch over completely**

The VarioCam does not switch over completely from power to torque valve timing.

An indication of this problem is misfiring detected by the DME control module in the range of 1200 - 1500 rpm occurring in an entire bank.

The mixture adaptation values are normal.

Remedy:

**1 - Replace VarioCam.****2 - Road test vehicle.**

Other possible fault causes

- ◆ worn camshafts
- ◆ leaking valves
- ◆ faulty piston rings

If opposing cylinders have misfiring, the cause could be the sensor wheel.

If valve lift faults are suspected, perform the system test for large lift and the system test for small lift with the Porsche System Tester 2.

 **Note!**

*If the battery was disconnected, at least range 1 of sensor wheel adaptation must be adapted before troubleshooting is carried out; see actual values explanation.*

Affected terminals

-

## Diagnosis/Troubleshooting

 **Note!**

*If there is a lot of oil in the engine, check that the oil filler tube and cap are tight.*

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	⇒ Step 2.	Repair intake air system → End.
2	Carry out pressure loss test	⇒ Step 3.	Repair engine → End
3	Check spark plugs. Specified spark plugs: Electrode gap: 1.6 mm ± 0.2 mm. Check appearance of spark plugs	⇒ Step 4.	Replace faulty spark plug(s). → End
4	Check spark plug connectors	Approx. 2 kΩ ⇒ Step 5	Replace faulty spark plug connectors. → End

Work instruction		Display OK	If not OK
5	Check ignition coil(s) ◆ Measure resistance between Pin 1 and Pin 15	0,3 to 0,7 $\Omega$ (at 20 °C) ⇒ Step 6.	Replace ignition coil(s) → End
6	Check all connectors for secure fastening and corrosion	⇒ Step 7.	Clean plug connections and connect securely. → End
7	Check fuel pressure ◆ Undo and remove the closure cap of the fuel collection pipe test connection (A/F 13 mm) ◆ Connect pressure gauge (special tool P 378a) to connecting line (special tool 9559) and connect to test connection. ◆ Actuate fuel pump, either with the Porsche System Tester or via a fuel pump relay without tester ◆ Nominal test value, stationary engine ◆ Nominal test value, engine idling	3,8 ± 0.2 bar  3,3 ± 0.2 bar ⇒ Step 9	⇒ Step 8.

**Note!**

*The seal or sealing ring in the brass closure cap is not exchangeable. It must therefore be used only once.*

**Tightening torque of new brass closure cap 2.5 ± 0.5 Nm  
(2.0 ± 0.5 ftlb.)**

Work instruction		Display OK	If not OK
8	Check volume supply of fuel pump. (Fuel filter and electrical supply OK)	<ul style="list-style-type: none"> <li>◆ Relieve pressure in fuel tank by opening tank cap.</li> <li>◆ Connect Porsche System Tester 2</li> <li>◆ Remove complete air filter system</li> <li>◆ Detach fuel return line (A/F 17 mm) from the engine compartment (left), taking care to hold it fast (A/F 17 mm).</li> <li>◆ Collect residual fuel</li> <li>◆ Observe safety regulations</li> <li>◆ Connect fuel hose (shop-made, approx. 1.5 metres long) to the fitting and hold in a measuring container</li> <li>◆ Actuate fuel pump with the Porsche System Tester 2 and allow fuel to flow into the measuring container for 30 seconds</li> <li>◆ Volume supply must be at least 850 cm<sup>3</sup>/ 30 s, i.e. after 30 seconds at least 850 cm<sup>3</sup> of fuel must be in the measuring container.</li> </ul>	→ End.


**Note!**

*It is essential to observe safety regulations for handling fuel.*

Work instruction		Display OK	If not OK
9	Check triggering of fuel injectors	The engine idle speed decreases if triggering is OK	Check triggering ⇒ Step 9a
9a	B+ supply	> 11 V ⇒ Step 9b	Check wiring according to wiring diagram for continuity or short circuit → End
9b	Coil resistance of fuel injectors	11 - 13 Ω ⇒ Step 9c	

Work instruction			Display OK	If not OK
9c	Injection output stage (negative supply)	<ul style="list-style-type: none"><li>◆ Connect special tool V.A.G 1315 A/1 between fuel injector and connector</li><li>◆ Connect engine tester according to manufacturer's instructions. Connect cable for special input to special tool</li><li>◆ Start the engine.</li></ul>	See Figure ⇒ Step 9d	
9d	◆ Perform system test for large lift		→ End.	

Figure:



**Warning!**

**Tester cables must not be connected to ground.**

**Note!**

*If the engine does not start, or if the idling speed drops, replace tester cable connected to special tool.*

Perform system test for large lift

**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**i Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**Continue by performing the system test for small lift**



Perform system test for small lift

**Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type "below limit" is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1**


**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.



**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**End**

## P0304

### 511 Misfire, cylinder 4

#### Diagnosis conditions

- A cycle of 1,000 crankshaft revolutions is evaluated (for misfire damaging to the TWC, 200 crankshaft revolutions). The misfire rates are compared with a threshold value. If the misfire rate is greater than the threshold value, a fault is recorded in the memory.
- The Check Engine Malfunction Indicator Lamp (MIL) is switched on and stays on when the misfire rate lies above the threshold value at which the emission limit values are exceeded during two consecutive driving cycles (in the case of EOBD 3 driving cycles).
- If the misfire rate may lead to permanent damage to the TWC, the Check Engine MIL flashes. If the misfire rate is no longer reached during the first journey, the MIL goes out. If the rate is reached during the next journey, the MIL flashes. If this misfire rate is subsequently no longer reached, the MIL changes to a continuous light.



#### Note!

- ◆ *When using a block heater (for heating coolant), start and driving off difficulties or misfiring can occur if the block heater was connected for less than 4 hours.*
- ◆ *When the fuel tank is driven to empty, misfiring can occur. For this reason the fuel level in the tank is also stored in the memory when misfiring occurs. If the tank was nearly empty, there was probably no fault. Erase fault memory and road test vehicle.*
- ◆ *In the event of a short circuit to B+ or ground in the oxygen sensors ahead of the TWC, the mixture becomes too lean or too rich. This can cause misfiring. If, in addition, an oxygen sensor signal fault ahead of the TWC is stored in memory, first correct this fault and then road test the vehicle.*

#### Possible fault cause

- ◆ Fault in ignition system
- ◆ Fault in injection system
- ◆ Flat-base tappets (valve lift fault)
- ◆ Mixture too rich
- ◆ Mixture too lean

- ♦ Mechanical causes:

### **Valve lifter chattering**

This is caused by dirt in the valve lifter.

When the Check Engine MIL lights up, a chattering valve lifter may also occur for a certain time. The DME control module registers (sporadic) misfiring at one or more cylinders. The mixture adaptation values are normal.

Remedy:

- 1 - Remove lifter bores, check for damage and blow out oil passages.**
- 2 - Replace all valve lifters.**
- 3 - During the test drive, listen for valve lifter noises.**

### **Camshaft control times adjusted**

The camshaft control times have changed. No chattering noises occur. The DME control module indicates misfiring for the entire cylinder bank 1 or 2. The mixture adaptation values in the idle speed range differ in bank 1 and bank 2, the mixture adaptation values in the upper and lower load ranges are generally normal.

Remedy:

- 1 - Carry out raw emission measurement:**
  1. Reset mixture adaptation values (disconnect battery)
  2. Disconnect oxygen sensors

If the difference between bank 1 and bank 2 is greater than approx. 0.8 %, then

- 1 - Set the camshaft control times again.**
- 2 - Road test vehicle. The mixture adaptation values must be normal.**

### **VarioCam does not switch over completely**

The VarioCam does not switch over completely from power to torque valve timing.

An indication of this problem is misfiring detected by the DME control module in the range of 1200 - 1500 rpm occurring in an entire bank.

The mixture adaptation values are normal.

Remedy:

**1 - Replace VarioCam.****2 - Road test vehicle.**

Other possible fault causes

- ◆ worn camshafts
- ◆ leaking valves
- ◆ faulty piston rings

If opposing cylinders have misfiring, the cause could be the sensor wheel.

If valve lift faults are suspected, perform the system test for large lift and the system test for small lift with the Porsche System Tester 2.

 **Note!**

*If the battery was disconnected, at least range 1 of sensor wheel adaptation must be adapted before troubleshooting is carried out; see actual values explanation.*

Affected terminals

-

## Diagnosis/Troubleshooting

 **Note!**

*If there is a lot of oil in the engine, check that the oil filler tube and cap are tight.*

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	⇒ Step 2.	Repair intake air system → End.
2	Carry out pressure loss test	⇒ Step 3.	Repair engine → End
3	Check spark plugs. Specified spark plugs: Electrode gap: 1.6 mm ± 0.2 mm. Check appearance of spark plugs	⇒ Step 4.	Replace faulty spark plug(s). → End
4	Check spark plug connectors	Approx. 2 kΩ ⇒ Step 5	Replace faulty spark plug connectors. → End

Work instruction		Display OK	If not OK
5	Check ignition coil(s) ◆ Measure resistance between Pin 1 and Pin 15	0,3 to 0,7 $\Omega$ (at 20 °C) ⇒ Step 6.	Replace ignition coil(s) → End
6	Check all connectors for secure fastening and corrosion	⇒ Step 7.	Clean plug connections and connect securely. → End
7	Check fuel pressure ◆ Undo and remove the closure cap of the fuel collection pipe test connection (A/F 13 mm) ◆ Connect pressure gauge (special tool P 378a) to connecting line (special tool 9559) and connect to test connection. ◆ Actuate fuel pump, either with the Porsche System Tester or via a fuel pump relay without tester ◆ Nominal test value, stationary engine ◆ Nominal test value, engine idling	     3,8 ± 0.2 bar  3,3 ± 0.2 bar ⇒ Step 9	⇒ Step 8.

**Note!**

*The seal or sealing ring in the brass closure cap is not exchangeable. It must therefore be used only once.*

**Tightening torque of new brass closure cap 2.5 ± 0.5 Nm  
(2.0 ± 0.5 ftlb.)**

Work instruction		Display OK	If not OK
8	Check volume supply of fuel pump. (Fuel filter and electrical supply OK)	<ul style="list-style-type: none"> <li>◆ Relieve pressure in fuel tank by opening tank cap.</li> <li>◆ Connect Porsche System Tester 2</li> <li>◆ Remove complete air filter system</li> <li>◆ Detach fuel return line (A/F 17 mm) from the engine compartment (left), taking care to hold it fast (A/F 17 mm).</li> <li>◆ Collect residual fuel</li> <li>◆ Observe safety regulations</li> <li>◆ Connect fuel hose (shop-made, approx. 1.5 metres long) to the fitting and hold in a measuring container</li> <li>◆ Actuate fuel pump with the Porsche System Tester 2 and allow fuel to flow into the measuring container for 30 seconds</li> <li>◆ Volume supply must be at least 850 cm<sup>3</sup>/ 30 s, i.e. after 30 seconds at least 850 cm<sup>3</sup> of fuel must be in the measuring container.</li> </ul>	→ End.

**Note!**


*It is essential to observe safety regulations for handling fuel.*

Work instruction		Display OK	If not OK
9	Check triggering of fuel injectors	The engine idle speed decreases if triggering is OK	Check triggering ⇒ Step 9a
9a	B+ supply	> 11 V ⇒ Step 9b	Check wiring according to wiring diagram for continuity or short circuit → End
9b	Coil resistance of fuel injectors	11 - 13 Ω ⇒ Step 9c	

Work instruction			Display OK	If not OK
9c	Injection output stage (negative supply)	<ul style="list-style-type: none"><li>◆ Connect special tool V.A.G 1315 A/1 between fuel injector and connector</li><li>◆ Connect engine tester according to manufacturer's instructions. Connect cable for special input to special tool</li><li>◆ Start the engine.</li></ul>	See Figure ⇒ Step 9d	
9d	◆ Perform system test for large lift		→ End.	



Figure:



**Warning!**

**Tester cables must not be connected to ground.**

**Note!**

*If the engine does not start, or if the idling speed drops, replace tester cable connected to special tool.*

Perform system test for large lift

**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**i Note!**

- ◆ If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).
- ◆ It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.

**Continue by performing the system test for small lift**

Perform system test for small lift

**Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type "below limit" is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1**


**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.



**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**End**

## P0305

### 512 Misfire, cylinder 5

#### Diagnosis conditions

- A cycle of 1,000 crankshaft revolutions is evaluated (for misfire damaging to the TWC, 200 crankshaft revolutions). The misfire rates are compared with a threshold value. If the misfire rate is greater than the threshold value, a fault is recorded in the memory.
- The Check Engine Malfunction Indicator Lamp (MIL) is switched on and stays on when the misfire rate lies above the threshold value at which the emission limit values are exceeded during two consecutive driving cycles (in the case of EOBD 3 driving cycles).
- If the misfire rate may lead to permanent damage to the TWC, the Check Engine MIL flashes. If the misfire rate is no longer reached during the first journey, the MIL goes out. If the rate is reached during the next journey, the MIL flashes. If this misfire rate is subsequently no longer reached, the MIL changes to a continuous light.



#### Note!

- ◆ *When using a block heater (for heating coolant), start and driving off difficulties or misfiring can occur if the block heater was connected for less than 4 hours.*
- ◆ *When the fuel tank is driven to empty, misfiring can occur. For this reason the fuel level in the tank is also stored in the memory when misfiring occurs. If the tank was nearly empty, there was probably no fault. Erase fault memory and road test vehicle.*
- ◆ *In the event of a short circuit to B+ or ground in the oxygen sensors ahead of the TWC, the mixture becomes too lean or too rich. This can cause misfiring. If, in addition, an oxygen sensor signal fault ahead of the TWC is stored in memory, first correct this fault and then road test the vehicle.*

#### Possible fault cause

- ◆ Fault in ignition system
- ◆ Fault in injection system
- ◆ Flat-base tappets (valve lift fault)
- ◆ Mixture too rich
- ◆ Mixture too lean

- ♦ Mechanical causes:

### **Valve lifter chattering**

This is caused by dirt in the valve lifter.

When the Check Engine MIL lights up, a chattering valve lifter may also occur for a certain time. The DME control module registers (sporadic) misfiring at one or more cylinders. The mixture adaptation values are normal.

Remedy:

- 1 - Remove lifter bores, check for damage and blow out oil passages.**
- 2 - Replace all valve lifters.**
- 3 - During the test drive, listen for valve lifter noises.**

### **Camshaft control times adjusted**

The camshaft control times have changed. No chattering noises occur. The DME control module indicates misfiring for the entire cylinder bank 1 or 2. The mixture adaptation values in the idle speed range differ in bank 1 and bank 2, the mixture adaptation values in the upper and lower load ranges are generally normal.

Remedy:

- 1 - Carry out raw emission measurement:**
  1. Reset mixture adaptation values (disconnect battery)
  2. Disconnect oxygen sensors

If the difference between bank 1 and bank 2 is greater than approx. 0.8 %, then

- 1 - Set the camshaft control times again.**
- 2 - Road test vehicle. The mixture adaptation values must be normal.**

### **VarioCam does not switch over completely**

The VarioCam does not switch over completely from power to torque valve timing.

An indication of this problem is misfiring detected by the DME control module in the range of 1200 - 1500 rpm occurring in an entire bank.

The mixture adaptation values are normal.

Remedy:

**1 - Replace VarioCam.****2 - Road test vehicle.**

Other possible fault causes

- ◆ worn camshafts
- ◆ leaking valves
- ◆ faulty piston rings

If opposing cylinders have misfiring, the cause could be the sensor wheel.

If valve lift faults are suspected, perform the system test for large lift and the system test for small lift with the Porsche System Tester 2.

 **Note!**

*If the battery was disconnected, at least range 1 of sensor wheel adaptation must be adapted before troubleshooting is carried out; see actual values explanation.*

Affected terminals

-

## Diagnosis/Troubleshooting

 **Note!**

*If there is a lot of oil in the engine, check that the oil filler tube and cap are tight.*

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	⇒ Step 2.	Repair intake air system → End.
2	Carry out pressure loss test	⇒ Step 3.	Repair engine → End
3	Check spark plugs. Specified spark plugs: Electrode gap: 1.6 mm ± 0.2 mm. Check appearance of spark plugs	⇒ Step 4.	Replace faulty spark plug(s). → End
4	Check spark plug connectors	Approx. 2 kΩ ⇒ Step 5	Replace faulty spark plug connectors. → End

Work instruction		Display OK	If not OK
5	Check ignition coil(s) ◆ Measure resistance between Pin 1 and Pin 15	0,3 to 0,7 $\Omega$ (at 20 °C) ⇒ Step 6.	Replace ignition coil(s) → End
6	Check all connectors for secure fastening and corrosion	⇒ Step 7.	Clean plug connections and connect securely. → End
7	Check fuel pressure ◆ Undo and remove the closure cap of the fuel collection pipe test connection (A/F 13 mm) ◆ Connect pressure gauge (special tool P 378a) to connecting line (special tool 9559) and connect to test connection. ◆ Actuate fuel pump, either with the Porsche System Tester or via a fuel pump relay without tester ◆ Nominal test value, stationary engine ◆ Nominal test value, engine idling	3,8 ± 0.2 bar  3,3 ± 0.2 bar ⇒ Step 9	⇒ Step 8.

**Note!**

*The seal or sealing ring in the brass closure cap is not exchangeable. It must therefore be used only once.*

**Tightening torque of new brass closure cap 2.5 ± 0.5 Nm  
(2.0 ± 0.5 ftlb.)**



Work instruction		Display OK	If not OK
8	<p>Check volume supply of fuel pump. (Fuel filter and electrical supply OK)</p> <ul style="list-style-type: none"> <li>◆ Relieve pressure in fuel tank by opening tank cap.</li> <li>◆ Connect Porsche System Tester 2</li> <li>◆ Remove complete air filter system</li> <li>◆ Detach fuel return line (A/F 17 mm) from the engine compartment (left), taking care to hold it fast (A/F 17 mm).</li> <li>◆ Collect residual fuel</li> <li>◆ Observe safety regulations</li> <li>◆ Connect fuel hose (shop-made, approx. 1.5 metres long) to the fitting and hold in a measuring container</li> <li>◆ Actuate fuel pump with the Porsche System Tester 2 and allow fuel to flow into the measuring container for 30 seconds</li> <li>◆ Volume supply must be at least 850 cm<sup>3</sup>/ 30 s, i.e. after 30 seconds at least 850 cm<sup>3</sup> of fuel must be in the measuring container.</li> </ul>	→ End.	


**Note!**

*It is essential to observe safety regulations for handling fuel.*

Work instruction		Display OK	If not OK
9	Check triggering of fuel injectors	The engine idle speed decreases if triggering is OK	Check triggering ⇒ Step 9a
9a	B+ supply	> 11 V ⇒ Step 9b	Check wiring according to wiring diagram for continuity or short circuit → End
9b	Coil resistance of fuel injectors	11 - 13 Ω ⇒ Step 9c	

Work instruction			Display OK	If not OK
9c	Injection output stage (negative supply)	<ul style="list-style-type: none"><li>◆ Connect special tool V.A.G 1315 A/1 between fuel injector and connector</li><li>◆ Connect engine tester according to manufacturer's instructions. Connect cable for special input to special tool</li><li>◆ Start the engine.</li></ul>	See Figure ⇒ Step 9d	
9d	◆ Perform system test for large lift		→ End.	

Figure:



**Warning!**

**Tester cables must not be connected to ground.**

**Note!**

*If the engine does not start, or if the idling speed drops, replace tester cable connected to special tool.*

Perform system test for large lift

**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**i Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**Continue by performing the system test for small lift**

Perform system test for small lift

**Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type "below limit" is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.


A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1****B - Oxygen sensing, bank 2****1 - Select system test.****2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**End**

## P0306

### 513 Misfire, cylinder 6

#### Diagnosis conditions

- A cycle of 1,000 crankshaft revolutions is evaluated (for misfire damaging to the TWC, 200 crankshaft revolutions). The misfire rates are compared with a threshold value. If the misfire rate is greater than the threshold value, a fault is recorded in the memory.
- The Check Engine Malfunction Indicator Lamp (MIL) is switched on and stays on when the misfire rate lies above the threshold value at which the emission limit values are exceeded during two consecutive driving cycles (in the case of EOBD 3 driving cycles).
- If the misfire rate may lead to permanent damage to the TWC, the Check Engine MIL flashes. If this misfire rate is subsequently no longer reached, the MIL changes to a continuous light.



#### Note!

- ◆ *When using a block heater (for heating coolant), start and driving off difficulties can occur or misfiring if the block heater was connected for less than 4 hours.*
- ◆ *When the fuel tank is driven to empty, misfiring can occur. For this reason the fuel level in the tank is also stored in the memory when misfiring occurs. If the tank was nearly empty, there was probably no fault. Erase fault memory and road test vehicle.*
- ◆ *In the event of a short circuit to B+ or ground in the oxygen sensors ahead of the TWC, the mixture becomes too lean or too rich. This can cause misfiring. If, in addition, an oxygen sensor signal fault ahead of the TWC is stored in memory, first correct this fault and then road test the vehicle.*

#### Possible fault cause

- ◆ Fault in ignition system
- ◆ Fault in injection system
- ◆ Flat-base tappets (valve lift fault)
- ◆ Mixture too rich
- ◆ Mixture too lean
- ◆ Mechanical causes:

#### Valve lifter chattering

This is caused by dirt in the valve lifter.

When the Check Engine MIL lights up, a chattering valve lifter may also occur for a certain time. The DME control module registers (sporadic) misfiring at one or more cylinders. The mixture adaptation values are normal.

Remedy:

- 1 - Remove lifter bores, check for damage and blow out oil passages.**
- 2 - Replace all valve lifters.**
- 3 - During the test drive, listen for valve lifter noises.**

### **Camshaft control badly adjusted**

The camshaft control has changed. No chattering noises occur. The DME control module indicates misfiring for the entire cylinder bank 1 or 2. The mixture adaptation values in the idle speed range differ in bank 1 and bank 2, the mixture adaptation values in the upper and lower load ranges are generally normal.

Remedy:

- 1 - Carry out raw emission measurement:**
  1. Reset mixture adaptation values (disconnect battery)
  2. Disconnect oxygen sensors

If the difference between bank 1 and bank 2 is greater than approx. 0.8 %, then

- 1 - Reset camshaft control.**
- 2 - Road test vehicle. The mixture adaptation values must be normal.**

### **VarioCam does not switch over completely**

The VarioCam does not switch over completely from power to torque valve timing.

An indication of this problem is misfiring detected by the DME control module in the range of 1200 - 1500 rpm occurring in an entire bank.

The mixture adaptation values are normal.

Remedy:

- 1 - Replace VarioCam.**
- 2 - Road test vehicle.**



## Other possible fault causes

- ◆ worn camshafts
- ◆ leaking valves
- ◆ faulty piston rings

If opposing cylinders have misfiring, the cause could be the sensor wheel.

If valve lift faults are suspected, perform the system test for large lift and the system test for small lift with the Porsche System Tester 2.

**Note!**

*If the battery was disconnected, at least range 1 must be adapted before troubleshooting is carried out.*

## Affected terminals

-

## Diagnosis/Troubleshooting

**Note!**

*If there is a lot of oil in the engine, check that the oil filler tube and cap are tight.*

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	⇒ Step 2.	Repair intake air system → End.
2	Carry out pressure loss test	⇒ Step 3.	Repair engine → End
3	Check spark plugs. Specified spark plugs: Electrode gap: 1.6 mm ± 0.2 mm. Check appearance of spark plugs	⇒ Step 4.	Replace faulty spark plug(s). → End
4	Check spark plug connectors	Approx. 2 kΩ ⇒ Step 5	Replace faulty spark plug connectors. → End
5	Check ignition coil(s) <ul style="list-style-type: none"> <li>◆ Measure resistance between Pin 1 and Pin 15</li> </ul>	0,3 to 0,7 Ω (at 20 °C) ⇒ Step 6.	Replace ignition coil(s) → End

Work instruction		Display OK	If not OK
6	Check all connectors for secure fastening and corrosion	⇒ Step 7.	Clean plug connections and connect securely. → End
7	Check fuel pressure <ul style="list-style-type: none"> <li>◆ Undo and remove the closure cap of the fuel collection pipe test connection (A/F 13 mm)</li> <li>◆ Connect pressure gauge (special tool P 378a) to connecting line (special tool 9559) and connect to test connection.</li> <li>◆ Actuate fuel pump, either with the Porsche System Tester or via a fuel pump relay without tester</li> <li>◆ Nominal test value, stationary engine</li> <li>◆ Nominal test value, engine idling</li> </ul>	3,8 ± 0.2 bar  3,3 ± 0.2 bar ⇒ Step 9	⇒ Step 8.

**Note!**

*The seal or sealing ring in the brass closure cap is not exchangeable. It must therefore be used only once.*

**Tightening torque of new brass closure cap 2.5 ± 0.5 Nm  
(2.0 ± 0.5 ftlb.)**

Work instruction		Display OK	If not OK
8	<p>Check volume supply of fuel pump. (Fuel filter and electrical supply OK)</p> <ul style="list-style-type: none"> <li>◆ Relieve pressure in fuel tank by opening tank cap.</li> <li>◆ Connect Porsche System Tester 2</li> <li>◆ Remove complete air filter system</li> <li>◆ Detach fuel return line (A/F 17 mm) from the engine compartment (left), taking care to hold it fast (A/F 17 mm).</li> <li>◆ Collect residual fuel</li> <li>◆ Observe safety regulations</li> <li>◆ Connect fuel hose (shop-made, approx. 1.5 metres long) to the fitting and hold in a measuring container</li> <li>◆ Actuate fuel pump with the Porsche System Tester 2 and allow fuel to flow into the measuring container for 30 seconds</li> <li>◆ Volume supply must be at least 850 cm<sup>3</sup>/ 30 s, i.e. after 30 seconds at least 850 cm<sup>3</sup> of fuel must be in the measuring container.</li> </ul>	→ End.	


**Note!**

*It is essential to observe safety regulations for handling fuel.*

Work instruction		Display OK	If not OK
9	Check triggering of fuel injectors	The engine idle speed decreases if triggering is OK	Check triggering ⇒ Step 9a
9a	B+ supply	> 11 V ⇒ Step 9b	Check wiring according to wiring diagram for continuity or short circuit → End
9b	Coil resistance of fuel injectors	11 - 13 Ω ⇒ Step 9c	

Work instruction			Display OK	If not OK
9c	Injection output stage (negative supply)	<ul style="list-style-type: none"><li>◆ Connect special tool V.A.G 1315 A/1 between fuel injector and connector</li><li>◆ Connect engine tester according to manufacturer's instructions. Connect cable for special input to special tool</li><li>◆ Start the engine.</li></ul>	See Figure ⇒ Step 9d	
9d	◆ Perform system test for large lift		→ End.	

Figure:



**Warning!**

**Tester cables must not be connected to ground.**

**Note!**

*If the engine does not start, or if the idling speed drops, replace tester cable connected to special tool.*

Perform system test for large lift

**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


System test for large lift means that faults are detected if a valve does not switch to large lift (fault type: above limit).

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

As a rule, only the cylinder bank with the faulty valve can be detected. Therefore in the case of a fault, the flat-base tappets of the inlet valves of the entire cylinder bank must be replaced.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**i Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**Continue by performing the system test for small lift**

Perform system test for small lift




**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

System test for small lift means that faults are detected if a valve remains jammed at large lift (fault type: below limit).

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty. As a rule, only the cylinder bank with the faulty valve can be detected. Therefore in the case of a fault, the flat-base tappets of the inlet valves of the entire cylinder bank must be replaced.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1**


**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

 **Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

 **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

**End**



## P0324

### Knock Control Zero Test - Signal Implausible

#### Diagnosis conditions

- Engine speed less than 5600 rpm
- Knock control active
- Engine load greater than 45 %

#### Possible fault cause

- ◆ DME control module



#### Note!

*When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.*

#### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2.	
2	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	



## P0327

### 210 Knock sensor 1 - below limit

#### Diagnosis conditions

- Engine speed more than 3600 rpm
- Engine load greater than 45 %

#### Possible fault cause

- ◆ Break in wiring or short to ground
- ◆ Contact corrosion on the connector
- ◆ Knock sensor loose
- ◆ Short circuit to B+
- ◆ Knock sensor

#### Note!

- ◆ *When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.*
- ◆ *Knock control adaptation is inactive.*
- ◆ *If knock control becomes active here, this may indicate engine damage (increased noise level)*

#### Affected terminals

Terminal III/49 and III/50

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check plug connection of knock sensor 1	⇒ Step 2	Connect plug connection → End
2	Check plug-in contacts of connector for corrosion	⇒ Step 3	Clean plug-in contacts, replace if necessary. → End
3	Check mounting of knock sensor. Tightening torque: $20 \pm 2$ Nm ( $15 \pm 1.5$ ftlb.)	⇒ Step 4	Mount knock sensor correctly. → End

Work instruction		Display OK	If not OK
4	<p>Check wiring from DME control module, Pins III/49 and III/50 to knock sensor 1 for continuity</p> <ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 1</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/49 and knock sensor plug connection Pin 1</li> <li>◆ Measure resistance between special tool 9637 Pin III/50 and knock sensor plug connection Pin 2</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math> ⇒ Step 5</p>	<p>Repair wiring harness → End</p>
5	<p>Check wiring from DME control module, Pin III/49, to knock sensor 1 for short to ground</p> <ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 1</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/49 and ground</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 6</p>	<p>Repair wiring harness → End</p>
6	<p>Replace knock sensor 1</p>	<p>→ End</p>	

## P0328

### 210 Knock sensor 1 - above limit

#### Diagnosis conditions

- Engine speed more than 3600 rpm
- Engine load greater than 45 %

#### Possible fault cause

- ◆ Short circuit to B+
- ◆ Contact corrosion on the connector
- ◆ Knock sensor loose
- ◆ Short circuit to B+
- ◆ Knock sensor



#### Note!

- ◆ When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.
- ◆ Knock control adaptation is inactive.
- ◆ If knock control becomes active here, this may indicate engine damage (increased noise level)

#### Affected terminals

Terminal III/49 and III/50

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check plug connection of knock sensor 1	⇒ Step 2	Connect plug connection → End
2	Check plug-in contacts of connector for corrosion	⇒ Step 3	Clean plug-in contacts, replace if necessary. → End
3	Check mounting of knock sensor. Tightening torque: 20 ± 2 Nm (15 ± 1.5 ftlb.)	⇒ Step 4	Mount knock sensor correctly. → End

Work instruction		Display OK	If not OK
4	<p>Check wiring from DME control module, Pins III/49 and III/50 to knock sensor 1 for continuity</p> <ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 1</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/49 and knock sensor plug connection Pin 1</li> <li>◆ Measure resistance between special tool 9637 Pin III/50 and knock sensor plug connection Pin 2</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math> ⇒ Step 5</p>	<p>Repair wiring harness → End</p>
5	<p>Check wiring from DME control module, Pin III/49, to knock sensor 1 for short to B+</p> <ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 1</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 Pin III/49 and ground</li> </ul>	<p>0 V ⇒ Step 6</p>	<p>Repair wiring harness → End</p>
6	<p>Replace knock sensor 1</p>	<p>→ End</p>	

## P0332

### 211 Knock sensor 2 - below limit

#### Diagnosis conditions

- Engine speed more than 3600 rpm
- Engine load greater than 45 %

#### Possible fault cause

- ◆ Break in wiring or short to ground
- ◆ Contact corrosion on the connector
- ◆ Knock sensor loose
- ◆ Short circuit to B+
- ◆ Knock sensor



#### Note!

- ◆ When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.
- ◆ Knock control adaptation is inactive.
- ◆ If knock control becomes active here, this may indicate engine damage (increased noise level)

#### Affected terminals

Terminal III/36 and III/37

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check plug connection of knock sensor 2	⇒ Step 2	Connect plug connection → End
2	Check plug-in contacts of connector for corrosion	⇒ Step 3	Clean plug-in contacts, replace if necessary. → End
3	Check mounting of knock sensor. Tightening torque: 20 ± 2 Nm (15 ± 1.5 ftlb.)	⇒ Step 4	Mount knock sensor correctly. → End

Work instruction		Display OK	If not OK
4	<p>Check wiring from DME control module, Pins III/36 and III/37 to knock sensor 2 for continuity</p> <ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 2</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/36 and knock sensor plug connection Pin 2</li> <li>◆ Measure resistance between special tool 9637 Pin III/37 and knock sensor plug connection Pin 2</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math> ⇒ Step 5</p>	<p>Repair wiring harness → End</p>
5	<p>Check wiring from DME control module, Pin III/36, to knock sensor 2 for short to ground</p> <ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 2</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/36 and ground</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 6</p>	<p>Repair wiring harness → End</p>
6	<p>Replace knock sensor 2</p>	<p>→ End</p>	



## P0333

### 211 Knock sensor 2 - above limit

#### Diagnosis conditions

- Engine speed more than 3600 rpm
- Engine load greater than 45 %

#### Possible fault cause

- ◆ Short circuit to B+
- ◆ Contact corrosion on the connector
- ◆ Knock sensor loose
- ◆ Short circuit to B+
- ◆ Knock sensor

#### Note!

- ◆ *When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.*
- ◆ *Knock control adaptation is inactive.*
- ◆ *If knock control becomes active here, this may indicate engine damage (increased noise level)*

#### Affected terminals

Terminal III/36 and III/37

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check plug connection of knock sensor 2	⇒ Step 2	Connect plug connection → End
2	Check plug-in contacts of connector for corrosion	⇒ Step 3	Clean plug-in contacts, replace if necessary. → End
3	Check mounting of knock sensor. Tightening torque: 20 ± 2 Nm (15 ± 1.5 ftlb.)	⇒ Step 4	Mount knock sensor correctly. → End

Work instruction		Display OK	If not OK
4	Check wiring from DME control module, Pins III/36 and III/37 to knock sensor 2 for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 2</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/36 and knock sensor plug connection Pin 1</li> <li>◆ Measure resistance between special tool 9637 Pin III/37 and knock sensor plug connection Pin 2</li> </ul>	Repair wiring harness → End
5	Check wiring from DME control module, Pin III/36, to knock sensor 2 for short to B+	<ul style="list-style-type: none"> <li>◆ Remove connector of knock sensor 2</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 Pin III/38 and ground</li> </ul>	Repair wiring harness → End
6	Replace knock sensor 2	→ End	

## P0335

### Engine Speed Sensor Signal – Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Corrosion in the connector
- ◆ Open circuit or short circuit in the wiring harness
- ◆ Rpm/crankshaft position sensor faulty.
- ◆ DME control module faulty


#### Affected terminals

III/32, III/45 and III/46

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Remove connector.		
2	Check connector for corrosion.		Clean contacts.
3	Check rpm/crankshaft position sensor.	◆ Measure resistance between pins 1 and 2.	Replace rpm/crankshaft position sensor.
		◆ Measure resistance between pins 1 and 3.	
4	Check signal with engine tester.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect engine tester. Use special input, connect positive cable to pin III/32, negative cable to pin III/46</li> <li>◆ Start engine or crank engine with starter motor.</li> </ul>	The following display should appear on the oscilloscope.

Figure:



Work instruction		Display OK	If not OK	
5	Check wiring from rpm/crankshaft position sensor to DME control module for open circuit and short circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness</li> <li>◆ Remove connector of rpm/crankshaft position sensor</li> <li>◆ Measure resistance between special tool 9637 pin III/32 and plug connection pin 1</li> <li>◆ Measure resistance between special tool 9637 pin III/46 and plug connection pin 2</li> <li>◆ Measure resistance between ohmmeter on special tool 9637 pin III/45 and plug connection pin 3</li> </ul>	0 - 5 Ω	
		<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool 9637 pin III/32 and ground.</li> <li>◆ Measure resistance between pin III/46 and ground</li> </ul>	∞ Ω	

## P0336

### 110 Engine Speed Sensor Signal - Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Corrosion in the connector
- ◆ Open circuit or short circuit in the wiring harness
- ◆ Rpm/crankshaft position sensor faulty.
- ◆ DME control module faulty


#### Affected terminals

III/32, III/45 and III/46

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Remove connector		
2	Check for corrosion		Clean contacts
3	Check rpm/crankshaft position sensor	◆ Measure resistance between pins 1 and 2	Replace rpm/crankshaft position sensor
		◆ Measure resistance between pins 1 and 3	
4	Check signal with engine tester	◆ Connect special tool 9637 ◆ Connect engine tester. Use special input, connect positive cable to pin III/32, negative cable to pin III/46 ◆ Start engine or crank engine with starter motor	The following display should appear on the oscilloscope

Figure:



Work instruction		Display OK	If not OK	
5	Check wiring from rpm/crankshaft position sensor to DME control module for open circuit and short circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness</li> <li>◆ Remove connector of rpm/crankshaft position sensor</li> <li>◆ Measure resistance between special tool 9637 pin III/32 and plug connection pin 1</li> <li>◆ Measure resistance between special tool 9637 pin III/46 and plug connection pin 2</li> <li>◆ Measure resistance between ohmmeter on special tool 9637 pin III/45 and plug connection pin 3</li> </ul>	0 - 5 Ω	
		<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool 9637 pin III/32 and ground.</li> <li>◆ Measure resistance between pin III/46 and ground</li> </ul>	∞ Ω	

## P0336

### Crankshaft Position Sensor, Signal Implausible

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Corrosion in the connector
- ◆ Loose contact


#### Affected terminals

III/32, III/45 and III/46

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Remove connector.		
2	Check connector for corrosion.	◆ Visual inspection.	Clean contacts.
3	Check rpm/crankshaft position sensor.	◆ Measure resistance between pins 1 and 2.	Replace rpm/crankshaft position sensor.
		◆ Measure resistance between pins 1 and 3.	
4	Check signal with engine tester.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect engine tester. Use special input, connect positive cable to pin III/32, negative cable to pin III/46</li> <li>◆ Start engine or crank engine with starter motor.</li> </ul>	The following display should appear on the oscilloscope.

Figure:





## P0341

### 112 Camshaft position sensor 1 - signal implausible

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Loose contact
- ◆ Camshaft position sensor

#### Note!

- ◆ If both CMP sensor signals are missing, the start will take at least 10 seconds.
- ◆ For safety reasons, the ignition timing is retarded.

#### Affected terminals


Terminals III/7, III/12 and III/17

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check CMP voltage supply	<ul style="list-style-type: none"> <li>◆ Remove connector of CMP sensor 1</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin 1 and Pin 3</li> </ul>	Approx. 5 V ⇒ Step 5	⇒ Step 2
2	Check power supply wiring for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector of CMP sensor 1</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/7 and CMP sensor 1 plug Pin 3</li> <li>◆ Measure resistance between special tool 9637 Pin III/17 and CMP sensor 1 plug Pin 1</li> </ul>	0 - 5 Ω ⇒ Step 3	
3	Replace DME control module		⇒ Step 4	

Work instruction			Display OK	If not OK
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	
5	Check CMP sensor signal	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Connect engine tester; use special input</li> <li>◆ Positive cable to Pin III/12</li> <li>◆ Negative cable to Pin III/17</li> <li>◆ Start the engine</li> </ul>	See Figure 1 ⇒ Step 6	Replace CMP sensor → End

Figure 1:



Work instruction		Display OK	If not OK
6	Check signal wire from DME control module, Pin III/12, to CMP sensor <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of CMP sensor 1</li> <li>◆ Measure resistance between special tool 9637 Pin III/12 and CMP sensor 1 plug Pin 2</li> </ul>	0 - 5 $\Omega$ → End	Repair wiring harness → End



## P0342

### 112 Camshaft position sensor 1 - below limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit to ground



#### Note!

- ◆ *If both CMP sensor signals are missing, the start will take at least 10 seconds.*
- ◆ *For safety reasons, the ignition timing is retarded.*

#### Affected terminals

Terminal III/12

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check signal wire from DME control module, Pin III/12, to CMP sensor for short to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of CMP sensor 1</li> <li>◆ Measure resistance between special tool 9637 Pin III/12 and ground</li> </ul>	$\infty \Omega$ → End	Repair wiring harness → End



## P0343

### 112 Camshaft position sensor 1 - above limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit to B+



#### Note!

- ◆ *If both CMP sensor signals are missing, the start will take at least 10 seconds.*
- ◆ *For safety reasons, the ignition timing is retarded.*

#### Affected terminals

Terminal III/12

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check signal wire from DME control module, Pin III/12, to CMP sensor for short to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of CMP sensor 1</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 Pin III/12 and ground</li> </ul>	0 V → End	Repair wiring harness → End





## P0344

### Camshaft position sensor 1 - open circuit

#### Diagnosis conditions

- Engine running
- No other camshaft position sensor faults stored in memory (P0341; P0342; P0343)

#### Possible fault cause

- ◆ Camshaft rotor (phase sensor wheel) damaged

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

The 'No signal' comes because the DME expects a camshaft position sensor signal, but this does not appear because of damage to the camshaft rotor (phase sensor wheel)

Work instruction		Display OK	If not OK
1	Check for further fault entries for camshaft position sensor 1	No further entries ⇒ Step 2	Rectify other camshaft position sensor faults (P0341; P0342; P0343) according to instructions → End
2	Check camshaft rotor for damage	See HBT Group 1 Engine	

## P0346

## Camshaft Position Sensor 2 - Signal Implausible

## Diagnosis conditions

- Engine running

## Possible fault cause

- ◆ Loose contact
- ◆ Camshaft position sensor

**Note!**

- ◆ *If both CMP sensor signals are missing, the start will take at least 10 seconds.*
- ◆ *For safety reasons, the ignition timing is retarded.*

## Affected terminals


Terminals Ill/7, Ill/17 and Ill/18

## Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check CMP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin 1 and Pin 3</li> </ul>	Approx. 5 V ⇒ Step 5	⇒ Step 2.
2	Check power supply wiring for continuity.	<ul style="list-style-type: none"> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool 9637 Pin Ill/7 and CMP sensor 2 plug Pin 3</li> <li>◆ Measure resistance between special tool 9637 Pin Ill/17 and CMP sensor plug 2 Pin 1</li> </ul>	0 - 5 Ω ⇒ Step 3.	
3	Replace DME control module		⇒ Step 4.	

Work instruction		Display OK	If not OK
4	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	
5	Check CMP sensor signal <ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect engine tester; use special input</li> <li>◆ Positive cable to Pin III/18</li> <li>◆ Negative cable to Pin III/17</li> <li>◆ Start the engine.</li> </ul>	See Figure 1 ⇒ Step 6	Replace CMP sensor → End

Figure 1:



Work instruction		Display OK	If not OK
6	Check signal wire from DME control module, Pin III/18, to CMP sensor <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Measure resistance between special tool 9637 Pin III/18 and CMP sensor 21 plug Pin 2</li> </ul>	0 - 5 $\Omega$ → End.	Repair wiring harness → End.



## P0347

### Camshaft Position Sensor 2 – Below Limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit to ground



#### Note!

- ◆ *If both CMP sensor signals are missing, the start will take at least 10 seconds.*
- ◆ *For safety reasons, the ignition timing is retarded.*

#### Affected terminals

Terminal III/18

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check signal wire from DME control module, Pin III/18, to CMP sensor for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Measure resistance between special tool 9637 pin III/18 and ground.</li> </ul>	<ul style="list-style-type: none"> <li>◆ <math>\infty \Omega</math> → End.</li> </ul>
			<ul style="list-style-type: none"> <li>◆ Repair wiring harness → End.</li> </ul>



## P0348

### Camshaft Position Sensor 2 – Above Limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit to B+



#### Note!

- ◆ *If both CMP sensor signals are missing, the start will take at least 10 seconds.*
- ◆ *For safety reasons, the ignition timing is retarded.*

#### Affected terminals

Terminal III/18

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check signal wire from DME control module, Pin III/18, to CMP sensor for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between special tool 9637 pin III/18 and ground.</li> </ul>	0 V → End.	Repair wiring harness → End.





## P0349

### Camshaft position sensor 2 - open circuit

#### Diagnosis conditions

- Engine running
- No other camshaft position sensor faults stored in memory (P0346; P0347; P0348)

#### Possible fault cause

- ◆ Camshaft rotor (phase sensor wheel) damaged

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

The 'No signal' comes because the DME expects a camshaft position sensor signal, but this does not appear due to damage to the camshaft rotor (phase sensor wheel)

Work instruction		Display OK	If not OK
1	Check for further fault entries for camshaft position sensor 2	No further entries ⇒ Step 2	Rectify other camshaft position sensor faults (P0346; P0347; P0348) according to instructions → End
2	Check camshaft rotor for damage	See HBT Group 1 Engine	

## P0410

### 80 Secondary Air Injection System, Bank 1 – Below Limit

#### Diagnosis conditions

- Intake air temperature 4.5 - 60 °C
- Engine temperature 4.5 - 102 °C
- Mass air flow 36 - 150 kg/h
- Engine starting temperature less than 42 °C
- Altitude correction factor greater than 0.75
- Oxygen sensors 1 and 2 ahead of TWC are ready for operation
- The secondary air injection pump is switched on
- Diagnosis has not yet taken place during this cycle

#### Possible fault cause

- ◆ Secondary air injection pump is not triggered
- ◆ Secondary air injection pump does not work
- ◆ Air supply lines restricted
- ◆ Electric change-over valve does not function
- ◆ Air change-over valve does not function
- ◆ Vacuum system leaking

#### Affected terminals

III/11 and III/14

#### Diagnosis/troubleshooting

**Note!**

Secondary air diagnosis can be activated with the Porsche System Tester 2 in the "Short test" menu.

Work instruction		Display OK	If not OK
1	Activate secondary air pump.	⇒ Step 3	⇒ Step 2
	<ul style="list-style-type: none"> <li>◆ Remove relay of secondary air injection pump.</li> <li>◆ Jumper terminals 30 and 87.</li> <li>◆ The secondary air pump must be running (audible function).</li> <li>– or</li> <li>◆ Connect and switch on Porsche System Tester 2.</li> <li>◆ Select DME.</li> <li>◆ Call up "Drive links" menu.</li> <li>◆ Select "Secondary air pump".</li> <li>◆ Activate secondary air pump (audible function).</li> </ul>		
2	Check triggering of secondary air pump	Battery positive voltage	Check wire from pin 2 to DME control module pin III/11 for continuity.
	<ul style="list-style-type: none"> <li>◆ Check fuse (Maxi Fuse) of AIR pump (on relay carrier 2).</li> <li>◆ Remove relay of AIR pump (on relay carrier 2).</li> <li>◆ Measure voltage between pin 3 and ground</li> <li>◆ Push relay back on.</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove connector of AIR pump.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>	Battery positive voltage	
3	Check vacuum system for leaks		Seal vacuum system
4	Check electric change-over valve	Battery positive voltage	
	<ul style="list-style-type: none"> <li>◆ Remove two-pole connector of electric change-over valve.</li> <li>◆ Trigger AIR pump with Porsche System Tester 2.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose of electric change-over valve with the engine running.</li> </ul>	Vacuum must be present	

Work instruction			Display OK	If not OK
5	Check air change-over valve	<ul style="list-style-type: none"> <li>◆ Run engine briefly to produce vacuum.</li> <li>◆ Activate secondary air pump.</li> <li>◆ Remove vacuum hose of air change-over valve.</li> </ul>	Vacuum must be present	
		<ul style="list-style-type: none"> <li>◆ After activation, check air change-over valve for continuity</li> </ul>		
6	Check air supply lines for blockage			



## P0413

### 85 Electric change-over valve - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Wiring harness
- ◆ Electric change-over valve
- ◆ DME control module faulty



#### Note!

The triggering wire for the electric change-over valve is monitored.

#### Affected terminals

Terminal III/14

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check voltage supply for electric change-over valve	<ul style="list-style-type: none"> <li>◆ Remove connector of electric change-over valve</li> <li>◆ Measure voltage between electric change-over valve Pin 1 and ground</li> <li>◆ Switch on the ignition</li> </ul>	> 11 V ⇒ Step 2	Repair voltage supply → End
2	Check electric change-over valve	<ul style="list-style-type: none"> <li>◆ Remove connector of electric change-over valve</li> <li>◆ Measure resistance at electric change-over valve between Pin 1 and Pin 2</li> </ul>	30 Ω at 20 °C ⇒ Step 3	Replace electric change-over valve → End
3	Check wire from DME control module, Pin III/14, to electric change-over valve for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector of electric change-over valve</li> <li>◆ Measure resistance between DME control module Pin III/14 and electric change-over valve plug Pin 2</li> </ul>	0 - 5 Ω ⇒ Step 4	Repair wiring harness → End

Work instruction		Display OK	If not OK
4	Replace DME control module	⇒ Step 5	
5	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute. Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End



## P0414

### 85 Electric change-over valve - below limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground



#### Note!

The triggering wire for the electric change-over valve is monitored.

#### Affected terminals

Terminal III/14

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wire from DME control module, Pin III/14, to electric change-over valve for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove connector of electric change-over valve</li> <li>◆ Measure resistance between DME control module Pin III/14 and electric change-over valve plug Pin 2</li> </ul>	∞ Ω → End  Repair wiring harness → End

### 85 Electric change-over valve - above limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to B+



#### Note!

The triggering wire for the electric change-over valve is monitored.

**Affected terminals**

Terminal III/14

**Diagnosis/troubleshooting**

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
1	Check wire from DME control module, Pin III/14, to electric change-over valve for short circuit to B+	0 V → End	Repair wiring harness → End

## P0418

### 84 Secondary air injection pump - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Wiring harness
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal III/11

#### Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Check voltage supply for relay of secondary air injection pump, terminal 86	<ul style="list-style-type: none"> <li>◆ Remove relay of secondary air injection pump</li> <li>◆ Measure voltage between Pin 7 and ground</li> <li>◆ Switch on the ignition</li> </ul>	> 11 V ⇒ Step 2	Repair voltage supply → End
2	Check relay for secondary air injection pump	<ul style="list-style-type: none"> <li>◆ Remove relay for secondary air injection pump</li> <li>◆ Measure resistance between relay Pin 85 and Pin 86</li> </ul>	Approx. 70 Ω (at 25 °C)	Replace relay → End
3	Check wiring from DME control module, Pin III/11, to relay of secondary air injection pump for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector of electric change-over valve</li> <li>◆ Measure resistance between DME control module Pin III/11 and relay of secondary air injection pump</li> </ul>	0 - 5 Ω ⇒ Step 4	Repair wiring harness → End
4	Replace DME control module		⇒ Step 5	
5	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 84 Secondary air injection pump - below limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

### Possible fault cause

- ◆ Short circuit to ground

### Affected terminals

Terminal III/11

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, Pin III/11, to relay of secondary air injection pump Pin 85 for short to ground	0 V → End	Repair wiring harness → End
	<ul style="list-style-type: none"> <li>◆ Remove relay for secondary air injection pump</li> <li>◆ Measure voltage between DME control module Pin III/11 and B+</li> <li>◆ Switch on the ignition</li> </ul>		

## 84 Secondary air injection pump - above limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

### Possible fault cause

- ◆ Short circuit to B+

### Affected terminals

Terminal III/11

**Diagnosis/troubleshooting**

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>	
1	Check wiring from DME control module, Pin III/11, to relay of secondary air injection pump Pin 85 for short to B+	<ul style="list-style-type: none"><li>◆ Remove relay for secondary air injection pump</li><li>◆ Measure voltage between DME control module Pin III/11 and ground</li></ul>	0 V → End	Repair wiring harness → End



## P0420

### 40 TWC conversion, bank 1 - above limit

#### Diagnosis conditions

- TWC temperature 420 - 600 °C
- 85 seconds within rpm/load range (cumulative)
- EVAP canister burden < 8
- Speed 1280 - 2440 rpm
- 20 - 40 % engine load (relative air charge)
- Oxygen sensing ahead of TWC is active
- Oxygen sensing after TWC ready for operation
- Engine starting temperature > - 20 °C
- No faults in memory

#### Possible fault cause

- ◆ Oxygen sensor ahead of and after TWC exchanged
- ◆ Valve lift fault
- ◆ Aged oxygen sensor after TWC
- ◆ TWC faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

##### Note!

*If an ageing oxygen sensor is recorded in conjunction with a fault in the TWC, a check must be performed with a new oxygen sensor to see whether a TWC fault is still indicated.*

Work instruction		Display OK	If not OK
1	Check whether the oxygen sensors ahead of and after the TWC have been exchanged		

Work instruction		Display OK	If not OK
2	Perform system test for small lift	See below	
3	Replace TWC		

### Perform system test for small lift



**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.





**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

## P0430

### 45 TWC Conversion, Bank 2 - Above Limit

#### Diagnosis conditions

- TWC temperature 420 - 600 °C
- 85 seconds within rpm/load range (cumulative)
- EVAP canister burden < 8
- Speed 1280 - 2440 rpm
- 20 - 40 % engine load (relative air charge)
- Oxygen sensing ahead of TWC is active
- Oxygen sensing after TWC ready for operation
- Engine starting temperature > - 20 °C
- No faults in memory

#### Possible fault cause

- ◆ Oxygen sensor ahead of and after TWC exchanged
- ◆ Valve lift fault
- ◆ Aged oxygen sensor after TWC
- ◆ TWC faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

*If an ageing oxygen sensor is recorded in conjunction with a fault in the TWC, a check must be performed with a new oxygen sensor to see whether a TWC fault is still indicated.*

Work instruction		Display OK	If not OK
1	Check whether the oxygen sensors ahead of and after the TWC have been exchanged		

Work instruction		Display OK	If not OK
2	Perform system test for small lift	See below	
3	Replace TWC		

### Perform system test for small lift



#### Warning!


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type "below limit" is recorded.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**Note!**

*If "Request small lift" appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

## **P0440**

### **93 Fuel Tank Ventilation System (DTESK) - Above Limit**

#### **Diagnosis conditions**

- Oxygen sensing system active
- Engine running
- Vehicle speed = 0 km/h
- Intake air temperature between 5 °C and 60 °C
- Altitude correction factor greater than 0.75
- Battery positive voltage greater than 11 V
- Engine load less than 30%
- EVAP canister burden less than 3
- Time elapsed after engine start-up greater than 990 seconds or mixture adaptation completed
- No other faults in memory

#### **Possible fault cause**

- ◆ Tank cap seal
- ◆ One or several leaks in fuel tank ventilation system

#### **Affected terminals**

-

#### **Diagnosis/troubleshooting**

**Note!**

- ◆ Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.
- ◆ The EVAP canister purge valve is very sensitive to contamination. If the lines to the EVAP canister have to be detached, the outside of the canister must be cleaned beforehand.


Work instruction		Display OK	If not OK
1	Check shutoff valve for leaks <ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner</li> <li>◆ Detach connector of shutoff valve</li> <li>◆ Detach ventilation line of shutoff valve</li> <li>◆ Connect shutoff valve to the battery or a separate power supply unit via special tool V.A.G.1315A/1.</li> <li>◆ Do not actuate the shutoff valve for more than 5 minutes (overload)</li> <li>◆ Connect special tool 9160/1 to EVAP canister</li> <li>◆ Using special tool 9160/1, generate a vacuum of 100 mbar (0.1 bar)</li> </ul>		Replace shutoff valve



Figure:

**i Note!**

- ◆ Do not produce a vacuum of more than 100 mbar, as otherwise the vacuum will cause the shutoff valve to open.
- ◆ If no vacuum can be built up, replace the shutoff valve.
- ◆ Coat the sealing ring of the new shutoff valve with tyre fitting lubricant prior to installation.
- ◆ The shutoff valve can only be installed in one position: with the electrical connection facing upwards.



Work instruction		Display OK	If not OK
2	Check tank system for leaks		
	<ul style="list-style-type: none"> <li>◆ Check the tank system for leaks using an HC tester. To do so, hold the connecting hose of the HC tester in the spot to be tested. In the case of a leak, the display of the HC tester increases to above 1000 ppm. Values below 50 ppm indicate no leaks.</li> <li>◆ To test the ventilation lines, guide the connecting hose slowly along them.</li> <li>◆ Check the following locations                             <ol style="list-style-type: none"> <li>1. Tank cap</li> <li>2. Line connections to EVAP canister</li> <li>3. EVAP canister</li> <li>4. Line connections to fuel tank sender unit</li> <li>5. Pressure sensor</li> <li>6. Opening of fuel filler neck into tank</li> <li>7. Line connection of EVAP canister purge valve</li> <li>8. Ventilation lines</li> </ol> </li> </ul>		

**Note!**


If no leaks are found, a gauge pressure of max. 100 mbar (0.1 bar) can be generated at the EVAP canister at the connection to the tank using special tool 9160/1, in order to increase the escape of fuel vapours.

**Note!**

Before detaching the ventilation lines from the EVAP canister, clean the area around the connections. Dirt must not be allowed to get into the connectors.

Work instruction		Display OK	If not OK
3	Check EVAP canister purge valve for leaks		If no vacuum can be built up, replace the EVAP canister purge valve
	<ul style="list-style-type: none"> <li>◆ Detach the ventilation line to the EVAP canister purge valve from the EVAP canister (protective cap)</li> <li>◆ With special tool 9160/1, generate a vacuum of 200 mbar (0.2 bar)</li> </ul>		

Figure:





## P0441

### 93 Fuel Tank Ventilation System - Above Limit

#### Diagnosis conditions

- Engine idling
- Vehicle speed = 0 km/h
- Oxygen sensing system active
- No secondary air diagnosis
- No other faults in memory

#### Possible fault cause

- ◆ EVAP canister purge valve incorrectly installed
- ◆ EVAP canister purge valve faulty
- ◆ Blocked purge air line
- ◆ EVAP canister purge valve leaking
- ◆ Leaking line between EVAP canister and air intake system

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.

Work instruction			Display OK	If not OK
1	Check installation position of EVAP canister purge valve	Flow through the EVAP canister purge valve is possible in one direction only. The flow direction is indicated by an arrow on the EVAP canister purge valve. The arrow must point towards the intake manifold.		
2	Check triggering of EVAP canister purge valve.	<ul style="list-style-type: none"> <li>◆ Connect Porsche System Tester 2</li> <li>◆ In the "Drive links" menu, select EVAP canister purge valve.</li> </ul>	The EVAP canister purge valve must switch audibly.	

Work instruction		Display OK	If not OK
3	Check voltage supply and wiring.	<ul style="list-style-type: none"> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pin 1 and ground</li> </ul>	Battery positive voltage
		<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness</li> <li>◆ Measure resistance at pin III/3 and EVAP canister purge valve connector, pin 2</li> </ul>	0 - 5 $\Omega$
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes
5	Check hose line between EVAP canister purge valve and air intake system	<ul style="list-style-type: none"> <li>◆ Undo hose at intake system</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes

## **P0442**

### **97 Fuel Tank Ventilation System (Micro-leak) - Below Limit**

#### **Diagnosis conditions**

- Oxygen sensing system active
- Engine running
- Vehicle speed = 0 km/h
- Intake air temperature between 5 °C and 60 °C
- Altitude correction factor greater than 0.75
- Battery positive voltage greater than 11 V
- Engine load less than 30%
- EVAP canister burden less than 3
- Time elapsed after engine start-up greater than 990 seconds or mixture adaptation completed
- No other faults in memory

#### **Possible fault cause**

- ◆ Tank cap seal
- ◆ One or several leaks in fuel tank ventilation system

#### **Affected terminals**

-

#### **Diagnosis/troubleshooting**

**Note!**

- ◆ Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.
- ◆ The EVAP canister purge valve is very sensitive to contamination. If the lines to the EVAP canister have to be detached, the outside of the canister must be cleaned beforehand.


Work instruction		Display OK	If not OK
1	Check shutoff valve for leaks <ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner</li> <li>◆ Detach connector of shutoff valve</li> <li>◆ Detach ventilation line of shutoff valve</li> <li>◆ Connect shutoff valve to the battery or a separate power supply unit via special tool V.A.G.1315A/1.</li> <li>◆ Do not actuate the shutoff valve for more than 5 minutes (overload)</li> <li>◆ Connect special tool 9160/1 to EVAP canister</li> <li>◆ Using special tool 9160/1, generate a vacuum of 100 mbar (0.1 bar)</li> </ul>		Replace shutoff valve



Figure:

**i Note!**

- ◆ Do not produce a vacuum of more than 100 mbar, as otherwise the vacuum will cause the shutoff valve to open.
- ◆ If no vacuum can be built up, replace the shutoff valve.
- ◆ Coat the sealing ring of the new shutoff valve with tyre fitting lubricant prior to installation.
- ◆ The shutoff valve can only be installed in one position: with the electrical connection facing upwards.



Work instruction		Display OK	If not OK
2	Check tank system for leaks		
	<ul style="list-style-type: none"> <li>◆ Check the tank system for leaks using an HC tester. To do so, hold the connecting hose of the HC tester in the spot to be tested. In the case of a leak, the display of the HC tester increases to above 1000 ppm. Values below 50 ppm indicate no leaks.</li> <li>◆ To test the ventilation lines, guide the connecting hose slowly along them.</li> <li>◆ Check the following locations                             <ol style="list-style-type: none"> <li>1. Tank cap</li> <li>2. Line connections to EVAP canister</li> <li>3. EVAP canister</li> <li>4. Line connections to fuel tank sender unit</li> <li>5. Pressure sensor</li> <li>6. Opening of fuel filler neck into tank</li> <li>7. Line connection of EVAP canister purge valve</li> <li>8. Ventilation lines</li> </ol> </li> </ul>		

**i Note!**


If no leaks are found, a gauge pressure of max. 100 mbar (0.1 bar) can be generated at the EVAP canister at the connection to the tank using special tool 9160/1, in order to increase the escape of fuel vapours.

**i Note!**

Before detaching the ventilation lines from the EVAP canister, clean the area around the connections. Dirt must not be allowed to get into the connectors.

Work instruction		Display OK	If not OK
3	Check EVAP canister purge valve for leaks		If no vacuum can be built up, replace the EVAP canister purge valve
	<ul style="list-style-type: none"> <li>◆ Detach the ventilation line to the EVAP canister purge valve from the EVAP canister (protective cap)</li> <li>◆ With special tool 9160/1, generate a vacuum of 200 mbar (0.2 bar)</li> </ul>		

Figure:





## P0444

### 98 EVAP canister purge valve - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Wiring harness
- ◆ EVAP canister purge valve
- ◆ DME control module

#### Affected terminals

Terminal III/3

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check voltage supply for EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Measure voltage between EVAP canister purge valve plug Pin 1 and ground</li> <li>◆ Switch on the ignition</li> </ul>	> 11 V ⇒ Step 2	Repair voltage supply → End
2	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Measure resistance between EVAP canister purge valve Pin 1 and Pin 2</li> </ul>	$26 \pm 4 \Omega$ (at 20 °C) ⇒ Step 3	Check EVAP canister purge valve → End
3	Check triggering wire for EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between EVAP canister purge valve Pin 2 and special tool 9637 Pin III/3</li> </ul>	0 - 5 $\Omega$ ⇒ Step 4	Repair wiring harness → End

Work instruction		Display OK	If not OK
4	Replace DME control module	⇒ Step 5	
5	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P0445

### 98 EVAP canister purge valve - short circuit to B+

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module faulty

#### Affected terminals

Terminal III/3 and IV/26

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for EVAP canister purge valve for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between special tool 9637 Pin III/3 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0 V ⇒ Step 2	Repair wiring harness → End
2	Replace DME control module	⇒ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 98 EVAP canister purge valve - short to ground

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module faulty

### Affected terminals

Terminal III/3

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for EVAP canister purge valve for short circuit to ground <ul style="list-style-type: none"> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin III/3 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 2	Repair wiring harness $\rightarrow$ End
2	Replace DME control module	$\Rightarrow$ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	$\rightarrow$ End	



## P0446

### EVAP canister shutoff valve (function) - below limit

#### Diagnosis conditions

- Oxygen sensing system active
- No secondary air diagnosis
- Engine running
- Vehicle speed = 0 km/h
- Intake air temperature between 5 °C and 50 °C
- Engine starting temperature between 5 °C and 55 °C
- Battery positive voltage greater than 11 V
- Engine load less than 30%
- EVAP canister burden less than 3
- Altitude correction factor greater than 0.75
- Time elapsed after engine start-up > 990 seconds (16.5 minutes) or mixture adaptation completed
- No fault for throttle position sensor, idle air control, vehicle speed, EVAP canister purge valve, mass air flow sensor, voltage supply, pressure sensor, shutoff valve or engine temperature in memory



#### Note!

Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.

#### Possible fault cause

- ◆ Purge air line blocked
- ◆ EVAP canister purge valve sticks in the opened position (this causes continuous vacuum to go from the intake manifold to the tank system)
- ◆ EVAP canister shutoff valve is blocked/sticks in the opened position
- ◆ Flow resistance of EVAP canister too high (filter deformed/blocked)
- ◆ Pressure sensor connected incorrectly (polarity reversal)

## Affected terminals

-

## Diagnosis/troubleshooting




### Note!

- ◆
- ◆ The EVAP canister purge valve is very sensitive to contamination. If the lines to the EVAP canister have to be detached, the outside of the canister must be cleaned beforehand.

Work instruction		Display OK	If not OK
1	Check purge air line for blockage	<ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner.</li> <li>◆ Detach purge air line (connection faces up) from EVAP canister.</li> <li>◆ Blow through purge air line with compressed air.</li> </ul>	Line was clear ⇒ Step 2  Clean line → End
2	Check EVAP canister purge valve for leaks	<ul style="list-style-type: none"> <li>◆ Detach the ventilation line to the EVAP canister purge valve from the EVAP canister (protective cap)</li> <li>◆ With special tool 9160/1, generate a vacuum of 200 mbar (0.2 bar)</li> </ul>	Valve completely closed ⇒ Step 3  EVAP canister purge valve stays open Replace valve → End

Figure: Connecting special tool 9160/1



Work instruction			Display OK	If not OK
3	Check EVAP canister shutoff valve	<ul style="list-style-type: none"> <li>◆ Remove EVAP canister shutoff valve</li> <li>◆ Check if valve without flow is also completely opened</li> </ul>	Valve completely opened ⇒ Step 4	Valve stays closed ⇒ Replace valve → End
4	Check correct connection of pressure sensor	<ul style="list-style-type: none"> <li>◆ Get vehicle ready for operation</li> <li>◆ Erase fault memory</li> <li>◆ Unscrew tank cap</li> <li>◆ Perform fuel tank leak test using Porsche System Tester 2</li> </ul>	A "major leak" is detected ⇒ Step 5	Fault "P0446" is recorded again, (i.e. polarity reversal of pressure sensor) ⇒ Connect pressure sensor correctly → End
5	Check EVAP canister	<ul style="list-style-type: none"> <li>◆ Check canister for 'blockage' (with compressed air)</li> </ul>	Canister is not 'blocked' ⇒ Step 6	Canister is 'blocked' ⇒ Replace EVAP canister → End
6	Check vehicle history (previous repairs)	<ul style="list-style-type: none"> <li>◆ Was the EVAP canister already replaced (earlier) for this vehicle?</li> </ul>	YES: ⇒ Replace EVAP canister shutoff valve → End	NO: ⇒ Clean EVAP canister shutoff valve and erase the fault memory → End

## P0447

### 96 EVAP canister shutoff valve (output stage) - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Fuel tank ventilation active

#### Possible fault cause

- ◆ Wiring harness
- ◆ Shutoff valve faulty
- ◆ DME control module faulty



#### Note!

Fuel tank ventilation can be activated with the Porsche System Tester 2 in the 'Short test' menu.

#### Affected terminals

Terminal IV/30

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply for shutoff valve	> 11 V ⇒ Step 2	Repair voltage supply → End
	<ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner</li> <li>◆ Remove connector of shutoff valve</li> <li>◆ Measure voltage between shutoff valve plug Pin 2 and ground</li> <li>◆ Switch on the ignition</li> </ul>		

Work instruction			Display OK	If not OK
2	Check shutoff valve	<ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner</li> <li>◆ Remove connector of shutoff valve</li> <li>◆ Measure resistance between shutoff valve Pin 1 and Pin 2</li> </ul>	22 - 26 $\Omega$ (at 20 °C) ⇒ Step 3	Replace shutoff valve → End
3	Check triggering wire for shutoff valve for continuity	<ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner</li> <li>◆ Remove connector of shutoff valve</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between shutoff valve Pin 1 and special tool 9637 plug IV Pin 30</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

**Note!**

The wire is routed via connector X 2/5, Pin 6.

Work instruction			Display OK	If not OK
4	Replace DME control module		⇒ Step 4	
5	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## P0448

### 96 EVAP canister shutoff valve (output stage) - over limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Fuel tank ventilation active

#### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module faulty



#### Note!

Fuel tank ventilation can be activated with the Porsche System Tester 2 in the 'Short test' menu.

#### Affected terminals

Terminal IV/30

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for shutoff valve for short to B+	0 V ⇒ Step 2	Repair wiring harness → End
2	Replace DME control module	⇒ Step 3	
3	Perform adaptation	→ End	

## 96 EVAP canister shutoff valve (output stage) - under limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Fuel tank ventilation active

### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module faulty



### Note!

Fuel tank ventilation can be activated with the Porsche System Tester 2 in the 'Short test' menu.

### Affected terminals

Terminal IV/30

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for shutoff valve for short to ground <ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner</li> <li>◆ Remove connector of shutoff valve</li> <li>◆ Remove DME control module connector</li> <li>◆ Measure resistance between shutoff valve plug Pin 1 and ground</li> <li>◆ Switch on the ignition</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 2	Repair wiring harness $\rightarrow$ End
2	Replace DME control module	$\Rightarrow$ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	$\rightarrow$ End	

## P0450

### 99 Tank pressure sensor - signal implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Pressure sensor

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace pressure sensor	→ End	



## P0450

### Fuel Tank Ventilation System (Major Leak) – Signal Implausible

#### Diagnosis conditions

- Oxygen sensing system active
- No secondary air diagnosis
- Engine running
- Vehicle speed = 0 km/h
- Intake air temperature between 4.5 °C and 60 °C
- Battery positive voltage greater than 11 V
- Engine load less than 30%
- EVAP canister burden less than 3
- Altitude correction factor greater than 0.75
- Time elapsed after engine start-up > 990 seconds or mixture adaptation completed
- No faults in memory

#### Possible fault cause

- ◆ Pressure sensor

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.

Work instruction		Display OK	If not OK
1	Replace pressure sensor.		



## P0451

### Tank Pressure Sensor – Signal Implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Pressure sensor

#### Affected terminals

-

### Diagnosis/Troubleshooting

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
1	Replace pressure sensor	→ End.	



## P0452

### 99 Tank pressure sensor - below limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Short circuit to ground

#### Affected terminals

Terminal IV/21

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from pressure sensor to DME control module for short to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of pressure sensor</li> <li>◆ Measure resistance between special tool 9637 Pin IV/21 and ground</li> </ul>	$\infty \Omega$ → End	Repair wiring harness → End



**P0453****99 Tank pressure sensor - above limit****Diagnosis conditions**

- Ignition on

**Possible fault cause**

- ◆ Short circuit to B+

**Affected terminals**

Terminal IV/21

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check wiring from pressure sensor to DME control module for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of pressure sensor</li> <li>◆ Measure voltage between special tool Pin IV/21 and ground</li> </ul>	<p>0 V → End</p> <p>Repair wiring harness → End</p>





## P0455

### 94 Fuel Tank Ventilation System (Major Leak) - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- No secondary air diagnosis
- Engine running
- Vehicle speed = 0 km/h
- Intake air temperature between 4.5 °C and 60 °C
- Battery positive voltage greater than 11 V
- Engine load less than 30%
- EVAP canister burden less than 3
- Altitude correction factor greater than 0.75
- Time elapsed after engine start-up > 990 seconds or mixture adaptation completed
- No faults in memory

#### Possible fault cause

- ◆ Tank cap missing
- ◆ Tank cap seal
- ◆ Ventilation lines detached from EVAP canister
- ◆ Ventilation line detached from tank
- ◆ Ventilation line detached from fuel tank vent
- ◆ Break in ventilation lines

#### Affected terminals

-

#### Diagnosis/troubleshooting

**Note!**

- ◆ Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.
- ◆ A frozen EVAP canister shutoff valve can lead to this fault.

Work instruction		Display OK	If not OK
1	Check tank cap and seal	<ul style="list-style-type: none"> <li>◆ Check whether the tank cap is present.</li> <li>◆ Check whether the tank cap is correctly screwed on.</li> <li>◆ Check whether the seal is damaged.</li> </ul>	
2	Check ventilation lines on EVAP canister	<ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner.</li> <li>◆ Check whether ventilation lines are attached to the EVAP canister.</li> </ul>	
3	Check ventilation line on tank	<ul style="list-style-type: none"> <li>◆ Remove battery.</li> <li>◆ Remove battery cover.</li> <li>◆ Check whether ventilation line is attached to the fuel tank sender unit.</li> </ul>	
4	Check ventilation line on tank vent	<ul style="list-style-type: none"> <li>◆ Check whether ventilation line is attached to the EVAP canister purge valve.</li> </ul>	
5	Check ventilation lines	<ul style="list-style-type: none"> <li>◆ Check whether ventilation lines are:</li> <li>◆ cracked</li> <li>◆ broken</li> <li>◆ interrupted</li> </ul>	
6	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner.</li> <li>◆ Clean EVAP canister in the vicinity of the ventilation lines.</li> <li>◆ Detach the ventilation line to the EVAP canister purge valve at the EVAP canister (connection with protective cap).</li> <li>◆ With special tool 9160/1, generate a vacuum of 200 mbar (0.2 bar).</li> </ul> <p>If no vacuum can be built up, replace the EVAP canister purge valve.</p>	

## 94 Fuel Tank Ventilation System (Major Leak) - Signal Implausible

### Diagnosis conditions

- Oxygen sensing system active
- No secondary air diagnosis
- Engine running
- Vehicle speed = 0 km/h
- Intake air temperature between 4.5 °C and 60 °C
- Battery positive voltage greater than 11 V
- Engine load less than 30%
- EVAP canister burden less than 3
- Altitude correction factor greater than 0.75
- Time elapsed after engine start-up > 990 seconds or mixture adaptation completed
- No faults in memory

### Possible fault cause

- ◆ Pressure sensor

### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.

Work instruction		Display OK	If not OK
1	Replace pressure sensor		



## P0456

### Fuel Tank Ventilation System (Minor leak) - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Engine running
- Vehicle speed = 0 km/h
- Intake air temperature between 5 °C and 60 °C
- Altitude correction factor greater than 0.75
- Battery positive voltage greater than 11 V
- Engine load less than 30%
- EVAP canister burden less than 3
- Time elapsed after engine start-up greater than 990 seconds or mixture adaptation completed
- No other faults in memory

#### Possible fault cause

- ◆ Tank cap seal
- ◆ One or several leaks in fuel tank ventilation system

#### Affected terminals

-

## Diagnosis/Troubleshooting

**Note!**


- ◆ Fuel tank ventilation diagnosis is initiated with the Porsche System Tester 2 in the "Short test" menu. This reduces the time elapsed after engine start-up to 30 seconds.
- ◆ The EVAP canister purge valve is very sensitive to contamination. If the lines to the EVAP canister have to be detached, the outside of the canister must be cleaned beforehand.

Work instruction		Display OK	If not OK
1	Check shutoff valve for leaks		Replace shutoff valve
	<ul style="list-style-type: none"> <li>◆ Remove front right-hand wheel housing liner</li> <li>◆ Detach connector of shutoff valve</li> <li>◆ Detach ventilation line of shutoff valve</li> <li>◆ Connect shutoff valve to the battery or a separate power supply unit via special tool V.A.G.1315A/1.</li> <li>◆ Do not actuate the shutoff valve for more than 5 minutes (overload)</li> <li>◆ Connect special tool 9160/1 to EVAP canister</li> <li>◆ Using special tool 9160/1, generate a vacuum of 100 mbar (0.1 bar)</li> </ul>		

Figure:

**i Note!**

- ◆ Do not produce a vacuum of more than 100 mbar, as otherwise the vacuum will cause the shutoff valve to open.
- ◆ If no vacuum can be built up, replace the shutoff valve.
- ◆ Coat the sealing ring of the new shutoff valve with tyre fitting lubricant prior to installation.
- ◆ The shutoff valve can only be installed in one position: with the electrical connection facing upwards.



Work instruction		Display OK	If not OK
2	Check tank system for leaks		
	<ul style="list-style-type: none"> <li>◆ Check the tank system for leaks using an HC tester. To do so, hold the connecting hose of the HC tester in the spot to be tested. In the case of a leak, the display of the HC tester increases to above 1000 ppm. Values below 50 ppm indicate no leaks.</li> <li>◆ To test the ventilation lines, guide the connecting hose slowly along them.</li> <li>◆ Check the following locations               <ol style="list-style-type: none"> <li>1. Tank cap</li> <li>2. Line connections to EVAP canister</li> <li>3. EVAP canister</li> <li>4. Line connections to fuel tank sender unit</li> <li>5. Pressure sensor</li> <li>6. Opening of fuel filler neck into tank</li> <li>7. Line connection of EVAP canister purge valve</li> <li>8. Ventilation lines</li> </ol> </li> </ul>		

**Note!**

*If no leaks are found, a gauge pressure of max. 100 mbar (0.1 bar) can be generated at the EVAP canister at the connection to the tank using special tool 9160/1, in order to increase the escape of fuel vapours.*


**Note!**

*Before detaching the ventilation lines from the EVAP canister, clean the area around the connections. Dirt must not be allowed to get into the connectors.*

Work instruction		Display OK	If not OK
3	Check EVAP canister purge valve for leaks		If no vacuum can be built up, replace the EVAP canister purge valve
	<ul style="list-style-type: none"> <li>◆ Detach the ventilation line to the EVAP canister purge valve from the EVAP canister (protective cap)</li> <li>◆ With special tool 9160/1, generate a vacuum of 200 mbar (0.2 bar)</li> </ul>		



Figure:





## P0480

### 494 Fan output stage 1 - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Intake air temperature greater than 9 °C
- Air conditioning switched on and off once

#### Note!

The triggering wire for relays stage 1, terminal 85, is monitored

#### Possible fault cause

- ◆ Open circuit
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal IV/4

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 Ω ⇒ Step 2  Replace relay → End
2	Check wiring from DME control module, plug IV Pin 4, to relays for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 1 of coolant fan 1</li> <li>◆ Remove relay stage 2 of coolant fan 1</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 4 and relay slot of coolant fan 1 plug Pin 2</li> </ul>	0 - 5 Ω  Repair wiring harness → End

Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool 9637 plug IV Pin 4 and relay slot of coolant fan 2 plug Pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Check plug connection X 2/3, Pin 21, and check wiring harness for chafing and pinching damage
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 494 Fan output stage 1 - below limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Intake air temperature greater than 9 °C
- Air conditioning switched on and off once



### Note!

The triggering wire for relays stage 1, terminal 85, is monitored

### Possible fault cause

- ◆ Short circuit to ground
- ◆ Relay faulty
- ◆ DME control module faulty

### Affected terminals

Terminal IV/4

**Diagnosis/troubleshooting**

Work instruction			Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2	Replace relay → End
2	Check wiring from DME control module, plug IV Pin 4, to relays for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 1 of coolant fan 1</li> <li>◆ Remove relay stage 2 of coolant fan 1</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 4 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End
3	Replace DME control module		⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

**494 Fan output stage 1 - above limit****Diagnosis conditions**

- Engine running
- Battery voltage greater than 7 V
- Intake air temperature greater than 9 °C
- Air conditioning switched on and off once

**Note!**

The triggering wire for relays stage 1, terminal 85, is monitored

**Possible fault cause**

- ◆ Short circuit to B+
- ◆ Relay faulty
- ◆ DME control module faulty

**Affected terminals**

Terminal IV/4

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2 Replace relay → End
2	Check wiring from DME control module, plug IV Pin 4, to relays for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 1 of coolant fan 1</li> <li>◆ Remove relay stage 2 of coolant fan 1</li> <li>◆ Measure voltage between special tool 9637 plug IV Pin 4 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3 Repair wiring harness → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End

## P0481

### 495 Fan output stage 2 - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Medium pressure switch (air conditioning) active or engine temperature greater than 105 °C
- Air conditioning switched on and off once



#### Note!

The triggering wire for relays stage 2, terminal 85, is monitored

#### Possible fault cause

- ◆ Open circuit
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal IV/20

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 Ω ⇒ Step 2  Replace relay → End
2	Check wiring from DME control module, plug IV Pin 20, to relays for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 2 of coolant fan 1</li> <li>◆ Remove relay stage 2 of coolant fan 2</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 20 and relay slot of coolant fan 1 plug Pin 2</li> </ul>	0 - 5 Ω  Repair wiring harness → End

Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool 9637 plug IV Pin 20 and relay slot of coolant fan 2 plug Pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Check plug connection X 2/3, Pin 22, and check wiring harness for chafing and pinching damage
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 495 Fan output stage 2 - below limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Medium pressure switch (air conditioning) active or engine temperature greater than 105 °C
- Air conditioning switched on and off once



### Note!

The triggering wire for relays stage 2, terminal 85, is monitored

### Possible fault cause

- ◆ Short circuit to ground
- ◆ Relay faulty
- ◆ DME control module faulty

### Affected terminals

Terminal IV/20



**Diagnosis/troubleshooting**

Work instruction			Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2	Replace relay → End
2	Check wiring from DME control module, plug IV Pin 20, to relays for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 2 of coolant fan 1</li> <li>◆ Remove relay stage 2 of coolant fan 2</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 20 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End
3	Replace DME control module		⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

**495 Fan output stage 2 - above limit****Diagnosis conditions**

- Engine running
- Battery voltage greater than 7 V
- Medium pressure switch (air conditioning) active or engine temperature greater than 105 °C
- Air conditioning switched on and off once

**Note!**

The triggering wire for relays stage 2, terminal 85, is monitored

**Possible fault cause**

- ◆ Short circuit to B+
- ◆ Relay faulty
- ◆ DME control module faulty

**Affected terminals**

Terminal IV/20

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2 Replace relay → End
2	Check wiring from DME control module, plug IV Pin 20, to relays for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 2 of coolant fan 1</li> <li>◆ Remove relay stage 2 of coolant fan 2</li> <li>◆ Measure voltage between special tool 9637 plug IV Pin 20 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3 Repair wiring harness → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End

## P0482

### 591 Fan output stage 3 - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Engine temperature greater than 108 °C
- Vehicle speed greater than 25 km/h (15 mph)
- Engine speed more than 1000 rpm



#### Note!

The triggering wire for relays stage 3, terminal 85, is monitored.

#### Possible fault cause

- ◆ Open circuit
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal IV/31

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check both relays	◆ Remove relay ◆ Measure resistance between Pin 85 and Pin 86	Approx. 75 Ω ⇒ Step 2	Replace relay → End
2	Check wiring from DME control module, plug IV Pin 31, to relays for continuity	◆ Connect special tool 9637 to wiring harness (DME control module plug) ◆ Remove relay stage 3 of coolant fan 1 ◆ Remove relay stage 3 of coolant fan 2 ◆ Measure resistance between special tool 9637 plug IV Pin 31 and relay slot of coolant fan 1 plug Pin 2	0 - 5 Ω	Repair wiring harness → End

Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool 9637 plug IV Pin 31 and relay slot of coolant fan 2 plug Pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Check plug connection X 2/3, Pin 12, and check wiring harness for chafing and pinching damage
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

### 591 Fan output stage 3 - below limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Engine temperature greater than 108 °C
- Vehicle speed greater than 25 km/h (15 mph)
- Engine speed more than 1000 rpm



#### Note!

The triggering wire for relays stage 3, terminal 85, is monitored.

#### Possible fault cause

- ◆ Short circuit to ground
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal IV/31

**Diagnosis/troubleshooting**

Work instruction			Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2	Replace relay → End
2	Check wiring from DME control module, plug IV Pin 31, to relays for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 3 of coolant fan 1</li> <li>◆ Remove relay stage 3 of coolant fan 2</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 31 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End
3	Replace DME control module		⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

**591 Fan output stage 3 - above limit****Diagnosis conditions**

- Engine running
- Battery voltage greater than 7 V
- Engine temperature greater than 108 °C
- Vehicle speed greater than 25 km/h (15 mph)
- Engine speed more than 1000 rpm

**Note!**

The triggering wire for relays stage 3, terminal 85, is monitored.

**Possible fault cause**

- ◆ Short circuit to B+
- ◆ Relay faulty
- ◆ DME control module faulty

**Affected terminals**

Terminal IV/31

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check both relays	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2 Replace relay → End
2	Check wiring from DME control module, plug IV Pin 20, to relays for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay stage 3 of coolant fan 1</li> <li>◆ Remove relay stage 3 of coolant fan 2</li> <li>◆ Measure voltage between special tool 9637 plug IV Pin 31 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3 Repair wiring harness → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End

## P0491

### Secondary Air Injection System, Bank 1 – Below Limit

#### Diagnosis conditions

- Intake air temperature 4.5 - 60 °C
- Engine temperature 4.5 - 102 °C
- Mass air flow 36 - 150 kg/h
- Engine starting temperature less than 42 °C
- Altitude correction factor greater than 0.75
- Oxygen sensors 1 and 2 ahead of TWC are ready for operation
- The secondary air injection pump is switched on
- Diagnosis has not yet taken place during this cycle

#### Possible fault cause

- ◆ Secondary air injection pump is not triggered
- ◆ Secondary air injection pump does not work
- ◆ Air supply lines restricted
- ◆ Electric change-over valve does not function
- ◆ Air change-over valve does not function
- ◆ Vacuum system leaking

#### Affected terminals

III/11 and III/14

## Diagnosis/Troubleshooting

**Note!**

Secondary air diagnosis can be activated with the Porsche System Tester 2 in the "Short test" menu.

Work instruction		Display OK	If not OK
1	Activate secondary air pump	⇒ Step 3.	⇒ Step 2.
	<ul style="list-style-type: none"> <li>◆ Remove relay of secondary air injection pump.</li> <li>◆ Jumper terminals 30 and 87.</li> <li>◆ The secondary air pump must be running (audible function).</li> <li>– or</li> <li>◆ Connect and switch on Porsche System Tester 2.</li> <li>◆ Select DME.</li> <li>◆ Call up "Drive links" menu.</li> <li>◆ Select "Secondary air pump".</li> <li>◆ Activate secondary air pump (audible function).</li> </ul>		
2	Check triggering of secondary air pump	Battery voltage.	Check wire from pin 2 to DME control module pin III/11 for continuity.
	<ul style="list-style-type: none"> <li>◆ Check fuse (Maxi Fuse) of AIR pump (on relay carrier 2).</li> <li>◆ Remove relay of AIR pump (on relay carrier 2).</li> <li>◆ Measure voltage between pin 3 and ground</li> <li>◆ Push relay back on.</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove connector of AIR pump.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>	Battery voltage.	
3	Check vacuum system for leaks		Seal vacuum system
4	Check electric change-over valve	Battery voltage.	
	<ul style="list-style-type: none"> <li>◆ Remove two-pole connector of electric change-over valve.</li> <li>◆ Trigger AIR pump with Porsche System Tester 2.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose of electric change-over valve with the engine running.</li> </ul>	Vacuum must be present	



Work instruction		Display OK	If not OK
5	Check air change-over valve	Vacuum must be present	
	<ul style="list-style-type: none"> <li>◆ Run engine briefly to produce vacuum.</li> <li>◆ Activate secondary air pump.</li> <li>◆ Remove vacuum hose of air change-over valve.</li> </ul>		
6	Check air supply lines for blockage		



## P0492

### Secondary Air Injection System, Bank 2 – Below Limit

#### Diagnosis conditions

- Intake air temperature 4.5 - 60 °C
- Engine temperature 4.5 - 102 °C
- Mass air flow 36 - 150 kg/h
- Engine starting temperature less than 42 °C
- Altitude correction factor greater than 0.75
- Oxygen sensors 1 and 2 ahead of TWC are ready for operation
- The secondary air injection pump is switched on
- Diagnosis has not yet taken place during this cycle

#### Possible fault cause

- ◆ Secondary air injection pump is not triggered
- ◆ Secondary air injection pump does not work
- ◆ Air supply lines restricted
- ◆ Electric change-over valve does not function
- ◆ Air change-over valve does not function
- ◆ Vacuum system leaking

#### Affected terminals

III/11 and III/14

## Diagnosis/Troubleshooting

**Note!**

Secondary air diagnosis can be activated with the Porsche System Tester 2 in the "Short test" menu.

Work instruction		Display OK	If not OK
1	Activate secondary air pump	⇒ Step 3.	⇒ Step 2.
	<ul style="list-style-type: none"> <li>◆ Remove relay of secondary air injection pump.</li> <li>◆ Jumper terminals 30 and 87.</li> <li>◆ The secondary air pump must be running (audible function).</li> <li>– or</li> <li>◆ Connect and switch on Porsche System Tester 2.</li> <li>◆ Select DME.</li> <li>◆ Call up "Drive links" menu.</li> <li>◆ Select "Secondary air pump".</li> <li>◆ Activate secondary air pump (audible function).</li> </ul>		
2	Check triggering of secondary air pump	Battery voltage.	Check wire from pin 2 to DME control module pin III/11 for continuity.
	<ul style="list-style-type: none"> <li>◆ Check fuse (Maxi Fuse) of AIR pump (on relay carrier 2).</li> <li>◆ Remove relay of AIR pump (on relay carrier 2).</li> <li>◆ Measure voltage between pin 3 and ground</li> <li>◆ Push relay back on.</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove connector of AIR pump.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>	Battery voltage.	
3	Check vacuum system for leaks		Seal vacuum system
4	Check electric change-over valve	Battery voltage.	
	<ul style="list-style-type: none"> <li>◆ Remove two-pole connector of electric change-over valve.</li> <li>◆ Trigger AIR pump with Porsche System Tester 2.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose of electric change-over valve with the engine running.</li> </ul>	Vacuum must be present	

<b>Work instruction</b>			<b>Display OK</b>	<b>If not OK</b>
5	Check air change-over valve	<ul style="list-style-type: none"> <li>◆ Run engine briefly to produce vacuum.</li> <li>◆ Activate secondary air pump.</li> <li>◆ Remove vacuum hose of air change-over valve.</li> </ul>	Vacuum must be present	
		<ul style="list-style-type: none"> <li>◆ After activation, check air change-over valve for continuity</li> </ul>		
6	Check air supply lines for blockage			



## P0501

### 120 Vehicle speed - open circuit

#### Diagnosis conditions

- Inertia fuel shutoff
- Engine temperature greater than 30 °C
- Engine speed between 1,480 rpm and 2,520 rpm.

#### Possible fault cause

- ◆ Open circuit or short circuit in wire from rear right wheel speed sensor to ABS control module
- ◆ Rear right wheel speed sensor faulty
- ◆ Pulse wheel for speed sensor damaged or contaminated with brake dust
- ◆ Open circuit or short circuit in wire from ABS control module? to DME control module
- ◆ ABS control module faulty
- ◆ DME control module faulty

#### Affected terminals

III/52

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Read PSM control module fault memory.	No fault in memory.	If a rear right wheel speed sensor fault is stored, remedy the fault according to PSM Troubleshooting.

Work instruction		Display OK	If not OK
2	Check wiring from ABS control module pin 19 to DME control module pin III/52 for continuity or short to B+ or minus.		Repair wiring harness.
3	Check speed signal with Porsche System Tester 2. <ul style="list-style-type: none"> <li>◆ Connect and switch on Porsche System Tester 2.</li> <li>◆ Select the vehicle type 911 (996) and system ABS (PSM) menu 'Actual values, Rear right wheel speed sensor'.</li> <li>◆ Raise vehicle at rear right.</li> <li>◆ By hand, turn rear right wheel in driving direction.</li> </ul>	The speed must be displayed on the tester.	



## P0506

### 32 Idle air control at stop - below limit

#### Diagnosis conditions

- Start-up ended
- Speed = 0 km/h
- Throttle valve in idle position
- Engine temperature > 60 °C
- Intake air temperature > -10 °C
- No fuel tank ventilation or tank ventilation diagnosis
- No secondary air diagnosis
- Altitude correction factor > 0.75
- No faults in speed signal, throttle position sensor, engine temperature, EVAP canister purge valve or tank ventilation system

#### Possible fault cause

- ◆ Throttle is jammed

#### Affected terminals

-

#### Diagnosis/troubleshooting

#### Note!

*If faults are stored for the throttle jacking device, eliminate these faults first.*

Work instruction		Display OK	If not OK
1	Replace throttle part		
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute. Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>		



## P0507

### 32 Idle air control at stop - above limit

#### Diagnosis conditions

- Start-up ended
- Speed = 0 km/h
- Throttle valve in idle position
- Engine temperature > 60 °C
- Intake air temperature > -10 °C
- No fuel tank ventilation or tank ventilation diagnosis
- No secondary air diagnosis
- Altitude correction factor > 0.75
- No faults in speed signal, throttle position sensor, engine temperature, EVAP canister purge valve or tank ventilation system

#### Possible fault cause

- ◆ Throttle is jammed
- ◆ Leaks in intake air system

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check for air leaks in intake air system	→ End	→ Step 2
2	Replace throttle part		
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute. Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>		



## P0513

### Immobilizer – Signal Implausible

#### Diagnosis conditions

- Start condition
- Motronic reset

#### Possible fault cause

- ◆ Open circuit in wiring between DME control module and alarm system
- ◆ Short circuit to ground or short circuit to B+
- ◆ Alarm system control module faulty

#### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check signal wire for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and alarm system control module plug Pin I/23</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	⇒ Step 2.
2	Remove connector X 2/3	<ul style="list-style-type: none"> <li>◆ Measure resistance between plug connection X 2/3 bushing 6 and special tool 9637 Pin I/3</li> <li>◆ Measure resistance between plug connection X 2/3 Pin 6 and alarm system control module plug I Pin 23</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK	
3	Check signal wire for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 4.	Repair wiring harness $\rightarrow$ End.
4	Check signal wire for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure voltage between special tool 9637 Pin I/3 and ground</li> </ul>	0 V $\Rightarrow$ Step 4.	Repair wiring harness $\rightarrow$ End.
5	Replace alarm system control module.	$\rightarrow$ End.	$\rightarrow$ End.	

## Immobilizer - Open Circuit

### Diagnosis conditions

- Start condition
- Motronic reset

### Possible fault cause

- ◆ Open circuit in wiring between DME control module and alarm system
- ◆ Short circuit to ground or short circuit to B+
- ◆ Alarm system control module faulty

### Affected terminals

-

## Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check signal wire for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and alarm system control module plug Pin I/23</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	⇒ Step 2.
2	Remove connector X 2/3	<ul style="list-style-type: none"> <li>◆ Measure resistance between plug connection X 2/3 bushing 6 and special tool 9637 Pin I/3</li> <li>◆ Measure resistance between plug connection X 2/3 Pin 6 and alarm system control module plug I Pin 23</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.
3	Check signal wire for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and ground</li> </ul>	$\infty$ $\Omega$ ⇒ Step 4.	Repair wiring harness → End.
4	Check signal wire for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure voltage between special tool 9637 Pin I/3 and ground</li> </ul>	0 V ⇒ Step 4.	Repair wiring harness → End.
5	Replace alarm system control module.		→ End.	→ End.





## P0560

### 107 Voltage supply - signal implausible

#### Diagnosis conditions

- Vehicle speed greater than 0 km/h (0 mph)
- No fault in vehicle speed
- Time elapsed after start-up 60 sec.

#### Possible fault cause

- ◆ DME control module

#### Affected terminals

Terminal II/2

#### Diagnosis/troubleshooting

#### Note!

*In case of a fault, a replacement value of 14.06 V is used.*

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P0562

### 107 Voltage supply - below limit

#### Diagnosis conditions

- Vehicle speed greater than 0 km/h (0 mph)
- No fault in vehicle speed
- Time elapsed after start-up 60 sec.

#### Possible fault cause

- ◆ Battery
- ◆ Contact resistance

#### Affected terminals

Terminal I/2

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check battery	⇒ Step 2	Replace battery → End
2	Check wire, terminal 30, for contact resistance <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between special tool 9637 Pin I/2 and ground</li> </ul>	> 11 V ⇒ Step 4	⇒ Step 3
3	<ul style="list-style-type: none"> <li>◆ Check wire from special tool 9637, Pin I/2, to pin side of connector X 2/3, Pin 2, for continuity</li> <li>◆ Check connector for corrosion</li> </ul>	0 - 5 Ω ⇒ Step 4	
4	<ul style="list-style-type: none"> <li>◆ Check wire from connector X 2/3, sleeve side, to current distributor fuse C 1 for continuity</li> </ul>	0 - 5 Ω ⇒ Step 5	Remedy contact resistance → End
5	Check voltage regulator and alternator	→ End	



## P0563

### Voltage supply - above limit

#### Diagnosis conditions

- Vehicle speed greater than 0 km/h (0 mph)
- No fault in vehicle speed
- Time elapsed after start-up 60 sec.

#### Possible fault cause

- ◆ Voltage regulator faulty (overvoltage)

#### Affected terminals

Terminal II/2

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage regulator	→ End	Replace voltage regulator → End

## P0571

## Stop Light Switch – Signal Implausible

## Diagnosis conditions

- Ignition on

## Possible fault cause

- ◆ Stop light switch
- ◆ Wiring harness

**Note!**

The DME control module receives the signals from the stop light switches via CAN bus.

## Affected terminals

## Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check stop light switch	<ul style="list-style-type: none"> <li>◆ Remove stop light switch</li> <li>◆ Measure resistance between Pin 1 and Pin 4</li> <li>◆ Actuate stop light switch</li> <li>◆ Measure resistance between Pin 1 and Pin 2</li> <li>◆ Actuate stop light switch</li> <li>◆ Install stop light switch</li> </ul>	0 - 5 $\Omega$  $\infty \Omega$  $\infty \Omega$  0 - 5 $\Omega$ ⇒ Step 2.	Replace stop light switch → End
2	Check wiring from PSM control module to stop light switch 1 for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove PSM control module connector</li> <li>◆ Measure voltage between Pin 32 and ground</li> <li>◆ Switch on the ignition.</li> <li>◆ Actuate brake</li> </ul>	0 V.    Battery voltage ⇒ Step 3	Repair wiring harness → End.

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Check wiring from PSM control module to stop light switch 2 for short circuit to B+	Battery voltage.  0 V → End.	Repair wiring harness → End.

## P0600

### 236 CAN timeout Tiptronic - open circuit

#### Diagnosis conditions

- Vehicle with Tiptronic transmission
- Battery voltage greater than 10 V
- Ignition on

#### Possible fault cause

- ◆ Wiring harness
- ◆ Tiptronic control module not connected
- ◆ Tiptronic control module faulty



#### Note!

- ◆ If all CAN bus faults are stored, there must be a short circuit in the CAN bus wiring.
- ◆ If one CAN bus fault is stored, the cruise control system is out of order.
- ◆ CAN bus faults may be caused by a control module reset. The fault is then indicated as "Not present".

#### Affected terminals

Terminal II/3 and II/4

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check whether connector of Tiptronic control module is plugged in.	⇒ Step 2	
2	Check CAN bus from DME control module to Tiptronic control module for continuity <ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove Tiptronic control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 plug II Pin 3 and Tiptronic control module plug Pin 85</li> </ul>	0 - 5 Ω	Repair wiring harness → End



Work instruction		Display OK	If not OK	
	<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool 9637 plug II Pin 4 and Tiptronic control module plug Pin 86</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3		
3	Check CAN bus from DME control module to Tiptronic control module for short to ground	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove Tiptronic control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 plug II Pin 3 and ground</li> <li>◆ Measure resistance between special tool 9637 plug II Pin 4 and ground</li> </ul>	⇒ Step 4  $\infty \Omega$  $\infty \Omega$ ⇒ Step 4	Repair wiring harness → End
4	Check CAN bus from DME control module to Tiptronic control module for short to B+	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove Tiptronic control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between special tool 9637 plug II Pin 3 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 plug II Pin 4 and ground</li> <li>◆ Switch on the ignition</li> </ul>	⇒ Step 5  0 V  0 V ⇒ Step 5	Repair wiring harness → End
5	Check CAN bus from DME control module to Tiptronic control module for short circuit	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove Tiptronic control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 plug II Pin 3 and plug II Pin 4</li> </ul>	$\infty \Omega$ → End	Repair wiring harness → End

## P0601

### DME relay/control module faulty (computer monitoring: reset) – signal implausible

#### Diagnosis conditions

- Time elapsed after engine start-up greater than 10 seconds

#### Possible fault cause

- ◆ Undervoltage
- ◆ DME relay faulty
- ◆ DME control module faulty (checksum error caused by tampering with data record)

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply, terminal 15	◆ Measure voltage between pin I/1 and ground.	> 11 V
			Check voltage supply and repair if necessary → End
2	Check DME relay	◆ Switch on the ignition ◆ Measure voltage between pin I/8 and ground	Battery positive voltage
			Check triggering of DME relay Repair wiring or replace DME relay → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation.	◆ Switch on the ignition ◆ Wait one minute ◆ Do not press the accelerator ◆ Switch off the ignition for at least 10 seconds ◆ Read out the fault memory	→ End

## P0603

### 105 EEPROM Faulty

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ DME control module faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

If no fault is present, erase the fault memory.

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P0604

### 406 Control module faulty (RAM) - signal implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ DME control module faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting



**Note!**

*If no fault is present, delete the fault memory.*

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P0605

### 405 Control module faulty (ROM) - signal implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ DME control module faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

If no fault is present, delete the fault memory.

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End





## P0607

### Control Module Faulty (Computer Monitoring: Reset) – Signal Implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Undervoltage
- ◆ DME control module faulty

This fault may be entered if the control module has been operated with undervoltage.

#### Affected terminals

I/1

### Diagnosis/Troubleshooting



#### Note!

*If no fault is present, erase the fault memory.*

Work instruction		Display OK	If not OK
1	Check voltage supply, terminal 15	◆ Measure voltage between pin I/1 and ground. > 11 V ⇒ Step 2	
2	Replace DME control module.	⇒ Step 3.	
3	Perform adaptation.	◆ Switch on the ignition. ◆ Wait one minute. ◆ Do not press the accelerator. ◆ Switch off the ignition for at least 10 seconds. ◆ Read out the fault memory. → End.	→ End.



## P0638

### Throttle Jacking Unit, Position Error – Signal Implausible

#### Diagnosis conditions

- Driving with changing pedal position

#### Possible fault cause

- ◆ Short circuit in wiring harness
- ◆ Sluggish throttle

#### Affected terminals

Terminal I/9 and I/7

#### Note!


*The vehicle is in emergency function mode, i.e. the engine is turning at approx. 1200 rpm.*

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module pin I/7 to the throttle jacking unit for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/7 and ground.</li> <li>◆ Switch on the ignition.</li> </ul> Low battery voltage ⇒ Step 2.	Repair wiring harness → End.
2	Check wiring from DME control module pin I/9 to the throttle jacking unit for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/9 and ground.</li> <li>◆ Switch on the ignition.</li> </ul> Low battery voltage ⇒ Step 3.	Repair wiring harness → End.
3	Check wiring from DME control module pin I/7 to the throttle part for short circuit to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/7 and pin I/2.</li> </ul> 0 V ⇒ Step 4.	Repair wiring harness → End.

Work instruction		Display OK	If not OK	
4	Check wiring from DME control module pin I/9 to the throttle part for short circuit to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/9 and pin I/2.</li> </ul>	0 V ⇒ Step 5.	Repair wiring harness → End.
5	Check wiring from DME control module, pin I/7, for short circuit to wire, pin I/9.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of throttle part.</li> <li>◆ Measure resistance between pin I/7 and pin I/9.</li> </ul>	$\infty \Omega$ ⇒ Step 6.	Repair wiring harness → End.

Remove connector of throttle part:



Work instruction		Display OK	If not OK
6	Check resistance of motor actuator in throttle part. <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between pin I/7 and pin I/9.</li> </ul>	1,2 - 1,6 $\Omega$ (at 20 °C) ⇒ Step 7.	Replace throttle part ⇒ Step 8.
7	Replace DME control module.	⇒ Step 8.	
8	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.



## P0645

### A/C Compressor Control – Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V
- Air conditioning on

#### Possible fault cause

- ◆ A/C relay
- ◆ Open circuit in wiring

#### Affected terminals

Terminal IV/27

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check A/C relay	◆ Remove A/C relay ◆ Measure resistance between Pin 85 and Pin 86	Approx. 75 $\Omega$ ⇒ Step 2	Replace A/C relay → End
2	Check control wire for A/C relay, Pin 2 (terminal 85), for open circuit	◆ Remove A/C relay ◆ Connect special tool 9637 to wiring harness (DME control module plug). ◆ Measure resistance between special tool 9637 Pin IV/27 and A/C relay plug Pin 2	0 - 5 $\Omega$ → End.	Repair wiring harness → End.





## P0646

### A/C Compressor Control – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V
- Air conditioning on

#### Possible fault cause

- ◆ Short circuit to ground in wiring

#### Affected terminals

Terminal IV/27

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check control wire for A/C relay, Pin 2 (terminal 85), for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove A/C relay</li> <li>◆ Remove DME control module connector</li> <li>◆ Measure resistance between Pin 2 (terminal 85) and ground</li> </ul>	$\infty \Omega$ → End.
			Repair wiring harness → End.



## P0650

### 661 MIL Lamp (via CAN) - Open Circuit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Instrument cluster

#### Affected terminals

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace instrument cluster		



## P0674

### A/C Compressor Control – Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V
- Air conditioning on

#### Possible fault cause

- ◆ Short circuit to B+ in wiring

#### Affected terminals

Terminal IV/27

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check control wire for A/C relay, Pin 2 (terminal 85), for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove A/C relay</li> <li>◆ Remove DME control module connector</li> <li>◆ Measure voltage between A/C relay Pin 2 and ground</li> <li>◆ Ignition on</li> </ul>	0 V → End.	Repair wiring harness → End.



## P0700

Tiptronic (CAN transfer box setting implausible) or  
(Transmission oil temperature above maximum value)

### **Note!**

*In the case of some models, the fault text "CAN transfer box setting implausible" may be output. The correct fault text however is "Transmission oil temperature above maximum value".*

Diagnostic conditions

- Ignition on

Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

### **Note!**

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

Affected terminals

-

Diagnosis/troubleshooting

### **Note!**

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0700	48	Transmission oil temperature Above maximum value	Fault memory entry and request for torque reduction





## P0701

### Tiptronic (Gear implausible/transmission slips)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

#### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0701	15	Overspeed n2 or n3	Power transmission interrupted
	49	Engine overspeed	Power transmission interrupted
	50	Inadmissible transmission ratio	Power transmission interrupted
	51	Transmission slips or gear implausible	Control unit switches into third gear



## P0702

### Tiptronic (Control unit faulty)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.



#### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

<b>P code</b>	<b>Fault code</b>	<b>Fault text</b>	<b>Fault effect</b>
P0702	56	Control unit fault - encoding error (EEP-ROM: Version invalid)	Control unit in limp home mode, minimum cycle initiated
	57	Control unit faulty (clock)	Control unit in limp home mode, CAN Off
	58	Control unit fault (test of internal watchdog)	Control unit in limp home mode, minimum cycle initiated
	59	Control unit fault (test of external watchdog)	Control unit in limp home mode, minimum cycle initiated
	62	Control unit faulty (RAM)	Control unit in limp home mode, minimum cycle initiated, CAN Off
	63	Control unit faulty (ROM)	Control unit in limp home mode, minimum cycle initiated, CAN Off
	64	Control unit faulty (EEPROM function critical)	Control unit in limp home mode, minimum cycle initiated

## P0706

### Tiptronic (Selector lever switch implausible)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.



#### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0706	17	Selector lever switch implausible	Control unit in limp-home mode



## P0712

### Transmission Oil Temperature - Below Limit

#### Diagnosis conditions

- Idle speed

#### Possible fault cause

- ◆ Temperature sensor faulty
- ◆ Wiring harness
- ◆ DME control module faulty

#### Affected terminals

Terminal II/23 and IV/11

#### Resistance values

60 °C 2.8 -3.5 kΩ

90 °C 1.0 -1.3 kΩ

120 °C 0.4 -0.6 kΩ

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check temperature sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between Pin II/23 and Pin IV/11</li> </ul>	2.8 - 3.5 kΩ (at 60 °C) ⇒ Step 2	Replace temperature sensor → End
2	Check wiring from DME control module to temperature sensor for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of temperature sensor</li> <li>◆ Measure resistance between special tool 9637 Pin II/23 and temperature sensor plug Pin 2</li> <li>◆ Measure resistance between special tool 9637 Pin IV/11 and temperature sensor plug Pin 1</li> </ul>	0 - 5 Ω ⇒ Step 3.	Note The lines are routed via the transmission plug connection Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Check wiring from DME control module to temperature sensor for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of temperature sensor</li> <li>◆ Measure resistance between Pin IV/11 and ground</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 4.</p> <p>Repair wiring harness → End.</p>
4	Replace DME control module	⇒ Step 5.	
5	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.



## P0713

### Transmission Oil Temperature - Above Limit

#### Diagnosis conditions

- Idle speed

#### Possible fault cause

- ◆ Temperature sensor faulty
- ◆ Wiring harness
- ◆ DME control module faulty

#### Affected terminals

Terminal II/23 and IV/11

#### Resistance values

60 °C 2.8 -3.5 kΩ

90 °C 1.0 -1.3 kΩ

120 °C 0.4 -0.6 kΩ

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check temperature sensor.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between Pin II/23 and Pin IV/11</li> </ul>	2.8 - 3.5 kΩ (at 60 °C) ⇒ Step 2	Replace temperature sensor → End
2	Check wiring from DME control module to temperature sensor for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of temperature sensor</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between pin IV/11 and ground.</li> </ul>	0 V ⇒ Step 3.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module.	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P0715

### Tiptronic (Supply voltage of speed sensors)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.



#### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0715	11	Supply voltage of speed sensors (outside tolerance)	Control unit in limp-home mode, minimum cycle initiated
	12	Speed sensor n2 (or sensor supply interrupted)	Control unit in limp-home mode
	13	Speed sensor n3	Control unit in limp-home mode
	14	Speed comparison n2 with n3 implausible	Control unit in limp-home mode



## P0720

### Tiptronic (CAN: wheel speed rear right)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

#### **Note!**

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting

#### **Note!**

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0720	22	CAN: wheel speed rear right from PSM implausible	Substitute value wheel speed rear left; if more than one fault from Group 22, 23, 24, 25 appears, then control unit is in limp-home mode
	23	CAN: wheel speed rear left from PSM implausible	Substitute value wheel speed rear left; if more than one fault from Group 22, 23, 24, 25 appears, then control unit is in limp-home mode
	38	CAN: PSM communication disturbed	Control unit in limp-home mode



## P0730

### Tiptronic (Gear comparison negative)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

#### **Note!**

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting

#### **Note!**

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0730	55	Gear comparison negative (repeatedly)	Control unit in limp-home mode, minimum cycle initiated





## P0740

### Tiptronic (Converter lockup clutch)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.



#### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0740	53	Converter lockup clutch excessive power consumption	Converter lockup clutch open



## P0743

### Tiptronic (Converter lockup clutch solenoid valve)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

#### **Note!**

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting

#### **Note!**

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0743	5	Converter lockup solenoid valve	Control unit in limp-home mode, minimum cycle initiated



## P0748

Tiptronic (Control solenoid valve, modulating pressure)

Diagnostic conditions

- Ignition on

Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.



### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

Affected terminals

-

Diagnosis/troubleshooting



### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0748	6	Control solenoid valve, modulating pressure	Control unit in limp-home mode, minimum cycle initiated



## P0753

Tiptronic (Solenoid valve, 1-2/4-5 gearshift)

Diagnostic conditions

- Ignition on

Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.



### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

Affected terminals

-

Diagnosis/troubleshooting



### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0753	2	Solenoid valve, 1-2/4-5 gearshift	Control unit in limp-home mode, minimum cycle initiated





## P0758

### Tiptronic (Solenoid valve, 2-3 gearshift)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.



#### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0758	3	Solenoid valve, 2-3 gearshift	Control unit in limp-home mode, minimum cycle initiated



## P0763

### Tiptronic (Solenoid valve, 3-4 gearshift)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

#### **Note!**

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting

#### **Note!**

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0763	4	Solenoid valve, 3-4 gearshift	Control unit in limp-home mode, minimum cycle initiated



## P0778

### Tiptronic (Control solenoid valve, shifting pressure)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

#### **Note!**

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting

#### **Note!**

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P0778	7	Control solenoid valve, shifting pressure	Control unit in limp-home mode, minimum cycle initiated



## P0830

### Clutch Switch – Signal Implausible

#### Diagnosis conditions

- Speed greater than 50 km/h
- Time between two clutch engagement processes more than 5 sec
- Number of gearshifts more than 5

#### Possible fault cause

- ◆ Fuse faulty
- ◆ Clutch switch
- ◆ Short circuit to B+
- ◆ Open circuit

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ *The clutch switch is linked to the instrument cluster. The DME control module receives information from the instrument cluster via the CAN bus.*
- ◆ *If a clutch switch fault is stored, the cruise control system is out of order.*

Work instruction			Display OK	If not OK
1	Check fuse B 7.			
2	Check clutch switch.	◆ Clutch switch opens when actuated.		
3	Check wiring.	◆ Check the wiring from the clutch switch to the instrument cluster pin III/19 for short to B+. ◆ Check the wiring from the clutch switch to the instrument cluster pin III/19 for continuity.		





## DME 7.8

### P1101

**(Input variables, charge measurement - below limit)**

**Input variables, charge measurement - above limit**

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Heavily soiled throttle
- ◆ Throttle adjusting unit faulty
- ◆ Mass air flow sensor faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

*In case of a defect in the MAF sensor, this fault must also be stored in the fault memory.*

Work instruction		Display OK	If not OK
1	Check throttle adjusting unit for dirt (visual inspection)	⇒ Step 2	Clean throttle adjusting unit, replace if necessary → End
2	Check voltage signal of MAF sensor <ul style="list-style-type: none"> <li>◆ Ignition on</li> <li>◆ Measure voltage between special tool 9637 pin III/23 and ground.</li> <li>◆ In the Porsche System Tester 2, select the menu point "Actual values/mass air flow sensor"</li> </ul>	0.9 to 1.1 V	Replace mass air flow sensor → End
	<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	1.2 to 1.5 V at idle speed	Replace mass air flow sensor → End

## P1102

### Ambient Pressure Sensor – Above Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ DME control module

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

*If no fault is present, erase the fault memory.*

Work instruction		Display OK	If not OK
1	Replace DME control module.		
2	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>		



## P1105

### Oxygen Sensing Adaptation, Upper Load Range, Bank 1 – Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C
- Mass air flow greater than 180 kg/h

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### Note!

- ◆ If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1.4 V
2	Check fuel pressure		Replace MAF sensor

Work instruction		Display OK	If not OK
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> </ul>	0.4 - 0.6 bar  Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>	Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes
5	Check fuel injectors for leaks		

## P1106

### Oxygen Sensing Adaptation, Upper Load Range, Bank 2 – Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C
- Mass air flow greater than 180 kg/h

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### Note!

- ◆ If DTC P0445 (EVAP canister purge valve - short to ground) is stored in the memory, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1.4 V
2	Check fuel pressure		Replace MAF sensor

Work instruction		Display OK	If not OK
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> </ul>	0.4 - 0.6 bar  Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>	Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes
5	Check fuel injector for leaks		

## P1107

### Oxygen Sensing Adaptation, Lower Load Range, Bank 1 – Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK	
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.	Replace MAF sensor
		◆ Start the engine.	Approx. 1.4 V	
2	Check fuel pressure			



Work instruction		Display OK	If not OK	
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> </ul>	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
			<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>	
4	Check fuel injectors for leaks			

## P1108

### Oxygen Sensing Adaptation, Lower Load Range, Bank 2 – Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1.4 V
2	Check fuel pressure		Replace MAF sensor

Work instruction		Display OK	If not OK	
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> </ul>	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
			<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>	
4	Check fuel injectors for leaks			

## P1109

### Input variables, charge measurement - above limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Heavily soiled throttle
- ◆ Throttle adjusting unit faulty
- ◆ Mass air flow sensor faulty

#### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

*In case of a defect in the MAF sensor, this fault must also be stored in the fault memory.*

Work instruction		Display OK	If not OK
1	Check throttle adjusting unit for dirt (visual inspection)	⇒ Step 2	Clean throttle adjusting unit, replace if necessary → End
2	Check voltage signal of MAF sensor <ul style="list-style-type: none"> <li>◆ Ignition on</li> <li>◆ Measure voltage between special tool 9637 pin III/23 and ground.</li> <li>◆ In the Porsche System Tester 2, select the menu point "Actual values/mass air flow sensor"</li> </ul>	0.9 to 1.1 V	Replace mass air flow sensor → End
	<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	1.2 to 1.5 V at idle speed	Replace mass air flow sensor → End

## P1110

### 294 Oxygen Sensors Exchanged Ahead of TWC

#### Diagnosis conditions

- Engine at operating temperature
- Oxygen sensing system active

#### Possible fault cause

- ◆ Wiring harness

#### Affected terminals

II/15 and II/16

#### Diagnosis/Troubleshooting



#### Note!

When the oxygen sensors are exchanged, then the oxygen sensors run contrary to the adaptation limitation.

Work instruction		Display OK	If not OK	
1	Check wiring harness	◆ Measure resistance between oxygen sensor connector 1 pin 1 and DME control module connector pin II/15	0 - 5 Ω	Repair wiring harness
2		◆ Measure resistance between oxygen sensor connector 2 pin 1 and DME control module connector pin II/16	0 - 5 Ω	Repair wiring harness



## P1114

### 723 Heating LSU, Inertia Fuel Shutoff - Signal Implausible

#### Diagnosis conditions

- Exhaust temperature above 250 °C
- Battery positive voltage greater than 9.5 V
- Time elapsed after start-up greater than 60 seconds
- No faults of the oxygen sensor
- Inertia fuel shutoff greater than 4 seconds

#### Possible fault cause

- ◆ Open circuit
- ◆ Oxygen sensor
- ◆ DME control module

#### Affected terminals

II/19

#### Diagnosis/Troubleshooting



#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction		Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection	
2	Check oxygen sensor heating	◆ Remove oxygen sensor connector Bank 1 ahead of catalytic converter ◆ Check resistance between pin 3 and 4 towards the oxygen sensor	3.0 to 3.5 Ω at 20 °C  Replace oxygen sensor

Work instruction			Display OK	If not OK
3	Check B+ supply for oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Start the engine</li> <li>◆ Measure voltage between pin 3 towards the DME control module and ground</li> </ul>	Battery positive voltage	
4	Check wiring	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and pin II/19</li> </ul>	0 - 5 $\Omega$	
5	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 1 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 2 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 5 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 6 and the oxygen sensor housing</li> </ul>	$\infty \Omega$	Replace oxygen sensor


**Note!**

Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.



**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter





## P1115

### 13 Oxygen Sensor Ahead of TWC, Bank 1 – Signal Implausible

#### Diagnosis conditions

- Mass air flow above 32 kg/h
- No other oxygen sensor faults
- Battery voltage between 9.5 V and 16 V

#### Possible fault cause

- ◆ Open circuit
- ◆ Oxygen sensor heating faulty
- ◆ DME control module

#### Affected terminals

II/19

#### Diagnosis/Troubleshooting

 **Note!**

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction			Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection		
2	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Remove oxygen sensor connector ahead of catalytic converter Bank 1</li> <li>◆ Check resistance between pin 3 and 4 towards the oxygen sensor</li> </ul>	3.0 to 3.5 Ω at 20 °C	Replace oxygen sensor


Work instruction			Display OK	If not OK
3	Check B+ supply for oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Start the engine</li> <li>◆ Measure voltage between pin 3 towards the DME control module and ground</li> </ul>	Battery positive voltage	
4	Check wiring	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and pin II/19</li> </ul>	0 - 5 $\Omega$	
5	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 1 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 2 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 5 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 6 and the oxygen sensor housing</li> </ul>	$\infty \Omega$	Replace oxygen sensor

**Note!**

Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter

**13 Oxygen Sensor Heating Ahead of TWC, Bank 1 – Open Circuit****Diagnosis conditions**

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

**Possible fault cause**

- ◆ Open circuit

**Affected terminals**

II/19

**Diagnosis/Troubleshooting**

**i** **Note!**

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction		Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection	
2	Check oxygen sensor heating	◆ Remove oxygen sensor connector Bank 1 ahead of catalytic converter ◆ Check resistance between pin 3 and 4 towards the oxygen sensor	3.0 to 3.5 $\Omega$ at 20 °C  Replace oxygen sensor


Work instruction			Display OK	If not OK
3	Check B+ supply for oxygen sensor heating	<ul style="list-style-type: none"><li>◆ Start the engine</li><li>◆ Measure voltage between pin 3 towards the DME control module and ground</li></ul>	Battery positive voltage	
4	Check wiring	<ul style="list-style-type: none"><li>◆ Check resistance between pin 4 and pin II/19</li></ul>	0 - 5 $\Omega$	

**Note!**

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter

**13 Oxygen Sensor Ahead of TWC, Bank 1 – Below Limit****Diagnosis conditions**

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

**Possible fault cause**

- ◆ Short circuit to ground

**Affected terminals**

II/19

**Diagnosis/Troubleshooting**

**Note!**

Do not use contact spray on the connectors to oxygen sensor.

Work instruction		Display OK	If not OK	
1	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Remove oxygen sensor connector Bank 1 ahead of catalytic converter</li> <li>◆ Check resistance between pin 3 and 4 towards the oxygen sensor</li> <li>◆</li> </ul>	3.0 to 3.5 $\Omega$ at 20 °C	Replace oxygen sensor
2		<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor housing</li> </ul>	$\infty \Omega$	
3	Check wiring	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and vehicle ground towards DME control module</li> </ul>	$\infty \Omega$	Repair wiring harness


**Note!**

Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.



**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter

**13 Oxygen Sensor Heating Ahead of TWC, Bank 1 – Above Limit****Diagnosis conditions**

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

**Possible fault cause**

- ◆ Short circuit to B+

**Affected terminals**

II/19

**Diagnosis/Troubleshooting**

**Note!**

Do not use contact spray on the connectors to oxygen sensor.


Work instruction		Display OK	If not OK	
1	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Remove oxygen sensor connector Bank 1 ahead of catalytic converter</li> <li>◆ Check resistance between pin 3 and 4 towards the oxygen sensor</li> </ul>	3.0 to 3.5 $\Omega$ at 20 °C	Replace oxygen sensor
		<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 1 and pin 4</li> <li>◆ Check resistance between pin 2 and pin 4</li> <li>◆ Check resistance between pin 5 and pin 4</li> <li>◆ Check resistance between pin 6 and pin 4</li> </ul>	$\infty$ $\Omega$	
2	Check wiring	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pin 4 and vehicle ground towards DME control module</li> </ul>	0 V	Repair wiring harness

**Note!**

Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter





## P1116

### 724 Heating LSU Bank 2, Inertia Fuel Shutoff - Signal Implausible

#### Diagnosis conditions

- Exhaust temperature above 250 °C
- Battery positive voltage greater than 9.5 V
- Time elapsed after start-up greater than 60 seconds
- No faults of the oxygen sensor
- Inertia fuel shutoff greater than 4 seconds

#### Possible fault cause

- ◆ Open circuit
- ◆ Oxygen sensor
- ◆ DME control module

#### Affected terminals

II/13

#### Diagnosis/Troubleshooting



#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction		Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection	
2	Check oxygen sensor heating	◆ Remove oxygen sensor connector Bank 2 ahead of catalytic converter ◆ Check resistance between pin 3 and 4 towards the oxygen sensor	3.0 to 3.5 Ω at 20 °C  Replace oxygen sensor


Work instruction			Display OK	If not OK
3	Check B+ supply for oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Start the engine</li> <li>◆ Measure voltage between pin 3 towards the DME control module and ground</li> </ul>	Battery positive voltage	
4	Check wiring	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and pin II/13</li> </ul>	0 - 5 $\Omega$	
5	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 1 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 2 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 5 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 6 and the oxygen sensor housing</li> </ul>	$\infty \Omega$	Replace oxygen sensor

**Note!**

Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter







## P1117

### 14 Oxygen Sensor Heating After TWC, Bank 1 – Signal Implausible

#### Diagnosis conditions

- Exhaust temperature between 300 °C and 600 °C
- Battery voltage between 9.5 V and 16 V

#### Possible fault cause

- ◆ Corrosion in connector
- ◆ Oxygen sensor

#### Affected terminals

11/7

#### Diagnosis/Troubleshooting

##### Note!

*Do not use contact spray on the connectors to oxygen sensor.*


Work instruction		Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection	
2	Check oxygen sensor heating	◆ Remove oxygen sensor connector after catalytic converter Bank 1 ◆ Check resistance between pin 1 and 2 towards the oxygen sensor	9 to 10 Ω at 20 °C Replace oxygen sensor
3	Check oxygen sensor	◆ Check resistance between pin 1 and the oxygen sensor housing ◆ Check resistance between pin 1 and 3	∞ Ω

##### Note!

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P1118

### 4 Oxygen Sensor Heating After TWC, Bank 2 – Signal Implausible

#### Diagnosis conditions

- Exhaust temperature between 300 °C and 600 °C
- Battery voltage between 9.5 V and 16 V

#### Possible fault cause

- ◆ Corrosion in connector
- ◆ Oxygen sensor

#### Affected terminals

II/1

### Diagnosis/Troubleshooting

#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*


Work instruction			Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection		
2	Check oxygen sensor heating	◆ Remove oxygen sensor connector after catalytic converter Bank 2 ◆ Check resistance between pin 1 and 2 towards the oxygen sensor	9 to 10 Ω at 20 °C	Replace oxygen sensor
3	Check oxygen sensor	◆ Check resistance between pin 1 and the oxygen sensor housing ◆ Check resistance between pin 1 and 3	∞ Ω	

#### Note!

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P1119

### 5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Signal Implausible

#### Diagnosis conditions

- Mass air flow above 32 kg/h
- No other oxygen sensor faults
- Battery voltage between 9.5 V and 16 V

#### Possible fault cause

- ◆ Open circuit
- ◆ Oxygen sensor heating faulty
- ◆ DME control module

#### Affected terminals

II/13

#### Diagnosis/Troubleshooting

 **Note!**

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction		Display OK	If not OK
1	Check connector for corrosion	◆ Visual inspection	
2	Check oxygen sensor heating	◆ Remove oxygen sensor connector ahead of catalytic converter Bank 2 ◆ Check resistance between pin 3 and 4 towards the oxygen sensor	3.0 to 3.5 Ω at 20 °C Replace oxygen sensor


Work instruction			Display OK	If not OK
3	Check B+ supply for oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Start the engine</li> <li>◆ Measure voltage between pin 3 towards the DME control module and ground</li> </ul>	Battery positive voltage	
4	Check wiring	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and pin II/19</li> </ul>	0 - 5 $\Omega$	
5	Check oxygen sensor	<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 1 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 2 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 5 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 6 and the oxygen sensor housing</li> </ul>	$\infty \Omega$	Replace oxygen sensor

**Note!**

Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.

### Oxygen sensors ahead of and after catalytic converter

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



### 5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Open Circuit

#### Diagnosis conditions

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

#### Possible fault cause

- ◆ Open circuit

#### Affected terminals

II/13

### Diagnosis/Troubleshooting

#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction		Display OK	If not OK
1	Check connector for corrosion		
2	Check oxygen sensor heating	3.0 to 3.5 $\Omega$ at 20 $^{\circ}\text{C}$	Replace oxygen sensor

Work instruction			Display OK	If not OK
3	Check B+ supply for oxygen sensor heating	<ul style="list-style-type: none"><li>◆ Start the engine</li><li>◆ Measure voltage between pin 3 towards the DME control module and ground</li></ul>	Battery positive voltage	
4	Check wiring	<ul style="list-style-type: none"><li>◆ Check resistance between pin 4 and pin II/19</li></ul>	0 - 5 $\Omega$	


**Note!**

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*



**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter

**5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Below Limit****Diagnosis conditions**

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

**Possible fault cause**

- ◆ Short circuit to ground

**Affected terminals**

II/13

**Diagnosis/Troubleshooting**** Note!**

Do not use contact spray on the connectors to oxygen sensor.


Work instruction		Display OK	If not OK
1	Check oxygen sensor heating	◆ Remove oxygen sensor connector Bank 2 ahead of catalytic converter	Replace oxygen sensor
		◆ Check resistance between pin 3 and 4 towards the oxygen sensor	
2		◆ Check resistance between pin 4 and the oxygen sensor housing	
3	Check wiring	◆ Check resistance between pin 4 and vehicle ground towards DME control module	Repair wiring harness

**Note!**

Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter

**5 Oxygen Sensor Heating Ahead of TWC, Bank 2 – Above Limit****Diagnosis conditions**

- Battery voltage between 9.5 V and 16 V
- Time elapsed after engine start-up greater than 10 seconds

**Possible fault cause**

- ♦ Short circuit to B+

**Affected terminals**

II/13

**Diagnosis/Troubleshooting**

**i** **Note!**

*Do not use contact spray on the connectors to oxygen sensor.*


Work instruction			Display OK	If not OK
1	Check oxygen sensor heating	<ul style="list-style-type: none"> <li>◆ Remove oxygen sensor connector Bank 2 ahead of catalytic converter</li> <li>◆ Check resistance between pin 3 and 4 towards the oxygen sensor</li> </ul>	3.0 to 3.5 $\Omega$ at 20 °C	Replace oxygen sensor
		<ul style="list-style-type: none"> <li>◆ Check resistance between pin 4 and the oxygen sensor housing</li> <li>◆ Check resistance between pin 1 and pin 4</li> <li>◆ Check resistance between pin 2 and pin 4</li> <li>◆ Check resistance between pin 5 and pin 4</li> <li>◆ Check resistance between pin 6 and pin 4</li> </ul>	$\infty$ $\Omega$	
2	Check wiring	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between pin 4 and vehicle ground towards DME control module</li> </ul>	0 V	Repair wiring harness

**i** **Note!**

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P1120

### Throttle Valve – Signal Implausible

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit or short circuit in the wiring
- ◆ Throttle position sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal I/7, I/9, III/8, III/10, III/24 and III/25



#### Note!

- ◆ *Fault P01120 only appears in conjunction with fault P1121 or P1122.*
- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The opening angle of the throttle valve is limited to 30 %.*
- ◆ *The dynamic of the throttle valve is restricted.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply to throttle motor actuator	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect motor tester (oscilloscope) to Pin I/7 and Pin I/9</li> <li>◆ Use special input</li> <li>◆ Switch on the ignition.</li> <li>◆ Fully depress accelerator pedal</li> </ul> See Figure 1.  See Figure 2 ⇒ Step 2	⇒ Step 5.

Figure 1:





Figure 2:




Work instruction		Display OK	If not OK
2	Check TP voltage supply. <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> <li>◆ Switch on the ignition.</li> </ul>	Approx. 5 V	
3	Check voltage values of throttle position sensors. <ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> </ul>	Approx. 0.7 -0.9 V  Approx. 4.1 -4.5 V Approx. 4.0 -4.4 V	Replace throttle part
	<ul style="list-style-type: none"> <li>◆ Fully depress accelerator pedal</li> </ul>	Approx. 0.5 - 0.8 V	
4	Check wiring from throttle part to DME control module for continuity or short circuit to B+ and ground <ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> </ul>		

Work instruction	Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 5 and special tool 9637 Pin III/8</li> <li>◆ Measure resistance between disconnection point Pin 6 and special tool 9637 Pin III/24</li> <li>◆ Measure resistance between disconnection point Pin 4 and ground</li> <li>◆ Measure resistance between disconnection point Pin 5 and ground</li> <li>◆ Measure resistance between disconnection point Pin 6 and ground</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between disconnection point Pin 4 and ground</li> <li>◆ Measure voltage between disconnection point Pin 5 and ground</li> <li>◆ Measure voltage between disconnection point Pin 6 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p><math>\infty</math> <math>\Omega</math></p> <p><math>\infty</math> <math>\Omega</math></p> <p><math>\infty</math> <math>\Omega</math></p> <p>0 V.</p> <p>0 V.</p> <p>0 V.</p> <p>0 V.</p> <p>Repair wiring harness.</p>

Disconnection point throttle part:

**i Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module.		
6	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>		





Figure 1:





Figure 2:




Work instruction		Display OK	If not OK	
2	Check TP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> </ul>	Approx. 5 V ⇒ Step 3	⇒ Step 4
3	Check voltage values of throttle position sensor 1	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> </ul>	Approx. 0.7 - 0.9 V  Approx. 4.1 - 4.5 V	Replace throttle part ⇒ Step 6
4	Check wiring from throttle part to DME control module for continuity or short circuit to B+ and ground	<ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part.</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> </ul>		Repair wiring harness → End

Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 6 and special tool 9637 Pin III/24</li> <li>◆ Measure resistance between disconnection point Pin 4 and ground</li> <li>◆ Measure resistance between disconnection point Pin 6 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between disconnection point Pin 4 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between disconnection point Pin 6 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p><math>\infty \Omega</math></p> <p><math>\infty \Omega</math></p> <p>0 V</p> <p>0 V ⇒ Step 5</p>	

Disconnection point throttle part:

**i Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module	⇒ Step 6	
6	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



Figure 1:





Figure 2:




Work instruction		Display OK	If not OK	
2	Check TP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> </ul>	Approx. 5 V ⇒ Step 3	⇒ Step 4
3	Check voltage values of throttle position sensor 2	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> </ul>	Approx. 4.0 - 4.4 V  Approx. 0.5 - 0.8 V	Replace throttle part ⇒ Step 6
4	Check wiring from throttle part to DME control module for continuity or short circuit to B+ and ground	<ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part.</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> </ul>		Repair wiring harness → End

Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 5 and special tool 9637 Pin III/8</li> <li>◆ Measure resistance between Pin 4 and ground</li> <li>◆ Measure resistance between disconnection point Pin 5 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between disconnection point Pin 4 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between disconnection point Pin 5 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p><math>\infty \Omega</math></p> <p><math>\infty \Omega</math></p> <p>0 V</p> <p>0 V ⇒ Step 5</p>	

Disconnection point throttle part:

**i Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module	⇒ Step 6	
6	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P1124

### 167 Fuel pump relay output stage - below limit

#### Diagnosis conditions

- Engine started



#### Note!

The triggering wire for the fuel pump relay, terminal 85, is monitored.

#### Possible fault cause

- ◆ Fuel pump relay
- ◆ Short circuit to ground
- ◆ DME control module

#### Affected terminals

Terminal IV/10

#### Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Check fuel pump relay	<ul style="list-style-type: none"> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2	Replace fuel pump relay → End
2	Check wiring from DME control module, Pin IV/10, to fuel pump relay for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between special tool 9637 Pin IV/10 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End
3	Replace DME control module		⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 167 Fuel pump relay output stage - above limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V



### Note!

The triggering wire for the fuel pump relay, terminal 85, is monitored.

### Possible fault cause

- ◆ Fuel pump relay
- ◆ Short circuit to B+
- ◆ DME control module

### Affected terminals

Terminal IV/10

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check fuel pump relay	<ul style="list-style-type: none"> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2 Replace fuel pump relay → End
2	Check wiring from DME control module, Pin IV/10, to fuel pump relay for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove fuel pump relay</li> <li>◆ Measure voltage between special tool Pin IV/10 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3 Repair wiring harness → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End

## 167 Fuel pump relay output stage - open circuit

### Diagnosis conditions

- Engine started



### Note!

The triggering wire for the fuel pump relay, terminal 85, is monitored.

### Possible fault cause

- ◆ Fuel pump relay
- ◆ Open circuit
- ◆ DME control module

### Affected terminals

Terminal IV/10

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check fuel pump relay	<ul style="list-style-type: none"> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2 Replace fuel pump relay → End
2	Check wiring from DME control module, Pin IV/10, to fuel pump relay for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove fuel pump relay</li> <li>◆ Measure resistance between special tool 9637, Pin IV/10, and fuel pump relay slot, Pin 6 (terminal 85)</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3 Check plug connection X 2/3 and wiring harness → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End



## P1125

### 357 Oxygen Sensing Adaptation, Upper Load Range, Bank 1 - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C
- Mass air flow greater than 180 kg/h

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

- ◆ If DTC P0445 (EVAP canister purge valve - short to ground) is stored in the memory, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0.9 to 1.1 V
		<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	approx. 1.4 V
2	Check fuel pressure		

Work instruction		Display OK	If not OK	
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine</li> <li>◆</li> </ul>	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>		Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0 bar after 10 minutes	
5	Check fuel injectors for leaks			

### 357 Oxygen Sensing Adaptation, Upper Load Range, Bank 1 - Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C
- Mass air flow greater than 180 kg/h

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

**Affected terminals**

-

**Diagnosis/troubleshooting****Note!**

- ◆ Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction			Display OK	If not OK
1	Check signal from MAF sensor	◆ Connect special tool 9637	0.9 to 1.1 V	Replace MAF sensor
		◆ Measure voltage at pin III/23 and ground		
		◆ Switch on the ignition		
		◆ Start the engine	approx. 1.4 V	
2	Check exhaust system for leaks			
3	Check for air leaks in intake air system			
4	Check fuel pressure			
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	<ul style="list-style-type: none"> <li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li> <li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li> </ul>		





## P1126

### 356 Oxygen Sensing Adaptation, Lower Load Range, Bank 1 - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

- ◆ If DTC P0445 (EVAP canister purge valve - short to ground) is stored in the memory, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor	◆ Connect special tool 9637	Replace MAF sensor
		◆ Measure voltage at pin III/23 and ground	
		◆ Switch on the ignition	
		◆ Start the engine	
		0.9 to 1.1 V	
		approx. 1.4 V	
2	Check fuel pressure		

Work instruction		Display OK	If not OK
3	Check fuel pressure regulator, vacuum connection and fuel return line	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine</li> <li>◆</li> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>		Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check fuel injectors for leaks		

### 356 Oxygen Sensing Adaptation, Lower Load Range, Bank 1 - Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

#### Affected terminals

-

#### Diagnosis/troubleshooting

**Note!**

- ◆ Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction			Display OK	If not OK
1	Check signal from MAF sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0.9 to 1.1 V	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	approx. 1.4 V	
2	Check exhaust system for leaks			
3	Check for air leaks in intake air system			
4	Check fuel pressure			
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	<ul style="list-style-type: none"> <li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li> <li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li> </ul>		



## P1127

### 418 Oxygen Sensing Error by means of Short Test, Bank 1 - Below Limit

#### Diagnosis conditions

- Mixture adaptation performed with the Porsche System Tester 2

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.

Work instruction		Display OK	If not OK	
1	Check signal from MAF sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0.9 to 1.1 V	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	approx. 1.4 V	
2	Check fuel pressure			

Work instruction		Display OK	If not OK	
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine</li> <li>◆</li> </ul>	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>		Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes	
5	Check fuel injectors for leaks			

### 418 Oxygen Sensing Error by means of Short Test, Bank 1 - Above Limit

#### Diagnosis conditions

- Mixture adaptation performed with the Porsche System Tester 2

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

#### Affected terminals

-

## Diagnosis/troubleshooting

**i** **Note!**

Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.

Work instruction			Display OK	If not OK
1	Check signal from MAF sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0.9 to 1.1 V	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	approx. 1.4 V	
2	Check exhaust system for leaks			
3	Check for air leaks in intake air system			
4	Check fuel pressure			
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	<ul style="list-style-type: none"> <li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li> <li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li> </ul>		





## P1128

### 360 Oxygen Sensing Adaptation, Idle Range, Bank 1 - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1,4 V
2	Check fuel pressure		Replace MAF sensor

Work instruction		Display OK	If not OK
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> <li>◆</li> </ul>	0.4 - 0.6 bar  Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>	Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0 bar after 10 minutes
5	Check fuel injectors for leaks		

### 360 Oxygen Sensing Adaptation, Idle Range, Bank 1 - Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

- ◆ PCV valve leaks
- ◆ Cap of oil filler neck not closed correctly or seal is damaged

Affected terminals

-

Diagnosis/Troubleshooting



**Note!**

- ◆ *Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.*
- ◆ *Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.*
- ◆ *If the fuel tank reserve light is switched on, no fault is entered.*

Work instruction		Display OK	If not OK
1	Close cap of oil filler neck properly or replace the seal		
2	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1,4 V
3	Check exhaust system for leaks		
4	Check for air leaks in intake air system		
5	Check PCV valve for leaks		
6	Check fuel pressure		
7	Check volume supply of fuel pump		
8	Fuel injectors fouled	◆ If preceding Check Points were negative, the fuel injectors may be fouled ◆ Clean fuel injectors (ultrasonic cleaning device) or replace them	



## P1130

### 361 Oxygen Sensing Adaptation, Idle Range, Bank 2 - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

- ◆ If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1,4 V
2	Check fuel pressure		Replace MAF sensor

Work instruction		Display OK	If not OK	
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine.</li> <li>◆</li> </ul>	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>		Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0.5 bar after 10 minutes	
5	Check fuel injectors for leaks			

### 361 Oxygen Sensing Adaptation, Idle Range, Bank 2 - Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

- ◆ PCV valve leaks
- ◆ Cap of oil filler neck not closed correctly or seal is damaged

Affected terminals

-

Diagnosis/Troubleshooting



**Note!**

- ◆ *Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.*
- ◆ *Contrary adaptation values in connection with misfiring point to incorrectly adjusted control times ⇒ check control times and adjust if necessary.*
- ◆ *If the fuel tank reserve light is switched on, no fault is entered.*

Work instruction		Display OK	If not OK
1	Close cap of oil filler neck properly or replace the seal		
2	Check signal from MAF sensor.	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1,4 V
3	Check exhaust system for leaks		
4	Check for air leaks in intake air system		
5	Check PCV valve for leaks		
6	Check fuel pressure		
7	Check volume supply of fuel pump		
8	Fuel injectors fouled	◆ If preceding Check Points were negative, the fuel injectors may be fouled ◆ Clean fuel injectors (ultrasonic cleaning device) or replace them	





## P1132

### 359 Oxygen Sensing Adaptation, Upper Load Range, Bank 2 - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C
- Mass air flow greater than 180 kg/h

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

#### Diagnosis/troubleshooting

##### Note!

- ◆ If DTC P0445 (EVAP canister purge valve - short to ground) is stored in the memory, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor	◆ Connect special tool 9637 ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition	0.9 to 1.1 V
		◆ Start the engine	approx. 1.4 V
2	Check fuel pressure		

Work instruction		Display OK	If not OK	
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine</li> <li>◆</li> </ul>	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>		Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0 bar after 10 minutes	
5	Check fuel injector for leaks			

### 357 Oxygen Sensing Adaptation, Upper Load Range, Bank 1 - Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C
- Mass air flow greater than 180 kg/h

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

**Affected terminals**

-

**Diagnosis/troubleshooting****Note!**

- ◆ Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.
- ◆ For vehicles in the USA, the upper load range will probably not be reached. The only case in which a fault could be stored is during driving while towing a trailer or caravan on a hill.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction			Display OK	If not OK
1	Check signal from MAF sensor	◆ Connect special tool 9637	0.9 to 1.1 V	Replace MAF sensor
		◆ Measure voltage at pin III/23 and ground		
		◆ Switch on the ignition		
		◆ Start the engine	approx. 1.4 V	
2	Check exhaust system for leaks			
3	Check for air leaks in intake air system			
4	Check fuel pressure			
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	◆ If preceding Check Points were negative, the fuel injectors may be fouled  ◆		



## P1133

### 358 Oxygen Sensing Adaptation, Lower Load Range, Bank 2 - Below Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

- ◆ If DTC P0445 (EVAP canister purge valve - short to ground) is stored in the memory, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction		Display OK	If not OK
1	Check signal from MAF sensor	◆ Connect special tool 9637	Replace MAF sensor
		◆ Measure voltage at pin III/23 and ground	
		◆ Switch on the ignition	
		◆ Start the engine	
		0.9 to 1.1 V	
		approx. 1.4 V	
2	Check fuel pressure		

Work instruction		Display OK	If not OK
3	Check fuel pressure regulator, vacuum connection and fuel return line	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine</li> <li>◆</li> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>		Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check fuel injectors for leaks		

### 358 Oxygen Sensing Adaptation, Lower Load Range, Bank 2 - Above Limit

#### Diagnosis conditions

- Oxygen sensing system active
- Time elapsed after engine start-up: 250 to 350 seconds (USA)
- Time elapsed after engine start-up: 302 to 402 seconds (RoW)
- Engine temperature greater than 60 °C

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

#### Affected terminals

-

#### Diagnosis/troubleshooting

**Note!**

- ◆ Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.
- ◆ If the fuel tank reserve light is switched on, no fault is entered.

Work instruction			Display OK	If not OK
1	Check signal from MAF sensor	◆ Connect special tool 9637	0.9 to 1.1 V	Replace MAF sensor
		◆ Measure voltage at pin III/23 and ground		
		◆ Switch on the ignition		
		◆ Start the engine	approx. 1.4 V	
2	Check exhaust system for leaks			
3	Check for air leaks in intake air system			
4	Check fuel pressure			
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	<ul style="list-style-type: none"> <li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li> <li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li> </ul>		





## P1134

### 419 Oxygen Sensing Error by means of Short Test, Bank 2 - Below Limit

#### Diagnosis conditions

- Mixture adaptation performed with the Porsche System Tester 2

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Fuel pressure too high
- ◆ Fuel injector leaking
- ◆ EVAP canister purge valve open

#### Affected terminals

-

#### Diagnosis/troubleshooting



#### Note!

If DTC P0445 (fuel tank vent valve - short to ground) is stored, correct this fault first. An open EVAP canister purge valve can lead to the lean threshold being reached.

Work instruction		Display OK	If not OK	
1	Check signal from MAF sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0.9 to 1.1 V	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	approx. 1.4 V	
2	Check fuel pressure			

Work instruction		Display OK	If not OK	
3	Check fuel pressure regulator, vacuum connection and fuel return line	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose from fuel pressure regulator</li> <li>◆ Connect special tool 9103/2 to vacuum hose</li> <li>◆ Start the engine</li> <li>◆</li> </ul>	0.4 - 0.6 bar	Check the intake air system for leaks and check vacuum line to fuel pressure regulator for restrictions.
		<ul style="list-style-type: none"> <li>◆ Check housing of fuel pressure regulator for damage and deformation</li> </ul>		Replace the fuel pressure regulator if it is damaged with the result that the spring pre-tensioning is increased
4	Check EVAP canister purge valve	<ul style="list-style-type: none"> <li>◆ Disconnect hose from EVAP canister purge valve to intake system at EVAP canister purge valve</li> <li>◆ Remove connector of EVAP canister purge valve</li> <li>◆ Connect special tool 9160/1 to EVAP canister purge valve</li> <li>◆ Generate vacuum of approx. 0.7 bar</li> </ul>	The vacuum must not fall below 0 bar after 10 minutes	
5	Check fuel injectors for leaks			

### 419 Oxygen Sensing Error by means of Short Test, Bank 2 - Above Limit

#### Diagnosis conditions

- Mixture adaptation performed with the Porsche System Tester 2

#### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

#### Affected terminals

-

## Diagnosis/troubleshooting



### Note!

Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.

Work instruction			Display OK	If not OK
1	Check signal from MAF sensor	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0.9 to 1.1 V	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine</li> </ul>	approx. 1.4 V	
2	Check exhaust system for leaks			
3	Check for air leaks in intake air system			
4	Check fuel pressure			
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	<ul style="list-style-type: none"> <li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li> <li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li> </ul>		



## P1136

### Pressure sensors signal comparison charge pressure / ambient pressure - signal implausible

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Boost pressure sensor faulty
- ◆ DME control unit faulty (ambient pressure sensor)

#### Affected terminals

III/39

#### Diagnosis/troubleshooting



#### Note!

The pressure sensor for the ambient air pressure is installed in the DME control module.

Work instruction		Display OK	If not OK
1	Evaluate fault memory <ul style="list-style-type: none"> <li>◆ Evaluate fault memory</li> <li>◆ Check whether the faults 'P0237' or 'P0238' have been recorded</li> </ul>	Only fault 'P1136' has been recorded ⇒ Step 2	Either fault 'P0237' or fault 'P0238' is present ⇒ Work through faults according to instructions (wiring fault) → End

Work instruction		Display OK	If not OK
2	Check sensors	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ With the 9588 Porsche System Tester II, read out the actual value of the boost pressure sensor</li> <li>◆ Compare this value with the display value of a calibrated barometer</li> </ul>	<p>The values match ⇒ Step 3</p> <p>The value of the boost pressure sensor does not match that of the barometer ⇒ Replace boost pressure sensor → End</p>
3		<ul style="list-style-type: none"> <li>◆ With the 9588 Porsche System Tester II, read out the actual value of the ambient pressure sensor</li> <li>◆ Compare this value with the display value of a calibrated barometer</li> </ul>	<p>The values match ⇒ Delete fault memory → End</p> <p>The value of the ambient pressure sensor does not match that of the barometer ⇒ Replace engine control module → End</p>

## P1137

### 446 Clutch Switch - Signal Implausible

#### Diagnosis conditions

- Speed greater than 50 km/h
- Time between two clutch engagement processes more than 5 sec
- Number of gearshifts more than 5

#### Possible fault cause

- ◆ Fuse faulty
- ◆ Clutch switch
- ◆ Short circuit to B+
- ◆ Open circuit

#### Affected terminals

-

#### Diagnosis/Troubleshooting



#### Note!

- ◆ *The clutch switch is linked to the instrument cluster. The DME control module receives information from the instrument cluster via the CAN bus.*
- ◆ *If a clutch switch fault is stored, the cruise control system is out of order.*

Work instruction			Display OK	If not OK
1	Check fuse B 7.			
2	Check clutch switch.	◆ Clutch switch opens when actuated.		
3	Check wiring.	◆ Check the wiring from the clutch switch to the instrument cluster pin III/19 for short to B+. ◆ Check the wiring from the clutch switch to the instrument cluster pin III/19 for continuity.		





## P1138

### Throttle Position Sensor 1 – Above Limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit in wiring
- ◆ Throttle position sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal I/7, I/9, III/10, III/24 and III/25

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply to throttle motor actuator	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect motor tester (oscilloscope) to Pin I/7 and Pin I/9</li> <li>◆ Use special input</li> <li>◆ Switch on the ignition.</li> <li>◆ See Figure 1.</li> <li>◆ Fully depress accelerator pedal</li> </ul>	<p>See Figure 1.</p> <p>See Figure 2 ⇒ Step 2</p> <p>⇒ Step 5.</p>

Figure 1:





Figure 2:




Work instruction			Display OK	If not OK
2	Check TP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> </ul>	Approx. 5 V ⇒ Step 3	⇒ Step 4.
3	Check voltage values of throttle position sensor 1	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> </ul>	Approx. 0.7 -0.9 V  Approx. 4.1 -4.5 V	Replace throttle part ⇒ Step 6.
4	Check wiring from throttle part to DME control module for continuity or short circuit to B+	<ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part.</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> </ul>		Repair wiring harness → End.

Work instruction	Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 6 and special tool 9637 Pin III/24</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between disconnection point Pin 4 and ground</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between disconnection point Pin 6 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 V.</p> <p>0 V ⇒ Step 5.</p>

Disconnection point throttle part:

**i Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module.	⇒ Step 6.	
6	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.

## P1139

### Throttle Position Sensor 1 – Below Limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit in wiring
- ◆ Throttle position sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal I/7, I/9, III/10, III/24 and III/25

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply to throttle motor actuator	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect motor tester (oscilloscope) to Pin I/7 and Pin I/9</li> <li>◆ Use special input</li> <li>◆ Switch on the ignition.</li> <li>◆ See Figure 1.</li> <li>◆ Fully depress accelerator pedal</li> </ul>	<p>See Figure 1.</p> <p>See Figure 2 ⇒ Step 2</p> <p>⇒ Step 5.</p>

Figure 1:





Figure 2:



Work instruction			Display OK	If not OK
2	Check TP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> </ul>	Approx. 5 V ⇒ Step 3	⇒ Step 4.
3	Check voltage values of throttle position sensor 1	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/24 and Pin III/25</li> </ul>	Approx. 0.7 -0.9 V  Approx. 4.1 -4.5 V	Replace throttle part ⇒ Step 6.
4	Check wiring from throttle part to DME control module for short to ground.	<ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part.</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> </ul>		Repair wiring harness → End.


Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 6 and special tool 9637 Pin III/24</li> <li>◆ Measure resistance between disconnection point Pin 4 and ground</li> <li>◆ Measure resistance between disconnection point Pin 6 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p><math>\infty \Omega</math></p> <p><math>\infty \Omega</math></p>	

Disconnection point throttle part:



**Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module.	⇒ Step 6.	
6	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.



## P1140

### Throttle Position Sensor 2 – Above Limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit in wiring
- ◆ Throttle position sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal I/7, I/9, III/8, III/10 and III/25

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply to throttle motor actuator	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect motor tester (oscilloscope) to Pin I/7 and Pin I/9</li> <li>◆ Use special input</li> <li>◆ Switch on the ignition.</li> <li>◆ Fully depress accelerator pedal</li> </ul> See Figure 1.  See Figure 2 ⇒ Step 2	⇒ Step 5.

Figure 1:





Figure 2:




Work instruction		Display OK	If not OK
2	Check TP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> </ul>	<p>Approx. 5 V ⇒ Step 3</p> <p>⇒ Step 4.</p>
3	Check voltage values of throttle position sensor 2	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> </ul>	<p>Approx. 4.0 -4.4 V</p> <p>Approx. 0.5 -0.8 V</p> <p>Replace throttle part ⇒ Step 6.</p>
4	Check wiring from throttle part to DME control module for continuity or short circuit to B+	<ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part.</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> </ul>	<p>Repair wiring harness → End.</p>

Work instruction	Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 5 and special tool 9637 Pin III/8</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between disconnection point Pin 4 and ground</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between disconnection point Pin 5 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 V.</p> <p>0 V ⇒ Step 5.</p>

Disconnection point throttle part:

**i Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module.	⇒ Step 6.	
6	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.

## P1141

### Throttle Position Sensor 2 – Below Limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit in wiring
- ◆ Throttle position sensor faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal I/7, I/9, III/8, III/10 and III/25

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check voltage supply to throttle motor actuator <ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Connect motor tester (oscilloscope) to Pin I/7 and Pin I/9</li> <li>◆ Use special input</li> <li>◆ Switch on the ignition.</li> <li>◆ Fully depress accelerator pedal</li> </ul>	See Figure 1.          See Figure 2 ⇒ Step 2	⇒ Step 5.

Figure 1:





Figure 2:



Work instruction		Display OK	If not OK
2	Check TP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/10 and Pin III/25</li> </ul>	<p>Approx. 5 V ⇒ Step 3</p> <p>⇒ Step 4.</p>
3	Check voltage values of throttle position sensor 2	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> <li>◆ Fully depress accelerator pedal</li> <li>◆ Measure voltage between Pin III/8 and Pin III/25</li> </ul>	<p>Approx. 4.0 -4.4 V</p> <p>Approx. 0.5 - 0.8 V</p> <p>Replace throttle part ⇒ Step 6.</p>
4	Check wiring from throttle part to DME control module for continuity or short circuit to B+	<ul style="list-style-type: none"> <li>◆ Separate disconnection point to throttle part.</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> </ul>	<p>Repair wiring harness → End.</p>


Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between disconnection point Pin 1 and special tool 9637 Pin I/9</li> <li>◆ Measure resistance between disconnection point Pin 2 and special tool 9637 Pin III/25</li> <li>◆ Measure resistance between disconnection point Pin 3 and special tool 9637 Pin III/10</li> <li>◆ Measure resistance between disconnection point Pin 4 and special tool 9637 Pin I/7</li> <li>◆ Measure resistance between disconnection point Pin 5 and special tool 9637 Pin III/8</li> <li>◆ Measure resistance between Pin 4 and ground</li> <li>◆ Measure resistance between disconnection point Pin 5 and ground</li> </ul>	<p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p>0 - 5 <math>\Omega</math></p> <p><math>\infty \Omega</math></p> <p><math>\infty \Omega</math></p>	

Disconnection point throttle part:



**Note!**

The wires to the throttle part are routed via connector X 59/2.



Work instruction		Display OK	If not OK
5	Replace DME control module.	⇒ Step 6.	
6	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.



## P1142

Oxygen Sensing Error by means of Short Test, Bank 1  
– Above Limit

### Diagnosis conditions

- Mixture adaptation performed with the Porsche System Tester 2

### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

*Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.*

Work instruction			Display OK	If not OK
1	Check signal from MAF sensor.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage at pin III/23 and ground</li> <li>◆ Switch on the ignition.</li> </ul>	0.9 to 1.1 V.	Replace MAF sensor
		<ul style="list-style-type: none"> <li>◆ Start the engine.</li> </ul>	Approx. 1.4 V	
2	Check exhaust system for leaks			
3	Check for air leaks in intake air system			
4	Check fuel pressure			

Work instruction			Display OK	If not OK
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	<ul style="list-style-type: none"><li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li><li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li></ul>		

## P1143

Oxygen Sensing Error by means of Short Test, Bank 2  
– Above Limit

### Diagnosis conditions

- Mixture adaptation performed with the Porsche System Tester 2

### Possible fault cause

- ◆ Incorrect signal from MAF sensor
- ◆ Intake air system leaking
- ◆ Fuel pressure too low
- ◆ Volume supply of fuel pump too low
- ◆ Fuel injectors fouled

### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

*Air leaks ahead of the oxygen sensors can lead to a fault in adaptation ⇒ Check exhaust system for leaks.*

Work instruction		Display OK	If not OK
1	Check signal from mass air flow sensor	◆ Connect special tool 9637. ◆ Measure voltage at pin III/23 and ground ◆ Switch on the ignition.	0.9 to 1.1 V.
		◆ Start the engine.	Approx. 1.4 V
2	Check exhaust system for leaks		
3	Check for air leaks in intake air system		
4	Check fuel pressure		

Work instruction			Display OK	If not OK
5	Check volume supply of fuel pump			
6	Fuel injectors fouled	<ul style="list-style-type: none"><li>◆ If preceding Check Points were negative, the fuel injectors may be fouled</li><li>◆ Clean fuel injectors (ultrasonic cleaning device) or replace them</li></ul>		

## P1145

### Oxygen Sensor Ahead of TWC, Bank 1 – Above Limit

#### Diagnosis conditions

 **Note!**

*A lot of time is required (several days) until a fault is detected.*

#### Possible fault cause

- ◆ Valve lift fault
- ◆ False air on the oxygen sensor after TWC
- ◆ Oxygen sensor

#### Affected terminals

-

 **Note!**

- ◆ *As this fault can be caused by a faulty flat-base tappet, a system test for a small lift has to be performed initially. The fault can occur sporadically; the test should therefore be performed at least three times when the engine is at operating temperature.*
- ◆ *First indication of a valve lift fault can be provided by the adaptation values at idle speed (RKAT) and in the lower part load (FRAU) if they differ by more than 10 %.*

#### Perform system test for small lift

 **Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4000 rpm) appears.**

At speeds above 4000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

 **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

### Diagnosis/Troubleshooting

 **Note!**

- ◆ *Do not use contact spray on the connectors to oxygen sensor.*
- ◆ *If other faults (fuel supply) are stored in the memory, rectify these first.*


Work instruction		Display OK	If not OK
1	Check exhaust system for leaks		Repair exhaust system → End
2	Replace oxygen sensor		

 **Note!**

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter





## P1146

### Oxygen Sensor Ahead of TWC, Bank 1 – Open Circuit

#### Diagnosis conditions

- Vehicle at operating temperature, after this 3 minutes idle speed, then approx. 30 seconds increased idle speed.

#### Possible fault cause

- ◆ Oxygen sensors (heating connection)

#### Affected terminals

-

### Diagnosis/Troubleshooting



#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction		Display OK	If not OK
1	Replace oxygen sensor		




#### Note!

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P1155

### Oxygen Sensor Ahead of TWC, Bank 2 – Above Limit

#### Diagnosis conditions

 **Note!**

*A lot of time is required (several days) until a fault is detected.*

#### Possible fault cause

- ◆ Valve lift fault
- ◆ False air on the oxygen sensor after TWC
- ◆ Oxygen sensor

#### Affected terminals

-

 **Note!**

- ◆ *As this fault can be caused by a faulty flat-base tappet, a system test for a small lift has to be performed initially. The fault can occur sporadically; the test should therefore be performed at least three times when the engine is at operating temperature.*
- ◆ *First indication of a valve lift fault can be provided by the adaptation values at idle speed (RKAT) and in the lower part load (FRAU) if they differ by more than 10 %.*

#### Perform system test for small lift

 **Warning!**


**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection.

Several cylinders may be stored as faulty, although only one valve on one cylinder is faulty.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensing, bank 1**

**B - Oxygen sensing, bank 2**

**1 - Select system test.**

**2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If "Request small lift" appears, the valves remain at small lift, i.e. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis completed" (max. 4000 rpm) appears.**

At speeds above 4000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

 **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensors during acceleration with wide-open throttle or to record their behaviour with the data logger.*

## Diagnosis/Troubleshooting

 **Note!**

- ◆ *Do not use contact spray on the connectors to oxygen sensor.*
- ◆ *If other faults (fuel supply) are stored in the memory, rectify these first.*


Work instruction		Display OK	If not OK
1	Check exhaust system for leaks		Repair exhaust system → End
2	Replace oxygen sensor		

 **Note!**

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P1156

### Oxygen Sensor Ahead of TWC, Bank 2 – Open Circuit

#### Diagnosis conditions

- Vehicle at operating temperature, after this 3 minutes idle speed, then approx. 30 seconds increased idle speed.

#### Possible fault cause

- ◆ Oxygen sensors (heating connection)

#### Affected terminals

-

#### Diagnosis/Troubleshooting



#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*

Work instruction		Display OK	If not OK
1	Replace oxygen sensor		




#### Note!

*Do not exchange oxygen sensors ahead of catalytic converter and after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter





## P1157

### 30 Engine Compartment Temperature Sensor - Below Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Temperature sensor
- ◆ Short circuit to ground

#### Affected terminals

II/21

#### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check temperature sensor.	<ul style="list-style-type: none"> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure resistance between temperature sensor pin 1 and pin 2.</li> </ul>	Approx. 2.2 - 2.6 k $\Omega$ at 20° C	Replace temperature sensor.
2	Check wiring harness for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure resistance between special tool 9637 pin II/21 and ground.</li> </ul>	$\infty$ $\Omega$	Repair wiring harness.



## P1158

### 30 Engine Compartment Temperature Sensor - Above Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Temperature sensor
- ◆ Short circuit to B+

#### Affected terminals

II/21

#### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check temperature sensor.	<ul style="list-style-type: none"> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure resistance between temperature sensor pin 1 and pin 2.</li> </ul>	Approx. 2.2 - 2.6 k $\Omega$ at 20° C	Replace temperature sensor.
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug of temperature sensor.</li> <li>◆ Measure voltage between special tool 9637 pin II/21 and ground.</li> <li>◆ Switch on the ignition.</li> </ul>	0 V	Repair wiring harness.



## P1159

### O2 Sensor Circuit

#### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensor heating switched on for at least 120 seconds
- ◆ Exhaust temperature between 200°C and 800°C

#### Possible cause of fault

- Oxygen sensor faulty

#### Affected pins

DME control module connector II, pin 11 and oxygen sensor jack, bank 1, pin 3

DME control module connector II, pin 17 and oxygen sensor jack, bank 1, pin 4

#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction		Display OK	If not OK
1	Replace oxygen sensor	→ End	

## P1160

### 02 Sensor Circuit

#### Diagnostic conditions

- ◆ Battery positive voltage between 10 V and 16 V
- ◆ Oxygen sensor heating switched on for at least 120 seconds
- ◆ Exhaust temperature between 200°C and 800°C

#### Possible cause of fault

- Oxygen sensor faulty

#### Affected pins

DME control module connector II, pin 8 and oxygen sensor jack, bank 2, pin 3

DME control module connector II, pin 14 and oxygen sensor jack, bank 2, pin 4

#### Diagnosis/troubleshooting



#### Note!

*Do not use contact spray on the oxygen sensor plug connections as this may cause irreparable damage to the wiring (contamination of the oxygen sensor via the reference air channel).*

Work instruction	Display OK	If not OK
1 Replace oxygen sensor	→ End	

## P1213

### 150 Fuel Injector, Cylinder 1 - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/41



#### Note!

Short to B+ causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 1</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/41 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End



## P1214

### 151 Fuel Injector, Cylinder 6 - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/28



#### Note!

Short to B+ causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 6</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 Ω (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/28 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1215

### 152 Fuel Injector, Cylinder 2 - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/40



#### Note!

Short to B+ causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 2</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 Ω (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/40 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1216

### 153 Fuel Injector, Cylinder 4 - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/27



#### Note!

Short to B+ causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 4</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/27 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1217

### 154 Fuel injector, cylinder 3 - above limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/15



#### Note!

Short to B+ causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 3</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 Pin III/15 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End



## P1218

### 155 Fuel Injector, Cylinder 5 - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) short circuit
- ◆ Short circuit to B+ in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/2



#### Note!

Short to B+ causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 5</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure voltage between special tool 9637 pin III/2 and ground</li> <li>◆ Ignition on</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1219

### 256 Accelerator pedal - signal implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Pedal sensor

#### Affected terminals

-



#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*
- ◆ *The fault code only appears together with P1577 or P1578.*
- ◆ *The pedal value is reset to zero by actuating the brake.*

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace pedal sensor	→ End	



## P1225

### 150 Fuel Injector, Cylinder 1 - Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/41



#### Note!

Short to ground causes the fuel injector to be permanently open.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 1</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/41 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1226

### 151 Fuel Injector, Cylinder 6 - Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/28



#### Note!

Short to ground causes the fuel injector to be permanently open.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 6</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/28 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End



## P1227

### 152 Fuel injector, cylinder 2 - below limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/40



#### Note!

Short to ground causes the fuel injector to be permanently open.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 2</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 Pin III/40 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1228

### 153 Fuel Injector, Cylinder 4 - Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/27



#### Note!

Short to ground causes the fuel injector to be permanently open.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 4</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/27 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1229

### 154 Fuel injector, cylinder 3 - below limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/15



#### Note!

Short to ground causes the fuel injector to be permanently open.

#### Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 3</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 Pin III/15 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1230

### 155 Fuel Injector, Cylinder 5 - Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/2



#### Note!

Short to ground causes the fuel injector to be permanently open.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 5</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/2 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End



## P1237

### 150 Fuel Injector, Cylinder 1 - Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/41



#### Note!

Open circuit causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 1</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for open circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/41 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1238

### 151 Fuel Injector, Cylinder 6 - Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/28



#### Note!

Open circuit causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 6</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for open circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/28 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module		⇒ Step 4
4	Perform adaptation	◆ Switch on the ignition ◆ Wait one minute ◆ Do not press the accelerator ◆ Switch off the ignition for at least 10 seconds ◆ Read out the fault memory	→ End

## P1239

### 152 Fuel Injector, Cylinder 2 - Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/40



#### Note!

Open circuit causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 2</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for open circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/40 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1240

### 153 Fuel Injector, Cylinder 4 - Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/27



#### Note!

Open circuit causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 4</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for open circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/27 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End



## P1241

### 154 Fuel injector, cylinder 3 - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/15



#### Note!

Open circuit causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 3</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for open circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 Pin III/15 and fuel injector plug Pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1242

### 155 Fuel Injector, Cylinder 5 - Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Fuel injector (coil) open circuit
- ◆ Open circuit in wiring
- ◆ DME control module

#### Affected terminals

Terminal III/2



#### Note!

Open circuit causes the fuel injector to be continually closed.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check fuel injector	<ul style="list-style-type: none"> <li>◆ Remove connector of fuel injector 5</li> <li>◆ Connect special tool V.A.G. 1315 A/1</li> <li>◆ Measure resistance at special tool V.A.G. 1315 A/1</li> </ul>	11 - 13 $\Omega$ (at 20 °C) ⇒ Step 2	Replace fuel injector → End
2	Check wiring harness for open circuit	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of fuel injector</li> <li>◆ Measure resistance between special tool 9637 pin III/2 and fuel injector plug pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"><li>◆ Switch on the ignition</li><li>◆ Wait one minute</li><li>◆ Do not press the accelerator</li><li>◆ Switch off the ignition for at least 10 seconds</li><li>◆ Read out the fault memory</li></ul>	→ End

## P1249

### 231 Boost Pressure Control Deviation - Above/Below Limit

#### Diagnosis conditions

- Boost pressure control active (operating condition close to full load)
- No faults in mixture adaptation, pressure sensor, ambient pressure sensor, frequency valve

#### Possible fault cause

- ◆ Air cleaner clogged
- ◆ Hose line from air cleaner to turbocharger kinked
- ◆ Leakage on fresh-gas side
- ◆ Leakage at exhaust-gas side
- ◆ Hoses on frequency valve leaking
- ◆ Bypass flaps incorrectly adjusted
- ◆ Turbocharger faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check frequency valve		Replace frequency valve
2	Check for air leaks in intake air system		Repair intake air system
3	Check pressure hoses on frequency valve for leaks		Replace pressure hoses or eliminate leaks
4	Check exhaust system for leaks		Repair exhaust system
5	Check adjustment of bypass flaps		Adjust bypass flaps
6	Check whether turbocharger compressor shaft can rotate freely		Replace the turbocharger



## P1250

### Boost Pressure Control Deviation - Above Limit

#### Diagnosis conditions

- Boost pressure control active (operating condition close to full load)
- No faults in mixture adaptation, pressure sensor, ambient pressure sensor, frequency valve

#### Possible fault cause

- ◆ Bypass flaps incorrectly adjusted
- ◆ Turbocharger faulty

#### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check adjustment of bypass flaps		Adjust bypass flaps
2	Check whether turbocharger compressor shaft can rotate freely		Replace the turbocharger





## P1255

### 230 Boost Pressure Characteristic, Upper Value Exceeded - Above Limit

#### Diagnosis conditions

- Boost pressure control active

#### Possible fault cause

- ◆ Leakage at pressure hoses from frequency valve to the bypass flaps
- ◆ Frequency valve faulty
- ◆ Vacuum modulators for bypass flaps leaking
- ◆ Bypass flaps incorrectly adjusted

#### Affected terminals

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check frequency valve		Replace frequency valve
2	Check pressure hoses for leaks		Replace pressure hoses or eliminate leaks
3	Check vacuum modulators for bypass flaps for leaks		Replace vacuum modulators
4	Check adjustment of bypass flaps		Adjust bypass flaps



## P1265

### 301 Airbag signal - signal implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Airbag control module
- ◆ Open circuit
- ◆ Short circuit to ground


#### Affected terminals

Terminal 34 and IV/16

#### Diagnosis/troubleshooting


Work instruction		Display OK	If not OK
1	Check wiring from airbag control module to DME control module for continuity <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of airbag control module</li> <li>◆ Measure resistance between special tool 9637 Pin IV/16 and airbag plug Pin 34</li> </ul>	0 - 5 $\Omega$ ⇒ Step 2	Check disconnection point X2/5 or check wiring harness for chafing and pinching damage → End

Airbag control module:



Work instruction		Display OK	If not OK
2	<p>Check wiring from airbag control module to DME control module for short circuit to ground</p> <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of airbag control module</li> <li>◆ Measure resistance between special tool 9637 Pin IV/16 and ground</li> </ul>	<p><math>\infty \Omega</math> ⇒ Step 3</p>	<p>Repair wiring harness → End</p>
3	<p>Check signal from airbag control module</p> <ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Connect engine tester (oscilloscope) to Pin IV/16 and ground</li> <li>◆ Use special input</li> <li>◆ Ignition on</li> </ul>	<p>⇒ Step 4</p>	<p>Replace airbag control module →</p>

Oscilloscope display:



Work instruction		Display OK	If not OK
4	Erase fault memory	→ End	→ End



## P1266

### 409 Fuel shutoff function monitor - signal implausible

#### Diagnosis conditions

- Engine speed > 1,120 rpm

#### Possible fault cause

- ◆ DME control module faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End





## P1324

### 325 Position of Camshaft in Relation to Crankshaft, Bank 2 – Below Limit

#### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1.200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- Reference mark OK
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

#### Possible fault cause

- ◆ Allocation of camshaft to inlet camshaft incorrect

#### Affected terminals

-

#### Diagnosis/Troubleshooting

#### **Note!**

*This fault is stored if the engine was disassembled and the allocation of the camshaft to the inlet camshaft was incorrectly set.*

Work instruction		Display OK	If not OK
1	Set camshafts	◆ To adjust the camshafts, please refer to the 911 Turbo (996) Technical Manual.	

## 325 Position of Camshaft in Relation to Crankshaft, Bank 2 – Above Limit

### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1.200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- Reference mark OK
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

### Possible fault cause

- ◆ Solenoid hydraulic valve camshaft adjustment faulty
- ◆ Allocation of camshaft to inlet camshaft incorrect

### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End
	<ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>		

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



Work instruction		Display OK	If not OK
2	Set camshafts	◆ To adjust the camshafts, please refer to the 911 Turbo (996) Technical Manual.	



## P1325

### 178 Camshaft Adjustment, Bank 2 – Signal Implausible

#### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6.760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

#### Possible fault cause



#### Note!

*Camshaft does not reach early or late position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

#### Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End
	<ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>		

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## 178 Camshaft Adjustment, Bank 2 – Below Limit

### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6.760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

### Possible fault cause



#### Note!

*Solenoid hydraulic valve is triggered, camshaft does not switch into early position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment <ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## 178 Camshaft Adjustment, Bank 2 – Above Limit

### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6.760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

### Possible fault cause



#### Note!

*Solenoid hydraulic valve is not triggered, camshaft does not switch into late position*



- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment <ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## P1328

### Inlet camshaft output stage – open circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

V/7

#### Diagnosis/troubleshooting



#### Note!

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 14*

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/7 and solenoid hydraulic valve connector pin 2</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery positive voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pins 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C	



## P1331

### Inlet camshaft output stage, bank 2 - open circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

V/8

#### Diagnosis/troubleshooting



#### Note!

*The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 15*

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/8 and solenoid hydraulic valve connector pin 2</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery positive voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pins 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C	



## P1340

### 322 Position of Camshaft in Relation to Crankshaft, Bank 1 – Below Limit

#### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1.200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- Reference mark OK
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

#### Possible fault cause

- ◆ Allocation of camshaft to inlet camshaft incorrect

#### Affected terminals

-

#### Diagnosis/Troubleshooting

#### **Note!**

*This fault is stored if the engine was disassembled and the allocation of the camshaft to the inlet camshaft was incorrectly set.*

Work instruction		Display OK	If not OK
1	Set camshafts	◆ To adjust the camshafts, please refer to the 911 Turbo (996) Technical Manual.	

## 322 Position of Camshaft in Relation to Crankshaft, Bank 1 – Above Limit

### Diagnosis conditions

- Idle speed
- Reference mark recognized
- Engine speed between 600 rpm and 1.200 rpm.
- Engine temperature greater than 40 °C
- No fault in camshaft position sensors
- Reference mark OK
- No fault in camshaft adjustment
- No fault in engine temperature
- No fault in camshaft adjustment output stage

### Possible fault cause

- ◆ Solenoid hydraulic valve camshaft adjustment faulty
- ◆ Allocation of camshaft to inlet camshaft incorrect

### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment <ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End



Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



Work instruction		Display OK	If not OK
2	Set camshafts	◆ To adjust the camshafts, please refer to the 911 Turbo (996) Technical Manual.	



## P1341

### 174 Camshaft Adjustment, Bank 1 – Signal Implausible

#### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6.760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

#### Possible fault cause



#### Note!

*Camshaft does not reach early or late position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

#### Affected terminals

### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment	<ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## 174 Camshaft Adjustment, Bank 1 – Below Limit

### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6.760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

### Possible fault cause



#### Note!

*Solenoid hydraulic valve is triggered, camshaft does not switch into early position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

Affected terminals

### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment	<ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## 174 Camshaft Adjustment, Bank 1 – Above Limit

### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6.760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

### Possible fault cause



#### Note!

*Solenoid hydraulic valve is not triggered, camshaft does not switch into late position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

Affected terminals

### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment	<ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil





## P1342

### 189 Camshaft Adjustment, Bank 1 Output Stage - Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

V/7

#### Diagnosis/Troubleshooting



#### Note!

The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 14

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/7 and solenoid hydraulic valve connector pin 2.</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery positive voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pin 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C	

## 189 Camshaft Adjustment, Bank 1 Output Stage - Below Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short to ground triggering wire
- ◆ Solenoid hydraulic valve faulty

### Affected terminals

V/7

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/7 and ground</li> </ul>	$\infty \Omega$
2	Replace solenoid hydraulic valve		

## 189 Camshaft Adjustment, Bank 1 Output Stage - Above Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short circuit to B+ triggering wire

### Affected terminals

V/7

**Diagnosis/Troubleshooting**

<b>Work instruction</b>			<b>Display OK</b>	<b>If not OK</b>
1	Check triggering wire for short circuit to B+	<ul style="list-style-type: none"><li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li><li>◆ Remove connector of the solenoid hydraulic valve</li><li>◆ Switch on the ignition</li><li>◆ Measure voltage between V/7 and ground</li></ul>	0 V	Repair wiring harness



## P1343

### 149 Camshaft Adjustment, Bank 2 Output Stage - Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

V/8

#### Diagnosis/Troubleshooting



#### Note!

The wiring for the solenoid hydraulic valve is routed via the connector X 59/1 pin 15

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/8 and solenoid hydraulic valve connector pin 2.</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery positive voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pin 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C	

## 149 Camshaft Adjustment, Bank 2 Output Stage - Below Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short to ground triggering wire
- ◆ Solenoid hydraulic valve faulty

### Affected terminals

V/8

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/8 and ground</li> </ul>	$\infty \Omega$
2	Replace solenoid hydraulic valve		

## 149 Camshaft Adjustment, Bank 2 Output Stage - Above Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short circuit to B+ triggering wire

### Affected terminals

V/8

**Diagnosis/Troubleshooting**

<b>Work instruction</b>			<b>Display OK</b>	<b>If not OK</b>
1	Check triggering wire for short circuit to B+	<ul style="list-style-type: none"><li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li><li>◆ Remove connector of the solenoid hydraulic valve</li><li>◆ Switch on the ignition</li><li>◆ Measure voltage between V/8 and ground</li></ul>	0 V	Repair wiring harness





## P1344

### 579 Valve Lift Control, Bank 1, Output Stage - Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

III/1

#### Diagnosis/Troubleshooting



#### Note!

The wiring for the solenoid hydraulic valve is routed via the connector X 59/3 pin 4

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/1 and solenoid hydraulic valve connector pin 2.</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery positive voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pin 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C	

## 579 Valve Lift Control, Bank 1, Output Stage - Below Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short to ground triggering wire
- ◆ Solenoid hydraulic valve faulty

### Affected terminals

III/1

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/1 and ground</li> </ul>	$\infty \Omega$
2	Replace solenoid hydraulic valve		

## 579 Valve Lift Control, Bank 1, Output Stage - Above Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short circuit to B+ triggering wire

### Affected terminals

III/1

**Diagnosis/Troubleshooting**

Work instruction			Display OK	If not OK
1	Check triggering wire for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between III/1 and ground</li> </ul>	0 V	Repair wiring harness



## P1345

### 580 Valve Lift Control, Bank 2, Output Stage - Open Circuit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Open circuit in triggering wire
- ◆ Open circuit in B+ supply
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

III/26

#### Diagnosis/Troubleshooting



**Note!**

The wiring for the solenoid hydraulic valve is routed via the connector X 59/3 pin 5

Work instruction			Display OK	If not OK
1	Check triggering wire for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/26 and solenoid hydraulic valve connector pin 2</li> </ul>	0 - 5 $\Omega$	
2	Check B+ supply for solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage of solenoid hydraulic valve connector pin 1 and ground</li> </ul>	Battery positive voltage	
3	Check resistance of solenoid hydraulic valve	<ul style="list-style-type: none"> <li>◆ Measure resistance of solenoid hydraulic valve between pin 1 and 2</li> </ul>	8 - 12 $\Omega$ at 20° C	

## 580 Valve Lift Control, Bank 2, Output Stage - Below Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short to ground triggering wire
- ◆ Solenoid hydraulic valve faulty

### Affected terminals

III/26

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of the solenoid hydraulic valve</li> <li>◆ Measure resistance between III/26 and ground</li> </ul>	$\infty \Omega$
2	Replace solenoid hydraulic valve		

## 580 Valve Lift Control, Bank 2, Output Stage - Above Limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short circuit to B+ triggering wire

### Affected terminals

III/26

**Diagnosis/Troubleshooting**

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
1	Check triggering wire for short circuit to B+. <ul style="list-style-type: none"><li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li><li>◆ Remove connector of the solenoid hydraulic valve</li><li>◆ Switch on the ignition</li><li>◆ Measure voltage between Ill/26 and ground</li></ul>	0 V	Repair wiring harness





## P1348

### Camshaft Adjustment, Bank 1 – Above Limit

#### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6.760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

#### Possible fault cause



#### Note!

*Solenoid hydraulic valve is not triggered, camshaft does not switch into late position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

#### Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End
	<ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>		

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## P1349

### Camshaft Adjustment, Bank 1 – Below Limit

#### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

#### Possible fault cause



#### Note!

*Solenoid hydraulic valve is triggered, camshaft does not switch into early position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

#### Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment <ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## P1350

### 637 Valve lift control checksum error - above limit

#### Diagnosis conditions

- Speed between 5,280 and 6,520 rpm
- Load between 125 and 190 %
- Acceleration with wide-open throttle

#### Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank does not change the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 %, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

**637 Valve lift control checksum error - below limit****Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm
- Load between 45 and 70 %
- Acceleration with wide-open throttle

**Possible fault cause**

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

**Affected terminals**

-

**Diagnosis/troubleshooting****Perform system test for small lift****Warning!**


***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*



#### **4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

If misfires are stored, perform the system test again.

#### **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

### **637 Valve lift control checksum error - signal implausible**

#### **Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm and between 5,280 and 6,520 rpm
- Load between 45 and 70 % and between 125 and 190 %
- Acceleration with wide-open throttle

#### **Possible fault cause**

- ◆ A valve does not switch to large lift
  - ◆ Several valves (various cylinders) do not switch to large lift
- and
- ◆ A valve does not switch to small lift
  - ◆ Several valves (various cylinders) do not switch to small lift

#### **Affected terminals**

-

### **Diagnosis/troubleshooting**

#### **Perform system test for large lift**

#### **Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank does not change the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 %, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**


**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**



**Note!**

- ◆ If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).
- ◆ It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.

**Perform system test for small lift**



**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Differ-

ence from the other oxygen sensor > approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

If misfires are stored, perform the system test again.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

## P1350 - 911 Carrera

### Valve lift control checksum error - signal implausible

#### Diagnosis conditions

- Engine idle and acceleration with wide-open throttle

#### Possible fault cause

- ◆ In large lift, a valve stays at small lift, and in small lift, a valve stays at large lift
- ◆ In large lift, several valves (different cylinders) stay at small lift, and in small lift, several valves stay at large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for small lift

#### **Note!**

*The test is carried out at standstill with the engine running*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2,000 rpm and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3,000 rpm and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

Perform system test for large lift

 **Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

## P1351

### 627 Valve lift control, cylinder 1 - above limit

#### Diagnosis conditions

- Speed between 5,280 and 6,520 rpm
- Load between 125 and 190 %
- Acceleration with wide-open throttle

#### Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.


Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.



If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**627 Valve lift control, cylinder 1 - below limit****Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm
- Load between 45 and 70 %
- Acceleration with wide-open throttle

**Possible fault cause**

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

**Affected terminals**

-

**Diagnosis/troubleshooting****Perform system test for small lift****Warning!**


***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

#### **4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

#### **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

### **627 Valve lift control, cylinder 1 - signal implausible**

#### **Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm and between 5,280 and 6,520 rpm
- Load between 45 and 70 % and between 125 and 190 %
- Acceleration with wide-open throttle

#### **Possible fault cause**

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

and

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

#### **Affected terminals**

-

### **Diagnosis/troubleshooting**

#### **Perform system test for large lift**

#### **Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  $F_8$  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

 **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**Perform system test for small lift**

 **Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during

acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor > approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*



## P1351 - 911 Carrera

Valve lift control, cylinder 1 - below limit

Diagnosis conditions

- Acceleration with wide-open throttle

Possible fault cause

- ◆ A valve stays at small lift
- ◆ Several valves (various cylinders) do not switch to large lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1352

### 628 Valve lift control, cylinder 6 - above limit

#### Diagnosis conditions

- Speed between 5,280 and 6,520 rpm
- Load between 125 and 190 %
- Acceleration with wide-open throttle

#### Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**628 Valve lift control, cylinder 6 - below limit****Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm
- Load between 45 and 70 %
- Acceleration with wide-open throttle

**Possible fault cause**

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

**Affected terminals**

-

**Diagnosis/troubleshooting****Perform system test for small lift****Warning!**


***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  $F_8$  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

#### **4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

#### **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

### **628 Valve lift control, cylinder 6 - signal implausible**

#### **Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm and between 5,280 and 6,520 rpm
- Load between 45 and 70 % and between 125 and 190 %
- Acceleration with wide-open throttle

#### **Possible fault cause**

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

and

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

#### **Affected terminals**

-

### **Diagnosis/troubleshooting**

#### **Perform system test for large lift**

#### **Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.





**A - Oxygen sensor, bank 1****B - Oxygen sensor, bank 2****1 - Select system test.****2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key F8 immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.****Note!**

- ◆ If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).
- ◆ It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.
- ◆ If misfires are stored, see Troubleshooting misfires.

**Perform system test for small lift****Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during

acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor > approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

## P1352 - 911 Carrera

Valve lift control, cylinder 6 - below limit

Diagnosis conditions

- Acceleration with wide-open throttle

Possible fault cause

- ◆ A valve stays at small lift
- ◆ Several valves (various cylinders) do not switch to large lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1353

### 629 Valve lift control, cylinder 2 - above limit

#### Diagnosis conditions

- Speed between 5,280 and 6,520 rpm
- Load between 125 and 190 %
- Acceleration with wide-open throttle

#### Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**629 Valve lift control, cylinder 2 - below limit****Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm
- Load between 45 and 70 %
- Acceleration with wide-open throttle

**Possible fault cause**

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

**Affected terminals**

-

**Diagnosis/troubleshooting****Perform system test for small lift****Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  $F_8$  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

#### **4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

#### **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

### **629 Valve lift control, cylinder 2 - signal implausible**

#### **Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm and between 5,280 and 6,520 rpm
- Load between 45 and 70 % and between 125 and 190 %
- Acceleration with wide-open throttle

#### **Possible fault cause**

- ◆ A valve does not switch to large lift
  - ◆ Several valves (various cylinders) do not switch to large lift
- and
- ◆ A valve does not switch to small lift
  - ◆ Several valves (various cylinders) do not switch to small lift

#### **Affected terminals**

-

### **Diagnosis/troubleshooting**

#### **Perform system test for large lift**

#### **Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1****B - Oxygen sensor, bank 2****1 - Select system test.****2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key F8 immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.****Note!**

- ◆ If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).
- ◆ It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.
- ◆ If misfires are stored, see Troubleshooting misfires.

**Perform system test for small lift****Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during

acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor > approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

## P1353 - 911 Carrera

Valve lift control, cylinder 2 - below limit

Diagnosis conditions

- Acceleration with wide-open throttle

Possible fault cause

- ◆ A valve stays at small lift
- ◆ Several valves (various cylinders) do not switch to large lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.





## P1354

### 630 Valve lift control, cylinder 4 - above limit

#### Diagnosis conditions

- Speed between 5,280 and 6,520 rpm
- Load between 125 and 190 %
- Acceleration with wide-open throttle

#### Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**630 Valve lift control, cylinder 4 - below limit****Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm
- Load between 45 and 70 %
- Acceleration with wide-open throttle

**Possible fault cause**

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

**Affected terminals**

-

**Diagnosis/troubleshooting****Perform system test for small lift****Warning!**


***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  $F_8$  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

#### **4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

#### **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

### **630 Valve lift control, cylinder 4 - signal implausible**

#### **Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm and between 5,280 and 6,520 rpm
- Load between 45 and 70 % and between 125 and 190 %
- Acceleration with wide-open throttle

#### **Possible fault cause**

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

and

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

#### **Affected terminals**

-

### **Diagnosis/troubleshooting**

#### **Perform system test for large lift**

#### **Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**


**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**



**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**Perform system test for small lift**



**Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during

acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor > approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**



At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

## P1354 - 911 Carrera

Valve lift control, cylinder 4 - below limit

Diagnosis conditions

- Acceleration with wide-open throttle

Possible fault cause

- ◆ A valve stays at small lift
- ◆ Several valves (various cylinders) do not switch to large lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1355

### 631 Valve lift control, cylinder 3 - above limit

#### Diagnosis conditions

- Speed between 5,280 and 6,520 rpm
- Load between 125 and 190 %
- Acceleration with wide-open throttle

#### Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for large lift



**Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**631 Valve lift control, cylinder 3 - below limit****Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm
- Load between 45 and 70 %
- Acceleration with wide-open throttle

**Possible fault cause**

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

**Affected terminals**

-

**Diagnosis/troubleshooting****Perform system test for small lift****Warning!**


***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**i Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

#### **4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

#### **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

### **631 Valve lift control, cylinder 3 - signal implausible**

#### **Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm and between 5,280 and 6,520 rpm
- Load between 45 and 70 % and between 125 and 190 %
- Acceleration with wide-open throttle

#### **Possible fault cause**

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

and

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

#### **Affected terminals**

-

### **Diagnosis/troubleshooting**

#### **Perform system test for large lift**

#### **Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**




During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1****B - Oxygen sensor, bank 2****1 - Select system test.****2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key F8 immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.** **Note!**

- ◆ If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).
- ◆ It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.
- ◆ If misfires are stored, see Troubleshooting misfires.

**Perform system test for small lift** **Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during

acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor > approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

## P1355 - 911 Carrera

Valve lift control, cylinder 3 - below limit

Diagnosis conditions

- Acceleration with wide-open throttle

Possible fault cause

- ◆ A valve stays at small lift
- ◆ Several valves (various cylinders) do not switch to large lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for large lift

### **Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1356

### 632 Valve lift control, cylinder 5 - above limit

#### Diagnosis conditions

- Speed between 5,280 and 6,520 rpm
- Load between 125 and 190 %
- Acceleration with wide-open throttle

#### Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

#### Affected terminals

-

### Diagnosis/troubleshooting

#### Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ ) ⇒ see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.

If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.**



**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*
- ◆ *If misfires are stored, see Troubleshooting misfires.*

**632 Valve lift control, cylinder 5 - below limit****Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm
- Load between 45 and 70 %
- Acceleration with wide-open throttle

**Possible fault cause**

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

**Affected terminals**

-

**Diagnosis/troubleshooting****Perform system test for small lift****Warning!**


***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor  $>$  approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  $\boxed{F8}$  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**$\boxed{i}$  Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

#### **4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.



#### **Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

### **632 Valve lift control, cylinder 5 - signal implausible**

#### **Diagnosis conditions**

- Speed between 2,000 and 3,320 rpm and between 5,280 and 6,520 rpm
- Load between 45 and 70 % and between 125 and 190 %
- Acceleration with wide-open throttle

#### **Possible fault cause**

- ◆ A valve does not switch to large lift
  - ◆ Several valves (various cylinders) do not switch to large lift
- and
- ◆ A valve does not switch to small lift
  - ◆ Several valves (various cylinders) do not switch to small lift

#### **Affected terminals**

-

### **Diagnosis/troubleshooting**

#### **Perform system test for large lift**



#### **Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for large lift, the valves remain at large lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to large lift, the fault type 'over limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank hardly changes the mixture at all given acceleration with wide-open throttle ( $F_R$  at 1) and enriches the mixture in the opposite cylinder bank ( $F_R > 1$ )  $\Rightarrow$  see drawing below. Given a difference between  $F_{R1}$  and  $F_{R2}$  of more than 8 % during acceleration with wide-open throttle, a fault is certainly present.


If the difference is less than 4 %, 1 valve may be faulty on both cylinder banks. In this case, all flat-base tappets of the inlet valves must be replaced.



**A - Oxygen sensor, bank 1****B - Oxygen sensor, bank 2****1 - Select system test.****2 - Select 'Request large lift'.**

If "Valve diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key  immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" appears.****Note!**

- ◆ If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).
- ◆ It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.
- ◆ If misfires are stored, see *Troubleshooting misfires*.

**Perform system test for small lift****Warning!**

**Test is carried out while driving. Have a second person operate the Porsche System Tester 2.**


During the system test for small lift, the valves remain at small lift, regardless of the type of driving. Faulty switching conditions can be detected by rough running, just like with misfire detection. If a valve is not switched to small lift, the fault type 'under limit' is recorded.

Several cylinders may be stored as faulty, although only 1 valve on one cylinder is faulty.

In order to guarantee safety during repairs, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.

A faulty flat-base tappet can be detected because the oxygen sensor  $F_R$  for this cylinder bank enriches the mixture ( $F_R > 1$ ) during

acceleration with wide-open throttle  $\Rightarrow$  see drawing below. Difference from the other oxygen sensor > approx. 15 %. In the case of a fault, the flat-base tappets of the inlet valves for the entire cylinder bank must be replaced.



**A - Oxygen sensor, bank 1**

**B - Oxygen sensor, bank 2**

**1 - Select system test.**

**2 - Select 'Request small lift'.**

If "Valve lift diagnosis not ready" appears, a fault may have been stored.

1. Erase the fault memory.

**3 - Activate the system test with the key **F8** immediately before acceleration with wide-open throttle.**

The message "Drive link active" then appears.



**Note!**

*If 'Request small lift' appears, the valves remain at small lift, ie. the performance is reduced dramatically.*

**4 - Perform acceleration with wide-open throttle in 2nd gear, until "Valve lift diagnosis complete" (max. 4,000 rpm) appears.**

At speeds above 4,000 rpm, misfires may be stored. Delete the fault memory and repeat the test.

**Note!**

- ◆ *If a fault is detected, it is only recorded in the fault memory after 6,000 ignitions (at idling speed approx. 3 minutes waiting time).*
- ◆ *It is important to observe the oxygen sensor during acceleration with wide-open throttle or to record its behaviour with the data logger.*

## P1356 - 911 Carrera

Valve lift control, cylinder 5 - below limit

Diagnosis conditions

- Acceleration with wide-open throttle

Possible fault cause

- ◆ A valve stays at small lift
- ◆ Several valves (various cylinders) do not switch to large lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for large lift

### **Warning!**

***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.





## P1357

### Camshaft Adjustment, Bank 2– Above Limit

#### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

#### Possible fault cause



#### Note!

*Solenoid hydraulic valve is not triggered, camshaft does not switch into late position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

#### Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment <ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## P1358

### Camshaft Adjustment, Bank 2– Below Limit

#### Diagnosis conditions

- Time elapsed after start-up greater than 5 seconds
- Engine temperature greater than -10 °C
- Engine speed between 680 rpm and 6760 rpm
- No fault in camshaft adjustment output stage
- Reference mark OK
- No fault in camshaft position sensors
- No fault in engine temperature

#### Possible fault cause



#### Note!

*Solenoid hydraulic valve is triggered, camshaft does not switch into early position*

- ◆ Dirt in system
- ◆ Solenoid hydraulic valve mechanically blocked

#### Affected terminals

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check solenoid hydraulic valve camshaft adjustment <ul style="list-style-type: none"> <li>◆ Remove connector on solenoid hydraulic valve</li> <li>◆ Connect special tool 9675 to the solenoid hydraulic valve and to a power supply.</li> <li>◆ Connect oscilloscope or engine tester to the special tool 9675</li> <li>◆ Set 12 V</li> <li>◆ See Figure 1.</li> <li>◆ Set switch on special tool 9675 to 1</li> </ul>	See Figure 2 ⇒ Step 2	Replace solenoid hydraulic valve →End

Figure 1:





Figure 2:

- 1 - Voltage not applied yet, valve in output state
- 2 - Exponential voltage increase, magnetic field is built up, increase of the spring preload force
- 3 - Valve starts to move, spring force increases, valve reaches end position
- 4 - Exponential voltage increase, current limitation through self-induction of the coil



## P1359 - 911 Carrera

Valve lift control, cylinder 1 - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for small lift



### Note!

*The test is carried out at standstill with the engine running*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2,000 rpm and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3,000 rpm and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1360 - 911 Carrera

Valve lift control, cylinder 6 - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for small lift



### Note!

*The test is carried out at standstill with the engine running*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2,000 rpm and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3,000 rpm and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.





## P1361 - 911 Carrera

Valve lift control, cylinder 2 - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

Affected terminals

-

### Diagnosis/Troubleshooting

Perform system test for small lift



#### Note!

*The test is carried out with the engine running at a standstill*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2 000 1/min and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3 000 1/min and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1362 - 911 Carrera

Valve lift control, cylinder 4 - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for small lift



### Note!

*The test is carried out at standstill with the engine running*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2,000 rpm and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3,000 rpm and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1363 - 911 Carrera

Valve lift control, cylinder 3 - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for small lift



### Note!

*The test is carried out at standstill with the engine running*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2,000 rpm and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3,000 rpm and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1364 - 911 Carrera

Valve lift control, cylinder 5 - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ A valve does not switch to small lift
- ◆ Several valves (various cylinders) do not switch to small lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for small lift



### Note!

*The test is carried out at standstill with the engine running*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2,000 rpm and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3,000 rpm and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1371 - 911 Carrera

Valve lift control checksum error - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ Several valves (various cylinders) do not switch to small lift



### Note!

*The checksum error is only stored in connection with errors in valve lift control of cylinders 1 - 6.*

Affected terminals

-

## Diagnosis/troubleshooting

Perform system test for small lift



### Note!

*The test is carried out at standstill with the engine running*

#### **1 - Select system test.**

#### **2 - Select "Request small lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Increase the engine speed to 2,000 rpm and hold for 30 seconds.
2. Then press the F8 key.
3. Increase the engine speed to 3,000 rpm and hold for 30 seconds.
4. Operate the engine for 30 seconds at engine idle speed.

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1374 - 911 Carrera

Valve lift control checksum error - below limit

Diagnosis conditions

- Acceleration with wide-open throttle

Possible fault cause

- ◆ A valve does not switch to large lift
- ◆ Several valves (various cylinders) do not switch to large lift

Affected terminals

-

Diagnosis/troubleshooting

Perform system test for large lift



***Test is carried out while driving. Have a second person operate the Porsche System Tester 2.***

**1 - Select system test.**

**2 - Select "Request large lift".**

If "Valve lift diagnosis not ready" appears, a fault may have been stored. In this case, delete the fault memory.

The engine must be at operating temperature.

1. Carry out acceleration with wide-open throttle in 2nd gear up to 7,000 rpm. Test in manual range for Tiptronic vehicles

After 3,000 ignitions the Tester indicates whether a fault is present or not.

In order to ensure that the fault is repaired, the flat-base tappets of the inlet valves of the entire cylinder bank should be replaced if a fault occurs.



## P1384

### 220 Knock control zero test - signal implausible

#### Diagnosis conditions

- Engine speed less than 5,600 rpm
- Knock control active
- Engine load greater than 45 %

#### Possible fault cause

- ◆ DME control module



#### Note!

When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	



## P1385

### 221 Knock control offset - signal implausible

#### Diagnosis conditions

- Engine speed less than 5,600 rpm
- Knock control active
- Engine load greater than 45 %

#### Possible fault cause

- ◆ DME control module



#### Note!

When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module		⇒ Step 2
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	





## P1386

### 222 Knock control test pulse - signal implausible

#### Diagnosis conditions

- Engine speed less than 5,600 rpm
- Knock control active
- Engine load greater than 45 %

#### Possible fault cause

- ◆ DME control module



#### Note!

When a fault is stored, the ignition angle is retarded for all cylinders in the range in which knock control is active.

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	



## P1397

### 113 Camshaft position sensor 2 - signal implausible

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Loose contact
- ◆ Camshaft position sensor



#### Note!

- ◆ If both CMP sensor signals are missing, the start will take at least 10 seconds.
- ◆ For safety reasons, the ignition timing is retarded.

#### Affected terminals


Terminals Ill/7, Ill/17 and Ill/18

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check CMP sensor voltage supply	<ul style="list-style-type: none"> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between Pin 1 and Pin 3</li> </ul>	Approx. 5 V ⇒ Step 5	⇒ Step 2
2	Check power supply wiring for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin Ill/7 and CMP sensor 2 plug Pin 3</li> <li>◆ Measure resistance between special tool 9637 Pin Ill/17 and CMP sensor 2 plug Pin 1</li> </ul>	0 - 5 Ω ⇒ Step 3	
3	Replace DME control module		⇒ Step 4	

Work instruction			Display OK	If not OK
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	
5	Check CMP sensor signal	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637</li> <li>◆ Connect engine tester; use special input</li> <li>◆ Positive cable to Pin III/18</li> <li>◆ Negative cable to Pin III/17</li> <li>◆ Start the engine</li> </ul>	See Figure 1 ⇒ Step 6	Replace CMP sensor → End

Figure 1:



Work instruction		Display OK	If not OK
6	Check signal wire from DME control module, Pin III/18, to CMP sensor <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Measure resistance between special tool 9637 Pin III/18 and CMP sensor 2 plug Pin 2</li> </ul>	0 - 5 $\Omega$ → End	Repair wiring harness → End

## 113 Camshaft position sensor 2 - below limit

### Diagnosis conditions

- Engine running

### Possible fault cause

- ◆ Short circuit to ground

### **i** Note!

- ◆ If both CMP sensor signals are missing, the start will take at least 10 seconds.
- ◆ For safety reasons, the ignition timing is retarded.

### Affected terminals

Terminal III/18

## Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check signal wire from DME control module, Pin III/18, to CMP sensor for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Measure resistance between special tool 9637 Pin III/18 and ground</li> </ul>	$\infty \Omega$ → End  Repair wiring harness → End

### 113 Camshaft position sensor 2 - above limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Short circuit to B+



#### Note!

- ◆ If both CMP sensor signals are missing, the start will take at least 10 seconds.
- ◆ For safety reasons, the ignition timing is retarded.

#### Affected terminals

Terminal III/18

## Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check signal wire from DME control module, Pin III/18, to CMP sensor for short to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of CMP sensor 2</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 Pin III/18 and ground</li> </ul>	0 V → End  Repair wiring harness → End

## P1411

### 208 Secondary Air Injection System, Bank 2 – Below Limit

#### Diagnosis conditions

- Intake air temperature 4.5 - 60 °C
- Engine temperature 4.5 - 102 °C
- Mass air flow 36 - 150 kg/h
- Engine starting temperature less than 42 °C
- Altitude correction factor greater than 0.75
- Oxygen sensors 1 and 2 ahead of TWC are ready for operation
- The secondary air injection pump is switched on
- Diagnosis has not yet taken place during this cycle

#### Possible fault cause

- ◆ Secondary air injection pump is not triggered
- ◆ Secondary air injection pump does not work
- ◆ Air supply lines restricted
- ◆ Electric change-over valve does not function
- ◆ Air change-over valve does not function
- ◆ Vacuum system leaks

#### Affected terminals

III/11 and III/14

#### Diagnosis/troubleshooting

**Note!**

Secondary air diagnosis can be activated with the Porsche System Tester 2 in the "Short test" menu.

Work instruction		Display OK	If not OK
1	Activate secondary air pump	⇒ Step 3	⇒ Step 2
	<ul style="list-style-type: none"> <li>◆ Remove relay of secondary air injection pump.</li> <li>◆ Jumper terminals 30 and 87.</li> <li>◆ The secondary air pump must be running (audible function).</li> <li>– or</li> <li>◆ Connect and switch on Porsche System Tester 2.</li> <li>◆ Select DME.</li> <li>◆ Call up "Drive links" menu.</li> <li>◆ Select "Secondary air pump".</li> <li>◆ Activate secondary air pump (audible function).</li> </ul>		
2	Check triggering of secondary air pump	Battery positive voltage	Check wire from pin 2 to DME control module pin III/11 for continuity.
	<ul style="list-style-type: none"> <li>◆ Check fuse (Maxi Fuse) of AIR pump (on relay carrier 2).</li> <li>◆ Remove relay of AIR pump (on relay carrier 2).</li> <li>◆ Measure voltage between pin 3 and ground</li> <li>◆ Push relay back on.</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove connector of AIR pump.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>	Battery positive voltage	
3	Check vacuum system for leaks		Seal vacuum system
4	Check electric change-over valve	Battery positive voltage	
	<ul style="list-style-type: none"> <li>◆ Remove two-pole connector of electric change-over valve.</li> <li>◆ Trigger AIR pump with Porsche System Tester 2.</li> <li>◆ Measure voltage at pin 1 and pin 2</li> </ul>		
	<ul style="list-style-type: none"> <li>◆ Remove vacuum hose of electric change-over valve with the engine running.</li> </ul>	Vacuum must be present	



Work instruction			Display OK	If not OK
5	Check air change-over valve	<ul style="list-style-type: none"> <li>◆ Run engine briefly to produce vacuum.</li> <li>◆ Activate secondary air pump.</li> <li>◆ Remove vacuum hose of air change-over valve.</li> </ul>	Vacuum must be present	
		<ul style="list-style-type: none"> <li>◆ After activation, check pneumatic change-over valve for continuity</li> </ul>		
6	Check air supply lines for blockage			



## P1455

### 170 A/C compressor control - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Air conditioning on

#### Possible fault cause

- ◆ A/C relay
- ◆ Open circuit in wiring

#### Affected terminals

Terminal IV/27

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check A/C relay	<ul style="list-style-type: none"> <li>◆ Remove A/C relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2  Replace A/C relay → End
2	Check control wire for A/C relay, Pin 2 (terminal 85), for open circuit	<ul style="list-style-type: none"> <li>◆ Remove A/C relay</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin IV/27 and A/C relay plug Pin 2</li> </ul>	0 - 5 $\Omega$ → End  Repair wiring harness → End



## P1456

### 170 A/C compressor control - above limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Air conditioning on

#### Possible fault cause

- ◆ Short circuit to B+ in wiring

#### Affected terminals

Terminal IV/27

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check control wire for A/C relay, Pin 2 (terminal 85), for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove A/C relay</li> <li>◆ Remove DME control module connector</li> <li>◆ Measure voltage between A/C relay Pin 2 and ground</li> <li>◆ Ignition on</li> </ul>	0 V → End  Repair wiring harness → End



## P1457

### 170 A/C compressor control - below limit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Air conditioning on

#### Possible fault cause

- ◆ Short circuit to ground in wiring

#### Affected terminals

Terminal IV/27

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check control wire for A/C relay, Pin 2 (terminal 85), for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove A/C relay</li> <li>◆ Remove DME control module connector</li> <li>◆ Measure resistance between Pin 2 (terminal 85) and ground</li> </ul>	<ul style="list-style-type: none"> <li>◆ <math>\infty \Omega</math> → End</li> <li>◆ Repair wiring harness → End</li> </ul>





## P1501

### 403 Throttle jacking unit, output stage - signal implausible

#### Diagnosis conditions

- Engine idling

#### Possible fault cause

- ◆ Short circuit in wiring harness
- ◆ DME control module output stage faulty

#### Affected terminals

Terminal I/7



#### Note!

The vehicle is in emergency air function mode, i.e. the engine is turning at approx. 1200 rpm.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module Pin I/7 to the throttle jacking unit for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between Pin I/7 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0 V ⇒ Step 2  Repair wiring harness → End
2	Check wiring from DME control module Pin I/7 to the throttle jacking unit for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between Pin I/7 and ground</li> </ul>	$\infty \Omega$ → End  Repair wiring harness → End



## P1502

### 412 Throttle jacking unit, spring test - above limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Stationary vehicle
- Engine not running
- Engine temperature greater than 5 °C
- Intake air temperature greater than 5 °C

#### Possible fault cause

- ◆ Throttle part

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace throttle part	⇒ Step 2	
2	Erase fault memory	⇒ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Actuate accelerator pedal</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P1503

### 402 Throttle Jacking Unit, Position Error - Signal Implausible

#### Diagnosis conditions

- Driving with changing pedal position

#### Possible fault cause

- ◆ Short circuit in wiring harness
- ◆ Sluggish throttle

#### Affected terminals

Terminal I/9 and I/7



#### Note!


The vehicle is in emergency function mode, i.e. the engine is turning at approx. 1200 rpm.

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module pin I/7 to the throttle jacking unit for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/7 and ground.</li> <li>◆ Switch on the ignition.</li> </ul> Low battery voltage ⇒ Step 2.	Repair wiring harness → End.
2	Check wiring from DME control module pin I/9 to the throttle jacking unit for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/9 and ground.</li> <li>◆ Switch on the ignition.</li> </ul> Low battery voltage ⇒ Step 3.	Repair wiring harness → End.
3	Check wiring from DME control module pin I/7 to the throttle part for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/7 and pin I/2.</li> </ul> 0 V ⇒ Step 4.	Repair wiring harness → End.

Work instruction		Display OK	If not OK
4	Check wiring from DME control module pin I/9 to the throttle part for short circuit to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/9 and pin I/2.</li> </ul>	0 V ⇒ Step 5.  Repair wiring harness → End.
5	Check wiring from DME control module, pin I/7, for short circuit to wire, pin I/9.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of throttle part.</li> <li>◆ Measure resistance between pin I/7 and pin I/9.</li> </ul>	$\infty \Omega$ ⇒ Step 6.  Repair wiring harness → End.

Remove connector of throttle part:



Work instruction			Display OK	If not OK
6	Check resistance of motor actuator in throttle part.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between pin I/7 and pin I/9.</li> </ul>	1,2 - 1,6 $\Omega$ (at 20 °C) ⇒ Step 7.	Replace throttle part ⇒ Step 8.
7	Replace DME control module.		⇒ Step 8.	
8	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.





## P1504

### 410 Throttle jacking unit, emergency air position - signal implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)

#### Possible fault cause

- ◆ No adaptation performed
- ◆ Throttle part

#### Affected terminals

-

#### Note!

The fault is entered during the adaptation phase.

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	Fault entered ⇒ Step 2	→ End
2	Replace throttle part	⇒ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Actuate accelerator pedal</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P1505

### 404 Throttle Jacking Unit, Control Range - Open Circuit

#### Diagnosis conditions

- Driving with changing pedal position

#### Possible fault cause

- ◆ Open circuit
- ◆ Short circuit to B+


#### Affected terminals

Terminal I/7 and I/9

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	<p>Check wiring from DME control module pin I/7 to the throttle part for continuity.</p> <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of throttle part.</li> <li>◆ Measure resistance between special tool 9637 pin I/7 and throttle part plug connection pin 4.</li> </ul>	<p>0 - 5 <math>\Omega</math> ⇒ Step 2.</p>	<p>Repair wiring harness → End.</p>

Remove connector of throttle part:



Work instruction		Display OK	If not OK	
2	Check wiring from DME control module pin I/9 to the throttle part for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of throttle part.</li> <li>◆ Measure resistance between special tool 9637 pin I/9 and throttle part plug connection pin 1.</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3.	Repair wiring harness → End.
3	Check resistance of motor actuator in throttle part.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Measure resistance between special tool 9637 pin I/7 and pin I/9.</li> </ul>	1.2 to 1.6 $\Omega$ (at 20 °C) ⇒ Step 4.	Replace throttle part → End.
4	Replace DME control module.	⇒ Step 5.		
5	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.

## 404 Throttle Jacking Unit, Control Range - Below Limit

### Diagnosis conditions

- Driving with changing pedal position

**Possible fault cause**

- ◆ Open circuit
- ◆ Short circuit to B+

**Affected terminals**

Terminal I/7 and I/9

**Diagnosis/Troubleshooting**

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, pin I/7, to throttle part for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/7 and ground.</li> <li>◆ Switch on the ignition.</li> </ul>	Low battery voltage ⇒ Step 2.
2	Check wiring from DME control module, pin I/9, to throttle part for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/9 and ground.</li> <li>◆ Switch on the ignition.</li> </ul>	Low battery voltage → End.

**404 Throttle Jacking Unit, Control Range - Above Limit****Diagnosis conditions**

- Driving with changing pedal position

**Possible fault cause**

- ◆ Short circuit to ground
- ◆ Short circuit triggering wire
- ◆ Sluggish throttle

**Affected terminals**

Terminal I/7 and I/9

**Diagnosis/Troubleshooting**

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
1	Check wiring from DME control module, pin I/7, to throttle part for short circuit to ground. <ul style="list-style-type: none"><li>◆ Connect special tool 9637.</li><li>◆ Measure voltage between pin I/7 and pin I/2.</li></ul>	0 V ⇒ Step 2.	Repair wiring harness → End.
2	Check wiring from DME control module, pin I/9, to throttle part for short circuit to ground. <ul style="list-style-type: none"><li>◆ Connect special tool 9637.</li><li>◆ Measure voltage between pin I/9 and pin I/2.</li></ul>	0 V → End.	Repair wiring harness → End.

## P1506

### 413 Throttle jacking unit lower mechanical stop - signal implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Stationary vehicle
- Engine not running
- Engine temperature between 5 and 100 °C
- Intake air temperature between 5 and 100 °C
- Battery voltage greater than 10 V
- Pedal value less than 0.8 %

#### Possible fault cause

- ◆ No adaptation performed

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	Fault is being entered ⇒ Step 2
2	Replace throttle part	⇒ Step 1	





## P1507

### 411 Throttle jacking unit, gain adjustment - signal implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Stationary vehicle
- Engine not running
- Engine temperature between 5 and 100 °C
- Intake air temperature between 5 and 100 °C
- Battery voltage greater than 10 V
- Pedal value less than 0.8 %

#### Possible fault cause

- ◆ DME control module faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P1508

### 408 Torque comparison function monitor - signal implausible

#### Diagnosis conditions

- Engine speed greater than 1,120 rpm

#### Possible fault cause

- ◆ DME control module faulty

#### Affected terminals

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module	⇒ Step 2	
2	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P1509

### 429 Torque Limiter

#### Diagnosis conditions

- Driving operation

#### Possible fault cause

- ◆ DME control module

#### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace DME control module.		
2	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute. Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>		



## P1510

### 542 Throttle jacking unit - exchange detection without adaptation - signal implausible

#### Diagnosis conditions

- Ignition on
- Stationary vehicle
- Engine not running
- Engine temperature between 5 and 100 °C
- Intake air temperature between 5 and 100 °C
- Battery voltage greater than 10 V
- Pedal value less than 0.8 %

#### Possible fault cause

- ◆ No new adaptation after replacement of throttle part

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Actuate accelerator pedal</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End





## P1511

### 543 Throttle jacking unit - abortion of test due to negative influence on ambient condition

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Starting the vehicle during adaptation after replacement of throttle part

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End
2				



## P1512

### 76 Ambient Temperature (via CAN from instrument cluster) - Signal Implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Instrument cluster

#### Affected terminals

### Diagnosis/Troubleshooting



#### Note!

With an outside temperature of less than or equal to  $-40^{\circ}\text{C}$ , this fault is stored because no lower temperatures can be displayed in the instrument cluster. In this case, a fault status is not present.

Work instruction		Display OK	If not OK
1	Replace instrument cluster.		



## P1513

### 541 Throttle jacking unit, spring test - above limit/ below limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Stationary vehicle
- Engine not running
- Engine temperature greater than 5 °C
- Intake air temperature greater than 5 °C

#### Possible fault cause

- ◆ Throttle part

#### Affected terminals

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace throttle part	⇒ Step 2	
2	Erase fault memory	⇒ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	→ End



## P1514

### 540 Throttle jacking unit lower mechanical stop - signal implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ No adaptation values available despite repeated adaptations

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace throttle part	⇒ Step 2	
2	Perform adaptation	→ End	→ End
	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>		





## P1515

### Throttle Jacking Unit, Spring Test – Above Limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Stationary vehicle
- Engine not running
- Engine temperature greater than 5°C
- Intake air temperature greater than 5 °C

#### Possible fault cause

- ◆ Throttle part

#### Affected terminals

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace throttle part	⇒ Step 2	
2	Erase Fault Memory	⇒ Step 3	
3	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.



## P1516

### Throttle Jacking Unit, Control Range - Above Limit

#### Diagnosis conditions

- Driving with changing pedal position

#### Possible fault cause

- ◆ Short circuit to ground
- ◆ Short circuit triggering wire
- ◆ Sluggish throttle

#### Affected terminals

Terminal I/7 and I/9

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, pin I/7, to throttle part for short circuit to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/7 and pin I/2.</li> </ul> 0 V ⇒ Step 2	Repair wiring harness → End.
2	Check wiring from DME control module, Pin I/9, to throttle part for short circuit to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between Pin I/9 and Pin I/2.</li> </ul> 0 V → End.	Repair wiring harness → End.



## P1517

### Throttle Jacking Unit, Abortion of Test due to Negative Influence on Ambient Condition - Above Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Starting the vehicle during adaptation after replacement of throttle part

#### Affected terminals

-

#### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Perform adaptation.	<ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute. Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	→ End.



## P1518

### Throttle Jacking Unit, Control Range – Below Limit

#### Diagnosis conditions

- Driving with changing pedal position

#### Possible fault cause

- ◆ Open circuit
- ◆ Short circuit to B+

#### Affected terminals

Terminal I/7 and I/9

#### Diagnosis/Troubleshooting

Work instruction			Display OK	If not OK
1	Check wiring from DME control module, pin I/7, to throttle part for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/7 and ground.</li> <li>◆ Switch on the ignition.</li> </ul>	Low battery voltage ⇒ Step 2.	Repair wiring harness → End.
2	Check wiring from DME control module, pin I/9, to throttle part for short circuit to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637.</li> <li>◆ Measure voltage between pin I/9 and ground.</li> <li>◆ Switch on the ignition.</li> </ul>	Low battery voltage → End.	Repair wiring harness → End.





## P1546

### 171 Charge Pressure Control Valve Output Stage - Above Limit

#### Diagnosis conditions

- Charge pressure control active

#### Possible fault cause

- ◆ Charge pressure control valve (coil) short circuit
- ◆ Short circuit to B+

#### Affected terminals

III/4

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check charge pressure control valve.	◆ Measure resistance at the charge pressure control valve.	20 - 26 $\Omega$ at 20 °C.
2	Check wiring harness for short to B+.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of charge pressure control valve.</li> <li>◆ Ignition on.</li> <li>◆ Measure voltage between special tool 9637 pin III/4 and ground.</li> </ul>	0 V.  Repair wiring harness.



## P1547

### 171 Charge Pressure Control Valve Output Stage - Below Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Short circuit to ground

#### Affected terminals

III/4

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring harness for short to ground.	$\infty \Omega$	Repair wiring harness.
	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of charge pressure control valve.</li> <li>◆ Measure resistance between special tool 9637 pin III/4 and ground.</li> </ul>		



## P1548

### 171 Charge Pressure Control Valve Output Stage - Open Circuit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Charge pressure control valve (coil) open circuit
- ◆ Open circuit in wiring

#### Affected terminals

III/4

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check charge pressure control valve.	◆ Measure resistance at the charge pressure control valve.	20 - 26 $\Omega$ at 20 °C.
2	Check wiring harness for open circuit.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove connector of charge pressure control valve.</li> <li>◆ Measure resistance between special tool 9637 pin III/4 and charge pressure control valve plug pin 2.</li> </ul>	0 - 5 $\Omega$ Repair wiring harness → End.



## P1570

### 39 Immobilizer - signal implausible

#### Diagnosis conditions

- Start condition
- Motronic reset

#### Possible fault cause

- ◆ Open circuit in wiring between DME control module and alarm system
- ◆ Short circuit to ground or short circuit to B+
- ◆ Alarm system control module faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check signal wire for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and alarm system control module plug Pin I/23</li> </ul>	0 - 5 Ω ⇒ Step 3	⇒ Step 2
2	Remove connector X 2/3	<ul style="list-style-type: none"> <li>◆ Measure resistance between plug connection X 2/3 bushing 6 and special tool 9637 Pin I/3</li> <li>◆ Measure resistance between plug connection X 2/3 Pin 6 and alarm system control module plug I Pin 23</li> </ul>	0 - 5 Ω ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Check signal wire for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 4  Repair wiring harness $\rightarrow$ End
4	Check signal wire for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between special tool 9637 Pin I/3 and ground</li> </ul>	0 V $\Rightarrow$ Step 4  Repair wiring harness $\rightarrow$ End
5	Replace alarm system control module.	$\rightarrow$ End	$\rightarrow$ End



## P1571

### 39 Immobilizer - open circuit/no signal

#### Diagnosis conditions

- Start condition
- Motronic reset

#### Possible fault cause

- ◆ Open circuit in wiring between DME control module and alarm system
- ◆ Short circuit to ground or short circuit to B+
- ◆ Alarm system control module faulty

#### Affected terminals

-

#### Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Check signal wire for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and alarm system control module plug Pin I/23</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	⇒ Step 2
2	Remove connector X 2/3	<ul style="list-style-type: none"> <li>◆ Measure resistance between plug connection X 2/3 bushing 6 and special tool 9637 Pin I/3</li> <li>◆ Measure resistance between plug connection X 2/3 Pin 6 and alarm system control module plug I Pin 23</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Check signal wire for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 Pin I/3 and ground</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 4  Repair wiring harness $\rightarrow$ End
4	Check signal wire for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove connector I of alarm system control module</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between special tool 9637 Pin I/3 and ground</li> </ul>	0 V $\Rightarrow$ Step 4  Repair wiring harness $\rightarrow$ End
5	Replace alarm system control module.	$\rightarrow$ End	$\rightarrow$ End

## P1574

### 364 Stop light switch - signal implausible

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Stop light switch
- ◆ Wiring harness



#### Note!

The DME control module receives the signals from the stop light switches via CAN bus.

#### Affected terminals

#### Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Check stop light switch	<ul style="list-style-type: none"> <li>◆ Remove stop light switch</li> <li>◆ Measure resistance between Pin 1 and Pin 4</li> <li>◆ Actuate stop light switch</li> <li>◆ Measure resistance between Pin 1 and Pin 2</li> <li>◆ Actuate stop light switch</li> <li>◆ Install stop light switch</li> </ul>	0 - 5 $\Omega$  $\infty \Omega$  $\infty \Omega$  0 - 5 $\Omega$ ⇒ Step 2	Replace stop light switch → End
2	Check wiring from PSM control module to stop light switch 1 for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove PSM control module connector</li> <li>◆ Measure voltage between Pin 32 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Actuate brake</li> </ul>	0 V    Battery voltage ⇒ Step 3	Repair wiring harness → End

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
3	Check wiring from PSM control module to stop light switch 2 for short circuit to B+	Battery voltage  0 V → End	Repair wiring harness → End

## P1575

### Pedal Sensor Movement - Signal Implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Pedal sensor

#### Affected terminals

-



#### Note!

- ◆ *The system is located in the pedal sensor standby mode*
- ◆ *This fault only occurs in combination with fault P0121 or P0221*

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace pedal sensor	→ End.	→ End.



## P1576

### 662 Cruise Control Standby Lamp via CAN - Open Circuit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Instrument cluster

#### Affected terminals

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace instrument cluster		





## P1577

### 427 Accelerator pedal position sensor 1 - signal implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Pedal sensor

#### Affected terminals

-



#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace pedal sensor	→ End	→ End

### 427 Accelerator pedal position sensor 1 - below limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground
- ◆ Pedal sensor

**Affected terminals**

Terminal IV/8

**Note!**

- ◆ The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.
- ◆ The maximum pedal value is limited to 30 %.
- ◆ The dynamic is limited.

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, Pin IV/8, to pedal sensor, Pin 2, for short circuit to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool Pin IV/8 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 2	Repair wiring harness → End
2	Replace pedal sensor	→ End	→ End

**427 Accelerator pedal position sensor 1 - above limit****Diagnosis conditions**

- Ignition on (approx. 30 sec.)
- Battery voltage greater than 7 V

**Possible fault cause**

- ◆ Short circuit to B+
- ◆ Pedal sensor

**Affected terminals**

Terminal IV/8

**Note!**

- ◆ The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.
- ◆ The maximum pedal value is limited to 30 %.
- ◆ The dynamic is limited.

**Diagnosis/troubleshooting**

<b>Work instruction</b>		<b>Display OK</b>	<b>If not OK</b>
1	Check wiring from DME control module, Pin IV/8, to pedal sensor, Pin 2, for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool Pin IV/8 and ground</li> </ul>	0 V ⇒ Step 2	Repair wiring harness → End
2	Replace pedal sensor	→ End	→ End



## P1578

### 428 Accelerator pedal position sensor 2 - signal implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Pedal sensor

#### Affected terminals

-



#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Replace pedal sensor	→ End	→ End

### 428 Accelerator pedal position sensor 2 - below limit

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to ground
- ◆ Pedal sensor

**Affected terminals**

Terminal IV/13

**Note!**

- ◆ The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.
- ◆ The maximum pedal value is limited to 30 %.
- ◆ The dynamic is limited.

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, Pin IV/13, to pedal sensor, Pin 2, for short circuit to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool Pin IV/13 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 2	Repair wiring harness → End
2	Replace pedal sensor	→ End	→ End

**428 Accelerator pedal position sensor 2 - above limit****Diagnosis conditions**

- Ignition on (approx. 30 sec.)
- Battery voltage greater than 7 V

**Possible fault cause**

- ◆ Short circuit to B+
- ◆ Pedal sensor

**Affected terminals**

Terminal IV/13

**Note!**

- ◆ The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.
- ◆ The maximum pedal value is limited to 30 %.
- ◆ The dynamic is limited.

**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check wiring from DME control module, Pin IV/13, to pedal sensor, Pin 2, for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool Pin IV/13 and ground</li> </ul>	0 V ⇒ Step 2	Repair wiring harness → End
2	Replace pedal sensor	→ End	→ End





## P1579

### 111 Crankshaft Position Sensor Signal Implausible

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Corrosion in the connector
- ◆ Loose contact


#### Affected terminals

III/32, III/45 and III/46

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Remove connector.		
2	Check connector for corrosion.	◆ Visual inspection.	Clean contacts.
3	Check rpm/crankshaft position sensor.	◆ Measure resistance between pins 1 and 2.	Replace rpm/crankshaft position sensor.
		◆ Measure resistance between pins 1 and 3.	
4	Check signal with engine tester.	◆ Connect special tool 9637. ◆ Connect engine tester. Use special input, connect positive cable to pin III/32, negative cable to pin III/46. ◆ Start engine or crank engine with starter motor.	The following display should appear on the oscilloscope.

Figure:



## P1600

### 216 CAN timeout PSM - open circuit

#### Diagnosis conditions

- Vehicle has PSM
- Battery voltage greater than 10 V
- Ignition on

#### Possible fault cause

- ◆ Wiring harness
- ◆ PSM control module not connected
- ◆ PSM control module faulty



#### Note!

- ◆ If all CAN bus faults are stored, there must be a short circuit in the CAN bus wiring.
- ◆ If one CAN bus fault is stored, the cruise control system is out of order.
- ◆ CAN bus faults may be caused by a control module reset. The fault is then indicated as "Not present".

#### Affected terminals

Terminal IV/36 and IV/37

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check whether connector of PSM control module is plugged in.	⇒ Step 2	
2	Check CAN bus from DME control module to PSM control module for continuity <ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> </ul>		Repair wiring harness → End

Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool plug IV Pin 36 and PSM control module plug Pin 61</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 37 and PSM control module plug Pin 63</li> </ul>	0 - 5 $\Omega$  0 - 5 $\Omega$ ⇒ Step 3	

**Note!**

The wires are routed via two connectors.

Work instruction		Display OK	If not OK
3	Check CAN bus from DME control module to PSM control module for short circuit to ground <ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 36 and ground</li> <li>◆ Measure resistance between special tool plug IV Pin 37 and ground</li> </ul>	          $\infty \Omega$  $\infty \Omega$ ⇒ Step 4	Repair wiring harness → End

**Note!**

The wires are also routed to the instrument cluster.

Work instruction			Display OK	If not OK
4	Check CAN bus from DME control module to PSM control module for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure voltage between special tool 9637 plug IV Pin 36 and ground</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 plug IV Pin 37 and ground</li> <li>◆ Switch on the ignition</li> </ul>	<p>0 V</p> <p>0 V ⇒ Step 5</p>	Repair wiring harness → End
5	Check CAN bus from DME control module to PSM control module for short circuit	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 36 and plug IV Pin 37</li> </ul>	<p><math>\infty \Omega</math></p> <p>→ End</p>	Repair wiring harness → End



## P1601

### CAN timeout instrument cluster - signal implausible

#### Diagnosis conditions

- Battery positive voltage greater than 10 V
- Ignition on

#### Possible fault cause

- ◆ Instrument cluster faulty



#### Note!

- ◆ *If one CAN bus fault is stored, the cruise control system is out of order.*
- ◆ *CAN bus faults may be caused by a control module reset. The fault is then indicated as "Not present".*

#### Affected terminals

-

#### Diagnosis/troubleshooting

**Replace instrument cluster.**

### CAN timeout instrument cluster - open circuit

#### Diagnosis conditions

- Battery positive voltage greater than 10 V
- Ignition on

#### Possible fault cause

- ◆ Wiring harness faulty
- ◆ Plug on instrument cluster not connected
- ◆ Instrument cluster faulty

**Note!**

- ◆ If all CAN bus faults are stored, there is a short circuit in the CAN bus wiring
- ◆ If one CAN bus fault is stored, the cruise control system is out of order.
- ◆ CAN bus faults may be caused by a control module reset. The fault is then indicated as "Not present".

Affected terminals

Terminal I/15 and I/31

Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check whether connector of instrument cluster is plugged in	⇒ Step 2	
2	Check CAN bus from DME control module to instrument cluster for continuity	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 plug IV pin 36 and instrument cluster plug I pin 15</li> <li>◆ Measure resistance between special tool plug IV pin 37 and instrument cluster plug I pin 31</li> </ul>	Repair wiring harness → End.
		0 - 5 Ω	
		0 - 5 Ω ⇒ Step 3	
3	Check CAN bus from DME control module to instrument cluster for short circuit to ground	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Remove plug of steering angle sensor</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> </ul>	Repair wiring harness → End.



Work instruction		Display OK	If not OK
	<ul style="list-style-type: none"> <li>◆ Measure resistance between special tool 9637 plug IV pin 36 and ground</li> <li>◆ Measure resistance between special tool 9637 plug IV pin 37 and ground</li> </ul>	$\infty \Omega$  $\infty \Omega$ $\Rightarrow$ Step 4	

**Note!**

The wires are also routed to the PSM control module.

Work instruction		Display OK	If not OK	
4	Check CAN bus from DME control module to instrument cluster for short circuit to B+	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between special tool 9637 plug IV pin 36 and ground</li> <li>◆ Measure voltage between special tool 9637 plug IV pin 37 and ground</li> </ul>	$0 \text{ V}$ $\Rightarrow$ Step 5	Repair wiring harness $\rightarrow$ End.
5	Check CAN bus from DME control module to instrument cluster for short circuit	<ul style="list-style-type: none"> <li>◆ Remove DME control module connector</li> <li>◆ Remove plug I from instrument cluster</li> <li>◆ Remove PSM control module connector</li> <li>◆ Remove plug of steering angle sensor</li> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 36 and plug IV Pin 37</li> </ul>	$\infty \Omega$ $\rightarrow$ End.	Repair wiring harness $\rightarrow$ End.



## P1602

### CAN Timeout Instrument Cluster - Signal Implausible

#### Diagnosis conditions

- Battery positive voltage greater than 10 V
- Ignition on

#### Possible fault cause

- ◆ Instrument cluster faulty

#### **Note!**

- ◆ *If one CAN bus fault is stored, the cruise control system is out of order.*
- ◆ *CAN bus faults may be caused by a control module reset. The fault is then indicated as "Not present".*

#### Affected terminals

-

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace instrument cluster.		



## P1654

### Cooling Water Shutoff Valve - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module

#### Affected terminals

Terminal IV/40

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module to coolant shutoff valve for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of coolant shutoff valve</li> <li>◆ Measure voltage between special tool 9637 plug IV Pin 40 and ground</li> <li>◆ Switch on the ignition.</li> </ul>	0 V ⇒ Step 2	Repair wiring harness → End.
2	Replace DME control module	⇒ Step 3	
3	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	→ End.	



## P1655

### Cooling Water Shutoff Valve - Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V
- Coolant temperature greater than 90 °C or ATF temperature > 85 °C

#### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module

#### Affected terminals

Terminal IV/40

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module to coolant shutoff valve for short to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of coolant shutoff valve</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 40 and coolant shutoff valve plug Pin 2</li> </ul>	$\infty \Omega$ $\Rightarrow$ Step 2	Repair wiring harness $\rightarrow$ End.
2	Replace DME control module	$\Rightarrow$ Step 3	
3	Perform adaptation. <ul style="list-style-type: none"> <li>◆ Switch on the ignition.</li> <li>◆ Wait one minute.</li> <li>◆ Do not press the accelerator.</li> <li>◆ Switch off the ignition for at least 10 seconds.</li> <li>◆ Read out the fault memory.</li> </ul>	$\rightarrow$ End.	





## P1656

### 575 Coolant shutoff valve - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Coolant temperature greater than 90 °C or ATF temperature > 85 °C

#### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module
- ◆ Coolant shutoff valve

#### Affected terminals

Terminal IV/40

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK	
1	Check coolant shutoff valve for continuity	<ul style="list-style-type: none"> <li>◆ Remove connector of coolant shutoff valve</li> <li>◆ Measure resistance at coolant shutoff valve between Pin 1 and Pin 2</li> </ul>	Approx. 20 - 30 $\Omega$ ⇒ Step 2	Replace coolant shutoff valve → End
2	Check wiring from DME control module to coolant shutoff valve for continuity	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of coolant shutoff valve</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 40 and coolant shutoff valve plug Pin 2</li> </ul>	0 - 5 $\Omega$ ⇒ Step 3	Repair wiring harness → End
3	Replace DME control module	⇒ Step 4		
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 575 Coolant shutoff valve - below limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Coolant temperature greater than 90 °C or ATF temperature > 85 °C

### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module

### Affected terminals

Terminal IV/40

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module to coolant shutoff valve for short to ground <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of coolant shutoff valve</li> <li>◆ Measure resistance between special tool 9637 plug IV Pin 40 and coolant shutoff valve plug Pin 2</li> </ul>	$\infty \Omega$ ⇒ Step 2	Repair wiring harness → End
2	Replace DME control module	⇒ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 575 Coolant shutoff valve - above limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

### Possible fault cause

- ◆ Wiring harness
- ◆ DME control module

### Affected terminals

Terminal IV/40

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check wiring from DME control module to coolant shutoff valve for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector of coolant shutoff valve</li> <li>◆ Measure voltage between special tool 9637 plug IV Pin 40 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0 V ⇒ Step 2	Repair wiring harness → End
2	Replace DME control module	⇒ Step 3	
3	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	



## P1657

### 274 Overrun Recirculating Air Valve Output Stage - Open Circuit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Open circuit
- ◆ Open circuit in B+ supply
- ◆ Overrun recirculating air valve

#### Affected terminals

III/16

#### Diagnosis/Troubleshooting



#### Note!

The wiring for the overrun recirculating air valve is routed via the connector X 59/3 pin 8.

Work instruction		Display OK	If not OK
1	Check triggering wire for continuity.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of overrun recirculating air valve.</li> <li>◆ Measure resistance between III/16 and overrun recirculating air valve connector pin 1</li> </ul>	0 - 5 $\Omega$
2	Check B+ supply for overrun recirculating air valve.	<ul style="list-style-type: none"> <li>◆ Remove plug connection of overrun recirculating air valve.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between overrun recirculating air valve pin 2 and ground.</li> </ul>	Battery voltage.
3	Check overrun recirculating air valve resistance.	<ul style="list-style-type: none"> <li>◆ Measure overrun recirculating air valve resistance between pin 1 and 2.</li> </ul>	20 - 26 $\Omega$ at 20° C.

## 274 Overrun Recirculating Air Valve Output Stage - Below Limit

### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

### Possible fault cause

- ◆ Short to ground triggering wire

### Affected terminals

III/16

### Diagnosis/Troubleshooting



#### Note!

The wiring for the overrun recirculating air valve is routed via the connector X 59/3 pin 8.

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground.	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of overrun recirculating air valve.</li> <li>◆ Measure resistance between III/16 and ground.</li> </ul>	<p><math>\infty \Omega</math></p> <p>Repair wiring harness.</p>

## 274 Overrun Recirculating Air Valve Output Stage - Above Limit

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V

### Possible fault cause

- ◆ Short circuit to B+ triggering wire

### Affected terminals

III/16

## Diagnosis/Troubleshooting

**i** **Note!**

The wiring for the overrun recirculating air valve is routed via the connector X 59/3 pin 8.

Work instruction		Display OK	If not OK
1	Check triggering wire for short circuit to B+. <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of overrun recirculating air valve.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between Ill/16 and ground.</li> </ul>	0 V.	Repair wiring harness.





## P1658

### Overrun Recirculating Air Valve Output Stage - Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short circuit to B+ triggering wire

#### Affected terminals

III/16

### Diagnosis/Troubleshooting



#### Note!

*The wiring for the overrun recirculating air valve is routed via the connector X 59/3 pin 8.*

Work instruction		Display OK	If not OK
1	Check triggering wire for short circuit to B+. <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of overrun recirculating air valve.</li> <li>◆ Switch on the ignition.</li> <li>◆ Measure voltage between III/16 and ground.</li> </ul>	0 V.	Repair wiring harness.



## P1659

### Overrun Recirculating Air Valve Output Stage - Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Short to ground triggering wire

#### Affected terminals

III/16

### Diagnosis/Troubleshooting

 **Note!**

*The wiring for the overrun recirculating air valve is routed via the connector X 59/3 pin 8.*

Work instruction		Display OK	If not OK
1	Check triggering wire for short to ground.	$\infty \Omega$	Repair wiring harness.
	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove plug connection of overrun recirculating air valve.</li> <li>◆ Measure resistance between III/16 and ground.</li> </ul>		



## P1671

DME relay/control module faulty (computer monitoring: reset) – signal implausible

Diagnosis conditions

- Ignition on

Possible fault cause

- ◆ Undervoltage
- ◆ DME relay faulty
- ◆ DME control module faulty

This fault may be entered if the control module has been operated with undervoltage.

Affected terminals

I/1 and I/8

Diagnosis/troubleshooting



### Note!

*If no fault is present, erase the fault memory.*

Work instruction		Display OK	If not OK
1	Check voltage supply, terminal 15	◆ Measure voltage between pin I/1 and ground. > 11 V	
2	Check DME relay	◆ Switch on the ignition ◆ Measure voltage between pin I/18 and ground Battery positive voltage	Check triggering of DME relay Replace DME relay
3	Replace DME control module.	⇒ Step 4	
4	Perform adaptation.	◆ Switch on the ignition ◆ Wait one minute ◆ Do not press the accelerator ◆ Switch off the ignition for at least 10 seconds ◆ Read out the fault memory → End	→ End



## P1674

### 497 Engine compartment purge fan output stage - open circuit

#### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Engine compartment purge fan switched on once
- Engine compartment temperature greater than 75 °C
- Front and rear lids closed



#### Note!

The triggering wire for relay terminal 85 is monitored.

The rear lid may be opened to speed up the warming process. In order to proceed with the diagnosis, the rear lid must then be closed.

#### Possible fault cause

- ◆ Open circuit
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal II/20

#### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check relay	◆ Remove relay ◆ Measure resistance between Pin 85 and Pin 86	Approx. 75 Ω ⇒ Step 2  Replace relay → End
2	Check wiring from DME control module to relay for continuity	◆ Connect special tool 9637 to wiring harness (DME control module plug) ◆ Remove relay ◆ Measure resistance between special tool 9637, plug II Pin 20, and relay slot, Pin 2 (terminal 85)	0 - 5 Ω ⇒ Step 3  Repair wiring harness → End

Work instruction		Display OK	If not OK
3	Replace DME control module		⇒ Step 4
4	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## 497 Engine compartment purge fan output stage - short circuit to ground

### Diagnosis conditions

- Engine running
- Battery voltage greater than 7 V
- Engine compartment purge fan switched on once
- Engine compartment temperature greater than 75 °C
- Front and rear lids closed



### Note!

The triggering wire for relay terminal 85 is monitored.

The rear lid may be opened to speed up the warming process. In order to proceed with the diagnosis, the rear lid must then be closed.

### Possible fault cause

- ◆ Short circuit to ground
- ◆ Relay faulty
- ◆ DME control module faulty

### Affected terminals

Terminal II/20



**Diagnosis/troubleshooting**

Work instruction		Display OK	If not OK
1	Check relay	<ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2 Replace relay → End
2	Check wiring from DME control module to relay for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay</li> <li>◆ Measure resistance between special tool 9637 plug II Pin 20 and ground</li> </ul>	$\infty \Omega$ ⇒ Step 3 Repair wiring harness → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation	<ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End

**497 Engine compartment purge fan output stage - short circuit to B+****Diagnosis conditions**

- Engine running
- Battery voltage greater than 7 V
- Engine compartment purge fan switched on once
- Engine compartment temperature greater than 75 °C
- Front and rear lids closed

** Note!**

The triggering wire for relay terminal 85 is monitored.

The rear lid may be opened to speed up the warming process. In order to proceed with the diagnosis, the rear lid must then be closed.

**Possible fault cause**

- ◆ Short circuit to B+

- ◆ Relay faulty
- ◆ DME control module faulty

### Affected terminals

Terminal II/20

### Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check relay <ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2	Replace relay → End
2	Check wiring from DME control module to relay for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove relay</li> <li>◆ Measure voltage between special tool 9637 plug II Pin 20 and ground</li> <li>◆ Switch on the ignition</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End
3	Replace DME control module	⇒ Step 4	
4	Perform adaptation <ul style="list-style-type: none"> <li>◆ Switch on the ignition</li> <li>◆ Wait one minute</li> <li>◆ Do not press the accelerator</li> <li>◆ Switch off the ignition for at least 10 seconds</li> <li>◆ Read out the fault memory</li> </ul>	→ End	

## P1675

### 658 Engine Purge Fan Fault - Above Limit

#### Diagnosis conditions

- Ignition on

#### Possible fault cause

- ◆ Fuses
- ◆ Relays
- ◆ Fans

#### Affected terminals

-

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check fuses B4 and C5.		
2	Check fans. <ul style="list-style-type: none"> <li>◆ Remove engine compartment fan relay.</li> <li>◆ Bridge terminals 30 and 87.</li> </ul>	Fan must run.	<ul style="list-style-type: none"> <li>◆ Check ground supply wire for fan.</li> <li>◆ Check B+ supply wire for continuity.</li> </ul>
3	Check relays.		



## P1676

### Engine Compartment Purge Fan Output Stage – Above Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V
- Engine compartment purge fan switched on once
- Engine compartment temperature greater than 75 °C
- Front and rear lids closed



#### Note!

*The triggering wire for relay terminal 85 is monitored.*

The rear lid may be opened to speed up the warming process. In order to proceed with the diagnosis, the rear lid must then be closed.

#### Possible fault cause

- ◆ Short circuit to B+
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal II/20

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Check relays. <ul style="list-style-type: none"> <li>◆ Remove relay</li> <li>◆ Measure resistance between Pin 85 and Pin 86</li> </ul>	Approx. 75 $\Omega$ ⇒ Step 2	Replace relay → End
2	Check wiring from DME control module to relay for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug).</li> <li>◆ Remove relay</li> <li>◆ Measure voltage between special tool 9637 plug II Pin 20 and ground</li> <li>◆ Switch on the ignition.</li> </ul>	0 V ⇒ Step 3	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	

## P1677

### Engine Compartment Purge Fan Output Stage – Below Limit

#### Diagnosis conditions

- Engine running
- Battery positive voltage greater than 7 V
- Engine compartment purge fan switched on once
- Engine compartment temperature greater than 75 °C
- Front and rear lids closed

#### **Note!**

*The triggering wire for relay terminal 85 is monitored.*

The rear lid may be opened to speed up the warming process. In order to proceed with the diagnosis, the rear lid must then be closed.

#### Possible fault cause

- ◆ Short circuit to ground
- ◆ Relay faulty
- ◆ DME control module faulty

#### Affected terminals

Terminal II/20

#### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK	
1	Check relays.	◆ Remove relay ◆ Measure resistance between Pin 85 and Pin 86	Approx. 75 Ω ⇒ Step 2	Replace relay → End
2	Check wiring from DME control module to relay for short to ground	◆ Connect special tool 9637 to wiring harness (DME control module plug). ◆ Remove relay ◆ Measure resistance between special tool 9637 plug II Pin 20 and ground	∞ Ω ⇒ Step 3	Repair wiring harness → End.

Work instruction		Display OK	If not OK
3	Replace DME control module	⇒ Step 4.	
4	Perform adaptation. <ul style="list-style-type: none"><li>◆ Switch on the ignition.</li><li>◆ Wait one minute.</li><li>◆ Do not press the accelerator.</li><li>◆ Switch off the ignition for at least 10 seconds.</li><li>◆ Read out the fault memory.</li></ul>	→ End.	



## P1702

### Tiptronic (Supply voltage of valves)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control unit has detected a malfunction.

#### **Note!**

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting

#### **Note!**

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*

P code	Fault code	Fault text	Fault effect
P1702	10	Supply voltage of valves	Control unit in limp-home mode, minimum cycle initiated



## P1748

### Tiptronic (Control solenoid valve, shifting pressure)

#### Diagnostic conditions

- Ignition on

#### Possible cause of fault

- ◆ The Tiptronic control module has detected a malfunction.



#### Note!

- ◆ *The fault is diagnosed in the Tiptronic control unit. OBDII relevant fault codes are sent to the DME control module via the CAN drive. In the process the Tiptronic fault codes are converted to P-code!*
- ◆ *Fault management and any activation of the Check Engine lamp is done by the DME control module!*

#### Affected terminals

-

### Diagnosis/troubleshooting



#### Note!

- ◆ *The fault codes stored in the Tiptronic control unit for this P code are to be taken from the following table.*
- ◆ *For in-depth troubleshooting see ⇒ Rep. Gr. 3701; Tiptronic diagnosis in the On-Board Diagnosis Manual (OBD II), Tiptronic, Boxster (986), 911 Carrera (996), 911 Turbo (996)*



#### Note!

*This fault code "P1748" is only output by the DME of the 911 (996) Turbo of model year 2001. In the extended fault memory of the Tiptronic control unit, the currently valid P code "P0778" is generated by the 9588 Porsche System Tester II.*

P code	Fault code	Fault text	Fault effect
P1748 = P0778	7	Control solenoid valve, shifting pressure	Control unit in limp-home mode, minimum cycle initiated



## P2088

### Inlet camshaft output stage - below limit

#### Diagnosis conditions

- Engine running

#### Possible fault cause

- ◆ Triggering wire short to ground
- ◆ Solenoid hydraulic valve faulty

#### Affected terminals

V/7

#### Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/7 and ground</li> </ul>	$\infty \Omega$	
2	Replace solenoid hydraulic valve			



## P2089

Inlet camshaft output stage - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ Triggering wire short to B+

Affected terminals

V/7

Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between V/7 and ground</li> </ul>	0 V	Repair wiring harness





## P2092

Inlet camshaft output stage, bank 2 - below limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ Triggering wire short to ground
- ◆ Solenoid hydraulic valve faulty

Affected terminals

V/8

Diagnosis/troubleshooting

Work instruction			Display OK	If not OK
1	Check triggering wire for short to ground	<ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Measure resistance between V/8 and ground</li> </ul>	$\infty \Omega$	
2	Replace solenoid hydraulic valve			



## P2093

Inlet camshaft output stage, bank 2 - above limit

Diagnosis conditions

- Engine running

Possible fault cause

- ◆ Triggering wire short to B+

Affected terminals

V/8

Diagnosis/troubleshooting

Work instruction		Display OK	If not OK
1	Check triggering wire for short circuit to B+ <ul style="list-style-type: none"> <li>◆ Connect special tool 9637 to wiring harness (DME control module plug)</li> <li>◆ Remove connector on the solenoid hydraulic valve</li> <li>◆ Switch on the ignition</li> <li>◆ Measure voltage between V/8 and ground</li> </ul>	0 V	Repair wiring harness



## P2096

### Signal Delay Time for Oxygen Sensor Ageing - Above Limit

#### Diagnosis conditions

- Oxygen sensing after TWC is active
- No secondary air
- No diagnosis of secondary air system
- EVAP canister not highly loaded
- No faults in memory

#### Possible fault cause

- ◆ Oxygen sensor

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*


Work instruction		Display OK	If not OK
1	Read out regulator delay after TWC, bank 1, using PST 2 or a scan tool	Less than 1.2 seconds	Replace oxygen sensor

#### Note!

*Do not confuse oxygen sensor ahead of catalytic converter and oxygen sensor after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P2097

### Signal Delay Time for Oxygen Sensor Ageing - Below Limit

#### Diagnosis conditions

- Oxygen sensing after TWC is active
- No secondary air
- No diagnosis of secondary air system
- EVAP canister not highly loaded
- No faults in memory

#### Possible fault cause

- ◆ Oxygen sensor

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*


Work instruction		Display OK	If not OK
1	Read out regulator delay after TWC, bank 1, using PST 2 or a scan tool	more than 1.2 seconds	Replace oxygen sensor

#### Note!

*Do not confuse oxygen sensor ahead of catalytic converter and oxygen sensor after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter





## P2098

### Signal Delay Time for Oxygen Sensor Ageing, Bank 2 – Above Limit

#### Diagnosis conditions

- Oxygen sensing after TWC is active
- No secondary air
- No diagnosis of secondary air system
- EVAP canister not highly loaded
- No faults in memory

#### Possible fault cause

- ◆ Oxygen sensor

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*


Work instruction		Display OK	If not OK
1	Read out regulator delay after TWC, bank 2, using PST 2 or a scan tool	Less than 1.2 seconds	Replace oxygen sensor

#### Note!

*Do not confuse oxygen sensor ahead of catalytic converter and oxygen sensor after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P2099

### Signal Delay Time for Oxygen Sensor Ageing, Bank 2 Below Limit

#### Diagnosis conditions

- Oxygen sensing after TWC is active
- No secondary air
- No diagnosis of secondary air system
- EVAP canister not highly loaded
- No faults in memory

#### Possible fault cause

- ◆ Oxygen sensor

#### Affected terminals

-

### Diagnosis/Troubleshooting

#### Note!

*Do not use contact spray on the connectors to oxygen sensor.*


Work instruction		Display OK	If not OK
1	Read out regulator delay after TWC, bank 2, using PST 2 or a scan tool	more than 1.2 seconds	Replace oxygen sensor

#### Note!

*Do not confuse oxygen sensor ahead of catalytic converter and oxygen sensor after catalytic converter.*

**Oxygen sensors ahead of and after catalytic converter**

- 1 - Oxygen sensor ahead of catalytic converter
- 2 - Oxygen sensor after catalytic converter



## P2135

### Accelerator Pedal - Signal Implausible

#### Diagnosis conditions

- Ignition on (approx. 30 sec.)
- Battery positive voltage greater than 7 V

#### Possible fault cause

- ◆ Pedal sensor

#### Affected terminals

-



#### Note!

- ◆ *The system operates in pedal sensor standby mode, i.e. the angle of the accelerator pedal is calculated from the residual position sensor signal.*
- ◆ *The maximum pedal value is limited to 30 %.*
- ◆ *The dynamic is limited.*
- ◆ *The fault code only appears together with P0121 or P0221.*
- ◆ *The pedal value is reset to zero by actuating the brake.*

### Diagnosis/Troubleshooting

Work instruction		Display OK	If not OK
1	Replace pedal sensor	→ End.	

