

Vehicle at 0% Enclosure: How to Install 100% Enclosure

1. Open one or two doors.
2. Release Fin Clamper by pulling fabric Pull Loop. Both sides.
3. Open Rear Decklid.
4. Remove Soft-Top and open its Locking Latch while carrying.
5. Insert Soft-Top into vehicle windshield frame. Continue to maintain control of Soft-Top by hand and enter vehicle.
6. While seated in vehicle, fasten Locking Latch overhead.
7. Unroll the Soft-Top.
8. Secure Soft-Top onto both Supplemental Safety Bars.
9. Secure Tension Rope onto Hook. Both sides.
10. On passenger side, engage handheld Roof Tensioning Lever.
11. Remove Weather Protector from trunk and fasten center snap-in button and then remainder of snap-in buttons; tuck loose fabric of Weather Protector all the way down into crevice ahead of carpeted storage area.
12. Interface the plastic end piece of the Weather Protector (Weather Sealing Clip) with the Corner Bow (pole) and B-Pillar Slot. Both sides.
13. Close Rear Decklid.
14. Release Soft-Top Fin from Soft-Top Fin-Rest and slide it down onto the Fin Clamper but do not secure the Fin Clamper into locked position; repeat on other side.
15. Secure the Fin Clamper into locked position. Both sides.

This Soft-Top operation is complete.

Note: Top speed with the Soft-Top in place is 120 mph.