

Vehicle at 0% Enclosure: How to Install Sun Shade

1. Open one of the doors or both if another person is assisting.
2. Find the fabric Pull Loop on the external air intake fixture (Fin Clamper) on the Rear Decklid and pull the Loop to release the mechanism (Fin Clamper). Now do the other side.
3. Open Rear Decklid.
4. Remove the Soft-Top from the carpeted storage area above the engine (air filter housing). Maintain in hand.
5. On the underside of the Soft-Top, unlock the two-stage Locking Latch mechanism by pressing the red release button while pulling the release lever towards the edge of the soft-top; the Latch will release and pop out.
6. Insert the soft-top into the vehicle windshield frame by paying close attention to the interface between the Soft-Top Locking Latch and the receptacle on the windshield frame. Continue to hold on to the Soft-Top by hand and enter the vehicle.
7. While seated, check that the roof is in the correct position and then secure it by closing the hook on the Soft-Top Locking Latch overhead; this is done simply by moving the lever firmly toward the back of the vehicle and up. It should travel smoothly to closed position.
8. Unroll the Soft-Top. There is a pole, or Corner Bow, protruding from each outboard side of the Soft-Top which can be rotated to facilitate Soft-Top unrolling. Note that on each side at rear, there is a Soft-Top Fin, which is a triangular-shaped or pointed fabric end piece which is locked in place onto the Soft-Top's Fin-Rest.
9. Both Corner Bows have pins on them which need to be inserted into the rearward fascia of each Supplemental Safety Bar; this is done by inserting the pins and then rotating each pin into place to help make the secure connection.

10. On one side, find the Tension Rope and stretch it downwards towards the Fixed Hook; fasten around the Hook. Now do the other side.
11. On the passenger side, find the Roof Tensioning Lever, which looks like a grab handle or a hand brake. Grip it and pull it downward towards the outboard side of the vehicle to engage tension.
12. Close the Rear Decklid.
13. On one side of the vehicle, release the Soft-Top Fin from the Fin-Rest via the push-push element; press inwards and lift it upwards. Do the other side after (14). The Soft-Top Fin and Fin-Rest are referenced in (8).
14. Prepare to slide the released Soft-Top Fin down onto the Fin Clamper referenced in (2). Place the tip of the Soft-Top Fin at the marking of the Fin Slide located on the Fin Clamper; press it forward and push it downward. The Soft-Top Fin will now be resting in place on the top side of the Fin Clamper. Now go back to (13) and do the other side.
15. Prepare to secure the Fin Clamper to its locked position. Stand behind the Fin Clamper; place the palm of your inboard hand on top of the fabric top at the location of the fin-end; rest that inboard hand with fingers pointed towards the front of the vehicle. With your inboard hand resting on the fabric, rotate your body inward and place your outboard hand on top of the base of your resting hand in perpendicular fashion and exert enough downward pressure such that the Fin Clamper closes and exhibits a click sound. Now do the other side.

This Soft-Top operation is complete.

Note: Top speed with the Soft-Top in place is 120 mph.