

December 4, 1986

944 PORSCHE SUNROOF INSTALLATION

1. Remove factory panel.
2. Locate left/right wind deflector mounting brackets and remove the two (2) mounting screws fastening each bracket.
3. Remove factory shim (washer) located in the recessed area on top of mounting bracket. Replace with nylon shims supplied (two (2) each side).
4. Install one (1) original factory screw in forward hole on left and right bracket.
5. Install one (1) #8 - 1/2" large screw (supplied) in rear hole of left and right mounting brackets.

~~NOTE: Mounting brackets should now be flush or below vinyl trimmed inside ledge of roof opening.~~

6. Install glass sunroof panel into opening as you would the factory top.