

## DIY - RS Heater Bypass Installation

### Porsche Parts Needed

RS Hot Air Elbow	993-211-941-00
Fan Duct	964-106-403-02
Relay (Bridge Adaptor)	964-610-184-00

### Other Materials Needed

Plug for Rear Switchover Valve Vacuum Line  
Zip-Tie  
Dielectric Grease  
Electrical Connectors (2) Bosch Type EV1 Injector Connector

### Steps

1. Remove rear heater blower assembly
2. Apply dielectric grease to NTC and rear switchover valve connectors and attach the injector connectors to protect contacts
3. Zip-Tie the electrical wires to the fuel rail
4. Plug the vacuum line to the rear switchover valve
5. Remove the relay shown in the photo and replace with the bridge adaptor
6. Remove the 30A fuse next to the relay shown in the photo
7. Remove the 993 air duct
8. Fit the 964 air duct
9. Fit the RS hot air elbow
10. Connect the vacuum line from the distributor to the hot air elbow