

Step 4 - Install SharkWerks Bypass System

Now you are ready to install our muffler bypass system. Slide the muffler bypass over right hand side tubing extending from the right hand muffler.

Then re-install the left hand muffler, sliding it into the bypass. When re-installing do not tighten v-band clamp until you have positioned the bypass in the center of the bracket that is mounted to the rear of the engine.

Now use the two provided 3-inch t-clamps and secure and tighten with 11mm deep socket as shown in the picture. After the two 3-inch clamps are centered correctly and tightened then secure upper and lower tubes on either side with respective the provided 2 and 2.5 inch clamps (on both sides).

Now tighten V-band clamps and go ahead and re-install shrouds and bumper cover in reverse order as listed above.

