



- Interior nets should be installed so that the top strap sits just below the line of eye site and the lower strap sits 6-8" below the top of the shoulder
- Net should be mounted with  $\frac{1}{2}$  to  $\frac{3}{4}$  of the triangular section forward of the headrest or shoulder support
- In vehicles with traditional road racing FIA style seats we recommend the following:
  - Strap A – wrap/attach to a diagonal in the cage behind and just to the outside of the head. If a wrap does not hold it firmly in place weld a chain link loop to the cage at the proper position
  - Strap B – wrap around the back of head rest section of the seat just above the shoulder belt openings back to the main hoop ("B-pillar") area. It should support the head rest but not be too high where it could cover over the top of the headrest under load

