

**Complaint:**  
No kickdown downshift 3 → 2.

**Code**  
F 6

**Details:**  
No kickdown downshift 3 → 2 with the accelerator pedal pressed to kickdown, in 90 to 110 km/h speed range and selector lever in 3.

**Possible Damage Causes, see Reference:**  
PR 6, PR 15

**Complaint:**  
Howling noise only when changing gears under load.

**Code**  
G 3

**Details:**

**Possible Damage Causes, see Reference:**  
Replace ATF filter.

**Complaint:**  
Noise in reverse gear.

**Code**  
G 1

**Details:**  
Mechanical noise while backing up.  
Sometimes also metal rattling noise in forward.

**Possible Damage Causes, see Reference:**  
RE 26

**Complaint:**  
Slight grinding noise at idle speed in "P" or "N".

**Code**  
G 5

**Details:**  
With the engine running and the selector lever in "P" or "N" there is a slight grinding noise, which stops suddenly when engaging a driving range.

**Possible Damage Causes, see Reference:**  
RE 9