



## V-Belt Spray

- Prevents belts slipping, ensuring full transmission of power.
- Eliminates creaking and squealing noises.
- Saves adjustment work in minor cases of belt slip caused by cold, dampness or normal stretching.



**Art. No: 893.230**

Contents: 400 ml

Pack/Qty: 1/12

### Application:

Attach spray head and keeping spray tip close to the inside surface of the belt. If possible spray the belt for approx. 5 seconds whilst the engine is running.