

Checking Speed Sensors (Speed Sensor Test)

If speed sensors were replaced or if they need to be checked, use **PIWIS Tester II 9818** .

Connect PIWIS Tester II to the vehicle.

- Select Control unit overview >>PSM<<.
- Select Maintenance/repairs >>Speed sensor test<<.

Follow the instructions on PIWIS Tester II.

WM 451119 REMOVING AND INSTALLING FRONT SPEED SENSOR (EXCEPT CARRERA "EDITION", CARRERA CABRIOLET "EDITION", CARRERA 4 "EDITION", CARRERA 4 CABRIOLET "EDITION")

REMOVING AND INSTALLING FRONT SPEED SENSOR

Removing Front Speed Sensor

1. Remove wheel. → **REMOVING WHEEL**
2. Release electric plug connection -1- from the speed sensor -2- and pull it off.



Fig. 1: Releasing Electric Plug Connection From Speed Sensor
Courtesy of PORSCHE CARS NORTH AMERICA, INC.

3. Loosen fastening screw -3- and pull speed sensor -2- out of the wheel carrier -arrow- .

INSTALLING FRONT SPEED SENSOR

Information