

PORSCHE 911 991.2 C2S

Maintenance schedule MY 2017

Scheduled maintenance

The recommended service intervals and scope of work apply under normal driving conditions and do not take into account all optional equipment.

Dusty areas require more frequent checking and possible replacement of the air filter elements.

If the vehicle is driven on very dirty roads, the radiators and cooling-air inlets in the front should be checked and cleaned regularly.

Tire, clutch, brake pad and brake disk wear as well as the condition of the engine oil, the transmission fluids and the brake fluid (e.g. in the case of sporting events) are all largely dependent on driving habits, and are also affected by adverse operating conditions; this could mean shorter intervals between servicing and replacement.

Time-dependent maintenance

Oil maintenance: If the mileage for scheduled oil maintenance is not reached, oil maintenance must be performed after 1, 3, 5, 7 ... years at the latest.

Maintenance: If the mileage for scheduled maintenance is not reached, maintenance must be performed after 2, 4, 6, 8 ... years at the latest.

Proper care and maintenance will preserve the value of your Porsche and safeguard its functional capability. This will also protect your right to make warranty claims.

The terms "inspect" and "check" include all associated work such as checking the condition, adjustments, readjustments, corrections and replenishment.

They do not include the repair, replacement or overhaul of components or assemblies.

Oil maintenance

As per fixed service reminder indicator, at the latest after 10,000 mls or 1 year.

If the mileage for scheduled maintenance is not reached, oil maintenance must be performed after 1 year at the latest.

	911 Carrera, 911 Targa	911 Turbo	every 10,000 mls/1 year	every 30,000 mls/4 years
Drain engine oil	✓	✓	✓	
Replace oil filter	✓	✓	✓	
Underbody panels: Visual inspection for completeness, secure installation and damage	✓	✓	✓	
Visual inspection for leaks from underneath (oils and fluids)	✓	✓	✓	
Tires: Check condition	✓	✓	✓	
Brake lines: Visual inspection for damage, correct routing and corrosion	✓	✓	✓	
Brake hoses: Visual inspection for damage	✓	✓	✓	
Fill in engine oil	✓	✓	✓	
Replace spark plugs	✓	✓		✓
Reset maintenance interval	✓	✓	✓	

Maintenance

At 20,000, 40,000, 60,000, 80,000 mls etc.

If the mileage for scheduled maintenance is not reached, maintenance must be performed every 2 years at the latest.

	911 Carrera, 911 Targa	911 Turbo	every 20,000 mls/2 years	every 30,000 mls/4 years	every 40,000 mls/4 years	every 60,000 mls/6 years	every 80,000 mls/4 years	every 120,000 mls/12 years
Electrics	Windshield wiper/washer system, headlight cleaning system: check function	✓	✓	✓				
	Horn: check function	✓	✓	✓				
	Tires: check tire pressure (TPMS)	✓	✓	✓				
	Diagnostic system: read out fault memory; reset maintenance interval	✓	✓	✓				
	Check actuator travel of brake shoes	✓	✓	✓				
Inside the vehicle	Particle filter: replace filter element	✓	✓			✓		
	Seat belts: check function and condition	✓	✓			✓		
	Door locks: check function	✓	✓					
Luggage compartment	Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly	✓	✓	✓				
	Replace air intake pre-filter	✓	✓	✓				
	Windshield wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windshield cleaners approved by Porsche	✓	✓	✓				

	911 Carrera, 911 Targa	911 Turbo	every 20,000 mls/2 years	every 30,000 mls/4 years	every 40,000 mls/4 years	every 60,000 mls/6 years	every 80,000 mls/4 years	every 120,000 mls/12 years
Vehicle exterior	Check wiper blades	✓	✓	✓				
	Headlights: check adjustment	✓	✓	✓				
	Radiators and air intakes: visual inspection for external contamination and blockage	✓	✓	✓				
	Brake system: check brake pads and brake discs for wear (remove wheels)	✓	✓	✓		✓		
	Brake system: check brake pads and brake discs for wear (without removing wheels)	✓	✓	✓				
	Service and maintain convertible top; check and clear convertible top drains	✓	✓	✓				
	Service and maintain Targa roof	✓	✓	✓				
Under the vehicle	Drain engine oil	✓	✓	✓				
	Underbody panels: visual inspection for completeness, secure installation and damage	✓	✓			✓		
	Tires: check condition	✓	✓	✓				
	Visual inspection for leaks from underneath (oils and other fluids)	✓	✓	✓		✓		
	Brake lines: visual inspection for damage, routing and corrosion	✓	✓	✓				
	Brake hoses: visual inspection for damage	✓	✓	✓				
	Steering gear: visual inspection of the bellows for damage	✓	✓			✓		
	Tie rod joints: check play and dust bellows	✓	✓			✓		
	Drive shafts: visual inspection of the boots for leaks and damage	✓	✓	✓				
	Axle joints: check the play and visually inspect the dust boots for damage	✓	✓			✓		
Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage	✓	✓					✓	

	911 Carrera, 911 Targa	911 Turbo	every 20,000 mls/2 years	every 30,000 mls/4 years	every 40,000 mls/4 years	every 60,000 mls/6 years	every 80,000 mls/4 years	every 120,000 mls/12 years
Under the vehicle	Rear axle steering: check bellows, dust boots and play on joints	✓	✓			✓		
	Exhaust system: visual inspection for leaks and damage, check engine mount	✓	✓			✓		
	Replace spark plugs	✓	✓		✓			
	Controlled all-wheel drive: change oil	✓	✓				✓	
	Front axle final drive: change oil	✓	✓					✓
	Manual transmission: change oil	✓	✓					✓
	PDK: change transmission oil	✓	✓					✓
	PDK: change clutch fluid	✓	✓					✓
Engine compartment	Replace oil filter	✓	✓	✓				✓
	Fill in engine oil	✓	✓	✓				
	Coolant: check level and antifreeze	✓	✓	✓				
	PDCC: check fluid level	✓	✓	✓				
	PDCC: replace reservoir	✓	✓					
	Check drive belt	✓	✓			✓	✓	
	Replace drive belt	✓	✓			✓	✓	
	Fuel lines and connections: visual inspection	✓	✓			✓	✓	
	Replace filter elements of air cleaner	✓	✓			✓		
	Check intercooler for debris	✓		✓		✓		

	911 Carrera, 911 Targa	911 Turbo	every 20,000 mls/2 years	every 30,000 mls/4 years	every 40,000 mls/4 years	every 60,000 mls/6 years	every 80,000 mls/4 years	every 120,000 mls/12 years
Additional work every 2 years	Change brake fluid (use only original Porsche brake fluid)	✓	✓	✓				
	Prepare condition report for long-life guarantee	✓	✓	✓				
Test drive	Tire sealing compound: check use-by date and replace if necessary.							
	Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, PASM switch, Sport switch, mode-switch, lift-switch, sports exhaust system, door mirror fold-in function, heating, air conditioning and instruments: check function	✓	✓	✓				
	Oils, fluids: visual inspection for leaks	✓	✓	✓				