

No.	Procedure	Instructions
4	Unscrewing fastening screw	Unscrew fastening screw -2-
5	Unscrewing fastening screw	Unscrew fastening screw -2-
6-7	Unscrewing fastening screws	Unscrew fastening screws -2-
8	Unclipping side-panel lining for luggage compartment in vicinity of D-pillar	Unclip side-panel lining for luggage compartment -1--3-
9	Unclipping side-panel lining for luggage compartment in vicinity of C-pillar	
10	Disconnecting the plug connection	Disconnect plug connection -4-
	Removing side-panel lining for luggage compartment	