



### Maintenance

### Oil service

After a fixed service interval display, no later than every 15,000 km/ 10,000 miles or 1 year. If the mileage for the oil service is not reached, an oil service must be carried out after one year at the latest.

### Every 15,000 km / 10,000 miles / 1 year:

Drain engine oil

Replace oil filter

Underbody covers: Visual inspection for completeness, attachment and damage

Visual inspection from underneath for leaks (oils and liquids)

Tires: Check condition

Brake lines: Visual inspection for damage, routing and corrosion

Brake hoses: Visual inspection for damage

Add engine oil

Reset service interval

Vehicles with Connect: Reset Smart Service values for the replaced components

# Inspection

Every 30,000, 45,000, 60,000, 120,000, 240,000 km / 20,000, 30,000, 40,000, 80,000, 160,000 miles If the mileage for an inspection is not reached, an inspection must be carried out every 2 years at the latest.

#### **Electronics**

# Every 30,000 km / 20,000 miles / 2 years: Windshield wipers/washer system, headlight washer system: Check function and nozzle setting Horn: Check function Tires: Check tire pressure (TPMS) Diagnostic system: Read fault memory; reset service interval Check brake pad actuator travel Reset Smart Service values Every 45,000 km / 30,000 miles / 4 years: Reset Smart Service values Time-dependent: Reset Smart Service values Vehicle interior Every 30,000 km / 20,000 miles / 2 years: Particle filter: Replace filter insert 12V battery ventilation hose: Check condition

### Maintenance

# Every 60,000 km / 40,000 miles / 4 years:

Seat belts: Check function and condition

Vehicle exterior

### Every 30,000 km / 20,000 miles / 2 years:

Check windshield wipers

All headlights: Check setting

Tires and spare wheel: Check condition

Brake system: Check the brake pads and brake disks for wear (without removing the wheels)

Radiator and air intakes: Visual inspection for external dirt and blockages

### Every 60,000 km / 40,000 miles / 4 years:

Brake system: Check the brake pads and brake disks for wear

Trailer hitch: Check function

Grease door arrester and fastening pin

#### Vehicle bottom

# Every 30,000 km / 20,000 miles / 2 years:

Drain engine oil

Visual inspection from underneath for leaks (oils and liquids)

Brake lines: Visual inspection for damage, routing and corrosion

Brake hoses: Visual inspection for damage

Drive shafts: Visual inspection of sleeves for leaks and damage

Cardan shaft: Visual inspection of rubber bellows for damage

Steering gear: Visual inspection of the bellows for damage

Tie bar joints: Check play and dust caps

### Every 60,000 km / 40,000 miles / 4 years:

Underbody covers: Visual inspection for completeness, attachment and damage

Axle joints: Check clearance, visual inspection of dust caps for damage

Exhaust system: Visual inspection for leaks and damage, check suspension

Transfer case: Replace oil

# Every 240,000 km / 160,000 miles / 16 years:

Tiptronic transmission: Replace ATF and ATF filter

All-wheel axle drive: Replace oil

Rear axle drive: Replace oil

### Maintenance

#### **Engine compartment**

# Every 30,000 km / 20,000 miles / 2 years:

Replace oil filter

Add engine oil

Windshield wipers/washer system: Check fluid level; depending on season, check windshield cleaner and/or freeze protection; use only windshield cleaning agents approved by Porsche

Coolant: Check level and freeze protection

Check drive belt (only after off-road use)

# Every 45,000 km / 30,000 miles / 4 years:

Replace spark plugs

# Every 60,000 km / 40,000 miles / 4 years:

Visual inspection from above for leaks (oils and fluids)

Fuel lines and connections: Visual inspection

# Every 120,000 km / 80,000 miles / 4 years:

Air filter: Replace filter insert

# Additional work every 2 years

### Time-dependent:

Replace brake fluid (only use genuine Porsche brake fluid)

Status report - produce an extended warranty

Tire sealant: Check service life, replace if necessary

#### Test drive

### Every 30,000 km / 20,000 miles / 2 years:

Central locking system, front seats, electric parking brake and footbrake, engine, transmission, steering, ParkAssist, automatic cruise control, PSM switch, heating, sport exhaust system, air conditioning system and instruments: Check function

Oils, fluids: Visual inspection for leaks