



PORSCHE

# Maintenance intervals for Porsche vehicles

07/2010

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Minor maintenance 1 (only 2008)*	Minor maintenance 2 (only 2008)*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter***	Spark plugs***	Air filter***	Brake fluid
Boxster/Boxster S Cayman/Cayman S (as of 2006)	2001–2004	every 12,000 miles or every 2 years			every 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 12,000 miles or every 2 years	every 48,000 miles or every 4 years	every 24,000 miles or every 4 years	every 2 years
	2005–2007	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 20,000 miles or every 2 years	every 60,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years
	2008		every 12,000 miles or every year	every 24,000 miles or every 2 years	every 40,000 miles or every 3 years		every 12,000 miles or every year	every 40,000 miles or every 4 years	every 40,000 miles or every 3 years	every 2 years
	2009	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 40,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years
	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 40,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years
Carrera/ Carrera S	2001–2005	every 12,000 miles or every 2 years			every 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 12,000 miles or every 2 years	every 48,000 miles or every 4 years	every 24,000 miles or every 4 years	every 2 years
	2005–2007	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 20,000 miles or every 2 years	every 60,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years
	2008		every 12,000 miles or every year	every 24,000 miles or every 2 years	every 40,000 miles or every 3 years		every 12,000 miles or every year	every 40,000 miles or every 4 years	every 40,000 miles or every 3 years	every 2 years
	2009–2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 40,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years
911 Turbo	2001–2004	every 12,000 miles or every 2 years			every 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 12,000 miles or every 2 years	every 24,000 miles	every 24,000 miles or every 4 years	every 2 years
	2005–2007	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 20,000 miles or every 2 years	every 40,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years
	2008		every 12,000 miles or every year	every 24,000 miles or every 2 years	every 40,000 miles or every 3 years		every 12,000 miles or every year	every 24,000 miles or every 4 years	every 40,000 miles or every 3 years	every 2 years
	2009	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 30,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years
	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 30,000 miles or every 4 years	every 40,000 miles or every 4 years	every 2 years

\*The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' and 'Maintenance' in 2009.

\*\* On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.

\*\*\* In markets with reduced fuel quality it is possible that shortened maintenance intervals could occur concerning engine oil & oil filter, spark plugs and air filter as of MY 08. For further information please contact your Porsche Partner.

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Minor maintenance 1 (only 2008)*	Minor maintenance 2 (only 2008)*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter***	Spark plugs***	Air filter***	Brake fluid
Cayenne	2003–2006	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles/ 20,000 miles (or every year/every 2 years)	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2008	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		fixed, max. 10,000 miles or max. one year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2009	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		fixed, max. 10,000 miles or max. one year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		fixed, max. 10,000 miles or max. one year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2011	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every one year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
Cayenne Diesel	2009	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		fixed, max. 10,000 miles or max. one year		every 80,000 miles or every 4 years	every 2 years
	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		fixed, max. 10,000 miles or max. one year		every 60,000 miles or every 6 years	every 2 years
	2011	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every one year		every 60,000 miles or every 6 years	every 2 years
Cayenne S Cayenne GTS	2003–2006	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 20,000 miles or every 2 years	every 60,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2008		every 12,000 miles or every year	every 24,000 miles or every 2 years	every 40,000 miles or every 3 years		every 12,000 miles or every year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2009	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2011	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
Cayenne S Hybrid	2011	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every 1 year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years

\*The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' and 'Maintenance' in 2009.

\*\* On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.

\*\*\* In markets with reduced fuel quality it is possible that shortened maintenance intervals could occur concerning engine oil & oil filter, spark plugs and air filter as of MY 08. For further information please contact your Porsche Partner.

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Minor maintenance 1 (only 2008)*	Minor maintenance 2 (only 2008)*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter***	Spark plugs***	Air filter***	Brake fluid
Cayenne Turbo Cayenne Turbo S	2003–2006	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 20,000 miles or every 2 years	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2008		every 12,000 miles or every year	every 24,000 miles or every 2 years	every 40,000 miles or every 3 years		every 12,000 miles or every year	every 24,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2009	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 30,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 30,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
	2011	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles or every year	every 30,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
Panamera S Panamera 4S	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles km or every year	every 40,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years
Panamera Turbo	2010	every 20,000 miles or every 2 years			every 40,000 miles or every 4 years		every 10,000 miles km or every year	every 30,000 miles or every 4 years	every 80,000 miles or every 4 years	every 2 years

\*The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' and 'Maintenance' in 2009.

\*\* On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.

\*\*\* In markets with reduced fuel quality it is possible that shortened maintenance intervals could occur concerning engine oil & oil filter, spark plugs and air filter as of MY 08. For further information please contact your Porsche Partner.