


### Cayman GT4 Clubsport



Unlocking the fuel-cut-off valve

2.2.2.3

### Function of the fuel-cut-off valve



**WARNING**

Driving till fuel tank depleted

Unexpected driveability

Fuel-Cut off valve blocks the fuel inflow

Engine stops

- Never allow the fuel tank to run empty.
- If the warning lights have come on, do not take bends at high speed.

The fuel cut-off valve is a safety valve that prevents fuel leaking if the fuel lines are damaged. The valve closes the fuel supply line in the event of a leakage.



**Information**

When blocking occurs, the fuel-cut-off valve must be held open manually to ensure the fuel can flow again (Figure 2.2.2.3).

When driving on empty, fault messages may appear on the instrument cluster e.g. "reduced engine power"