

Current actual values/input signals

Switch displays by pressing [F8]. Switch to actual values/input signals selection by pressing [F11].

Control unit	Type	Name	Value
DME 997 Turbo + GT2 (DME Turbo up to model year 09 and GT3 from model year 09)		Number of ignitions at speed > maximum speed, range 1	4115
		Number of ignitions at speed > maximum speed, range 2	793
		Number of ignitions at speed > maximum speed, range 3	216
		Number of ignitions at speed > maximum speed, range 4	105
		Number of ignitions at speed > maximum speed, range 5	0
		Number of ignitions at speed > maximum speed, range 6	0
		Operating hours counter reading at overspeed, range 1	1386.700
		Operating hours counter reading at overspeed, range 2	1378.600
		Operating hours counter reading at overspeed, range 3	1377.700

Navigation buttons: Save, Minimum, Logs, Back, TOR

Function keys: F3, F4, F5, F6, F7, F8, F9, F10, F11, F12

Standard keyboard keys: \$, 4, €, 5, %, ^, 6, &, 7, \*, 8, (, )

Special keys: Num Lock, PrtSc SysRq, Scroll Lock