Mileage Shown in Miles	10,000	20,000	30,000	40,000	50,000	60,000	70,000	80,000	90,000	100,000	110,000	120,000
Change engine oil and oil filter	•	•	•	•	•	•	•	•	•	•	•	•
Air filter: Replace filter element				•				•				•
Change PDK transmission oil												•
Change all-wheel drive controller oil								•				
Pollen filter: Replace filter element		•		•		•		•		•		•
Pollen filter: Replace pre-filter element		•		•		•		•		•		•
Replace PDCC reservoir						•						•
Replace Polyrib belt						•						•
Replace Spark Plugs			•			•			•			•
PDK transmission: Change clutch oil						•						•
All headlights - Check adjustment		•		•		•		•		•		•
Ancillary unit mounts and chassis: visual inspection…								•				
Axle joints: Check play; visual inspection of the dust…				•				•				•
Brake hoses: Visual inspection for damage	•	•	•	•	•	•	•	•	•	•	•	•
Brake lines: Visual inspection for damage, routing a…	•	•	•	•	•	•	•	•	•	•	•	•
Brake system: Check of the brake pads and brake di…				•				•				•
Brake system: Visual inspection of the brake pads a…		•				•				•		
Check actuator travel of brake shoes		•		•		•		•		•		•
Check drive belt				•				•				•
Check front firewall body drains for debris		•		•		•		•		•		•
Check front lid lock and safety hook of the front lid …		•		•		•		•		•		•
Check rear firewall body drains for debris		•		•		•		•		•		•
Check wiper blades		•		•		•		•		•		•
Coolant: Check level and antifreeze protection		•		•		•		•		•		•
Diagnosis system: Read fault memory; reset mainte…		•		•		•		•		•		•
Door locks: check function				•				•				•
Drive shafts: Visual inspection of the dust boots for …		•		•		•		•		•		•
Exhaust system: visual inspection for leaks and dam…				•				•				•
Fuel lines and connections: Visual inspection for da…				•				•				•
Horn: Check function		•		•		•		•		•		•
PDCC: Check fluid level		•		•		•		•		•		•
Radiators and air intakes: Visual inspection for exter…		•		•		•		•		•		•
Rear axle steering: Check bellows, dust boots and p…				•				•				•
Reset maintenance interval	•	•	•	•	•	•	•	•	•	•	•	•
Road Test - Check function: ESC Off switch, ESC/TC …		•		•		•		•		•		•
Road Test - Check function: Remote control, front se…		•		•		•		•		•		•
Seat belts: Check function and condition				•				•				•
Service and maintain sunroof		•		•		•		•		•		•
Steering gear: Visual inspection of the dust boots fo…				•				•				•
Tie rod ends: Check play and dust boot				•		•		•				•
Tires: Check condition	•	•	•	•	•	•	•	•	•	•	•	•
Tires: Check tire pressure (TPMS)		•		•		•		•		•		•
Underbody panels: Visual inspection for completen…	•	•	•	•	•	•	•	•	•	•	•	•
Vehicles w/PCCB: PCCB brake discs must be checke…		•		•		•		•		•		•
Visual inspection for leaks from underneath (oils an…	•	•	•	•	•	•	•	•	•	•	•	•
Visual inspection for leaks: (Oil and fluids)		•		•		•		•		•		•
Windshield wiper/washer system, headlight cleanin…		•		•		•		•		•		•
Windshield wiper/washer system: check fluid level; …		•		•		•		•		•		•