PORSCHE

Porsche Classic

Communication Management Plus

Navigation manual

Part number:
99764259100
95564259100

Navigation manual Version 1.0

Porsche, the Porsche crest, and other marks are registered trademarks of Dr. Ing. h.c. F. Porsche AG. Reprinting, even of excerpts, or duplication of any type is only permissible with the written authorisation of Dr. Ing. h.c. F. Porsche AG.
© 2022 Dr. Ing. h.c. F. Porsche AG
Porscheplatz 1
70435 Stuttgart
Germany

Equipment and owner's manual

Porsche reserves the right to update the illustrations and descriptions in this manual to keep current with any developments of the Porsche Classic Communication Management Plus. The equipment variants do not always reflect the standard scope of delivery and may depend on country-specific options. For information on how to install the Porsche Classic Communication Management Plus, please contact a Porsche Classic Partner or an Authorized Porsche Dealership. The equipment of your Porsche Classic Communication Management Plus may differ from the description due to the differing statutory provisions from country to country. If your Porsche Classic Communication Management Plus features equipment items not described here, your Porsche Classic Partner or an Authorized Porsche Dealership will tell you how to operate and maintain them properly.

Please direct any questions, suggestions or ideas concerning your Porsche Classic Communication Management Plus to:

Dr. Ing. h.c. F. Porsche AG
Vertrieb Customer Relations
Porscheplatz 1
70435 Stuttgart, Germany
Germany

Warnings and symbols

⚠ WARNING Serious injuries or death possible

Failure to observe "Warning" category instructions can result in serious injury or death.

- ▶ Warnings must be observed without exception.

Information

Supplemental information is labeled as "Information".

- ▶ Instructions to be followed.

1. Instructions to be followed with several sequential steps.

- ▷ Notice for more information.

Structure of the manual

Table of Contents

Gain an overview and find topics.

▷ From page 4.

Safety notices



Observe the safety instructions for safe navigation.

▷ From page 5.

Destination entry

Learn more about the various ways to enter a destination.

▷ From page 6.

Routes

Learn more about how to plan routes with several waypoints.

▷ From page 12.

Map view



Learn more about information in the map view.

▷ From page 18.

Navigation settings

Learn more about the extensive settings available to you in the navigation system.

▷ From page 21.

Glossary, Index

Jump to specific searched information.

▷ From page 30.

Table of Contents

Important instructions for operating and for safe driving 5

Destination entry 6
Short overview 7
Navigation access 8
Making menu selections 8
Leaving menus 8
Keyboard entries 8
Options for entering addresses 9
Entering addresses 9
Select city center as destination 9
Entering a destination without full address 9
Select destination from points of interest 9
Destination from stored locations 9
Select destination from history 10
Destination from stored routes 10
Destinations based on coordinates 10
Destination from all destination types 10
Destinations based on map 10
Store destination 11

Routes 12
Short overview 13
Enter a new route with waypoints 14
Save route 14
Save active route 14
Rename route 14
Edit route 14
Change destination sequence 14
Delete individual destination 15
Add waypoint 15
Avoid specific sections of a route 15
Avoid certain roads of a route 15
Avoid upcoming route 15
Restore original route 15
Show alternative route 15
Pause navigation 15
Continue navigation 16
Delete next waypoint 16
Delete active route 16
Delete individual saved route 16
Delete all saved routes 16
Determine new starting point 16
Delete new starting point 16
Start route simulation 16
Skip back to the last driving maneuver 17
Skip forward to the next driving maneuver 17
Cancel simulation 17
Increase simulation speed 17
End simulation 17

Map view 18
Switch to map view 19
Display during navigation 19
Driving maneuver 19
Recommended driving lane 19
Display useful information 20

Navigation settings 21
Short overview 22
Set route planning method 23
Set road type 23
Set tone volume 23
Tone output on/off 23
Set level of detail of voice instructions 24
Set warnings for warning points 24
Types of warnings 24
Set warnings on map 24
Set zoom and display angle of map 25
Set day/night view of the map 25
Set map colors 25
Display 3D objects on the map on/off 25
Display points of interest symbols on the map on/off 25
Set data fields on the map 26
Display progress bar for the route 26
Offer freeway services 26
Display points of interest near freeway exits 26
Automatic overview 26
Display traffic signs 26
Display intersection overview 26
Display tunnel view 27
Show parking near destination 27
Offer detour suggestions 27
Map view and direction 27
Set language of user interface 27
Set language for voice output 27
Set units and formats 27
Set time zone automatically 28
Set time zone manually 28
Set daylight saving time 28
Menu animation 28
Start configuration assistant 28
Update digital maps 28

Glossary, Index 30

Important instructions for operating and for safe driving

Perfect technology: Prerequisite for your safety. Premium materials and outstanding workmanship ensure a long life for the Porsche Classic Communication Management Plus. Your attention and care is required to ensure that the Porsche Classic Communication Management Plus can keep its promise. You will then be able to rely on your Porsche Classic Communication Management Plus even in critical situations.

The Porsche Classic Communication Management Plus is the central control unit for the radio, media functions, external audio sources, sound settings, navigation, and Bluetooth® telephony. You must observe the following to ensure that neither you nor others are placed at risk or come to harm when using the Porsche Classic Communication Management Plus:

⚠ WARNING

Accident hazard. Distracted driving can cause you to lose control over the vehicle.

- Only operate the Porsche Classic Communication Management Plus when you can operate your vehicle safely and the traffic situation permits. When in doubt, stop the vehicle and operate the Porsche Classic Communication Management Plus when at a full stop.

⚠ WARNING

Accident hazard. The navigation system is only intended as support for the driver and gives suggestions for the route. It does not relieve you from your full responsibility to observe the proper rules of the road and other applicable regulations governing conduct on public roads. You as the driver must assess the relevant traffic situation. You are solely responsible for driving your vehicle safely.

- Continue to pay attention to the traffic situation.

Destination entry

The following pages provide a description for entering a destination for navigating with the Porsche Classic Communication Management Plus, for example by entering an address or for navigating to points of interest.

Short overview

This short overview does not replace the full description of the "Destination entry" chapter. This short overview in particular does not replace safety instructions and warnings.



Fig.: Main menu

Fig.: Destination entry

What do I want to do?	What do I need to do?
Enter a destination address	▸ Press HOME ▸ **Nav** ▸ **New Route** ▸ **Address** ▸ **Country**, **City/Postcode**, **Street** ▸ **Select as Destination** ▸ **Start Navigation**.
Select last destination	▸ Press HOME ▸ **Nav** ▸ **New Route** ▸ **History** ▸ Select entry from list.
Enter point of interest	▸ Press HOME ▸ **Nav** ▸ **New Route** ▸ **Places** ▸ select point of interest from list.
Select destination directly on map and start	▸ Press HOME ▸ **Map** ▸ select destination directly on map ▸ **Select as Destination** ▸ **Start Navigation**.
End active route	▸ Press HOME ▸ **Nav** ▸ **Delete route**.
Start map view	▸ Press HOME ▸ **Map**.

⚠ WARNING

Accident hazard. The Porsche Classic Communication Management Plus guides you along your route and simplifies traveling to your destination. The rules of the road always apply in the event a driving instruction violates the respective traffic laws. The driver is always responsible for safe driving.

- Continue observing traffic.
- Your speed must be appropriate for visibility, weather, and the condition of the road and traffic.

Information

Within the map view, you can move the map in any desired direction. This is accomplished by pressing the finger on the touch screen and sliding the map in any direction.

Navigation access

Navigation is started automatically in the background when the Porsche Communication Management Plus is started.

- Press HOME ▸ **Nav** : Start in the main menu
- Press HOME ▸ **Map** : Start in the map view
- Press NAV : Start in the main menu (from navigation)
- Press NAV : Start in the map view (from external source, e.g. TUNER)

Information

After starting the Porsche Classic Communication Management Plus, it may take several seconds until the navigation function is available.

Making menu selections

The menu items can be operated with the right rotating knob ●.

- Mark a menu item by rotating the right rotating knob (●).
- Select the marked menu item by pressing the right rotating knob →●.

Menu selections can be entered alternatively on the touch screen.

Leaving menus

- Pressing BACK cancels an operation and returns you to the next higher level menu.

Keyboard entries

You only need to enter letters and numbers when this is required. You can press your fingers on the symbol keys. You can also use the right rotating knob (●) to enter characters on the keyboard.

Fig.: Keyboard entries

A Data entry field
B Suggestions
C Keyboard
D Delete data entry field
E Shift (upper/lower case)
F One step back in the menu
G Toggle between letters/numbers
H Space
I Keyboard type
J Hide keyboard
K Delete last entry

Information

Refer to the user manual for more information about the basic operation of the Porsche Classic Communication Management Plus.

Options for entering addresses

You can for example enter the

- city or postal code, and the street and house number
- city or postal code, and the street
- city or postal code, and center
- city or postal code, and the street and intersection

Information

You can enter all cities, streets, postal codes, etc, that are stored in the digital map.

However, postal codes are not available for certain countries. The country and city are sufficient for navigation. You can enter either a city or a postal code. The street and house number complete the destination address.

Entering addresses

Proceed as follows for general address entries:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Address**.
4. Select menu item **Country**.
5. Select menu item **Town** or **Postcode**.
6. Select menu item **Street**.
7. Select menu item **House number or crossing street.**
8. Press **Select as Destination**.
9. Press **Start Navigation**.

Select city center as destination

Proceed as follows to enter the city center of a city as the destination:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Address**.
4. Select menu item **Country**.
5. Select menu item **Town** or **Postcode**.
6. Select menu item **Go to Town**.
7. Press **Select as Destination**.
8. Press **Start Navigation**.

Entering a destination without full address

You can also enter a destination without all address information. Start by entering all available information and proceed as follows:

1. Press **Select as Destination**.
2. Press **Start Navigation**.

The route is now calculated based on the available information.

Select destination from points of interest

You select the destination from the collection of available points of interest, such as fueling stations, restaurants, or parking. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Places**.
4. Select the point of interest with the menu item **Search by Name or Category** or from a category.
5. Press **Select as Destination**.
6. Press **Start Navigation**.

Information

Use the functions 'along route' or 'at destination' to select points of interest at the destination or along the route.

Destination from stored locations

You can enter a destination from previously stored destinations. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Saved Location.**

4. Select saved location.
5. Press **Select as Destination**.
6. Press **Start Navigation**.

Information

Destinations can only be selected from stored cities, provided cities were already stored.

Select destination from history

You can enter a destination from already previously driven to destinations. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **History**.
4. Select the desired destination.
5. Press **Select as Destination**.
6. Press **Start Navigation**.

Destination from stored routes

You can enter a destination from previously stored routes. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Saved Routes**.
4. Select the desired route.
5. Press **Calculate route**.
6. Press **Start Navigation**.

Information

Destinations can only be selected from stored routes, provided routes were already stored.

Destinations based on coordinates

You can enter a destination by entering coordinates. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Coordinates**.
4. Enter desired latitude.
5. Press **OK**.
6. Enter desired longitude.
7. Press **Go**.
8. Press **Select as Destination**.
9. Press **Start Navigation**.

Destination from all destination types

You can enter a destination from all available destination types. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Search in All**.
4. Enter name, address, or category of the desired destination.
5. Press . A list of available destinations is shown. The right column shows search results filtered by category, such as last destinations.
6. Select desired destination. The location is highlighted on the map.
7. Press **Select as Destination**.
8. Press **Start Navigation**.

Destinations based on map

You can enter a destination directly on map view. Proceed as follows:

1. Press HOME ▶ **Map**.
2. Select the desired point on the map.
3. Press **Select as Destination**.
4. Press **Start Navigation**.

Store destination

Proceed as follows to store destinations:

1. Enter the desired destination.
2. Press .
3. Select menu item **Save Location**.
4. Press .

Routes

The following pages provide a description for entering a route for navigating with the Porsche Classic Communication Management Plus, for example by entering multiple waypoints or by storing routes.

Short overview

This short overview does not replace the full description of the "Routes" chapter. This short overview in particular does not replace safety instructions and warnings.



Fig.: Main menu



Fig.: Route with waypoints

What do I want to do?	What do I need to do?
Enter a route with waypoints	▸ Press HOME ▸ **Nav** ▸ **Multipoint Route** ▸ Enter all destinations ▸ **Calculate route** ▸ **Start Navigation**.
Store a route with waypoints	▸ Press HOME ▸ **Nav** ▸ **Multipoint Route** ▸ Enter all destinations ▸ **Calculate route** ▸ ▸ **Save Route**.
Start saved route	▸ Press HOME ▸ **Nav** ▸ **New Route** ▸ **Saved Routes** ▸ Select route from list ▸ **Calculate Route** ▸ **Start Navigation**.
Change route	▸ Press HOME ▸ **Nav** ▸ **New Route** ▸ **Saved Routes** ▸ Select/change route ▸ **Calculate Route** ▸ **Start Navigation**.
Delete saved route	▸ Press HOME ▸ **Nav** ▸ **New Route** ▸ **Saved Routes** ▸ ▸ **Edit** ▸ Select route ▸ **Delete**.

Enter a new route with waypoints

Proceed as follows to enter a new route with waypoints:

1. Press HOME ▸ **Nav**.
2. Select menu item **Multipoint Route**.
3. Enter a final destination.
4. Press **Select as destination**.
5. Press **Insert Waypoint**.
6. Add a waypoint.
7. Press **Select as Waypoint**.
8. Press **Calculate Route**.
9. Press **Start Navigation**.

Save route

Proceed as follows to store routes:

1. Enter a route.
2. Select menu item **Calculate Route**.
3. Press .
4. Select menu item **Save Route**.
5. Enter route name and press .

Save active route

Proceed as follows to store the active route:

1. Press HOME ▸ **Nav**.
2. Select menu item **Route Summary**.
3. Press .
4. Select menu item **Save Route**.
5. Enter route name and press .

Rename route

Proceed as follows to rename a route:

1. Press HOME ▸ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Saved Routes**.
4. Press .
5. Select menu item **Edit**.
6. Select the desired route.
7. Select menu item **Rename**.
8. Enter route name and press .

Edit route

Proceed as follows to edit a route:

1. Press HOME ▸ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Saved Routes**.
4. Select the desired route and enter changes.
5. Press **Calculate Route**.
6. Press **Start Navigation**.

Change destination sequence

You have the option to change the sequence of the waypoints in your planned route. Proceed as follows:

1. Press HOME ▸ **Nav**.
2. Select menu item **Multipoint Route**.
3. Select destination and waypoints.
4. Select menu item **Move Up** or **Move Down**.

The destination is moved up or down one position in the route list.

Delete individual destination

Proceed as follows to delete individual destinations from a planned route:

1. Press HOME ▸ **Nav**.
2. Select menu item **Multipoint Route**.
3. Select waypoint to delete.
4. Select menu item **Delete**.

Add waypoint

Proceed as follows to add waypoints to an active route:

1. Press HOME ▸ **Nav**.
2. Select menu item **Add Waypoint**.
3. Enter the desired destination.
4. Press **Select as waypoint**.
5. Press **Start Navigation**.

Avoid specific sections of a route

You can avoid certain sections of an active route. Proceed as follows:

1. Press HOME ▸ **Nav**.
2. Select menu item **Detours & Alternatives**.
3. Select menu item **Avoid Special Sections**.
4. Select the desired specific section.
5. Press **Accept**.

Avoid certain roads of a route

You can avoid certain roads of an active route. Proceed as follows:

1. Press HOME ▸ **Nav**.
2. Select menu item **Detours & Alternatives**.
3. Select menu item **Avoid Specific Road**.
4. Select the desired road.
5. Press **Accept**.

Avoid upcoming route

You can avoid upcoming route sections of an active route. Proceed as follows:

1. Press HOME ▸ **Nav**.
2. Select menu item **Detours & Alternatives**.
3. Select menu item **Avoid Route Ahead**
4. Press + or − to determine the length of the route section to avoid.
5. Press **Avoid**.

Restore original route

Proceed as follows to restore the original route:

1. Press HOME ▸ **Nav**.
2. Select menu item **Detours & Alternatives**.
3. Select menu item **Restore Original Route**.
4. Press **OK**.

Show alternative route

Proceed as follows to show alternative routes during an active route:

1. Press HOME ▸ **Nav**.
2. Select menu item **Detours & Alternatives**.
3. Select menu item **Alternative Routes**.
4. Select an alternative from the list on the right.
5. Press **Select**.

Information

The function is available if a route was calculated or navigation is active.

Pause navigation

Proceed as follows to pause an active route:

1. Press HOME ▸ **Nav**.
2. Press ❚❚.

Continue navigation

Press the **Continue Guidance** button to continue the active route.

Delete next waypoint

Proceed as follows to delete the next waypoint:

1. Press HOME ▶ **Nav**.
2. Select menu item **Delete Waypoint** and reconfirm.

Delete active route

Proceed as follows to delete the active route:

1. Press HOME ▶ **Nav**.
2. Select menu item **Delete Route**.
3. Press **OK**.

Delete individual saved route

Proceed as follows to delete a saved route:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Saved Routes**.
4. Press .
5. Select menu item **Edit**.
6. Select the desired route.
7. Select menu item **Delete** and press **Delete**.

Delete all saved routes

Proceed as follows to delete all saved routes:

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Select menu item **Saved Routes**.
4. Press .
5. Select menu item **Edit**.
6. Press .
7. Select the menu item **Delete All**.

Determine new starting point

Proceed as follows to determine a starting point for route different than the current GPS position.

1. Press HOME ▶ **Nav**.
2. Select menu item **Multipoint Route.**
3. Select menu item **Current GPS position**.
4. Select menu item **Set Starting point**.
5. Press **OK**.
6. Enter the desired starting point.
7. Select menu item **Select starting point**.
8. Press **Continue without route**.

Delete new starting point

Proceed as follows to restore the current GPS positions as the starting point.

1. Press HOME ▶ **Nav**.
2. Select menu item **Multipoint Route.**
3. Select starting point.
4. Select menu item **Delete Starting Point**.
5. Press **OK**.

Start route simulation

This function can render a route simulation.

1. Press HOME ▶ **Nav**.
2. Select menu item **New Route**.
3. Enter the destination with the desired method.
3. Select menu item **Select as Destination**.
4. Press .
5. Select menu item **Simulation**.

Information

A route must be calculated before it can be simulated. A route can also be simulated while navigation is running.

▶ Press NAV ▶ **Route Summary** ▶ ▶ **Simulation**.

Skip back to the last driving maneuver

▶ Press .

Skip forward to the next driving maneuver

▶ Press .

Cancel simulation

▶ Press .

Increase simulation speed

▶ Press **1 x** . The simulation speed is increased by 4x, 8x, or 16x.

End simulation

▶ Press .

Map view

The following pages provide a description of the most important information in the map view of the Porsche Classic Communication Management Plus.

Switch to map view

You can switch to the map view of the navigation with the following methods:

1. Press HOME.
2. Press **Map**.

Display during navigation



Fig.: Display during navigation

A The projected arrival time
B The current driving time to destination
C The current distance to destination
D The current vehicle position

Driving maneuver



Fig.: Driving maneuver

A The next driving maneuver and the distance to the driving maneuver
B The next following driving maneuver
C The next street or the next city

The symbol for the next driving maneuver (top left) provides information about the type of driving maneuver, e.g. turn right. A subsequent driving maneuver that follows shortly thereafter is rendered as a smaller symbol (to the right).

Recommended driving lane



Fig.: Recommended driving lane

A The not recommended driving lanes
B The recommended driving lanes

When the digital map contains the corresponding data, the Porsche Classic Communication Management Plus can display driving lane recommendations for the upcoming driving maneuvers on multi-lane roads. Driving lane recommendations are shown with small arrows along the bottom of the map. The recommended driving lane is highlighted.



Fig.: Recommended driving lane

A The recommended driving lane

B The not recommended driving lane

When additional information is available, the arrows are replaced by traffic signs. The traffic signs show the available destinations and the number of the street to where the relevant lane travels. During active navigation, the signs that lead to the recommended traveling lane are highlighted.

Display useful information

The navigation software supplies certain useful additional information, such as country information. Proceed as follows to retrieve these:

1. Press HOME ▸ **Nav** .
2. Select menu item **Useful Information**.
3. Select from the following information:

- **Where Am I:** Shows the current vehicle position.
- **Help nearby:** Shows preset points of interest categories, such as nearby repair shops.
- **Sunrise & Sunset:** Shows the sunup and sundown time for the current vehicle position.
- **GPS information:** Shows information for GPS signal strength and satellite positions.

Navigation settings

The following pages provide a description of the extensive settings made available by the Porsche Classic Communication Management Plus navigation, such as tone settings, display options, or regional adjustments.

Short overview

This short overview does not replace the full description of the "Navigation settings" chapter. This short overview in particular does not replace safety instructions and warnings.



Fig.: Settings



Fig.: Route settings

What do I want to do?	What do I need to do?
Set route planning method	▸ Press HOME ▸ **Nav** ▸ **Settings** ▸ **Route Preferences** ▸ **Route Planning Methods** ▸ **Fast**, **Easy**, **Short** or **Green**.
Set road type	▸ Press HOME ▸ **Nav** ▸ **Settings** ▸ **Route Preferences** ▸ Checkbox **Motorways** ☑, **Road With Period Charge** ☑, **Road With Per-use Toll** ☑ or other options.
Set warnings	▸ Press HOME ▸ **Nav** ▸ **Settings** ▸ **Warnings** ▸ Desired option.
Set navigation display	▸ Press HOME ▸ **Nav** ▸ **Settings** ▸ **Navigation View** ▸ Desired option.
Retrieve map index	▸ Press HOME ▸ **Nav** ▸ **About** ▸ **Content** ▸ **Maps** ▸ Desired country.

Set route planning method

Proceed as follows to set defaults for route planning, such as fast or short:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Route settings**.
4. Select menu item **Route planning methods**.
5. Select the desired default setting.

- **Fast:** The Porsche Classic Communication Management Plus calculates a route with the shortest possible travel time.
- **Easy:** The Porsche Classic Communication Management Plus calculates a route with the easiest possible travel, such as the lowest possible number of turns.
- **Short:** The Porsche Classic Communication Management Plus calculates a route with the shortest possible travel distance.
- **Green:** The Porsche Classic Communication Management Plus calculates a route with the best possible fuel economy.

Set road type

You have the ability to include or exclude various road types when calculating the route. Proceed as follows:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Route Preferences**.
4. Enable or disable the desired checkbox:

- **Motorways:** When this function is set, the route calculation includes highways.
- **Road With Period Charge:** When this function is set, the route calculation includes roads subject to time-dependent use fees.
- **Road With Per-use Toll:** When this function is set, the route calculation includes roads subject to a route-dependent use fee.
- **Ferries:** When this function is set, the route calculation includes automobile ferries.
- **Car Shuttle Trains:** When this function is set, the route calculation includes car trains.
- **Carpool Lanes (HOV):** When this function is set, the route calculation includes Carpool Lanes.
- **Unpaved Roads:** When this function is set, the route calculation includes unpaved roads.

Set tone volume

Proceed as follows to set the volume for signal tones and voice output:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Sound**.
4. Select the desired function and set the volume:

- **Silent Mode**
- **Voice:** Set volume for voice output.
- **Alerts:** Set the volume for acoustic warnings.
- **Ding:** Set the volume or attention tone. The attention tone sounds prior to navigation announcements.
- **Keys:** Set volume for button tones.

Tone output on/off

Proceed as follows to enable/disable tone output:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Sound**.

4. Enable or disable the desired checkbox ☑:

- **Voice Guidance:** Voice instructions are output when this function is switched on.
- **Early driving maneuver announcement:** When this function is switched on, the Porsche Classic Communication Management Plus announces the driving maneuver earlier than in the standard setting. When the function is switched off, the announcement is made only shortly before the upcoming driving maneuver.

Set level of detail of voice instructions

Proceed as follows to set the level of detail of voice instructions:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Sound**.
4. Select menu item **Verbosity Level**.
5. Select the desired function:

- **Minimum:** Output voice instruction once directly prior to the next driving maneuver.
- **Medium:** Voice instructions are announced when approaching the next driving maneuver and immediately prior thereto.
- **Wordy:** Voice instructions are announced at a relatively large distance to the next driving maneuver and immediately prior thereto.

Set warnings for warning points

A warning point is a location along the route that requires special attention, such as a school zone. The Porsche Classic Communication Management Plus gives a warning as you approach the location. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Warnings**.
4. Select menu item **Alert Points**.
5. Enable or disable checkbox **Alert Point Warnings** ☑.

Types of warnings

Proceed as follows to determine at what types of locations a warning is given.

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Warnings**.
4. Select menu item **Alert Points**.
5. Select menu item **Alert Types**.
6. Select the desired type of warning, such as **Railway crossing**, **Fire station** or **Toll station**.

Information

The function **Alert Point Warnings** must be enabled for the settings.

Set warnings on map

When the function is enabled, the warnings appear on the map.

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Warnings**.
4. Select menu item **Road Signs**.
5. Enable checkbox **Road Signs** ☑ and select the desired options.
6. Select the desired street signs.
7. Select menu item **Warning Type**.
8. Enable the desired setting.
9. Select menu item **Distance**.
10. Enter the desired distance.

Information

The options give a warning for special traffic situations, such as sharp turns (Curves and Corners), end of lane, no passing (Lanes and Overtaking), dangerous crossings (Traffic and Crossings) or miscellaneous hazard situations defined by local conditions (General Warnings).

Set zoom and display angle of map

Proceed as follows to set the display angle of the map:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Select menu item **Map Appearance**.
5. Select menu item **Viewpoint**.
6. Enable the desired setting.
   - **Far,**
   - **– or –**
   - **Normal,**
   - **– or –**
   - **Close.**

Set day/night view of the map

Proceed as follows to set the day/night view of the map:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Select menu item **Map Appearance**.
5. Select menu item **Color Mode**.
6. Enable the desired setting.
   - **Automatic,**
   - **– or –**
   - **Day,**
   - **– or –**
   - **Night.**

Set map colors

Proceed as follows to set the map colors:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Select menu item **Map Appearance**.
5. Select menu items **Day Map Colors** or **Night Map Colors**.
6. Use the arrows to select the desired map color.

Display 3D objects on the map on/off

Proceed as follows to display 3D objects on the map:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Select menu item **Map Appearance**.
5. Enable chekboxes **Landmarks**, **Buildings** or **3D Terrain** ☑. The following 3D objects can be selected:
   - **Landmarks:** 3D rendering of landmarks or known objects
   - **Buildings:** 3D renderings of city buildings
   - **3D Terrain:** 3D rendering of surrounding terrain

Display points of interest symbols on the map on/off

Proceed as follows to display points of interest on the map:

1. Press HOME ▸ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Select menu item **Map Appearance**.
5. Enable checkbox **Place Markers** ☑.
6. Select menu item **Select Marked Places**.
7. Select the desired point of interest category, such as **Shopping**, **Restaurant** and others.

Set data fields on the map

You have the option to determine the data shown in the map view. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Select menu item **Data Fields**.
5. Press **First**, **Second**, **Third** or **Without Route**.
6. Select the desired setting, such as **Time to Destination** and others.

Display progress bar for the route

The route progress bar can be enabled to simplify the display of the vehicle position along the route. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Activate or deactivate checkbox **Route Progress Bar**.

Offer freeway services

This function allows you to retrieve information during freeway travel, e.g. for fueling stations.

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Activate or deactivate checkbox **Offer Motorway Services**.

Display points of interest near freeway exits

This function gives you the ability to determine what point of interest categories near freeway exits are displayed on the map. Proceed as follows:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Select menu item **Services Displayed**.
5. Select the point of interest category to be edited.
6. Select desired subcategory.
7. Select menu item **Select**.

Automatic overview

This function simplifies recognizing the upcoming driving maneuver by changing the map section and the angle of view. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Activate or deactivate checkbox **Automatic Overview**.

Display traffic signs

This function displays travel lanes by showing traffic signs. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Activate or deactivate checkbox **Signposts**.

Display intersection overview

When the digital map contains the corresponding data, a 3D view is displayed as you approach a freeway exit or a difficult intersection. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Activate or deactivate checkbox **Junction View**.

Display tunnel view

This function displays a tunnel view while traveling through a tunnel. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Activate or deactivate checkbox **Tunnel View**.

Show parking near destination

The Porsche Classic Communication Management Plus uses this function to show parking near the destination. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Activate or deactivate checkbox **Offer Parking Around Destination**.

Offer detour suggestions

The Porsche Classic Communication Management Plus uses this function to show points of interest near the freeway exit or avoidable route sections (e.g toll roads) when you leave the calculated freeway route. Proceed as follows to enable/disable the function:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Navigation View**.
4. Enable or disable checkbox **Offer Hints Upon Detour**.

Map view and direction

Proceed as follows to set the map view and direction:

1. Press HOME ▶ **Nav**.
2. Press **3D**, **2D** or 2D.

- **3D map in travel direction:** The map display is slightly inclined and rotates in travel direction.
- **2D map in travel direction:** The map display shows the birds-eye perspective and rotates in travel direction.
- **2D map in northerly direction:** The map view shows the birds-eye perspective. The map does not rotate in travel direction. North is always on top.

Set language of user interface

Information

The menu language for navigation is controlled centrally by the global settings menu of the Porsche Classic Communication Management Plus. Navigation is restarted after the menu language is changed.

Set language for voice output

Proceed as follows to change the language of the voice output:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Regional**.
4. Select menu item **Voice Language**.
5. Select the desired language and speaker.

Set units and formats

Proceed as follows to change the units used for navigation:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Regional**.
4. Select menu item **Units and Formats**.

5. Select the desired unit/the desired format
   - **Distance,**
   - **– or –**
   - **Fuel Consumption,**
   - **– or –**
   - **Weight,**
   - **– or –**
   - **Time Format,**
   - **– or –**
   - **Date Format,**
   - **– or –**
   - **Date Delimiter,**
   - **– or –**
   - **Coordinate Display Format.**
6. Make the desired changes.

Set time zone automatically

Proceed as follows to automatically adjust the time zone:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Region**.
4. Select menu item **Time zone**.
5. Press **Determine Time zone automatically**.

Set time zone manually

Proceed as follows to manually adjust the time zone:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Regional**.
4. Select menu item **Time Zone**.
5. Select menu item **Manual Time Zone.**
6. Select menu item **Time Zone**.
7. End of the desired value.

Set daylight saving time

Proceed as follows to enable/disable daylight saving time:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Region**.
4. Select menu item **Time Zone**.
5. Select menu item **Manual Time Zone.**
6. Activate or deactivate checkbox **Daylight Saving Time**.

Menu animation

Proceed as follows to enable/disable menu animation:

1. Press HOME ▶ **Nav**.
2. Select menu item **Settings**.
3. Select menu item **Display**.
4. Activate or deactivate checkbox **Menu Animations**.

Start configuration assistant

The configuration assistant gives you the ability to adjust the basic settings, such as language, time format, and other units according to your region. Proceed as follows to start the configuration assistant:

1. Press HOME ▶ **Nav**.
2. Press **Settings**.
3. Press **Start Configuration Wizard**. The configuration system starts and guides you through the configuration.

Update digital maps

Optimized navigation can only be achieved with up-to-date map data. The map data is updated by purchasing a data storage device (MicroSDHC card) with map data. Then replace the MicroSDHC card currently in the "MAP" card slot with the new card. Contact your authorized Porsche dealer for the availability of up-to-date map data.

Glossary, Index

A

Add waypoint 15
Automatic overview 26
Avoid certain roads of a route 15
Avoid specific sections of a route 15
Avoid upcoming route 15

C

Cancel simulation 17
Change destination sequence 14
Continue navigation 16

D

Delete active route 16
Delete all saved routes 16
Delete individual destination 15
Delete individual saved route 16
Delete new starting point 16
Delete next waypoint 16
Destination entry 6
Destination from all destination types 10
Destination from stored locations 9
Destination from stored routes 10
Destinations based on coordinates 10
Destinations based on map 10
Determine new starting point 16
Display 3D objects on the map on/off 25
Display during navigation 19
Display intersection overview 26
Display points of interest near freeway exits 26
Display points of interest symbols on the map on/off 25
Display progress bar for the route 26
Display traffic signs 26
Display tunnel view 27
Display useful information 20
Driving maneuver 19

E

Edit route 14
End simulation 17
Enter a new route with waypoints 14
Entering addresses 9
Entering a destination without full address 9

I

Important instructions for operating and for safe driving 5
Increase simulation speed 17

K

Keyboard entries 8

L

Leaving menus 8

M

Making menu selections 8
Map view 18
Map view and direction 27
Menu animation 28

N

Navigation access 8
Navigation settings 21

O

Offer detour suggestions 27
Offer freeway services 26
Options for entering addresses 9

P

Pause navigation 15

R

Recommended driving lane 19
Rename route 14
Restore original route 15
Routes 12

S

Save active route 14
Save route 14
Select city center as destination 9
Select destination from history 10
Select destination from points of interest 9
Set data fields on the map 26
Set daylight saving time 28
Set day/night view of the map 25
Set language for voice output 27
Set language of user interface 27
Set level of detail of voice instructions 24
Set map colors 25
Set road type 23
Set route planning method 23
Set time zone automatically 28
Set time zone manually 28
Set tone volume 23
Set units and formats 27
Set warnings for warning points 24
Set warnings on map 24
Set zoom and display angle of map 25
Show alternative route 15
Show parking near destination 27
Skip back to the last driving maneuver 17
Skip forward to the next driving maneuver 17
Start configuration assistant 28
Start route simulation 16

Store destination 11
Switch to map view 19

T

Tone output on/off 23
Types of warnings 24

U

Update digital maps 28