

Print at: Wednesday, May 30, 2012 9:08:05 PM  
 Host: YOUR-699C5579F9  
 User: Fujitsu T Series

MoTeC ECU Manager - porsche 944 Eastern Creek I2

File Adjust View Tools Layout Utilities Help

Standard knock idle Cam pos dbw

Ign Main (BTDC)

RPM	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	5500	5750	6000	6250	6500
260.0	20.0	21.5	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.5	20.0	21.0	20.0	19.5	19.0	18.0	17.5	17.5	17.5	17.5	17.5	17.5
240.0	20.0	22.5	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.5	21.0	22.0	22.0	22.5	22.0	22.0	22.0	22.0	22.0	22.0	22.0	22.0
220.0	20.0	23.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.5	21.5	22.5	23.5	24.5	25.0	25.0	24.5	24.5	24.0	24.0	24.0	24.0
200.0	20.0	24.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.5	22.5	23.5	24.5	25.5	27.0	27.0	26.0	26.0	26.0	26.0	26.0	26.0
180.0	20.0	25.0	20.0	20.0	20.0	20.0	20.0	20.0	20.5	21.0	23.0	24.0	26.0	27.5	29.0	30.0	29.5	29.0	29.0	29.0	29.0	29.5
160.0	21.0	25.5	21.0	21.0	21.0	21.0	21.0	21.0	21.5	23.0	25.0	26.5	27.5	28.5	30.0	30.5	32.0	33.5	34.0	35.0	34.0	35.0
140.0	24.0	26.5	22.0	22.0	22.0	22.0	22.0	22.5	23.5	27.0	28.0	28.5	28.5	30.0	31.0	33.0	34.5	34.5	35.0	35.5	36.5	36.5
120.0	25.5	27.5	24.0	24.0	24.0	25.0	27.0	28.0	29.0	30.0	31.0	32.5	33.5	34.5	35.5	37.0	38.0	38.5	39.5	40.0	40.0	40.0
100.0	26.0	28.0	24.0	24.0	25.5	28.5	30.5	31.5	32.5	33.5	34.5	36.0	38.0	39.5	40.0	40.5	42.0	43.5	44.5	44.5	44.5	44.5
80.0	28.0	29.0	24.0	24.0	25.5	28.5	31.0	32.0	33.0	33.5	35.0	36.5	38.5	40.0	41.0	42.0	43.5	44.5	45.5	45.5	45.5	45.5
60.0	15.0	30.0	24.0	24.0	25.5	29.0	31.0	33.0	34.0	35.5	36.0	38.0	39.5	40.5	42.0	43.0	44.5	45.5	46.0	46.0	46.5	46.5
40.0	15.0	30.0	25.5	25.5	26.0	29.0	31.5	34.0	38.0	39.5	40.0	41.0	42.0	43.0	44.0	44.5	45.5	46.0	47.0	47.0	47.0	47.0
20.0	15.0	31.5	28.2	29.0	30.5	33.5	35.7	38.5	41.7	43.5	44.0	44.2	45.0	45.2	46.0	46.0	46.5	46.5	47.0	47.2	47.2	47.2
10.0	15.0	32.0	31.0	32.5	34.5	36.5	38.5	41.0	43.5	45.5	46.0	46.0	46.5	46.5	47.0	47.0	47.0	47.0	47.5	47.5	47.5	47.5

Ign Overall Trim  
 Ignition Trims (dBTDc)

Trim Storage  
 Sync Voltage  
 Battery Voltage

13.00  
 -3.00  
 -60.0 s 0.0 s

ECU NOT Connected Unable to find a USB or CAN connection to the device. Arrow Keys-Select PgUp/PgDn-Adjust Enter-Set Value