

Intermediate Maintenance Checklist – Cayenne (V6)/S/GTS/S Hybrid/Turbo/Diesel (2013)
 Required Maintenance and Lubrication Service

Oil Change Cayenne/S/GTS/S Hybrid/Turbo Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**
 Cayenne Diesel (USA Only) Every 5,000 miles (7,500 km) or 1 year. **See Below Check Box.**

- Intermediate Maintenance** (Labor Operation 03 14 00 ...) See Technical Manual
 After 20,000, 60,000, 100,000, 140,000 miles etc. / 30,000, 90,000, 150,000, 210,000 km etc.
Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10,.... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Electrics

- Diagnosis system: Read out fault memory and transfer gear wear integrator; reset maintenance interval
 Read out soot mass particle filter (Cayenne Diesel only)
- Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment
- Horn: Check operation
- Tires: Check tire pressure
- Batteries and ventilation hoses: Check condition
- Electrical equipment as well as indicator and warning lights: Check operation

Outside of Vehicle

- Check wiper blades
- External spare tire: Check condition and tire pressure
- Vehicle lighting: Check operation
- All headlights: Check adjustment
- Radiators and air intakes: Visual inspection for exterior debris and blockage

Under the Vehicle

- Drain engine oil and change oil filter (Except Diesel) (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 00)
- Drain engine oil and change oil filter Diesel (USA Only) (Every 5,000 miles/7,500 km, see separate Oil Change Sheet, PNA 000 162 01)
- Tires: Check condition and tire pressure
- Brake system: Visual inspection of the brake pads and brake discs for signs of wear (without removing wheels)
- Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
- Axle shafts: Visual inspection of the dust boots for leaks & signs of damage
- Drive shafts: Visual inspection of the sleeves for leaks & signs of damage

Engine Compartment

- Fill engine oil (See separate Oil Change Sheets, PNA 000 162 0X or PNA 000 162 0L)
- Check drive belt
- Replace fuel filter (Cayenne Diesel only)
- Coolant and hoses: Check level and antifreeze, check condition of hoses
- Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level
- PDCC: Check fluid level
- Check firewall body drains for debris

Luggage Compartment

- Check and fill AdBlue®, diesel exhaust fluid (Cayenne Diesel only)

Additional Maintenance – Drain Water From Fuel Filter (Labor Operation 20 34 07 ...)

- Drain water from fuel filter: Cayenne Diesel every 10,000 miles / 15,000 km or 1 year

Additional Maintenance – Replace Spark Plugs (Labor Operation 03 81 00 ...)

- Replace spark plugs: Cayenne V6 every 40,000 miles / 60,000 km or 4 years
- Replace spark plugs: Cayenne S Hybrid every 40,000 miles / 60,000 km or 4 years
- Replace spark plugs: Cayenne S every 40,000 miles / 60,000 km or 4 years
- Replace spark plugs: Cayenne Turbo every 30,000 miles / 45,000 km or 4 years

Additional Maintenance every 60,000 miles / 90,000 km or 6 years (Labor Operation 03 83 00 ...)

- Replace PDCC reservoir
- Replace air filter element: Cayenne Diesel
- Replace supercharger drive belt: Cayenne S Hybrid

Additional Maintenance every 80,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00 ...)

Air filter element/s should be changed more often dependent on vehicle use and operation in dusty environments.

- Air filter element/s (1 or 2 dependent on options)

Additional Maintenance every 160,000 miles / 240,000 km or 16 years (Labor Operation 03 95 00 ...)

- Change front differential oil
- Change rear differential drive oil
- Change transfer case oil: (Cayenne V6, Diesel, S Hybrid)
- Change manual transmission oil
- Change Tiptronic transmission oil and ATF filter

Additional Maintenance every 2 years (Labor Operation 03 51 00 ...)

- Change brake fluid (use only Original Porsche Brake Fluid)
- Clutch: Change brake fluid & perform test and adaption (use only Original Porsche Brake Fluid) Cayenne S Hybrid

Additional Maintenance every 4 years (Labor Operation 03 52 00 ...)

- Replace tire sealant
- Replace AdBlue® fluid if the vehicle is driven less than 10,000 miles / 15,000 km within the 4-year time period

Inspection Performed - Technician Signature: _____

Road Test Check

- Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, automatic speed control, PSM switches, sports exhaust system, heater, air-conditioning system and instruments: Check operation
- Oils, fluids: Visual inspection for leaks

Road Test Performed - Technician Signature: _____

Customer Name: _____ Date: ____/____/____

VIN: WP1 _____

Mileage (check one) Miles Kilometers: _____

Dealer Name: _____ Dealer Code: _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____

Oil Change Service Checklist – Cayenne Diesel – USA only (2013)

- Change Engine Oil & Filter Service** (Labor Operation 03 04 00 ..) See Technical Manual
Every 5,000 miles (7,500 km) or 1 year
Includes: Topping off AdBlue® reducing agent

Note: See appropriate Cayenne Maintenance Checklists for complete maintenance requirements.

Oil Change Service Performed - Technician Signature: _____

Customer Name: _____

Date: ___/___/___

VIN: WP1 _____

Mileage (check one) Miles Kilometers: _____

Dealer Name: _____

Dealer Code: _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____