

# PORSCHE

## Maintenance (C markets\*) Cayman GT4 (981) as of 2015 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

**Maintenance**

at 40000, 80000, 120000, 160000 km / 24000, 48000, 72000, 96000 miles etc.

(Labour operation: 03 16 00..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

**Note:** If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓

<b>Electrics</b>	
Windscreen wiper/washer system, headlight cleaning system: check function	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory; reset maintenance interval	
<b>Inside the vehicle</b>	
Particle filter: replace filter element	
Seat belts: check function and condition	
Door locks: check function	
<b>Front luggage compartment</b>	
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly	
Replace air intake pre-filter	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche	
<b>Outside the vehicle</b>	
Check wiper blades	
All headlights: check adjustment	
Radiators and air intakes: visual inspection for external contamination and blockage	
Brake system: check brake pads and brake discs for wear	
Brake hoses: visual inspection for damage	
<b>Under the vehicle</b>	
Drain engine oil	
Change oil filter	
Underbody panels: visual inspection for completeness, secure installation and damage	
Tyres: check condition	
Visual inspection for leaks from underneath (oils and other fluids)	
Brake lines: visual inspection for damage, routing and corrosion	
Steering gear: visual inspection of the bellows for damage	
Tie rod joints: check play and dust bellows	
Drive shafts: visual inspection of the boots for leaks and damage	
Axle joints: check the play and visually inspect the dust boots for damage	
Check that threaded connections for chassis adjustment at front and rear are secure	
Check vehicle height	
Exhaust system: visual inspection for leaks and damage, check engine mount	
Control boxes for exhaust flaps: check function	
<b>Rear luggage compartment</b>	
Fill in engine oil	
Coolant: check level and antifreeze	
Check rubber stops on rear lid	

# PORSCHE

Maintenance (C markets\*)

Cayman GT4 (981)

as of 2015 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

--

<b>Engine compartment</b>	
Fuel lines and connections: visual inspection	
Visual inspection for leaks from above (oils and other fluids)	

\* For country allocation, see overview of A, B and C markets

# PORSCHE

## Maintenance (C markets\*) Cayman GT4 (981) as of 2015 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

--

**Additional maintenance every 2 years**  
(Labour operation: 03 51 00..)

Change brake fluid (use only original Porsche brake fluid)	
Prepare condition report for long-life guarantee	
Tyre sealing compound: check use-by date and replace if necessary	

**Additional maintenance for drive belt**  
(Labour operation: 03 60 00..)

Check drive belt, at 60,000 km/36,000 miles or every 4 years	
Check drive belt, at 140,000 km/84,000 miles or every 10 years	
Check drive belt, at 220,000 km/132,000 miles or every 16 years	

**Additional maintenance for spark plugs**  
**every 20000 km / 12000 mls or every 4 years**  
(Labour operation: 03 81 00..)

Replace spark plugs	
---------------------	--

**Additional maintenance every 80000 km / 48000 mls or every 6 years**  
(Labour operation: 03 82 00..)

Air cleaner: replace filter elements	
Replace drive belt	

**Additional maintenance every 120000 km / 72000 mls or every 4 years**  
(Labour operation: 03 85 00..)

Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage	
---	--

**Additional maintenance every 180000 km / 108000 mls or every 12 years**  
(Labour operation: 03 88 00..)

Manual transmission: change oil	
---------------------------------	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, clutch, steering, transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, sports exhaust system, Automatic intermediate acceleration, heating, air conditioning and instruments: check function	
---	--

Signature (final check): \_\_\_\_\_

┌──────────────────┐  
└──────────────────┘  
Porsche Centre