

Major Maintenance Checklist – 911 GT3 (997)

Required Maintenance and Lubrication Service (USA & Canadian Vehicles Only)

☐ Major Maintenance (Labor Operation 03 26 00) See Technical Manual
After 24,000, 48,000, 72,000, 96,000 miles (40,000, 80,000, 120,000, 160,000 km) etc.
Note: If the mileage for scheduled maintenance is not reached, major maintenance must be performed no later than after
4, 8, 12 years.
The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and
topping off, but do not include repairing, replacing and reconditioning parts or assemblies.
☐ Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O.
☐ Change engine oil and oil filter
☐ Drive belt: Check condition
Replace spark plugs: See Additional maintenance
☐ Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses);
Underbody panels: visual inspection for completeness, installation and damage ☐ Coolant hoses: Check condition
Radiators and air intakes: Visual inspection for external debris and blockage
Coolant: Check level and antifreeze
☐ Air filter: Replace filter element
Pollen filter: Replace filter element
☐ Fuel lines and connections: Visual inspection for damage and leaks
☐ Brake system: Visual inspection of the brake pads and brake discs for wear
Parking brake: Check free play of parking brake lever
Brake hoses and lines: Visual inspection for damage, routing and corrosion
Clutch: Check pedal end position
Steering gear: Visual inspection of the dust boots for damage
Tie rod ends: Check play and dust boots Axle joints: Check play; visual inspection of the dust boots for damage. Check the screw connections of the front and
rear running gear adjustment points are secure
☐ Drive shafts: Visual inspection of the dust boots for leaks and damage
Exhaust system: Visual inspection for leaks and damage; check mounting and heat shields
Check function of vacuum operated exhaust flaps
Tires: Check condition and tire pressure
Check firewall body drains for debris
Check the door, lid locks and safety hook of the front lid for secure seating and function properly
Seat belts: Check function and condition
Vehicle lighting: Check function All headlights: Check setting
☐ Horn: Check function
Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protec-
tion during winter months)
Battery: Check condition and electrolyte level
Electrical equipment, warning and indicator lights: Check function
Additional maintenance for spark plugs Labor operation 03 81 00
Replace spark plugs every 24,000 miles (40,000 km) or every 4 years
Additional maintenance 48,000 miles (80,000 km) or every 6 years Labor operation 03 82 00
Replace drive belt
Replace fuel filter
ALIN 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
Additional maintenance every 96,000 miles (160,000 km) or 12 years Labor operation 03 88 00
Change manual transmission oil
Every 2 years
☐ Change brake fluid
☐ File Condition Report for Long-life guarantee
Every 4 years
Replace tire sealant
After 4, then every 2 years

After 4, 8, 10, then every 2 years		
 ☐ Inspect airbag system ☐ Mounts for engine, transmission and running gear: Visually check all rubber mounts for signs of wear and/or damage 		
Inspection Performed - Technician Signature:		
Road Test Check		
Remote control, seats, foot and parking brake (also actuation travel), engine, clutch, steering, transmission, cruise control, TC switch, PASM switch, SPORT switch, heating, air conditioning system and instruments: Check function		
Oils, fluids: Visual inspection for leaks		
Road Test Performed - Technician Signature:		
Customer Name:	Date:/	
VIN: WPO		
Mileage (check one) 🖵 Miles 🖵 Kilometers:		
Dealer Name:	_ Dealer Code:	
Repair Order #:		
Technician Name:	-	
Technician Signature:		