

Maintenance Checklist - 911 GT3 (997) (2010)

Required Maintenance and Lubrication Service (USA & Canadian Vehicles Only, Not For 911 Turbo (997), use separate checklist)

■ Maintenance (Labor Operation 03 16 00) See Technical Manual
After 24,000, 48,000, 72,000, 96,000 miles (40,000, 80,000, 120,000, 160,000 km) etc.
Note: If the mileage for scheduled maintenance is not reached, maintenance must be performed no later than after 4, 8, 12 years.
The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and
topping off, but do not include repairing, replacing and reconditioning parts or assemblies.
Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O.
Change engine oil and oil filter (Every 12,000 miles/20,000 km, see separate Oil Change Sheet, PNA 000 162 GA)
Replace drive belt
Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, secure installation and damage
Coolant hoses: Check condition
Radiators and air intakes: Visual inspection for external debris and blockage
Coolant: Check level and antifreeze protection level
Air filter: Replace filter element
Pollen filter: Replace filter element
Fuel lines and connections: Visual inspection for damage and leaks
Brake system: Visual inspection of the brake pads and brake discs for wear
Parking brake: Check free play of parking brake lever
Parking brake: Check free play of parking brake lever
Brake hoses and lines: Visual inspection for damage, routing and corrosion
Clutch: Check pedal end position
Steering gear: Visual inspection of the dust boots for damage
Tie rod ends: Check play and dust boots
Axle joints: Check play; visual inspection of the dust boots for damage. Check the screw connections of the front and
rear running gear adjustment points are secure
Check and torque all front and rear suspension adjustment points Drive shafts: Visual inspection of the dust boots for leaks and damage
☐ Drive shafts: Visual inspection of the dust boots for leaks and damage ☐ Exhaust system: Visual inspection for leaks and damage; check mounting and heat shields
Check operation of exhaust flap control
☐ Tires: Check condition and tire pressure
☐ Check firewall body drains for debris
Check the door, lid locks and safety hook of the front lid for secure seating and function properly
Seat belts: Check function and condition
Vehicle lighting: Check function
All headlights: Check setting
Horn: Check function
☐ Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze
protection during winter months)
Check wiper blades
Battery: Check condition and electrolyte level
Electrical equipment, warning and indicator lights: Check function
Additional maintenance for spark plugs Labor operation 03 81 00
Replace spark plugs every 24,000 miles (40,000 km) or every 4 years
Additional maintenance every 96,000 miles (160,000 km) or 12 years Labor operation 03 86 00
Change manual transmission oil
Every 2 years
☐ Change brake fluid
Every 4 years
Replace tire sealant
After 4, then every 2 years
☐ Check battery for the tire pressure monitoring system

After 4, 8, 10, then every 2 years		
 Inspect airbag system Assembly and running gear mounts: Visual inspection of all rubber/hydraulic mounts for damage 		
Inspection Performed - Technician Signature:		
Road Test Check		
Remote control, front seats, foot brake and parking brake (also operating travel), engine, clutch, steering, transmission, TC Switch, automatic speed control, PASM switch, Sport switch, heater, air-conditioning system and instruments: Check operation Oils, fluids: Visual inspection for leaks		
		Road Test Performed - Technician Signature:
Customer Name:	Date:/	
VIN: WPO	_	
Mileage (check one) Miles Kilometers:	_	
Dealer Name:	Dealer Code:	
Repair Order #:		
Technician Name:		
Technician Signature:		