

Intermediate Maintenance Checklist – Macan/S/GTS/Turbo (2015-on)

Required Maintenance and Lubrication Service

Oil Change Macan Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

- Intermediate Maintenance** (Labor Operation 03 14 00 ..) See Technical Manual
After 20,000, 60,000, 100,000, 140,000 miles etc. / 30,000, 90,000, 150,000, 210,000 km etc.
Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10..... years.

The terms ‘check’ and ‘inspection’ include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Electrics

- Diagnosis system: Read out fault memory and transfer gear wear integrator; reset maintenance interval
- Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment
- Horn: Check operation
- Tires: Check tire pressure (TPM)

Inside of Vehicle

- Pollen filter: Replace filter element

Outside of Vehicle

- Check wiper blades
- Vehicle lighting: Check operation
- All headlights: Check adjustment
- Radiators and air intakes: Visual inspection for exterior debris and blockage
- Check all body drains for debris

Under the Vehicle

- Drain engine oil and change oil filter (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 NC)
- Tires: Check condition
- Brake system: Visual inspection of the brake pads and brake discs for signs of wear (without removing wheels)
- Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
- Axle shafts: Visual inspection of the dust boots for leaks & signs of damage
- Axle joints: Check play; visual inspection of the dust boots for signs of damage
- Drive shaft/Cardan shaft: Visual inspection of the rubber bellows for leaks & signs of damage

Engine Compartment

- Fill engine oil (See separate Oil Change Sheet, PNA 000 162 NC)
- Coolant and hoses: Check level and antifreeze, check condition of hoses
- Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level

Additional Maintenance – Replace Spark Plugs (Labor Operation 03 81 00 ..)

- Replace spark plugs: Macan/S/GTS/Turbo every 30,000 miles / 45,000 km or 4 years

Additional Maintenance every 40,000 miles / 60,000 km or 4 years (Labor Operation 03 79 00 ..)

- PDK transmission: Change oil and filter

Additional Maintenance every 80,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00 ..)

Air filter element/s should be changed more often dependent on vehicle use and operation in dusty environments.

- Air Filter: Replace filter elements

Additional Maintenance every 160,000 miles / 240,000 km or 16 years (Labor Operation 03 95 00 ..)

- All-wheel final drive: Change oil
- Change rear final drive oil

Additional Maintenance every 2 years (Labor Operation 03 51 00 ..)

- Change brake fluid (use only Original Porsche Brake Fluid)
- Tire sealant (check expiration date and replace as necessary)

Inspection Performed - Technician Signature: _____

Road Test Check

- Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, Cruise control, PSM switch, sports exhaust system, heater, air-conditioning system and instruments: Check operation
 - Oils, fluids: Visual inspection for leaks
-

Road Test Performed - Technician Signature: _____

Customer Name: _____ **Date:** ____/____/____

VIN: WP1 _____

Mileage (check one) **Miles** **Kilometers:** _____

Dealer Name: _____ **Dealer Code:** _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____